

Product manual Feather duster



Power and productivity for a better world[™]

Product manual Feather Duster

Document ID: 3HAW050027150 Revision: B The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damages to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Additional copies of this manual may be obtained from ABB.

© Copyright 2013-2015 ABB All rights reserved.

ABB Engineering (Shanghai) Ltd. N°4528, Kangxin Highway, Pudong New District, Shanghai 201319, P.R.CHINA

0.0.1 Overview of this manual 0.0.2 Product documentation, M2004 0.0.3 How to read the product manual	5 7 9
1 Safety	11
1.1 Introduction	11
1.2 General safety information . 1.2.1 Safety in the robot system	12 12
 1.3 Safety risks related to the robot 1.3.1 Safety risks during installation and service work on robot 1.3.2 Safety risks related to tools/workpieces 1.3.3 Safety risks related to pneumatic/hydraulic systems 1.3.4 Safety risks during operational disturbances 1.3.5 Risks associated with live electric parts 	13 13 15 16 17 18
 1.4 Safety actions related to the robot 1.4.1 Safety fence dimensions 1.4.2 Fire extinguishing 1.4.3 Emergency release of the robots/manipulators axes 1.4.4 Brake testing 1.4.5 Risk of disabling function "Reduced speed 250 mm/s" 1.4.6 Safe use of the Teach Pendant Unit 1.4.7 Work inside the manipulator's working range 1.4.8 Translate the information on safety and information labels 1.5 Safety stops. 1.5.1 What is an emergency stop? 	
1.6 Safety related instructions	29
2 System description	29 31
2 System description 2.1 System overview . 2.1.1 System basics 2.1.2 Components overview 2.1.3 Process diagram 2.2 Feather roller. 2.3 Ionization 2.4 Exhaust system 2.5 Compressed air system	29 31 31 35 36 37 38 39
2 System description 2.1 System overview. 2.1.1 System basics 2.1.2 Components overview 2.1.3 Process diagram 2.2 Feather roller. 2.3 Ionization 2.4 Exhaust system 2.5 Compressed air system 2.5 Compressed air system	29 31 31 35 36 37 38 39 40
2 System description 2.1 System overview . 2.1.1 System basics 2.1.2 Components overview 2.1.3 Process diagram 2.2 Feather roller. 2.3 Ionization 2.4 Exhaust system 2.5 Compressed air system 3.1 Feather Duster and robot specifications 3.2 Feather Duster dimensions	29 31 31 31 35 36 36 37 38 39 40 40 41
Image: 1.6.1 Safety signals in the manual. 2 System description 2.1 System overview . 2.1.1 System basics 2.1.2 Components overview 2.1.3 Process diagram 2.2 Feather roller. 2.3 Ionization 2.4 Exhaust system 2.5 Compressed air system 2.5 Compressed air system 3.1 Feather Duster and robot specifications 3.2 Feather Duster dimensions 4 Installation and commissioning	29 31 31 31 35 36 36 39 40 40 41 43
2 System description 2.1 System overview. 2.1.1 System basics 2.1.2 Components overview 2.1.3 Process diagram 2.2 Feather roller. 2.3 Ionization 2.4 Exhaust system 2.5 Compressed air system 3.1 Feather Duster and robot specifications 3.2 Feather Duster and robot specifications 3.1 Feather Duster dimensions 4 Installation and commissioning 4.1 Introduction	29 31 31 31 35 36 37 38 39 40 40 40 41 43
2 System description 2.1 System overview . 2.1.1 System basics 2.1.2 Components overview 2.1.3 Process diagram 2.2 Feather roller. 2.3 Ionization 2.4 Exhaust system 2.5 Compressed air system. 2.5 Compressed air system. 3.1 Feather Duster and robot specifications 3.2 Feather Duster dimensions 4 Installation and commissioning 4.1 Introduction 4.2.2 Carbon fiber covers 4.2.3 Instructions for the installation of the steel structure frame. 4.2.4 Instructions for the connection of flexible hoses and cables 4.3 Electrical installation	29 31 31 31 35 36 36 37 38 39 40 40 41 43 41 43 43 44 45 46 49 54

5 Maintenance 63	
5.1 Introduction	
5.2 Expected components lifetime	
5.3 Maintenance planning	
5.4 Maintenance activities	
5.4.1 Weekly cleaning and inspection	
5.4.2 Feather roller care and replacement	
5.4.3 Belt replacement	
5.4.4 Motor replacement	
6 Reference information 75	
6.1 Introduction	
6.2 Unit conversion	
6.3 Bolt, screws, tightening torques	
6.4 Standard toolkit	
6.5 Special tools	
7 Spare parts 81	
7.1 Introduction	
7.2 Mechanical spare parts	
7.3 Electrical spare parts	
8 Appendix 87	
8.1 Assembly drawings	
8.2 Wiring diagrams	

0.0.1. Overview of this manual

About this manual		
	This manual contains instru	actions for:
	• the characteristics of	f the Feather Duster
	mechanical and elec	trical installation instructions for the Feather Duster
	maintenance instruct	tions for the Feather Duster
	• spare parts	
Usage		
	This manual should be used	l when working during:
	• installation, from life	ting the Feather Duster to its work site and securing it to the
	foundation, to makir	ng it ready for operation
	maintenance work	
	• repair work.	
Who should read thi	is manual?	
	This manual is intended for	:
	installation personne	91
	maintenance person	nel
	• repair personnel.	
Prerequisites		
	A maintenance /repair/ insta	allation craftsman working with an ABB Feather Duster must:
	• be trained by ABB a installation/repair/m	nd have the required knowledge of mechanical and electrical aintenance work.
One of the state o	-4	
Organization of chap	pters The menual is errorized in	the following chapters:
	The manual is organized in	the following enapters.
	Chapter	Content
	Safety	Safety information that must be read through before performing any installation or service work on the Feather Duster. Contains general safety aspects as well as more specific information about how to avoid personal injuries and damage to the product.
	Description and technical details	Specifications and characteristics of the Feather Duster.
	Installation	Information for installing the Feather Duster and connection to the control system.
	Unpacking, acceptance and handling	Information relative to the steps following the reception of the Feather Duster, until its installation.
	Maintenance	Step-by-step procedures that describe how to perform maintenance of the Feather Duster. Based on a maintenance schedule that may be used in the work of planning periodical maintenance.
	Spare parts	List of the spare parts available for the Feather Duster.

References

Reference - ABB documentation	Document ID
Operating manual - General safety information	3HAC031045-001
Product manual - IRC5 Robot Controller with FlexPendant	3HAC021313-001
Service Information System - IRC5	3HAC025709-001
Operating manual - IRC5 with FlexPendant	3HAC16590
Getting started, IRC5 and RobotStudio	3HAC021564-001
Product manual - IRB6640	3HAC026876
Product manual - IRB6700	3HAC044266
Reference - SEW documentation	Document ID
System Manual – MOVIDRIVE® MDX60B/61B (09/2010)	16838017 / EN
Download from:	
http://www.seweurodrive.com/download/pdf/16838017_G01.pdf	
http://www.seweurodrive.com/download/pdf/16838017_G01.pdf Operating Instructions – MOVIDRIVE® MDX60B/61B (01/2010)	16837614 / EN
http://www.seweurodrive.com/download/pdf/16838017_G01.pdf Operating Instructions – MOVIDRIVE® MDX60B/61B (01/2010) Download from: http://download.sew-eurodrive.com/download/pdf/16837614.pdf	16837614 / EN
http://www.seweurodrive.com/download/pdf/16838017_G01.pdf Operating Instructions – MOVIDRIVE® MDX60B/61B (01/2010) Download from: http://download.sew-eurodrive.com/download/pdf/16837614.pdf Applications Manuals – MOVIDRIVE® MDX61B - DriveSync via Fieldbus Application (08/2010)	16837614 / EN 17004411 / EN

Revisions

Revision	Description
A	Updated - Spare parts list - Requirements for air flow - Wiring diagrams
В	Updated
	- Robot specification
	- RB6700 is added
	- Electrical diagrams added

0.0.2. Product documentation, M2004

Categories for manipulator documentation

The manipulator documentation is divided into a number of categories. This listing is based on the type of information in the documents, regardless of whether the products are standard or optional.

All documents listed can be ordered from ABB on a DVD. The documents listed are valid for M2004 manipulator systems.

Product manuals

All hardware, manipulators and controllers will be delivered with a **Product manual** that contains:

- Safety information.
- Installation and commissioning (descriptions of mechanical installation, electrical connections).
- Maintenance (descriptions of all required preventive maintenance procedures including intervals).
- Repair (descriptions of all recommended repair procedures including spare parts).
- Additional procedures, if any (calibration, decommissioning).
- Reference information (article numbers for documentation referred to in Product manual, procedures, lists of tools, safety standards).
- Parts list.
- Foldouts or exploded views.
- Circuit diagrams (or references to circuit diagrams).

Technical reference manuals

The technical reference manuals describe the manipulator software in general and contain relevant reference information.

- RAPID Overview: An overview of the RAPID programming language.
- **RAPID Instructions, Functions and Data types**: Description and syntax for all RAPID instructions, functions, and data types.
- RAPID Kernel: A formal description of the RAPID programming language.
- System parameters: Description of system parameters and configuration workflows.

Application manuals

Specific applications (for example software or hardware options) are described in **Application manuals**. An application manual can describe one or several applications.

An application manual generally contains information about:

- The purpose of the application (what it does and when it is useful).
- What is included (for example cables, I/O boards, RAPID instructions, system parameters, CD with PC software).
- How to use the application.
- Examples of how to use the application.

Operating manuals

The operating manuals describe hands-on handling of the products. The manuals are aimed at those having first-hand operational contact with the product, that is production cell operators, programmers, and trouble shooters.

The group of manuals includes:

- Emergency safety information
- General safety information
- Getting started, IRC5 and RobotStudio
- IRC5 with FlexPendant
- RobotStudio
- Introduction to RAPID
- Trouble shooting, for the controller and manipulator.

0.0.3. How to read the product manual

Reading the procedures

The procedures contain references to figures, tools, material etc. The references are read as described below.

References to figures

The procedures often include references to components or attachment points located on the robot/controller. The components or attachment points are marked with *italic text* in the procedures and completed with a reference to the figure where the current component or attachment point is shown.

The denomination in the procedure for the component or attachment point corresponds to the denomination in the referenced figure.

The table below shows an example of a reference to a figure from a step in a procedure.

	Action	Note/Illustration
8.	Remove the rear attachment screws, gearbox.	Shown in the figure <i>Location</i> of gearbox on page xx.

Reference to required equipment

The procedures often include references to equipment (spare parts, tools etc.) required for the different actions in the procedure. The equipment is marked with italic text in the procedures and completed with a reference to the section where the equipment is listed with further information, i.e. article number, dimension.

The denomination in the procedure for the component or attachment point corresponds to the denomination in the referenced list.

The table below shows an example of a reference to a list of required equipment, from a step in a procedure.

	Action	Note/Illustration
3.	Fit a new sealing, 2 to the gearbox.	Art. no. is specified in <i>Required</i> equipment on page xx.

Safety information

The manual includes a separate safety chapter that must be read through before proceeding with any service or installation procedures. All procedures also include specific safety information when dangerous steps are to be performed.

Read more in Safety on page 11.

1 Safety

1.1. Introduction

Overview

The safety information in this manual is divided in two categories:

- general safety aspects, important to attend to before performing any service work on the robot. These are applicable for all service work and are found in *General safety information on page 12*.
- specific safety information, pointed out in the procedure at the moment of the danger. How to avoid and eliminate the danger is either detailed directly in the procedure, or further detailed in separate instructions, found in *Safety related instructions on page* 29.

1.2.1. Safety in the robot system

1.2 General safety information

1.2.1. Safety in the robot system

Validity and responsibility

The information does not cover how to design, install and operate a complete system, nor does it cover all peripheral equipment, which can influence the safety of the total system. To protect personnel, the complete system must be designed and installed in accordance with the safety requirements set forth in the standards and regulations of the country where the robot is installed.

The users of ABB industrial robots are responsible for ensuring that the applicable safety laws and regulations in the country concerned are observed and that the safety devices necessary to protect people working with the robot system are designed and installed correctly. Personnel working with robots must be familiar with the operation and handling of the industrial robot, described in the applicable documents, e.g. User's Guide and Product Manual.

Connection of external safety devices

Apart from the built-in safety functions, the robot is also supplied with an interface for the connection of external safety devices. Via this interface, an external safety function can interact with other machines and peripheral equipment. This means that control signals can act on safety signals received from the peripheral equipment as well as from the robot.

Limitation of liability

Any information given in this manual regarding safety, must not be construed as a warranty by ABB that the industrial robot will not cause injury or damage even if all safety instructions are complied with.

Related information

Type of information	Detailed in document	Section
Installation of safety devices	Product manual for the robot	Installation and commissioning
Changing robot modes	Operators manual (RobotWare 5.0)	Operating modes
Restricting the working space	Product manual for the robot	Installation and commissioning

1.3 Safety risks related to the robot

1.3.1. Safety risks during installation and service work on robot

Overview	
	This section includes information of general safety risks to be considered when performing installation and service work on the robot.
General risks during	installation and service
	• The instructions in the Product Manual - Installation and Commissioning must always be followed.
	• Emergency stop buttons must be positioned in easily accessible places so that the robot can be stopped quickly.
	• Those in charge of operations must make sure that safety instructions are available for the installation in question.
	• Those who install the robot must have the appropriate training for the robot system in question and in any safety matters associated with it.
Nation/region specifi	ic regulations
	To prevent injuries and damage during the installation of the robot system, the regulations applicable in the country concerned and the instructions of ABB Robotics must be complied with.
Non-voltage related	risks
-	• Safety zones, which have to be crossed before admittance, must be set up in front of the robot's working space. Light beams or sensitive mats are suitable devices.
	• Turntables or the like should be used to keep the operator out of the robot's working space.
	• The axes are affected by the force of gravity when the brakes are released. In addition to the risk of being hit by moving robot parts, you run the risk of being crushed by the parallel arm.
	• Energy, stored in the robot for the purpose of counterbalancing certain axes, may be released if the robot, or parts thereof, are dismantled.
	• When dismantling/assembling mechanical units, watch out for falling objects.
	• Be aware of stored heat energy in the controller.
	• Never use the robot as a ladder, i.e. do not climb on the robot motors or other part during service work. There is a serious risk of slipping because of the high temperature of the motors or oil spills that can occur on the robot.
To be observed by th	ne supplier of the complete system
	• The supplier of the complete system must ensure that all circuits used in the safety function are interlocked in accordance with the applicable standards for that function.
	• The supplier of the complete system must ensure that all circuits used in the emergency stop function are interlocked in a safe manner, in accordance with the applicable standards for the emergency stop function.

1 Safety

1.3.1. Safety risks during installation and service work on robot

Complete robot



Cabling

Safety risk	Description
Cable packs are sensitive to mechanical damage!	Caution signal
	The cable packs are sensitive to mechanical damage! They must be handled with care, especially the connectors, in order to avoid damaging them!

Gearboxes and motors

Safety risk	Description
Gears may be damaged if excessive force is used!	Caution signal Caution! Whenever parting/mating motor and gearbox, the gears may be damaged if excessive force is used!

1.3.2. Safety risks related to tools/workpieces

1.3.2. Safety risks related to tools/workpieces

Safe handling	
	It must be possible to safely turn off tools, such as milling cutters, etc. Make sure that guards remain closed until the cutters stop rotating.
	It should be possible to release parts by manual operation (valves).
Safe design	
	Grippers/end effectors must be designed so that they retain workpieces in the event of a power
	failure or a disturbance of the controller.
	CAUTION!
	Ensure that a gripper is prevented from dropping a workpiece, if such is used.

1.3.3. Safety risks related to pneumatic/hydraulic systems

1.3.3. Safety risks related to pneumatic/hydraulic systems

General	
	Special safety regulations apply to pneumatic and hydraulic systems.
Residual energy	
	• Residual energy may be present in these systems. After shutdown, particular care must be taken.
	• The pressure in pneumatic and hydraulic systems must be released before starting to repair them.
Safe design	
	• Gravity may cause any parts or objects held by these systems to drop.
	• Dump valves should be used in case of emergency.
	• Shot bolts should be used to prevent tools, etc., from falling due to gravity.

General	
	• The industrial robot is a flexible tool which can be used in many different industrial applications.
	• All work must be carried out professionally and in accordance with the applicable safety regulations.
	• Care must be taken at all times.
Qualified personnel	
	• Corrective maintenance must only be carried out by qualified personnel who are familiar with the entire installation as well as the special risks associated with its different parts.
Extraordinary risks	If the working process is interrupted, extra care must be taken due to risks other than those

1.3.4. Safety risks during operational disturbances

If the working process is interrupted, extra care must be taken due to risks other than those associated with regular operation. Such an interruption may have to be rectified manually.

1.3.5. Risks associated with live electric parts

1.3.5. Risks associated with live electric parts

Voltage related risks, general

- Although troubleshooting may, on occasion, have to be carried out while the power supply is turned on, the robot must be turned off (by setting the mains switch to OFF) when repairing faults, disconnecting electric leads and disconnecting or connecting units.
- The mains supply to the robot must be connected in such a way that it can be turned off outside the robot's working space.

Voltage related risks, controller IRC5

A danger of high voltage is associated with the following parts:

- Be aware of stored electrical energy (DC link, Ultra Cap unit) in the controller.
- Units inside the controller, e.g. I/O modules, can be supplied with power from an external source.
- The mains supply/mains switch
- The transformers
- The power unit
- The control power supply (230 VAC)
- The rectifier unit (400-480 VAC and 700 VDC. Note: Capacitors!)
- The drive unit (700 VDC)
- The drive system power supply (230 VAC)
- The service outlets (115/230 VAC)
- The customer power supply (230 VAC)
- The power supply unit for tools, or special power supply units for the machining process.
- The external voltage connected to the control cabinet remains live even when the robot is disconnected from the mains.
- Additional connections.

Voltage related risks, robot

A danger of high voltage is associated with the robot in:

- The power supply for the motors (up to 800 VDC).
- The user connections for tools or other parts of the installation (max. 230 VAC, see chapter Installation and commissioning in the Product manual).

Voltage related risks, tools, material handling devices, etc.

Tools, material handling devices, etc., may be live even if the robot system is in the OFF position. Power supply cables which are in motion during the working process may be damaged.

1.4 Safety actions related to the robot

1.4.1. Safety fence dimensions

General

Install a safety cell around the robot to ensure safe robot installation and operation.

Dimensioning

Dimension the fence or enclosure to enable it to withstand the force created if the load being handled by the robot is dropped or released at maximum speed. Determine the maximum speed from the maximum velocities of the robot axes and from the position at which the robot is working in the work cell (see *Product Specification - Description, Robot Motion*).

Also consider the maximum possible impact caused by a breaking or malfunctioning rotating tool or other device fitted to the manipulator.

1.4.2. Fire extinguishing

1.4.2. Fire extinguishing



NOTE!

Use a CARBON DIOXIDE (CO2) extinguisher in the event of a fire in the robot (manipulator or controller)!

1.4.3. Emergency release of the robots/manipulators axes

1.4.3. Emergency release of the robots/manipulators axes

Description	
	In an emergency situation, any of the robot's/manipulators axes may be released manually by pushing the brake release buttons on the robot.
	How to release the brakes is detailed in the robot product manual.
	• The robot arm may be moved manually on smaller robot models, but larger models may require using an overhead crane or similar.
Increased injury	

Before releasing the brakes, make sure that the weight of the arms does not increase the pressure on the trapped person, further increasing any injury!

1.4.4. Brake testing

1.4.4. Brake testing

When to test	
	During operation the holding brakes of each axis motor wear normally. A test may be per-
	formed to determine whether the brake can still perform its function.
How to test	
	The function of each axis' motor holding brakes may be checked as detailed below:
	1. Run each manipulator axis to a position where the combined weight of the manipulator arm and any load is maximized (max. static load).
	2. Switch the motor to the MOTORS OFF position with the Operating mode selector on the controller.
	3. Check that the axis maintains its position.
	If the manipulator does not change position as the motors are switched off, then the brake function is adequate.

1.4.5. Risk of disabling function "Reduced speed 250 mm/s"



NOTE!

Do not change *Transm. gear ratio* or other kinematic parameters from the Teach Pendant Unit or a PC. This will affect the safety function Reduced speed 250 mm/s.

1.4.6. Safe use of the Teach Pendant Unit

1.4.6. Safe use of the Teach Pendant Unit



NOTE!

The enabling device is a push button located on the side of the Teach Pendant Unit (TPU) which, when pressed halfway in, takes the system to MOTORS ON. When the enabling device is released or pushed all the way in, the robot is taken to the MOTORS OFF state. To ensure safe use of the Teach Pendant Unit, the following must be implemented:

- The enabling device must never be rendered inoperative in any way.
- During programming and testing, the enabling device must be released as soon as there is no need for the robot to move.
- The programmer must always bring the Teach Pendant Unit with him/her, when entering the robot's working space. This is to prevent anyone else taking control of the robot without the programmer knowing.

1.4.7. Work inside the manipulator's working range



WARNING!

If work must be carried out within the robot's work envelope, the following points must be observed:

- The operating mode selector on the controller must be in the manual mode position to render the enabling device operative and to block operation from a computer link or remote control panel.
- The robot's speed is limited to max. 250 mm/s when the operating mode selector is in position < 250 mm/s. This should be the normal position when entering the working space. The position 100% "full speed" may only be used by trained personnel who are aware of the risks that this entails.
- Pay attention to the rotating axes of the manipulator! Keep a distance to the axes in order not to get entangled with hair or clothing. Also be aware of any danger that may be caused by rotating tools or other devices mounted on the manipulator or inside the cell.

1.4.8. Translate the information on safety and information labels

1.4.8. Translate the information on safety and information labels

Labels on the product

Both the manipulator and the controller are marked with several safety and information labels, containing important information about the product. The information is useful for all personnel handling the robot system, e.g. during installation, service or operation.

Translation possibilities

The labels fitted to the product contain space for adding a fourth language underneath the three standard languages (English, German and French).

Add a local language to the label by:

• using a transparent sticker over the standard label with text added in a fourth language. Drawings detailing the design (text, figure, dimensions) of the standard labels can be ordered from ABB. Notice that each label is identified according to the article number located in the lower corner of the label.

Example of transparent sticker

The figure below shows the location of the free space on one of the labels on the robot, where the fourth language can be added. The figure also shows a transparent sticker, containing the text in Swedish.



1.5 Safety stops

1.5.1. What is an emergency stop?

Definition of emergency stop

An emergency stop is a state that overrides any other manipulator control, disconnects drive power from the manipulator motors, stops all moving parts, and disconnects power from any potentially dangerous functions controlled by the manipulator system.

An emergency stop state means that all power is disconnected from the manipulator except for the manual brake release circuits. You must perform a recovery procedure, i.e, resetting the emergency stop button and pressing the Motors On button, in order to return to normal operation.

The manipulator system can be configured so that the emergency stop results in either:

- An uncontrolled stop, immediately stopping the manipulator actions by disconnecting power from the motors.
- A controlled stop, stopping the manipulator actions with power available to the motors so that the manipulator path can be maintained. When completed, power is disconnected.

The default setting is uncontrolled stop. However, controlled stops are preferred since they minimize extra, unnecessary wear on the manipulator and the actions needed to return the manipulator system back to production. Please consult your plant or cell documentation to see how your manipulator system is configured.



NOTE!

The emergency stop function may only be used for the purpose and under the conditions for which it is intended.

NOTE!

The emergency stop function is intended for immediately stopping equipment in the event of an emergency.

NOTE!

Emergency stop should not be used for normal program stops as this causes extra, unnecessary wear on the manipulator.

Classification of stops

The safety standards that regulates automation and manipulator equipment defines categories in which each type of stop applies:

If the stop is	then it is classified as
uncontrolled	category 0 (zero)
controlled	category 1

1.5.1. What is an emergency stop?

Emergency stop devices

In a manipulator system there are several emergency stop devices that can be operated in order to achieve an emergency stop. There are emergency stop buttons available on the Flex-Pendant and on the controller cabinet (on the Control Module on a Dual Cabinet Controller). There can also be other types of emergency stops on your manipulator, consult your plant or cell documentation to see how your manipulator system is configured.

1.6 Safety related instructions

1.6.1. Safety signals in the manual

Introduction to safety signals

This section specifies all dangers that may arise from performing the work detailed in the manual. Each danger is detailed in its own section consisting of:

- A caption specifying the danger level (DANGER, WARNING or CAUTION) and the type of danger.
- A brief description of what will happen if the operator/service personnel do not eliminate the danger.
- An instruction of how to eliminate the danger to facilitate performing the activity at hand.

Danger levels

The table below defines the captions specifying the danger levels used throughout this manual.

Symbol	Designation	Signification
danger	DANGER	Warns that an accident will occur if the instructions are not followed, resulting in a serious or fatal injury and/or severe damage to the product. It applies to warnings that apply to danger with, for example, contact with high voltage electrical units, explosion or fire risk, risk of poisonous gases, risk of crushing, impact, fall from height etc.
warning	WARNING	Warns that an accident may occur if the instructions are not followed, that can lead to serious injury, possibly fatal, and/or great damage to the product. It applies to warnings that apply to danger with, for example, contact with high voltage electrical units, explosion or fire risk, risk of poisonous gases, risk of crushing, impact, fall from height etc.
Electrical shock	ELECTRICAL SHOCK	The electrocution or electrical shock symbol indicates electrical hazards which could result in severe personal injury or death.
caution	CAUTION	Warns that an accident may occur if the instructions are not followed, that can result in injury and/or damage to the product. It also applies to warnings of risks that include burns, eye injury, skin injury, hearing damage, crushing or slipping, tripping, impact, fall from height etc. Furthermore, it applies to warnings that include function requirements when fitting and removing equipment, where there is a risk of damaging the product or causing a breakdown.

1.6.1. Safety signals in the manual

Symbol	Designation	Signification
Electrostatic discharge (ESD)	ELECTROSTATIC DISCHARGE (ESD)	The electrostatic discharge (ESD) symbol indicates electrostatic hazards which could result in severe damage to the product.
Magnetic fields	MAGNETIC FIELDS	An intense and/or variable magnetic field can affect or damage certain electrical devices like cardiac pacemakers.
Note	NOTE	Note symbols alert you to important facts and conditions.
Tip	TIP	Tip symbols direct you to specific instructions, where to find additional information or how to perform a certain operation in an easier way.

2.1.1. System basics

2 System description

2.1 System overview

2.1.1. System basics

General

The Feather Duster Robot system is a pre-paint finishing equipment mounted on a 6 axis manipulator. It is used to remove dust and dirt particles from car bodies and from surfaces to be painted.

This system utilizes brushes manufactured from ostrich feathers to remove contaminants, which are then vacuumed from the brushes with an exhaust fan. It replaces the tack-off machine with more flexibility and high efficiency.

System overview

Besides robot and robot controller, a complete Feather Duster system consists mainly of an ostrich roller, a de-ionization unit, an exhaust system and a process cabinet.

For details, see Components overview on page 33



Figure 1: System - main components

Item	Description
А	Ostrich feather roller
В	Ionizing air knife
С	ABB IRB6640 or IRB6700
D	Exhaust hose
E	Control cabinet
F	Process cabinet
G	Compressed air supply

2 System description

2.1.1. System basics

Function	The Feather Duster Robot system is designed to remove contaminants from surfaces to be painted. The surface is cleaned by the rotating ostrich feather brushes. The brushes come across the body shell with a depth of immersion of approximately 30~40 mm. Through this movement, the contaminants are absorbed by the feather brushes and then vacuumed from the brushes with an exhaust fan. Two AC Ionization bars are mounted on the Feather Duster to deliver an ionized air stream, both to remove any static charge from the feather brushes just prior to the exhaust slot and to neutralize the body surface after cleaning. Removable outer carbon fiber covers allow easy access to the inner mechanical and electrical components, which are based on a modular design principle.
Benefits	
Benefits	 As a pre-paint finishing equipment using ostrich feather integrated on a robot, the Feather Duster Robot system aims at providing a more flexible and easier way to increase production efficiency. Compared with a tack-off machine, it brings a lot of benefits: 6 axes robot for a perfect profile follow up, flexible movement for optimum cleaning, tracking of the car body for both horizontal and critical surface. The cleaning of critical zone is shown in the figure below. High reliability (MTBF>50,000h) and easy maintenance. Reduces possible contamination caused by dust collecting surfaces and mechanical parts in the roof. Modular design and convenient installation.
	electrical parts.Low air consumption thanks to optimized air gaps and reduced amount of required rollers.
	• Easy programming, high flexibility, large working area and accessibility.
	 Common graphic user interface for both cleaning and painting robots. <i>i</i> = 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1

Critical zone

А

© Copyright 2013-2015 ABB. All rights reserved.

2.1.2. Components overview

2.1.2. Components overview

Unit overview

The Feather Duster system consists mainly in the ostrich roller, ionization unit, exhaust system, process cabinet, compressed air system and control cabinet.



Figure 3: System - Components overview

Item	Description
А	Ionizing air knife
В	Ostrich roller
С	Suction slot with flexible lips
D	Ionizing bar
E	Anti-collision safe edge

Ostrich roller	
	The Feather Duster is equipped with an ostrich feather roller. The roller is made up of disks of feathers stacked on a stainless steel shaft. See <i>Feather roller on page 36</i> .
Ionization unit	The ionization system consists in an ionizing air knife har mounted on the trailing edge and

The ionization system consists in an ionizing air knife bar mounted on the trailing edge and a ionization bar mounted in the mechanical unit. Its purpose is to eliminate static charge from the feathers and surface to be cleaned. See *Ionization on page 37*.

Exhaust system

An adjustable opening that spans the full length of the hood collects all of the dust and contaminants from the feathers. The air is routed from an exhaust fan to the hood through ductwork and flexible hose. See *Exhaust system on page 38*.

Compressed air system

The air knife is equipped with blowoff tubes which must be supplied in compressed air. See *Compressed air system on page 39*.

2 System description

2.1.2. Components overview

Process cabinet	
	The process cabinet is used to control the roller, the ionization bars and the compressed air valve. It is also an interface to automats (e.g. PLC cabinet), providing the signal from the main sensors (e.g. anti-collision switch).
Control cabinet	
	The control cabinet is a standard ABB IRC5 controller, used to control robot motion.
	For more information, see Product Manual, Control Cabinet IRC5.
2.1.3. Process diagram

2.1.3. Process diagram



The figure below shows the general process diagram:



2 System description

2.2. Feather roller

2.2. Feather roller

General

The Feather Duster is equipped with a roller which is an assembly of ostrich feathers disks stacked on a stainless steel shaft. The shaft is equipped with coupling hubs for quick change.

An approach switch monitors the speed on the drive shaft of the rollers. The rotating speed of the feather rollers can therefore be optimally controlled and adjusted to the body and the conveyor speed, achieving a uniform relative speed between feathers and body.

The feather roller is adapted to nearly all body profiles and can be replaced quickly and easily.



Function

The feathers of the rotating roller run across the surface of the body with low pressure. The contact effect and subsequent separation generates electrostatic positive and negative charging, on the body and on the feathers. For this reason the dust particles, charged positively and negatively as well, are consolidated by the respective opposite charge potential and absorbed by the feathers.

The rotating feather roller transfers the feathers that are full of dust particles into the area of the ionization air lock built within the roller covers. The ionization air lock neutralizes the electrostatic charges on the feathers. The suction device then sucks the dust particles off the neutralized feathers.

2.3. Ionization

2.3. Ionization

General

The Feather Duster system is equipped with an ionization system which purpose is to reduce or eliminate static charge from the cleaned surface. The system includes a high voltage generator, an ionizing bars and an ionizing air knife.

High voltage generator

The AC high voltage generator produces both positive and negative ions at a rate of sixty times per second (60Hz line frequency). During the first half of the cycle, a discharge begins when the potential exceeds 2000V and positive ions are generated until the potential falls below the 2000V level. During the second half of the cycle, negative ions are generated. When the potential is comprised between -2000V and 2000V, no ions are generated; this results in a gap between positive and negative ions.



Ionization bar

Each system has two ionization bars, one mounted on the trailing edge, and another one mounted inside the hood. The outer unit is an ionizing air knife which blows the ions onto the feathers and vehicle. This creates a curtain of air that sweeps contaminants off the vehicle and neutralizes the body surface after cleaning. The inner bar mounted inside the hood neutralizes the dust particles in feathers.

Proper ion bar alignment is critical. The ion bar mounted on the trailing edge of the duster hood should be adjusted so that the air stream blows onto the vehicle.



2.4. Exhaust system

2.4. Exhaust system

General

The Feather Duster system requires an exhaust fan to suck the dust and dirt from the feathers. An adjustable 1016 mm (40") long exhaust slot spans the full length of the feather shaft, where all of the dust and contaminants are collected from the feathers. The exhaust air from the ductwork is routed through flexible hose.

The exhaust air volume will vary depending on the fan location, fan power and ductwork arrangement, but the Feather Duster system requires an air flow of at least $30 \text{ m}^3/\text{min}$ at 1000 bar.

A pressure sensor connected to the ductwork ensures that the exhaust is running. If no exhaust air flows, a fault will be generated.



Figure 8: Exhaust system

2.5. Compressed air system

2.5. Compressed air system

General

The compressed air system is required to supply air to the ionization air knife. The system is supplied with a solenoid controlled air valve, mounted on the process cabinet. If the air pressure is lower than the setting value, a fault will be created.



Figure 9: Compressed air system

Air supply requirement	Description
Pressure	3.5 bar min 6 bar max.
Filter accuracy	5 µm
Volume	3 m ³ /min

3.1. Feather Duster and robot specifications

3 Technical Specification

3.1. Feather Duster and robot specifications

Feather Duster specifications

Weight	140 kg
Cover Length	1200 mm
Cover Width	620 mm
Cover Depth	680 mm
Roller Widths	1000 mm
Motor Power	0.37 kw
Motoreducer Reduction Ration	23.15
Roller Speed	10-90 rpm variable (motor: 230 - 2085 rpm)
Exhaust Air Flow	30 m ³ /min at 1000Pa dynamic, per roller
Compressed Air Supply	1.5 m ³ /min at 3.5 bar, per robot
Downdraft Air Velocity	0.3m/s (±0.05)
Humidity and Temperature	Humidity: 60-70%; Temperature: 20-25°C
Conveyor System	Deviation ≤ 25mm

Robot specifications

Feather Duster is designed to be integrated with ABB IRB6640-185 or IRB6700-175.

No particular option is required for the robot. See 3HAC028284-001, IRB6640 Product specification or 3HAC044265, IRB6700 Product specification.

For compatibility with other robot variants, please contact ABB.

range of movement	Max axis speed
+170 to -170	100/s
+85 to -85	90/s
+70 to -70	90/s
+180 to -180	190/s
+90 to -90	140/s
+180 to -180	190/s
	range of movement +170 to -170 +85 to -85 +70 to -70 +180 to -180 +90 to -90 +180 to -180

3.2. Feather Duster dimensions

3.2. Feather Duster dimensions

Dimensions

The following figure shows the Feather Duster dimensions:



© Copyright 2013-2015 ABB. All rights reserved.

3HAW050027150 Revision: B

3 Technical Specification

3.2. Feather Duster dimensions

4 Installation and commissioning

4.1. Introduction

Safety information

Before any service work is commenced, it is important that all safety information is observed! Read *Safety on page 11* before performing any service work.

Required equipment

Equipment	Note
Standard toolkit	Specified in Standard toolkit on page 78.
Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below.	Specified in <i>Special tools on page</i> 79.

Bolts and screws and tightening torques

Specified in Bolt, screws, tightening torques on page 77.

4.2.1. Introduction

4.2 Mechanical installation

4.2.1. Introduction

Safety information		
	Before any service work is commenced, it is extremely important that all safety information is observed! There are general safety aspects that must be read through, as well as more specific safety information that describe danger and safety risks when performing the procedures. Read <i>Safety on page 11</i> before performing any service work.	
General		
	The Feather Duster mechanical installation consists mainly in the installation of the steel structure frame and the mounting of the exhaust air and compressed air supply hoses. Refer to <i>Assembly drawings on page 87</i> for details.	
Robot position		
	The robot must be positioned as shown on the following picture:	
	The flange surface of axis 6 must be horizontal and both axis 4 and 6 must be at 0°.	

Figure 11: Robot in Feather Duster service position

Correct feather rotation

The figure below shows the correct orientation of the feathers rotation in relation to the travel of the vehicle. Note that the curve of the feathers follows the travel of the vehicle. As a result, the feathers are not bent backward while spinning.



4.2.2. Carbon fiber covers

4.2.2. Carbon fiber covers

General

The covers are interchangeable carbon fiber panels, fastened on the frame with 4 M8 screw bolts.



Figure 13: Carbon fiber cover

4.2.3. Instructions for the installation of the steel structure frame

4.2.3. Instructions for the installation of the steel structure frame

Procedure

Steps	Action	Info/Illustration
1.	Ensure that the robot's axis 4 and 6 are set at 0°.	
2.	Remove the original 6th axis calibration label.	C
3.	Loosen (but do not remove) the 6 M8 hexagon socket head cap screws at the upper end of 5th axis, keeping about 10mm of distance between the screw head and the 5th axis end surface. NOTE: This distance allows the assembly of the interface plate. keep the washers in contact with the screw heads, away from the 5th axis surface. CAUTION! Only loosen the upper 6 screws.	<image/>
	simultaneously, the lubrication oil may leak out. Don't loose the three screws (A) highlighted in the picture.	
4	Insert the upper half interface plate into the gap.	

Steps	Action	Info/Illustration
4.	Tighten the 6 screws. Tightening torque: 35Nm.	
5.	Once the upper interface plate is tight, install the lower interface plate the same way.	
6.	Install the new calibration label. Make sure that the label orientation (+ / -) is the same as the original.	New calibration label Previous label
7.	Set the sealing guide and the sealing rubber ring on the steel plate.	

4.2.3. Instructions for the installation of the steel structure frame

4.2.3. Instructions for the installation of the steel structure frame

Steps	Action	Info/Illustration
8.	Jog the robot vertically and bring its roleface down in contact with the steel structure frame. Pay attention to the direction of installation: the groove must be aligned with the 0°calibration mark of the 6th axis. Pre-tighten 2x M12 hexagon socket head cap screws. Insert the Ø12mm pin to locate the steel frame.	Interface plate Oil plug, draining Groove on Duster upper flange
9.	Tighten all 7 hexagon socket head cap M12 screws.	
10.	Assemble one half of the exhaust hose connector (the one with the connector) to the interface plate. The other half shouldn't me assembled until all mechanical installation is complete. Pay attention to the branch orientation, make sure that the calibration label is not hidden. Tighten only the 2x upper hexagon socket head M10 screws to the interface plate. The 5 screws used to tighten the cover to the sealing guide should be tightened later, upon the installation of the other cover.	

ш

/

4.2.4. Instructions for the connection of flexible hoses and cables

4.2.4. Instructions for the connection of flexible hoses and cables

Pneumatic system overview

The pneumatic system is described in the diagram below:



Figure 14: pneumatic diagram

4 Installation and commissioning

4.2.4. Instructions for the connection of flexible hoses and cables

External routing

The external routing of the exhaust hose, pneumatic tube and cables must be completed before the internal connection of the feather duster.

The electrical cables are combined with the air tube within a protection flexible conduit. Exhaust hose and conduit are fixed at different locations on the robot to minimize wearing during operation.



Figure 15: External pipe sys

ltem	Description	Info/Illustration
А	Exhaust hose	Ø150mm, L=10m
В	Air supply tube and electrical cables contained in the flexible protection conduit	Ø36mm, L=2.5m
С	Routing of the conduit at the robot base	
D	Routing of the conduit at the robot within the lower arm	
E	Fixture of the exhaust hose on the lower arm	
F	Fixture on the upper arm	

4.2.4. Instructions for the connection of flexible hoses and cables

Internal routing

Once the exhaust hose and the flexible conduit (which contains the pneumatic tube and the harness) have been assembled onto the robot, connect them to the hose connector at the back of the Feather Duster. The electrical harness must be guided through the cover from the external connector to the internal connector.

A pneumatic elbow fitting must be set within the junction connectors to connect the inner and outer air tubes.



Item	Description	Item	Description
А	Exhaust hose connector	С	External flexible conduit connector
В	Internal flexible conduit connector	D	Pneumatic elbow fitting (inside)

The cables and air tube must be inserted in Ø29mm, 1.2m long internal flexible conduit, then routed in the Feather Duster as shown on the picture below.

The flexible conduit must be turned 1 times 1/2 (540°) around the steel column when the manipulator's 6th axis is set at +360°:



4 Installation and commissioning

4.2.4. Instructions for the connection of flexible hoses and cables

Steps	Action	Info/Illustration
1.	Before routing the internal cables and air pipe, use the Teach Pendant to jog the manipulator's 6 th axis to +360°	
2.	Insert the pneumatic tube and the cable harness in the Ø29mm, 1.2m long internal flexible conduit. Route the conduit 1 and 1/2 turns (540°) around the steel column.	
3.	Connect the conduit to the junction box.	
4.	Let the air tube go through the fitting on the other side of the junction box. Connect the air tube to the quick connector on the side of the steels structure frame. CAUTION! Make sure the air is not supply is not blocked at any point	
5.	Connect the cables to the junction box as described in Electrical installation on page 54 Close the junction box.	

4.2.4. Instructions for the connection of flexible hoses and cables

Steps	Action	Info/Illustration
6.	Run the robot in manual to make sure that the assembly allows for all axis to run a complete stroke. If necessary, adjust the distance of the flexible conduit and the exhaust hose between clamps.	
7.	Fasten the other half of the exhaust hose connector cover to the interface plate with 2x hexagon socket head M10 screws.	
8.	If necessary, adjust the orientation of the sealing guide so that the calibration label on the exhaust hose connector cover is aligned with the slot on the sealing guide. Tighten the 10x hexagon socket head M4 screws to the steel structure frame.	

4.3. Electrical installation

Introduction

The electrical system of the feather duster consists mainly in the process cabinet, the deionization bars and the motor.

The feather duster is controlled by the PLC, so no connection needs to be made with the robot controller.



Junction box



All the electrical devices connect to the process cabinet through the junction box. The figure below shows the cable connection details in the junction box.



	Juction box	-X10	01	02 (3 (4	5 0	⊳ 6 (57 6	8	39	0 10	011	012	018
Fig	Figure 20: Cable connection between junction box and robot base harting connector														
Tl	There are five <i>Harting</i> connectors on the process cabinet:														
	<u>a</u>	0	0		0	0	6		8						ţ
					\					9				-(-	Ð

Signal

380V power

PG1 $\begin{array}{c} Har1 & Har2 & Har3 \\ \mbox{Figure 21: Layout of the } \textit{Harting connectors below the process cabinet} \end{array}$ Har5 Har4

Vacuum

Air unit

Field bus

Motor control

5 3-6

6

	Pin number	Description
	1-1	Power supply
	1-2	Power supply
Har1	1-3	Power supply
	1-4	Ν
	1-5	PE
	1-1	High current alarm
	1-2	High current alarm
	1-3	High current alarm
	1-4	High current alarm
	1-5	Safety edge crash signal
	1-6	Safety edge crash signal
	1-7	Safety edge crash signal
	1-8	Safety edge crash signal
Hor?	1-9	Rotation speed output
	1-10	Rotation speed output
	1-11	Air pressure alarm
	1-12	Air pressure alarm
	1-13	Alarm from fan
	1-14	Alarm from fan
	1-15	Ionization bar enable
	1-16	Ionization bar enable
	1-17	Compressed air valve opened
	1-18	Compressed air valve opened
	1-1	Compressed air valve open (L)
	1-2	Compressed air valve open (N)
Har3	1-3	Compressed air valve open (E)
TIdio	2-1	Pressure switch
	2-2	Pressure switch
	2-3	Pressure switch (PE)
Har4	1-1	VACUUM SWITCH
	1-2	VACUUM SWITCH
	1-1	Feather duster motor
	1-2	Feather duster motor
	1-3	Feather duster motor
	1-4	Feather duster motor
	2-1	Ionization bar
	2-2	Ionization bar
Har 5	2-3	Ionization bar
	3-1	Safety edge sensor
	3-2	Safety edge sensor
	3-3	Safety edge sensor
	3-4	Approach switch
	3-5	Approach switch
	3-6	Approach switch

Transducer for the roller motor

A SEW *Movidrive* MDX61B is used in the process cabinet to control the rotation speed of the roller. Other boards such as field bus, operation panel, are also installed. The field bus type is specific to the project's requirements. One can find installation, operation, and program detail in the SEW documentation. See *References on page 6*.

Power supply

	Power spec. 1	Power spec. 2
Voltage	380 V	480 V
Frequency	50 Hz	60 Hz
Current	16 A	16 A
Connection	Harting connector	Harting connector



NOTE!

As of today, the standard exhaust fan is only available for 380 V power supply. If another voltage is required, a transformer or a locally purchased exhaust fan will be needed.

Harting connections

Male core HSB-0	06-M
Female core HSB-0	06-F
Top cover H16B-	SE-4B-M25
Bottom cover H16B-	BK-2L
Male core HE-024	4-M
Har2 Female core HE-024	4-F
Top cover H24B-	SE-4B-M25
Bottom cover H24B-	BK-2L
12 core modules HMD-0	012-MC
12 core modules HMD-0	012-FC
Frame HF6B-	UA
Har3 Frame HF6B-	LA
Top cover H6B-S	E-2B-M20
Bottom cover H6B-B	K-1L
M20 conduit connector WNAM	120
Male core HE006	ô-М
Female core HE006	3-F
Har4 Top cover H6B-S	E-2B-M20
Bottom cover H6B-B	K-1L
M20 conduit connector WNAM	120

4.4.1. Introduction

4.4 System start-up

4.4.1. Introduction

Introduction						
	This cha physical	pter contains the instructions for setting up the Feather Duster system once the installation has been completed, and the robot and robot controller have been started				
	up.					
	To start on page) start the robot system up, refer to the controller and robot documentation. See <i>References</i> $page 6$.				
Safety information						
	Follow t	he procedure below when performing the first test run after a service activity (repair,				
	installat	ion or maintenance):				
	Steps	Action				
	1.	Remove all service tools and foreign objects from the robot and its working area!				
	2.	Install all safety equipment properly!				
	3.	Make sure all personnel are standing at a safe distance from the robot, i.e. out of its reach behind safety fences, etc.!				
	4.	Pay special attention to the function of the part previously serviced!				
Set the robot TCP	The Too Steps	l Center Point must be set as shown below: Action				
	1.	Use the FTP software to connect the robot				
	2.	Download \HOME\robdata\robdata.sys. Before any modification, back the current file up.				
	2. 3.	Download \HOME\robdata\robdata.sys. Before any modification, back the current file up. Use the shopfloor editor or UE editor to open the file robdata.sys.				
	2. 3. 4.	Download \HOME\robdata\robdata.sys. Before any modification, back the current file up. Use the shopfloor editor or UE editor to open the file robdata.sys. Add one line as below to define the TCP for the feather duster:				
	2. 3. 4.	Download \HOME\robdata\robdata.sys. Before any modification, back the current file up. Use the shopfloor editor or UE editor to open the file robdata.sys. Add one line as below to define the TCP for the feather duster: PERS tooldata Tool_Cleaner: =[TRUE,[[0,0,900],[1,0,0,0]],[125.1,[7.1,3.8,319.5],[1,0,0,0],26.302,12.415,18.623]]; Save the file.				
	2. 3. 4. 5.	Download \HOME\robdata\robdata.sys. Before any modification, back the current file up. Use the shopfloor editor or UE editor to open the file robdata.sys. Add one line as below to define the TCP for the feather duster: PERS tooldata Tool_Cleaner: =[TRUE,[[0,0,900],[1,0,0,0]],[125.1,[7.1,3.8,319.5],[1,0,0,0],26.302,12.415,18.623]]; Save the file. Download the modified file to the controller, replace the previous one.				

4.4.2. Start up of the Feather Duster motor

4.4.2. Start up of the Feather Duster motor

Introduction							
	The cor 168376	ntent of this chapter is an adapte 14- <i>Movidrive</i> MDX61B (See <i>R</i>	ent of this chapter is an adapted extract from the SEW Operating Instructions 4- <i>Movidrive</i> MDX61B (See <i>References on page 6</i>).				
Movidrive key pad							
<i>Movialive</i> key pau	The figure	ure below shows the key pad matrix entation. $ \begin{array}{c} $	ain keys	3. More details can be found in the SEW			
	1 🕣	Move up to the next menu item	4	Move down to the next menu item			
	2	Confirm entry	4 🖭	Change the menu, display mode \leftrightarrow edit mode.			
	3 🔵	Activate the context menu	6 🕥	Cancel or abort startup			
Set a language for th	he <i>Movi</i>	idrive					
	Set the	language for the SEW Movidriv	ve follov	ving these steps:			
	Steps	Action					
	1.	Press the 🋞 key. A list of lan	guages	is displayed on the screen.			
	2.	Use the ()/() keys to select	t the re	quired language.			
	3.	Confirm your selection using t	he 🕒 l	key. The basic display is now shown in your			

chosen language.

4.4.2. Start up of the Feather Duster motor

Startup procedure

The instruction below are an extract from the *Movidrive* 6837614-Operating Instructions *Movidrive* MDX61B (*References on page 6*).

Some settings depend on the local power supply type and the motor type (380VAC-50Hz or 480VAC-60 Hz). In case of doubt, refer to the nameplate on the motor or contact ABB.

Steps	Action	Parameters	
1.	Activate the context menu by pressing the key	BASIC VIEW PARAMETER MODE VARIABLE MODE	
2.	Press the 🚺 key to scroll down to the "STARTUP" menu	MANUAL MODE STARTUP COPY TO DBG COPY TO MDX	
	Press the key to begin the startup procedure. The first parameter appears. The flashing cursor under the parameter number indicates that the keypad is in display mode. • Press the key to change to edit mode. The flashing cursor dicappears	STARTUP PREPARE FOR STARTUP	
3.	 Press the key or key to select PARAMETER SET 1". Confirm the setting by pressing the key. Press the key to return to display mode. The flashing cursor appears again. Press he key to select the next parameter (C22*MOTORS). 	C00*STARTUP PARAMETER SET 1 PARAMETER SET 2	
4.	Select "stand-alone motor". Press the () key to select the next parameter (C26*OPER. MODE 1).	C22*MOTORS SINGLE MOTOR IDENT. MOTORS	
5.	Select "VFC". Press the f key to select the next parameter (C29*encoder).	C26*OPER. MODE 1 STANDARD V/F VFC	
6.	Set that no encoder is to be evaluated. Press the fight key to select the next parameter (C36*OPER.MODE).	C29*encoder NO YES	
7.	Select "SPEED CONTROL". Press the () key to select the next parameter (C02*MOTOR TYPE1).	C36*OPER.MODE SPEED CONTROL HOIST	
8.	Select the "DT71D4" motor type. Press the () key to select the next parameter (C03* V MOT. RATED VOLT 1).	C02*MOTOR TYPE1 DT71D2 DT71D4 DT80K2	
9.	Enter the rated motor voltage for the selected connection type according to the value specified on the motor nameplate. Press the free key to select the next parameter (C04* Hz	C03* V MOT. RATED VOLT1 400.000	

4.4.2. Start up of the Feather Duster motor

Steps	Action	Parameters
10.	Enter the rated frequency specified on the motor nameplate. Press the ① key to select the next parameter.	C04* Hz MOT.RATED FREQ1 50.000
11.	Enter the rated power supply voltage.	C05* V RATED MAINS VLTG 400.000
12.	Set "NO RESPONSE". Press the ① key to select the next parameter.	835* RESP. TF-SIG. NO RESPONSE DISPLAY ERROR
13.	Start the calculation for the startup data by choosing "YES". The process lasts a few seconds.	C06*CALCULATION NO YES
14.	The calculation is performed. After calculation, the next menu item appears automatically.	C06*SAVE NO YES
15.	Set "SAVE" to "YES" The data (motor parameters) are copied to the non-volatile memory of <i>Movidrive</i> .	STARTUP DATA IS BEING COPIED
16.	The startup procedure is now complete. Press the return to the context menu.	MANUAL MODE STARTUP COPY TO DBG COPY TO MDX
17.	Press the weys to scroll down to the "QUIT" menu item.	SIGNATURE QUIT BASIC VIEW
18.	Confirm the setting by pressing the key. The basic display appears.	0.00rpm 0.000Amp CONTROLLER INHIBIT

4 Installation and commissioning

4.4.2. Start up of the Feather Duster motor

5 Maintenance

5.1. Introduction

General						
	This chapter details all maintenance activities r	ecommended for the Feather Duster.				
	It is based on the maintenance schedule, located contains information about required maintenan- procedures for the activities. Each procedure co- activity, e.g., required tools and materials. The divided according to the maintenance activity.	in the beginning of the chapter. The schedule ce activities including intervals and refers to ntains all information required to perform the procedures are gathered in different sections,				
Safety information						
	Before any service work is commenced, it is ex- is observed! There are general safety aspects the specific safety information that describe danger procedures. Read <i>Safety on page 11</i> before perf	tremely important that all safety information at must be read through, as well as more and safety risks when performing the forming any service work.				
Precautions						
	The precautions below should be observed before proceeding with the maintenance of the					
	Feather Duster:					
	CAUTION!					
	• Before any intervention on the mechanic supplies to the Feather Duster as well as must be turned off.	cal and electrical components, all power to other machines within the danger zone				
	• If required, the main switch should be lo	ocked.				
	• Make sure that the pneumatic system is	not pressurized.				
	• Use only original ABB spare parts. The original parts will void the warranty.	use of unauthorized parts or others than				
Required equipment	t					
	Equipment	Note				
	Standard toolkit	Specified in Standard toolkit on page 78.				
	Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below.	Specified in <i>Special tools on page</i> 79.				
Bolts and scrows an	d tightening torques					

Specified in Bolt, screws, tightening torques on page 77.

5.2. Expected components lifetime

5.2. Expected components lifetime

General

The expected lifetime of the components can vary greatly depending on how intensively the feather duster is run.

Item	Maintenance
Cables	1,000,000 cycles
Belt	Over 16,000h
Roller	Over 6 month
Motor	Over 10 years

5.3. Maintenance planning

5.3. Maintenance planning

General

The feather duster must be maintained regularly to ensure proper function. The maintenance activities and intervals are specified in the table below.

Non-predictable situations may also give rise to inspections of the feather duster. Any damage must be attended immediately!

Time interval	Maintenance	More info.		
Daily	Check for faults			
	Check for loose or damaged feathers			
	Check for machine damage			
Weekly	Clean the unit	Weekly cleaning and		
	Clean and adjust ion bars	inspection on page 66		
	Check ionizing bars correct operation			
	Check cables and flexible hoses for wear			
	Check that all pneumatic connections are secure			
Ever 2500h	Check the belt tension			
	Check the bearing guides and bearings			
Every 6 months	Replace the feather roller	Feather roller care and replacement on page 67		
Annually	Verify that all fasteners, bolts and nuts are tight			
Every 16000h	Replace the timing belt	Belt replacement on page 71		

5 Maintenance

5.4.1. Weekly cleaning and inspection

5.4 Maintenance activities

5.4.1. Weekly cleaning and inspection

General

It is recommended to clean and inspect the Feather Duster every week.



Cleaning

Remove the 2 side carbon fiber covers and use a brush to clean the vacuum, the motor, the hood, the ionization bars and the support frame. Alcohol may be used but with care: Strong alcohol such as acetone, etc. should be avoided. A high pressure cleaning device may be used, but spraying directly on the Feather Duster robot should be avoided. Ensure that the ionization bars are properly aligned.

Inspection

- Check for oil leaks.
- Check for excessive play in gears.
- Check that cables and hoses between control cabinet, robot and feather duster are not damaged.

5.4.2. Feather roller care and replacement

5.4.2. Feather roller care and replacement



The feather roller wears normally. It is necessary to replace it every six month.

Location



Feather Roller Care

Ostrich feathers contain millions of tiny hairs on each of their threads. These hairs are what grabs on to the dirt and removes it from the surface. The feather hairs can be lost through wear, sharp edges and aging. The roller is no longer effective and should be replaced when no more hairs can be seen at the feathers tips.



Feather in good condition Worn feat

Worn feather - replace soon

Destroyed feather - replace

CAUTION!

When replacing feather roller, care must be taken to ensure that the feathers are not damaged or contaminated.

- Wash hands before installing feathers. Keep all grease and oil away from feathers
- Keep the feather roller in its package until it is ready to be installed on the machine
- · Reseal packages if they have been opened for inspection
- Do not allow feathers to rest on the floor. If possible, use the ABB feather roller support 3HAW050024260 (See *Special tools on page 79*)

5 Maintenance

5.4.2. Feather roller care and replacement

Replacement procedure

Steps	Action	Info/Illustration
1.	Loosen the nuts on both ends of the roller shaft.	Screw Bolt Roller Shaft
2.	Extract the screw bolts. Proceed on both sides simultaneously.	
3.	Remove the roller shaft from the mechanical unit. If available, place it on the ABB feather roller support 3HAW050024260 (See <i>Special</i> <i>tools on page 79</i>).	SteelStructure Frame Screw Feather Roller
4.	Remove one locknut at the shaft's end and remove the feather disks.	Locknut

5.4.2. Feather roller care and replacement



5.4.2. Feather roller care and replacement


5.4.3. Belt replacement

5.4.3. Belt replacement

Steps	Action	Info/Illustration
1.	Remove the two carbon fiber covers.	
2.	Remove the tunnel cover on the motor side.	
3.	Loosen the 4 nuts of the motor fixing flange to release the belt tension. Remove the belt.	
4.	Install the new belt, and adjust the tension by moving the motor up or down. The distance between the belt when you pinch it should be around 50-55mm. When the tension is satisfying, tighten the 4 nuts.	югеет 2 3 5m 4 5 6
5.	Re-assemble the tunnel cover and the carbon fiber covers.	

5.4.4. Motor replacement

5.4.4. Motor replacement

Location



Procedure

Steps	Action	Info/Illustration
1.	Remove the two carbon fiber covers.	
2.	Remove the motor cover.	

5.4.4. Motor replacement

Steps	Action	Info/Illustration
3.	Open the junction box and disconnect the cables. See <i>Electrical installation on page 54</i> .	
4.	Remove the tunnel cover on the motor side.	
5.	Loosen the 4 nuts of the motor fixing flange to release the belt tension. Remove the belt, the shaft end cover, and the pulley.	
6.	Remove the key on the motor shaft and remove the shaft spacer.	
7.	Remove the 4 nuts on the motor fixture flange, and remove the motor.	

5.4.4. Motor replacement

Steps	Action	Info/Illustration
8.	Remove the motor flange.	
9.	Install the flange on the new motor, and fasten the 4 screws. Mount the top shaft spacer on the motor axis.	
10.	Install the motor on the support frame, and pre-tighten the 4 screws. Install the shaft spacer, the pulley and the shaft end cover.	
11.	Install the belt and adjust the belt tension (See <i>Belt</i> <i>replacement on page</i> 71). Connect the cable in the junction box (See <i>Electrical</i> <i>installation on page</i> 54).	
12.	Re-assemble the tunnel cover, the motor cover and the carbon fiber covers.	

6.1. Introduction

6 Reference information

6.1. Introduction

General

This chapter includes general information, complementing the more specific information in the different procedures in the manual.

6.2. Unit conversion

6.2. Unit conversion

Converter table

Use the following table to convert units used in this manual.

Quantity	Unit		
Length	1 m	3.28 ft	39.37 in
Weight	1 kg	2.21 lb	
Pressure	1 bar	100 kPa	14.5 psi
Force	1 N	0.738 lbf	
Moment	1 N.m	0.738 lbf-tn	
Volume	1 L	0.264 US gal	

6.3. Bolt, screws, tightening torques

6.3. Bolt, screws, tightening torques

Bolt and screws

Before tightening any screw, observe the following:

- Determine whether a **standard** tightening torque or **special** torque is to be applied. The **standard torques** are specified in the following tables. Any **special torques** are specified in the repair, maintenance or installation procedure descriptions. **Any special torque specified overrides the standard torque!**
- Use the *correct tightening torque* for each type of screw joint.
- Only use *correctly calibrated* torque keys.
- Always *tighten the joint by hand*, and never use pneumatic tools.
- Use the correct tightening technique, tighten the screw in a slow, flowing motion.
- Maximum allowed total deviation from the specified value is 10%!



NOTE!

Unless indicated otherwise, the bolts used on (or provided with) the Feather Duster are of class 8.8.

NOTE!

Unless indicated otherwise, all bolts must be clean of oil or grease and tightened with a mild thread-locker such as Loctite 243.

Standard tightening torques

The following table specifies the recommended standard tightening torques for *hex screws* and *socket head hex screws*:

Screw thread size	M5	M6	M8	M10	M12
Tightening torque	5.5 N.m	9.5 N.m	23 N.m	46 N.m	79 N.m
CLASS 8.8					
Tightening torque	8.1 N.m	14 N.m	34 N.m	67 N.m	116 N.m
CLASS 10.9					
Tightening torque	9.5 N.m	16.4 N.m	40 N.m	79 N.m	136 N.m
CLASS 12.9					

The following table specifies the recommended standard tightening torque for *water and air connectors* when one or both connectors are made of brass:

Dimension	Tightening torque Nm - Nominal	Tightening torque Nm - Minimal	Tightening torque Nm - Maximum
1/8	12 N.m	8 N.m	15 N.m
1/4	15 N.m	10 N.m	20 N.m
3/8	20 N.m	15 N.m	25 N.m
1/2	40 N.m	30 N.m	50 N.m
3/4	70 N.m	55 N.m	90 N.m

6.4. Standard toolkit

6.4. Standard toolkit

General

All service (repairs, maintenance and installation) procedures contain lists of tools required to perform the specified activity.

All special tools required are listed directly in the procedures while all the tools that are considered standard are gathered in the standard toolkit and defined in the table below.

This way, the tools required are the sum of the standard toolkit and any tools listed in the instruction.

Contents, standard toolkit

Qty	ΤοοΙ
1	Set of spanners or ring-open-end spanner 8-22 mm
1	Hex keys (Allen key) 3, 4, 5, and 6 mm
1	Torque wrench
1	Ratchet head for torque wrench 1/4"
1	Socket head cap 3mm, 4mm, 5mm, 6mm, 8mm and 10mm socket 1/4" bit L 20 MM
	(for socket head cap screws - ISO 4762)
1	Mild thread-locker (Recommended: Loctite 243)
1	Small flat tip screwdriver
1	Small cross tip screwdriver
1	Plastic mallet
1	Ladder 2.5m
1	Ruler
1	Brush

6.5. Special tools

6.5. Special tools

General					
	All service instructions contain lists of tools required to perform the specified activity. The required tools are a sum of standard tools, defined in the section <i>Standard toolkit on page 78</i> , and of special tools, listed directly in the instructions and also gathered in this section.				
Special tools					
	The following table specifies the special tools required during several of the service procedures. The tools are also specified directly in concerned instructions in the Product manual.				
	Otv	Oty Tool Product			
	1 Thread sealant for conical fittings Loctite 577				
	For ope	For operations on electrical parts:			
	Qty	Qty Tool Product			
	1	Multimeter			
	1	Wire strippers			
	1	Cable cutters			

Special tools available from ABB

The following table specifies the special tools required during several of the service procedures. The tools may be ordered separately and are also specified directly in concerned instructions in the Product manual.

Qty	ΤοοΙ	ABB Article no.
1	Feather roller support	3HAW050024260



Figure: Feather roller support

6 Reference information

6.5. Special tools

7.1. Introduction

7 Spare parts

7.1. Introduction

General

This chapter specifies all spare parts and replacement articles of the Feather Duster. It is divided in 2 sections:

- Mechanical spare parts
- Electrical parts and cables

Some parts are available in several types, depending on the Feather Duster configuration. If you do not know what type of material is required for your Feather Duster, contact ABB.

7 Spare parts

7.2. Mechanical spare parts

7.2. Mechanical spare parts

List of spare parts



Item	Qty	ABB part no.	Description	Note
A	2	3HAW050024263	Carbon fiber covers	Symetrical part - 2 covers per Feather Duster
В	1	3HAW050024318	Safe edge sensor	



3HAW050024258 Roller shaft

7.2. Mechanical spare parts

ltem	Qty	ABB part no.	Description	Note
D	20	3HAW050024273	Feather Brush	To form a complete brush, 20 pieces are stacked on the shaft
-	2	3HAW050024230	Shaft bearing with housing	



ltem	Qty	ABB part no.	Description	Note
E	1	3HAW050024220	Motor and gear (380VAC-50Hz)	The motor 3HAW050024221 is to be used only if the mains power supply type is 480VAC- 60Hz <u>and</u> if the process cabinet is not equipped with a transfomer 3HAC037015-001.
		3HAW050024221	Motor and gear (480VAC-60Hz)	If the mains power supply type is 380VAC-50Hz or if the process cabinet is equipped with a transformer 3HAC037015-001, the motor 3HAW050024220 is to be used.
F	1	3HAW050024243	Air knife	



7.2. Mechanical spare parts

Item	Qty	ABB part no.	Description	Note
G	1	3HAW050024222	Timing belt	
-	2	3HAW050024229	Pulley	
Н	1	3HAW050024233	lonizing bar	
I	1	3HAW050024314	Approach switch	



ltem	Qty	ABB part no.	Description	Note
J	1	3HAW050024238-010	Exhaust hose 10m	
К	1	3HAW050024207-004	Outer protection flexible conduit Ø 36mm	Used from robot base to wrist (Feather Duster Dresspack)
-	1	3HAW050024240-001	Inner protection flexible conduit Ø 29mm	Used from the robot wrist to the electrical junction box in the Feather Duster.
L	3	3HAW050024236	Exhaust pipe support	

7.3. Electrical spare parts

7.3. Electrical spare parts

List of spare parts

Item	Quantity	ABB part reference no.	Note
-	1	3HAW050024312	Safety edge sensor relay
-	1	3HAW050024313	General relay
-	1	3HAW050024317	Safe edge controller
-	1	3HAW050024325	Brake resistor
-	1	3HAW050024294-010	Control cable (from process cabinet to robot base) - 10m
-	1	3HAW050024294-015	Control cable (from process cabinet to robot base) - 15m
-	1	3HAW050024279	Flexible control harness (from robot base to junction box)

© Copyright 2013-2015 ABB. All rights reserved.

8.1. Assembly drawings

8 Appendix

8.1. Assembly drawings

List

This section contains following drawings:

- Exhaust manifold assembly
- Shaft assembly
- Tack off
- IRB 6640 Feather duster dresspack left
- IRB 6640 Feather duster dresspack right
- IRB 6700 Feather duster dresspack left

8.2. Wiring diagrams

8.2. Wiring diagrams

List

- 3HAW050024286: EMU process cabinet
- 3HAW050024294: Ground control cable
- 3HAW050024279: Flexible control harness



tions/ Revisions	Re Iter	pere n NO.	Indice Update			
naust manifold divi	а	А				
arts revised.	b	В				
4x10, EN 470	62			10		
4x16, EN 470	52			4		
10x12, DIN 9	212			4		
				2		
6x12, DIN 91	2			4		
PMGOB-29N	/32Z			1		
20				1		
nge PAFOB	-36	001		1		
		304	<u> </u>	1		
		Q_{235}		1		
		O_{2354}	<u>`</u>	' 1		
		Q235/		1		
tion		Mat.	G	ty.	Rei	marks
mbly			I		Mat	erial:
				_		
SIEK				_	Threa	tment:
assembly				_	Br	ut:
				_		
: CNAUS	Dpt: R	& D	VISA:			
			I	AI	BB	
g Ltd				Engii No5, L	neering	g Ltd
				201319 Shar	9 Nanhui 1 ahai . 1	District PRC
de ABB Body In Wh es tiers sans autoris	ite SA et n ation écrite	e peut être e préalable		tel: + fax:	-86 216 +86 21	1298980 61056905
Ŵ7					Ve	ehicle:
					S	iheet:
					⊥ .	쉬 //
	050	0242	25	2		ע∥ ש
					-	



Modific	Name	Date
Exploded vie	Yonglong Jin	08/05/2014
3HAW050024273	Yonglong Jin	08/14/2014
Sub-j	King Jin	01/05/2015
Sub-	King Jin	05-26-2015

11					Hex nut M12, DIN 93				
10					Socket flat screw MS				
9	ЗН	AW0500)242	230	Bed	aring h	nousir	ng	
8	зн	AW0500)242	229	Hig	h Toro	ue Tir	min	g F
7	ЗН	AW0500)242	227	Key	Y			
6	ЗН	AW0500)242	228	Fix	conne	ected	axi	i
5	ЗН	AW0500)242	226	Loc	cated	ring		
4	ЗН	AW0500)242	224	Co	nnect	ed sh	aft	
3	ЗН	AW0500)242	219	Pip	e fram	ne_1\$	T a>	ki
2	ЗН	AW0500)242	218	Bed	aring k	ottor	n	
1	ЗН	AW0500)242	258	Rol	ler shc	ıft		
Item		PartN	10				De	scri	pti
		Designa	ition	i: Pa	rf, su Fe	ather	mbly Duste	or A er Sl	lsse hal
								-	
Date: 5	5/27/	2015		Par	r: F LEGELEUX Plant				
Eng	ginee	ering by: onglong				BB E	ngin	eel	rin iété
					re	eproduit o	J COMMU	Jniqué	àd
Conce	ption	Copie	ļ	Archiv	age	Format	Oth	er	\mathbb{N}
Manue CAO-D	elle DAO	Scanner MicroFilm	n			A3	ID		
Pour Usine:					Classement Archives				
							Drawi ID	ing	

tions/ Revisions	Repere Item NO.	Indice Update
v added on sheet 2.		А
Feather Brush removed.		В
arts revised.		С
art revised.		D

4			2		
5x12, DIN799	21		6		
			2		
rulley			1		
		304	1		
		304	1		
		304	1		
		304	1		
		304	2		
		304	2		
		2A16	1		
on		Mat.	Qty.	Re	emarks
mbly					Material:
t assembly	,			Th	reatment:
					Brut:
: CNAUS	D	pt: R & D	VISA:	•	
g Ltd de ABB Body In Wh	ite S	A et ne peut êti	e	AB Engine Chuangy 201319 N Shangt tel: +86	ering Ltd e 369 ve Rd, Kangajao anhui District nai, PRC 2 161298980
es tiers sans autoriso	ation	i écrite préalab	е	fax: +8	6 2161056905
\mathbb{N}]	venicie.
					Sheet:
	$\mathbb{Z}^{\mathbb{Z}}$: _ _ _ _ _ _ _ _ _ _ _ _ _	I M R I		1/2

<u>3HAW050024255</u>

0 1	2 3	4	5	6	7	8	
							F26_AE
Draiaat Discription	Footbor Ductor EDE J	Jarpace Cabinat ta	Dobot Doco				
	reallier Dusler FD5 r						
Document Number	3HAW050024294-XX	X					
Revision	004						
					Ν	umber of pages	1
	Feather Duster FD5 Harness Cabinet to Robot Ba		Title n	ago / covor shoot	Status: Approved	2012/6/1 = +	



We reserve all rights in this document and in the information contained therein Reproduction, use or disclosure to third parties without express authority is srictly forbidden. Copyright ABB



We reserve all rights in this document and in the information contained therein Reproduction, use or disclosure to third parties without express authority is sricitly forbidden. Copyright ABB

Cable diagram								F09_002_ABE
Cable name =+-W1			cable type		Igus:CF140.15.04.UL			
function text			no. of condu	uctors 4G		cross-sectio	n 1.5	Length
function text	Page / column	Target designation from	Connection point	conductor	Target designation to	Connection point	Page / column	function text
	/3.1	-FD5-a	1	1	-R1.FD5-A	1	/3.1	
	/3.1	-FD5-a	2	2	-R1.FD5-A	2	/3.1	
	/3.1	-FD5-a	3	3	-R1.FD5-A	3	/3.1	
	/3.2	-FD5	PE	SH	-R1.FD5	PE	/3.2	
	/3.2	-ED5-a	4	Y/G	-R1 ED5-A	4	/3.2	

7

6

8

9

4

0

1

2

3

Respsonsible Department:	RS / BIW	
Prepare by, Date N,Cao	2014/4/24	Approve by, Date

Replaced by

2012/6/1

Replacement of



Status:	2012/6/1	=	=			
Approved		+				
Document no.				Rev.Ind	Page	
3HAW05002	4294-XXX			004	Total Pag	

Cable diagram									
								F09_	_002_AE
Cable name =+-W2			cable type		Igus:CF130.15.04.UL				
function text				no. of conductors 4G			n 1.5	Length	
function text	Page / column	Target designation from	Connection point	conductor	Target designation to	Connection point	Page / column	function text	
	/3.3	-FD5-b	1	1	-R1.FD5-B	1	/3.3		
	/3.3	-FD5-b	2	2	-R1.FD5-B	2	/3.3		
	/3.3	-FD5-b	3	GNYE	-R1.FD5-B	3	/3.3		

Respsonsible Department:	RS / BIW		
Prepare by, Date N,Cao	2014/4/24	Approve by, Date	2012/6/1



Replaced by

Replacement of



						0
I	Status:	2012/6/1	-			
l	Approved		+			
I	Document no.			Rev.Ind	Page	5
	3HAW050024294-	XXX		004	Total Page	10

Cable diagram								F09_002_AB
Cable name =+-W3			cable type		Igus:CF130.07.07.UL			
function text			no. of cond	uctors 7G		cross-sectio	n 0.75	Length
function text	Page / column	Target designation from	Connection point	conductor	Target designation to	Connection point	Page / column	function text
	/3.4	-FD5-c	1	1	-R1.FD5-C	1	/3.4	
	/3.5	-FD5-c	2	2	-R1.FD5-C	2	/3.5	
	/3.5	-FD5-c	3	3	-R1.FD5-C	3	/3.5	
	/3.5	-FD5-c	4	4	-R1.FD5-C	4	/3.5	
	/3.5	-FD5-c	5	5	-R1.FD5-C	5	/3.5	
	/3.5	-FD5-c	6	6	-R1.FD5-C	6	/3.5	
	/3.6	-FD5	PE	Y/G	-R1.FD5	PE	/3.6	

6

7

8

9

4

0

1

2

Respsonsible Department:	RS / BIW	
Prepare by, Date N,Cao	2014/4/24	Approve by, Date

	Feather Duster FD5 Harness Cabinet to Robot B						
2012/6/1	Replacement of	Replaced by					



						'
Sta	tus: 2012/6/1		=			
Ap	proved		+			
Doo	cument no.			Rev.Ind	Page	6
3H	AW050024294-XXX		004	Total Page	10	
3H	AW050024294-XXX			004	Page Total Page	1

					F26_ABB_(
Project Discription	Feather Duster FD5 Har	ness Robot Base to Arm	n		
Document Number Revision	3HAW050024279 006				
				Nuclear Course	
				Number of pages	14
				Status:	

We reserve all rights in this document and in the information contained therein Reproduction, use or disclosure to third parties without express authority is sricity forbidden. Copyright ABB

Prepare by, Date N,Cao

	0	1	2	3	4	5	6	7	8	9
Reproduction, use or disclosure to third parties without express authority is sricity forbidden. Copyright ABB		ı I	2	3 ength = 4M Tube Len Cable Length = 6.8M	$\frac{1}{12}$			Technical Provisions	BINDE TYPE D TP 31	ocument Description IABB053-1 Barcodes
	1 Responsible Department: RS / BIW Penerara but bate, N Con-	Anneue by Pate	Feather Dus	ter FD5 Harness Robot Base to Arm			Layout Harness	Status: Approved Document no. 3HAW/050024279		Rev.Ind Page

2.b 2.a 14

0	1	2	3	4	5	6	7	8	9
								Supplementary Document	Doc Type Document Description
					Image: Constraint of the second state of the second sta			Technical Provisions 1	IP 3HAB8053-1 Barcodes
2.a					R2.FD5		Status:		3
		Feather Duste	r FD5 Harness Robot Base to A	rm		Lavout Pay	Approved		+
Respsonsible Department: RS / BIW						Layout Box	Document no.	4070	Rev.Ind Page 2.t
Prepare by, Date N,Cao 2014/6/16	Approve by, Date	Replacement of	Replaced by				3HAVVU5UU2	4279	UUD Total Page 14

We reserve all rights in this document and in the information contained therein Reproduction, use or disclosure to third parties without express authority is sricity forbidden. Copyright ABB



I	2	3	4		5 6		/	8	9
able diagram									F09 01
Cable name =+-W1			cable type		Igus:CF140.15.04.UL				
function text			no. of cond	uctors 4G		cross-sectio	Length 7		
function text	Page / column	Target designation from	Connection point	conductor	Target designation to	Connection point	Page / column	function text	
	/3.1	-R1.FD5-a	1	1	-R2.FD5-XP1	1	/3.1		
	/3.1	-R1.FD5-a	2	2	-R2.FD5-XP1	2	/3.1		
	/3.1	-R1.FD5-a	3	3	-R2.FD5-XP1	3	/3.1		
	/3.2	-R1.FD5	PE	SH		SH	/3.2		
	/3.2		SH	SH	-R2.FD5	PE	/3.2		

SH

Y\G

-R2.FD5

-R2.FD5-XP1

PE

4

/3.2

/3.1

PE

4

Respsonsible Department:	RS / BIW

Prepare by, Date N,Cao

2014/6/16 Approve by, Date

Replaced by

Replacement of

/3.2

/3.1

-R1.FD5

-R1.FD5-a



				5				
Status:	=							
Approved	+							
Document no.		Rev.Ind	Page	4				
3HAW050024279		006	Total Page	14				

Cable diagram									F09_002_AB
Cable name =+-W2			cable type		Igus:CF130.15.04.UL				
function text			no. of condu	uctors 4G		cross-sectio	n 1.5		Length 7
function text	Page / column	Target designation from	Connection point	conductor	Target designation to	Connection point	Page / column		function text
	/3.3	-R1.FD5-b	1	1	-R2.FD5-XP1	5	/3.3	IonzB +	
	/3.3	-R1.FD5-b	2	2	-R2.FD5-XP1	6	/3.3	IonzB -	
	/3.3	-R1.FD5-b	3	GNYE	-R2.FD5-XP1	7	/3.3	IonzB PE	

6

7

8

9

4

Respsonsible Department:	RS / BIW	I

2014/6/16 Approve by, Date

Prepare by, Date N,Cao

0

1

2

3

Replaced by

Replacement of



				0				
Status:	=							
Approved	+							
Document no.		Rev.Ind	Page	5				
3HAW050024279		006	Total Page	14				

0 1	2	3	4		5 6		1	8	9
able diagram									F09_
Cable name =+-W3			cable type		Igus:CF130.07.07.UL				
function text			no. of cond	uctors 7G		cross-sectio	on 0.75		Length 7
function text	Page / column	Target designation from	Connection point	conductor	Target designation to	Connection point	Page / column		function text
	/3.4	-R1.FD5-c	1	1	-R2.FD5-XP1	8	/3.4	AntCls Br	
	/3.4	-R1.FD5-c	2	2	-R2.FD5-XP1	9	/3.4	AntCls Wh	
	/3.5	-R1.FD5-c	3	3	-R2.FD5-XP1	10	/3.5	AntCls Gn	
	/3.5	-R1.FD5-c	4	4	-R2.FD5-XP1	11	/3.5	RotSw+	
	/3.5	-R1.FD5-c	5	5	-R2.FD5-XP1	12	/3.5	RotSw-	

6

Y/G

-R2.FD5-XP1

-R2.FD5

13

PE

/3.5

/3.5

6

PE

Respsonsible Departmen	t: RS / BIW	
Prepare by, Date N,Cac	2014/6/16	Approve by, Date

Prepare by, Date N,Cao

Replaced by

Replacement of

-R1.FD5-c

-R1.FD5

/3.5

/3.5



Status:	=			
Approved	+			
Document no.		Rev.Ind	Page	6
3HAW050024279		006	Total Page	14

RotSwSg

0	1	2	3	4		5	6		7	8	9
Cable diagr	am										F09_002_A
Cable name	=+-W4			cable type		Igus:CF14	0.15.04.UL				
function text		_	_	no. of cond	uctors 4G			cross-sectio	n 1.5		Length 1.8
functio	on text	Page / column	Target designation from	Connection point	conductor	Target de	signation to	Connection point	Page / column	1	function text
		/3.1	-R2.FD5-XP1	1	1	-X1		U	/3.1		
		/3.1	-R2.FD5-XP1	2	2	-X1		V	/3.1		
		/3.1	-R2.FD5-XP1	3	3	-X1		W	/3.1		
		/3.2	-R2.FD5	PE	SH	-X1		SH	/3.2		

Y\G

-X1

PE

/3.1

4

Respsonsible Department:	RS / BIW

2014/6/16 Approve by, Date

Prepare by, Date N,Cao

Replaced by

Replacement of

/3.1

-R2.FD5-XP1



Status:	-		
Approved	+		
Document no.		Rev.Ind	Page
3HAW050024279		006	Total Pa



FIXED MOBILE

SOUDUF WELDING Discond Discond Contin Contin	RE tinue: tinuous: u uuous	Long Leng Space bee Cla Categ	e 3 si aucun ory 3 unles :: : : :	e autre indi s otherwise	ication indicated	TOLERANCES GENERALES GENERALS TOLERANCES Sauf indication contraire Unless otherwise indicated										
CLASSE Controle ressuage 100 % + certificat Sweating inspection								E STOC K	RUT MATERIAL	F	R25	R12.5		5 R6.3		
	<u> </u>		Co de	<u>0 % + c</u> ntrole re s zones c	<u>ertificat</u> ssuage critiques	e	0 —	150	±	1	±	0.25	±	0.20	±	0.15
		-	Sw of	∠ Sweating inspection of critical areas Controle visuel				400	±	1.25	±	0.35	±	0.30	±	0.20
			3 v (s	oir proce isual insp ee proce	edure) ection edure)		>	400	±	1.50	±	0.50	±	0.40	±	0.30
Qualite des mecanosoudures: S6_F024 Weldment quality:												/				
Ep.tole Plate thick.	5 a	10	10 a 15	15 a 20	20 a 25	25 a 30	USINE MAC HINED		0.2/1000)	0.2/	1000		0.3/1000	
L	11	14	14 17 17 17 17					RUT MATERIAL	2/1000			2/		2.5/1000		

(x1) Adjustable asm 3HAW050024254 (x4) Screw bolt M8x15 GB/T 70.1-2000 (x4) Screw bolt M5x15 GB/T 70.1-2000 (x4) Nut M8 GB/T 41-2000

06/09/2015	King Jin Few sub-assemblies & parts revised.													
01/22/2015	King Jin	b	В											
08/15/2014	King Jin	а	A											
Date	Name				м	Modifications/ Revisions								
Scale: 테미테에	Designo	Material:												
				F	EATHER	R D	USTER			Three	eatment:			
														
					Tak	e o	Brut:							
· + ·														
Date: 6/9/2	015	Par: FLE	GELEUX		Plc	ant: CNAUS	VISA:							
Engine Kir	ering by: ng Jin			e docume	ngine	eri	i ng Ltd eté de ABB Body In Wh	ABB Engineering Ltd No5, Lane 369 Chuangye Rd, Kangqiao 201319 Nanhui District Shanghai, PRC tol: +94 2141208980						
			re	produit o	u communia	qué à	à des tiers sans autoris	ation écrite préalable		fax: +86 21	61056905			
Conception	F Copie		rchivage	Format	Other	r	\mathbb{W}			enicie:				
Manuelle CAO-DAO	Scanner MicroFilm													
Pour Usine:				Classeme	ent				Sheet:					
Inventaires			Matricul	Archives	s l			лпл						
					Drawing ID		262		1/1					
1					1									



	1 1 1					0.4						,	10	
						34			washer M	46, DIN 9250			40	
						33			Washer N	18, DIN 9250			10	
						32			Washer M	12, DIN 9250			8	
W						31			washer M	(18, DIN 9250			2	
						30				5, DIN 934			16	
						29			Screw M6x10,	DIN 912 Class 8	<u>.8</u>		4	
						28			Screw M6x16,	DIN 912 class 8	3.8		12	
						2/			Screw M6x20,	DIN 912 class 8	3.8		16	
						26			Screw M6x25,	DIN 912 class 8	3.8		8	
						25			Screw M8x12,	DIN 912 class 8	3.8		6	
						24			Screw M8x25,	DIN 912 class 8	3.8		4	
						23			Screw M12x20,	DIN 912 class 8	3.8		8	
						22			Screw M18x30,	DIN 912 class 8	8.8		2	
						21 3HA	AW050024	375	90 Deg	gree Joint			1	Legris
						20 3H <i>A</i>	AW050024	374	Protec	tion Shell			0.05 m	Misumi
						19 3HA	AW050024	276	Standard Protect	or 36mm, PAPR	≀B-36F		3	REIKU
						18 3HA	AW050024	272	Τυ	bing			15 m	Legris
						17 3HA	AW050024	247	Cable Ball joint cla	mp 36mm, PAk	<gb_36< td=""><td></td><td>3</td><td>REIKU</td></gb_36<>		3	REIKU
						16 3HA	AW050024	277	Gripping Clamp Ho	ose 52mm, PAS	SB-52M		3	REIKU
						15 3F	AWL0010	01	Tubing Cable Pro	otection, PURRE	3-36F		1	REIKU
						14 3HA	AW050024	239	CI	amp			2	友动
						13 3F	AWL0010	03	Exhaust h	ose, VM152			10 m	友动
81						12 3HA	AW050024	368	Fixing	plate 3		Q235A	1	
İ.						11 3HA	AW050024	367	Fixing	plate 2		Q235A	1	
ľ						10 3HA	AW050024	366	Fixing	plate 1		Q235A	1	
		// / -)				9 3HA	AW050024	365	New Brac	cket Support		Q235A	2	
ł						8 3HA	AW050027	152	IRB6640 Robot Cove	er Plate Feathe	r Duster	r 6061	1	
						7 3HA	AW050027	151	SP	ACER		Q235A	1	
8	•					6 3HA	AW050024	261	Exhau	st Flange		304	1	
						5 3HA	AW050024	242	Join	t plate		Q235A	1	
	3	F I I				4 3HA	AW050024	241	3ND ai	x Hangor		Q235-	1	
ļ			564			3 344		237	Support f	irame Avis 1		Q235-	1	
								237	5000011			A		
					-	2 3HA	AW050024	3/9	Exhaust p	onpe support			5	
		<i>i</i>				I 3HA	AVV050024	235	Pipe fran	ne_2ND axi		Q235A		D
Ý					IT		Partino		Desc	cription		Mat.	Qfy.	Remarks
1						Scale: दी ¤दी (ୁ Designat	tion: I	Part, sub-assembly or A	Assembly				
-									FEATHER	DUSTER			Т	hreatment:
		1-1												
						$ \in (\bullet)$)		Feather Duster D	Presspack - LEFT				Brut:
						1								
						Date: 5/2	6/2015		Par: F LEGELEUX F	Plant: CNAUS	Dpt: R &	D VI:	SA:	
						Engin	eering by:						AB	B
									ABB Enginee	ring Ltd			Engine No5, La	eering Ltd
							king jin		0	5			201319	gye Rd, Kangqiao Nanhui District ahai PRC
									Ce document est la prop reproduit ou communiqu	riété de ABB Body In Whi é à des tiers sans autorisc	ite SA et ne p ation écrite p	ceut être céalable	tel: +8 fax: +	36 2161298980 86 2161056905
							В		Other					Vehicle:
						Conceptie Manuelle	on Copie Scanner	Arc	chivage Format ID					
	I				1	CAO-DAO	D MicroFilm							Charte
	05-26-2015	King Jin	Sub-parts revised.	b	В	Pour Usine	e: Intaires		Classement Archives					sneet:
	2014-8-4	Jin Yonglong	Revised for better performance.	a	А									- - - - - - - - - - - - - - - - - - -
	Date	Name	Modifications/ Revisions	Repere	Indice				Drawing	13HAW	<u>)500</u>)242(59	
	2 310			ITEM NO.	l nbqate	<u> </u>								

SOUDURE WELDING Discontinue:							TOLERANCES GENERALES GENERALS TOLERANCES												
$\bigotimes_{\substack{\text{Continu}\\\text{Continuous}}}^{\text{Continu}} \xrightarrow{\text{Classe}} = (1) (2) (3)$								Sauf indication contraire Unless otherwise indicated											
C LASSE C ATEGO)RY		Co 10 1 Sw	ntrole re 0 % + c eating in	ssuage ertificat spection			BRUT STOCK MATERIAL		R25		R12.5		R6.3					
		Controle ressuage des zones critiques					150	±	1	\pm	0.25	± C	.20	±	0.15				
			∠ Sw of	eating in <u>critical a</u> Controle v	spection reas isuel		150 —	400	±	1.25	+	0.35	± C	.30	±	0.20			
	J (voir procedure) J Visual inspection (see procedure)							400	±	1.50	+	0.50	± C	.40	±	0.30			
Qualite de Weldment	es me qualit	canos y:	oudure	e <mark>s:</mark> S6	6_F0.	24						//							
Ep.tole Plate thick.	5 a 9	10	10 a 15	15 a 20	20 a 25	25 a 30	USII MAC H	NE HINED	0.2/1000			0.2/1000			0.3/1000				
L	11	14	17	17	17	17	B F STOCK I	BRUT STOCK MATERIAL		2/100) 2/		1000	1	2.5/1000				


05-26-2015	King Jin	Sub-parts revised.	b	В
2014-8-4	Jin Yonglong	Revised for better performance.	a	А
Date	Name	Modifications/ Revisions	Repere Item NO.	Indice Update

SOUDURE Classes 3 st alcune autre indication Category 3 unless otherwise indicated WELDING Longueur cordon: Lenght of weld: Longueur espace:							TOLERANCES GENERALES GENERALS TOLERANCES								
Discontinuous: Space beetwen welds: Continu Classe = () (3) Continuous Category = () (3)						Sauf indication contraire Unless otherwise indicated									
CLASSE Controle ressuage CATEGORY 100 % + certificat Sweating inspection								BRUT STOCK MATERIAL		R25		R12.5		5 R6.3	
		Co de	100 % + certificate Controle ressuage des zones critiques Sweating inspection of critical areas Controle visuel		e	0 —	150	±	1	±	0.25	±	0.20	±	0.15
	_	Sw of				150 —	400	±	1.25	±	0.35	±	0.30	±	0.20
		3 (v (s	(voir procedure) Visual inspection (see procedure)			>	400	±	1.50	±	0.50	+	0.40	±	0.30
Qualite des mecanosoudures: S6_F024 Weldment quality:										/		'/			
5 a 9	10	10 a 15	15 a 20	20 a 25	25 a 30	USINE MACHINED BRUT STOCK MATERIAL		0.2/1000		C	0.2/10			0.3/1000 2.5/1000	
11	14	17	17	17	17					0					
	RE tinue: tinuous: uuous DRY es meo qualit 5 a 9 11	RE Long tinue: Long tinuous: Space bee u Cla uous Categ DRY Categorian es mecanoso quality: 5 10 9 11 14	RE Longueur cordon Longueur cordon Longueur espace Longueur espace Longueur espace Longueur espace Longueur espace Longueur espace Longueur espace Longueur espace Co Co Co Co Co Co Co Co Co Co	RE Longueur cordon: Length of weld: Longueur espace: Linuous: Space betwen welds: u Classe = $(100\% + c)$ (100% + c) (100% + c) (100% + c) (100% + c) (2%	RE Longueur cordon: Longueur cordon: Longueur cordon: Longueur espace: tinuous: Space beetwen welds: u Classe = $(100\% + certificat$ Sweating inspection 100\% + certificat Controle ressuage des zones critiques 2 Sweating inspection 100\% + certificat Controle ressuage des zones critiques 2 Sweating inspection of critical areas Controle visuel 3 Controle visuel Controle visuel 3 Controle visuel Controle visuel 3 Controle visuel 5 10 10 15 20 a 9 10 15 20 a 25 11 1 14 17 17 17 17	RE Consume and minimum and minimum and channe and minimum and min	RE Longueur cordon: Length of weld: Longueur espace: tinuous: Space betwen welds: u Classe = $() () (3)$ (3) (3	RE Clasery 3 unless otherwise indicated TOL Category 3 unless otherwise indicated TOL Longueur cordon: Longueur cordon: Longueur espace: tinuous: Space beetwen welds: u Classe = $Controle ressuage$ Controle ressuage Controle ressuage Controle ressuage Controle ressuage Controle ressuage Controle ressuage Controle ressuage Controle ressuage Controle visuel Controle visue	RE Longeur cordon: Langet of weld: Longeur espace: Linuous: Space betwen welds: u Classe = $() () (3)$ uous Category = () (3) Controle ressuage 100 % + certificat 100 % + certificate Controle ressuage des zones critiques 2 Sweating inspection 100 % + certificate Controle ressuage des zones critiques 2 Sweating inspection 100 % + certificate $0 - 150 \pm$ $150 - 400 \pm$ 150	$\begin{array}{c c c c c c c c c c c c c c c c c c c $	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	RE Lategory 3 miles otherwise indicated Lategory 3 miles otherwise indicated Langueur cordon: Langueur espace: Linuous: Space betwen welds: u Classe = $() (3)$ mous Category = $() (3)$ Controle ressuage Controle ressuage des zones critiques 2 Sweating inspection of critical areas Controle ressuage des zones critiques 2 Sweating inspection 3 Controle ressuage Controle ressuage 2 Sweating inspection 5 Controle visuel (voir procedure) Visual inspection (see procedure) 2 Show the state of	$\begin{array}{c c c c c c c c c c c c c c c c c c c $	$\begin{array}{c c c c c c c c c c c c c c c c c c c $	$\begin{array}{c c c c c c c c c c c c c c c c c c c $

			1									
36			Washer N	16, DIN 92		44						
35			Washer N	18, DIN 9		14						
34			Washer N	10, DIN 9		2						
33			Washer N	/12, DIN 9		4						
32			Washer N	118, DIN 9	9250			2				
31			NUT M6, [DIN 934				12				
30			Screw Ma	6x16, DIN	912 class 8.8			16				
29			Screw Ma	6x20, DIN	912 class 8.8			24				
28			Screw Ma	6x25, DIN		4						
27			Screw M8	3x20, DIN	912 class 8.8			10				
26			Screw M8	3x25, DIN	912 class 8.8			4				
25			Screw M	10x30, DII	v 912 class 8.8			2				
24			Screw M	12x20, DII	v 912 class 8.8			4				
23			Screw M ⁻	18x30, DII	v 912 class 8.8			2				
22	3HAW0500243	375	90 Degre	e Joint				1	Legris			
21	3HAW0500243	374	Protectio	n Shell				0.05 m	Misumi			
20	3HAW0500242	276	Standard	l Protecto	or 36mm, PAPR	RB-36F		3	REIKU			
19	3HAW0500242	272	Tubing					15 m	Legris			
18	3HAW0500242	247	Cable Bc PAKGB 3	all joint clo 6	amp 36mm,			3	REIKU			
17	3HAW0500242	277	Gripping 52M	Clamp H	lose 52mm, PA	SSB-		3	REIKU			
16	3HAWL001001	1	Tubing C	able Prot	ection, PURRB	-36F		1	REIKU			
15	3HAW0500242	239	Clamp					2	友动			
14	3HAWL001003	3	Exhaust h	nose, VM	152			1	友动			
13	3HAW0500243	371	Extend su	pport pl	Q235A	1						
12	3HAW0500243	370	New Axis	3 suppoi	t_RIGHT		Q235A	1				
11	3HAW0500243	369	New Axis	3 fixing p	Q235A	1						
10	3HAW0500243	368	Fixing pla	ite 3			Q235A	1				
9	3HAW0500243	367	Fixing pla	ite 2	Q235A	1						
8	3HAW0500243	366	Fixing pla	ite 1	Q235A	1						
7	3HAW0500243	365	New Brac	cket Supp	Q235A	2						
6	3HAW050027	152	IRB6640 R Duster	obot Co	6061	1						
5	3HAW050027	151	SPACER		Q235A	1						
4	3HAW0500242	261	Exhaust F	304	1							
3	3HAW0500242	237	Support f	rame Axi	Q235- A	1						
2	3HAW0500243	379	Exhaust p	pipe supp		6						
1	3HAW0500242	235	Pipe fram	ne_2ND c	ıxi		Q235A	1				
Item	PartNo			Des	cription	Mat.	QTY.	Remarks				
Scale:	Designation	n: Pa	rt, sub-asse	mbly or A	ssembly		II		Material:			
ן ורש ורש			F	EATHER [DUSTER				hreatment:			
Feather Duster Dresspack - RIGHT									Brut:			
Date: 5/26/2015 Par: FLEGFLEUX Plant: CNAUS Dot: R & D VISA:												
Engineering by:												
King Jin King Jin												
Ce document est la propriété de ABB Body In White SA et ne peut être reproduit ou communiqué à des tiers sans autorisation écrite préalable									Nanhui District ghai, PRC 36 2161298980			
									Vehicle:			
Concer Manue	otion Copie A elle Scanner	Archiv	rage Format	ID	$\mathbb{V}\mathbb{V}$							
Pour Usi	ne:			Classement					Sheet:			
Inv	rentaires	Мс	itricules	Archives	L				」 <i>𝔅/𝔅</i>			
				Drawing ID	3HAWO)500	2437	73	<i>ک) (ک)</i> ا			

Contact us

ABB Engineering (Shanghai) Ltd. N°4528, Kangxin Highway, Pudong New District, Shanghai 201319 P.R.CHINA Telephone +86 (0) 21 6105 6666

