

ROBOTICS

# Product manual

IRT 510



Trace back information:  
Workspace 24D version a12  
Checked in 2024-12-25  
Skribenta version 5.6.018

# Product manual

**IRT 510**

OmniCore

Document ID: 3HAC091203-001

Revision: B

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damage to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2024 ABB. All rights reserved.  
Specifications subject to change without notice.

# Table of contents

Overview of this manual .....	9
Product documentation .....	11
How to read the product manual .....	13
<b>1 Safety</b> .....	<b>15</b>
1.1 Safety information .....	15
1.1.1 Limitation of liability .....	15
1.1.2 Requirements on personnel .....	16
1.2 Safety signals and symbols .....	17
1.2.1 Safety signals in the manual .....	17
1.2.2 Safety symbols on manipulator labels .....	19
1.3 Robot stopping functions .....	25
1.4 Safety during installation and commissioning .....	26
1.5 Safety during operation .....	29
1.6 Safety during maintenance and repair .....	30
1.6.1 Safety during maintenance and repair .....	30
1.6.2 Emergency release of the robot axes .....	33
1.6.3 Brake testing .....	34
1.7 Safety during troubleshooting .....	35
1.8 Safety during decommissioning .....	36
<b>2 Track description</b> .....	<b>37</b>
2.1 About IRT 510 .....	37
2.2 Technical data .....	39
2.3 Dimensions .....	43
2.4 Travel length .....	47
2.5 The unit is sensitive to ESD .....	49
<b>3 Installation and commissioning</b> .....	<b>51</b>
3.1 Introduction to installation .....	51
3.2 Unpacking .....	52
3.3 Lifting .....	57
3.3.1 Preparations before lifting .....	57
3.3.2 Lifting and moving the track .....	58
3.3.3 Lifting cable chain .....	63
3.4 On-site installation .....	68
3.4.1 Assembling the track sections (for tracks longer than 9 m) .....	68
3.4.2 Orienting and securing .....	76
3.4.3 Positioning the stand .....	79
3.4.4 Geometric alignment of IRT 510 .....	84
3.4.5 Assembling the pedestal (option) .....	87
3.4.6 Assembling the manipulator and cable tray .....	89
3.4.6.1 Assembling the manipulator .....	89
3.4.6.2 Mounting of manipulator on the track .....	93
3.4.6.3 Changing manipulator orientation .....	96
3.4.6.4 Assembling the cable tray .....	99
3.4.7 Moving the carriage manually .....	101
3.4.8 Connecting long tracks .....	103
3.4.9 Restricting the working range .....	107
3.5 Electrical installation .....	108
3.5.1 Cable connections .....	108
3.5.2 Connectors on the OmniCore controller .....	111
3.5.3 Inspection of cables and covers prior to start-up .....	115
3.6 Software installation .....	116
3.6.1 Starting the system for the first time .....	116
3.6.2 Creating and downloading a system .....	117

# Table of contents

---

3.6.3	Setting upper and lower software limits for the track .....	119
3.6.4	Base frame configuration .....	125
3.6.4.1	Introduction .....	125
3.6.4.2	Configuration examples .....	127
3.6.5	Configuration of additional load .....	131
3.7	Lubrication .....	132
3.7.1	Replacing the grease cartridge in grease pump MEMOLUB® EPS .....	132
3.7.2	Configuration of grease pump MEMOLUB® .....	136
3.8	Commissioning .....	137
3.8.1	Check list for IRT 510 before commissioning .....	137
3.9	Test run after installation, maintenance, or repair .....	140
<b>4</b>	<b>Maintenance</b> .....	<b>141</b>
4.1	Introduction .....	141
4.2	Maintenance schedule and expected component life .....	142
4.2.1	Specification of maintenance intervals .....	142
4.2.2	Maintenance schedule .....	143
4.2.3	Gearbox oil .....	145
4.2.4	Expected component life .....	146
4.3	Activities 100 km or 1 month .....	147
4.3.1	Cleaning the racks .....	147
4.3.2	Cleaning the linear guides .....	149
4.4	Activities 1 month .....	151
4.4.1	Inspecting the automatic lubrication system .....	151
4.4.2	Emergency stop and stroke limit system .....	154
4.4.3	Inspecting the cables and connectors .....	155
4.5	Activities 3 months .....	156
4.5.1	Inspecting the cable chain .....	156
4.5.2	Inspecting the felt gear .....	160
4.6	Activities 12 months .....	161
4.6.1	Inspecting the cables and connectors .....	161
4.6.2	Inspecting the mechanical stops .....	162
4.6.3	Inspecting the gear wheel, gearbox and backlash .....	163
4.6.4	Adjusting the leveling .....	165
<b>5</b>	<b>Repair</b> .....	<b>167</b>
5.1	Introduction .....	167
5.2	Cut the paint or surface on the robot before replacing parts .....	168
5.3	Replacing the linear guides .....	169
5.4	Replacing the ball bearing blocks .....	172
5.5	Replacing the racks .....	177
5.6	Replacing the mechanical stops .....	180
5.7	Replacing the motor, gearbox and gear wheel .....	182
5.7.1	Replacing the motor .....	182
5.7.2	Replacing the gearbox .....	194
5.7.3	Replacing the gear wheel .....	206
5.8	Adjusting the gearbox backlash .....	219
5.9	Replacing the felt gear .....	223
5.9.1	Replacing the felt gear .....	223
5.10	Replacing the cable chain and cables .....	231
5.10.1	Replacing the cable chain .....	231
5.10.2	Replacing the side links and glide shoes .....	240
5.10.3	Replacing the cables .....	243
5.10.4	Replacing the lubrication sensor and sensor cable .....	251
<b>6</b>	<b>Calibration</b> .....	<b>255</b>
6.1	Overview .....	255
6.2	Fine calibration .....	256

6.3	Update revolution counters .....	257
6.4	Defining base frame .....	258
<b>7</b>	<b>Decommissioning</b> .....	<b>259</b>
7.1	Introduction to decommissioning .....	259
7.2	Environmental information .....	260
<b>8</b>	<b>Reference information</b> .....	<b>263</b>
8.1	Introduction .....	263
8.2	Applicable standards .....	264
8.3	Unit conversion .....	265
8.4	Screw joints .....	266
8.5	Weight specifications .....	269
8.6	Standard tools .....	270
8.7	Special tools .....	271
8.8	Lifting accessories and lifting instructions .....	273
8.9	HILTI adhesive anchor .....	274
<b>9</b>	<b>Spare parts</b> .....	<b>279</b>
9.1	Spare part lists and illustrations .....	279
<b>10</b>	<b>Circuit diagrams</b> .....	<b>281</b>
<b>Index</b>		<b>283</b>

**This page is intentionally left blank**



# Overview of this manual

## About this manual

This manual contains instructions for:

- mechanical and electrical installation of the IRT 510
- maintenance of the IRT 510
- mechanical and electrical repair of the IRT 510

## Product manual scope

The manual covers all variants and designs of the IRT 510. Some variants and designs may have been removed from the business offer and are no longer available for purchase.

## Usage

This manual should be used during:

- installation and commissioning, from lifting the product to its work site and securing it to the foundation, to making it ready for operation
- maintenance work
- repair work
- decommissioning work



### Note

It is the responsibility of the integrator to conduct a risk assessment of the final application.

It is the responsibility of the integrator to provide safety and user guides for the robot system.

## Who should read this manual?

This manual is intended for:

- installation personnel
- maintenance personnel
- repair personnel.

## Prerequisites

A maintenance/repair/installation craftsman working with an ABB robot must:

- be trained by ABB and have the required knowledge of mechanical and electrical installation/repair/maintenance work.
- be trained to respond to emergencies or abnormal situations.

## References

Documentation referred to in the manual, is listed in the table below.

Reference	Document ID
<i>Product manual, spare parts - IRT 510</i>	<i>3HAC091204-001</i>

*Continues on next page*

## Overview of this manual

---

Continued

Reference	Document ID
<i>Product specification - Product.ProductName</i>	<i>Document.ID-1</i>
<i>Circuit diagram - IRT 510</i>	<i>3HAC091050-001</i>
<i>Product manual - IRB 1520</i>	<i>3HAC043435-001</i>
<i>Product manual - IRB 1600/1660</i>	<i>3HAC026660-001</i>
<i>Product manual - IRB 2600</i>	<i>3HAC035504-001</i>
<i>Product manual - IRB 4600</i>	<i>3HAC033453-001</i>
<i>Operating manual - RobotStudio</i>	<i>3HAC065036-001</i>
<i>Operating manual - OmniCore</i>	<i>3HAC032104-001</i>

---

### Revisions

Revision	Description
A	First edition.
B	Published in release R24D. The following updates are made in this revision: <ul style="list-style-type: none"><li>• Updated forces data.</li></ul>

---

# Product documentation

---

## Categories for user documentation from ABB Robotics

The user documentation from ABB Robotics is divided into a number of categories. This listing is based on the type of information in the documents, regardless of whether the products are standard or optional.



### Tip

All documents can be found via myABB Business Portal, [www.abb.com/myABB](http://www.abb.com/myABB).

---

## Product manuals

Manipulators, controllers, DressPack, and most other hardware is delivered with a **Product manual** that generally contains:

- Safety information.
- Installation and commissioning (descriptions of mechanical installation or electrical connections).
- Maintenance (descriptions of all required preventive maintenance procedures including intervals and expected life time of parts).
- Repair (descriptions of all recommended repair procedures including spare parts).
- Calibration.
- Troubleshooting.
- Decommissioning.
- Reference information (safety standards, unit conversions, screw joints, lists of tools).
- Spare parts list with corresponding figures (or references to separate spare parts lists).
- References to circuit diagrams.

---

## Technical reference manuals

The technical reference manuals describe reference information for robotics products, for example lubrication, the RAPID language, and system parameters.

---

## Application manuals

Specific applications (for example software or hardware options) are described in **Application manuals**. An application manual can describe one or several applications.

An application manual generally contains information about:

- The purpose of the application (what it does and when it is useful).
- What is included (for example cables, I/O boards, RAPID instructions, system parameters, software).
- How to install included or required hardware.
- How to use the application.

*Continues on next page*

- Examples of how to use the application.

---

### Operating manuals

The operating manuals describe hands-on handling of the products. The manuals are aimed at those having first-hand operational contact with the product, that is production cell operators, programmers, and troubleshooters.

# How to read the product manual

---

## Reading the procedures

The procedures contain all information required for the installation or service activity and can be printed out separately when needed for a certain service procedure.

## Safety information

The manual includes a separate safety chapter that must be read through before proceeding with any service or installation procedures. All procedures also include specific safety information when dangerous steps are to be performed.

Read more in the chapter [Safety on page 15](#).

## Illustrations

The product is illustrated with general figures that does not take painting or protection type in consideration.

Likewise, certain work methods or general information that is valid for several product models, can be illustrated with illustrations that show a different product model than the one that is described in the current manual.

**This page is intentionally left blank**

# 1 Safety

## 1.1 Safety information

### 1.1.1 Limitation of liability

---

#### Limitation of liability

Any information given in this manual regarding safety must not be construed as a warranty by ABB that the industrial robot will not cause injury or damage even if all safety instructions are complied with.

The information does not cover how to design, install and operate a robot system, nor does it cover all peripheral equipment that can influence the safety of the robot system.

In particular, liability cannot be accepted if injury or damage has been caused for any of the following reasons:

- Use of the robot in other ways than intended.
- Incorrect operation or maintenance.
- Operation of the robot when the safety devices are defective, not in their intended location or in any other way not working.
- When instructions for operation and maintenance are not followed as intended.
- Non-authorized design modifications of the robot.
- Repairs on the robot and its spare parts carried out by in-experienced or non-qualified personnel.
- Foreign objects.
- Force majeure.

---

#### Spare parts and equipment

ABB supplies original spare parts and equipment which have been tested and approved for their intended use. The installation and/or use of non-original spare parts and equipment can negatively affect the safety, function, performance, and structural properties of the robot. ABB is not liable for damages caused by the use of non-original spare parts and equipment.

# 1 Safety

---

## 1.1.2 Requirements on personnel

### 1.1.2 Requirements on personnel

---

#### General

Only personnel with appropriate training are allowed to install, maintain, service, repair, and use the robot. This includes electrical, mechanical, hydraulics, pneumatics, and other hazards identified in the risk assessment.

Persons who are under the influence of alcohol, drugs or any other intoxicating substances are not allowed to install, maintain, service, repair, or use the robot.

The plant liable must make sure that the personnel is trained on the robot, and on responding to emergency or abnormal situations.

---

#### Personal protective equipment

Use personal protective equipment, as stated in the instructions.



## 1.2 Safety signals and symbols

### 1.2.1 Safety signals in the manual







#### Introduction to safety signals

This section specifies all safety signals used in the user manuals. Each signal consists of:

- A caption specifying the hazard level (DANGER, WARNING, or CAUTION) and the type of hazard.
- Instruction about how to reduce the hazard to an acceptable level.
- A brief description of remaining hazards, if not adequately reduced.

#### Hazard levels

The table below defines the captions specifying the hazard levels used throughout this manual.

Symbol	Designation	Significance
	DANGER	Signal word used to indicate an imminently hazardous situation which, if not avoided, will result in serious injury.
	WARNING	Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in serious injury.
	ELECTRICAL SHOCK	Signal word used to indicate a potentially hazardous situation related to electrical hazards which, if not avoided, could result in serious injury.
	CAUTION	Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in slight injury.
	ELECTROSTATIC DISCHARGE (ESD)	Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in severe damage to the product.
	NOTE	Signal word used to indicate important facts and conditions.


*Continues on next page*

# 1 Safety

---

## 1.2.1 Safety signals in the manual

*Continued*

Symbol	Designation	Significance
	TIP	Signal word used to indicate where to find additional information or how to do an operation in an easier way.

## 1.2.2 Safety symbols on manipulator labels

### Introduction to symbols

This section describes safety symbols used on labels (stickers) on the manipulator. Symbols are used in combinations on the labels, describing each specific warning. The descriptions in this section are generic, the labels can contain additional information such as values.



#### Note

The symbols on the labels on the product must be observed. Additional symbols added by the integrator must also be observed.




### Types of symbols

Both the manipulator and the controller are marked with symbols, containing important information about the product. This is important for all personnel handling the robot, for example during installation, service, or operation.

The safety labels are language independent, they only use graphics. See [Symbols on safety labels on page 19](#).

The information labels can contain information in text.

### Symbols on safety labels






Symbol	Description
 xx0900000812	<b>Warning!</b> Warns that an accident <i>may</i> occur if the instructions are not followed that can lead to serious injury, possibly fatal, and/or great damage to the product. It applies to warnings that apply to danger with, for example, contact with high voltage electrical units, explosion or fire risk, risk of poisonous gases, risk of crushing, impact, fall from height, etc.
 xx0900000811	<b>Caution!</b> Warns that an accident may occur if the instructions are not followed that can result in injury and/or damage to the product. It also applies to warnings of risks that include burns, eye injury, skin injury, hearing damage, crushing or slipping, tripping, impact, fall from height, etc. Furthermore, it applies to warnings that include function requirements when fitting and removing equipment where there is a risk of damaging the product or causing a breakdown.
 xx0900000839	<b>Prohibition</b> Used in combinations with other symbols.

*Continues on next page*






# 1 Safety

## 1.2.2 Safety symbols on manipulator labels

Continued

Symbol	Description
 xx0900000813	<b>See user documentation</b> Read user documentation for details. Which manual to read is defined by the symbol: <ul style="list-style-type: none"><li>No text: <i>Product manual</i>.</li></ul>
 xx0900000816	<b>Before disassembly, see product manual</b>
 xx0900000815	<b>Do not disassemble</b> Disassembling this part can cause injury.
 xx0900000814	<b>Extended rotation</b> This axis has extended rotation (working area) compared to standard.
 xx0900000808	<b>Brake release</b> Pressing this button will release the brakes. This means that the robot arm can fall down.




Continues on next page

Symbol	Description
 <p>xx0900000810</p>   <p>3HAC 057068-001</p> <p>xx1500002402</p>	<p><b>Tip risk when loosening bolts</b> The robot can tip over if the bolts are not securely fastened.</p>
  <p>xx0900000817</p>	<p><b>Crush</b> Risk of crush injuries.</p>








# 1 Safety

## 1.2.2 Safety symbols on manipulator labels

Continued

Symbol	Description
 <p>xx0900000818</p> <p>xx1300001087</p>	<p><b>Heat</b> Risk of heat that can cause burns. (Both signs are used)</p>
 <p>xx2400000736</p> <p>xx1500002616</p>	<p><b>Moving robot</b> The robot can move unexpectedly.</p>
 <p>xx0900000820</p> <p>xx1000001140</p>	<p><b>Brake release buttons</b></p>

Continues on next page




Symbol	Description
 <p>xx0900000821</p>	Lifting bolt
 <p>xx1000001242</p>	Adjustable chain sling with shortener
 <p>xx0900000822</p>	Lifting of robot
 <p>xx0900000823</p>	Oil Can be used in combination with prohibition if oil is not allowed.
 <p>xx0900000824</p>	Mechanical stop
 <p>xx1000001144</p>	No mechanical stop
 <p>xx0900000825</p>	Stored energy Warns that this part contains stored energy. Used in combination with <i>Do not disassemble</i> symbol.

*Continues on next page*

# 1 Safety

## 1.2.2 Safety symbols on manipulator labels

Continued

Symbol	Description
 xx0900000826	<b>Pressure</b> Warns that this part is pressurized. Usually contains additional text with the pressure level.
 xx0900000827	<b>Shut off with handle</b> Use the power switch on the controller.
 xx1400002648	<b>Do not step</b> Warns that stepping on these parts can cause damage to the parts.



### 1.3 Robot stopping functions

---

#### Protective stop and emergency stop

The protective stops and emergency stops are described in the product manual for the controller.

For more information see:

- *Product manual - OmniCore V250XT Type B*
- *Product manual - OmniCore V400XT*

# 1 Safety

---

## 1.4 Safety during installation and commissioning

### 1.4 Safety during installation and commissioning

---

#### National or regional regulations

The integrator of the robot system is responsible for the safety of the robot system.

The integrator is responsible that the robot system is designed and installed in accordance with the safety requirements set forth in the applicable national and regional standards and regulations.

The integrator of the robot system is required to perform a risk assessment.

---

#### Layout

The robot integrated to a robot system shall be designed to allow safe access to all spaces during installation, operation, maintenance, and repair.

If robot movement can be initiated from an external control panel then an emergency stop must also be available.

If the manipulator is delivered with mechanical stops, these can be used for reducing the working space.

A perimeter safeguarding, for example a fence, shall be dimensioned to withstand the following:

- The force of the manipulator.
- The force of the load handled by the robot if dropped or released at maximum speed.
- The maximum possible impact caused by a breaking or malfunctioning rotating tool or other device fitted to the robot.

The maximum TCP speed and the maximum velocity of the robot axes are detailed in the section *Robot motion* in the product specification for the respective manipulator.

Consider exposure to hazards, such as slipping, tripping, and falling.

Hazards due to the working position and posture for a person working with or near the robot shall be considered.

Hazards due to noise emission from the robot needs to be considered.

Consider hazards from other equipment in the robot system, for example, that guards remain active until identified hazards are reduced to an acceptable level.

---

#### Allergenic material

See [Environmental information on page 260](#) for specification of allergenic materials in the product, if any.

---

#### Securing the robot to the foundation

The robot must be properly fixed to its foundation/support, as described in the respective product manual.

When the robot is installed at a height, hanging, or other than mounted directly on the floor, there will be additional hazards.

---

*Continues on next page*

---

### Using lifting accessories and other external equipment

Ensure that all equipment used during installation, service and all handling of the robot are in correct condition for the intended use.

---

### Electrical safety

Incoming mains must be installed to fulfill national regulations.

The power supply wiring to the robot must be sufficiently fused and if necessary, it must be possible to disconnect it manually from the mains power.

The power to the robot must be turned off with the main switch and the mains power disconnected when performing work inside the controller cabinet. Lock and tag shall be considered.

Harnesses between controller and manipulator shall be fixed and protected to avoid tripping and wear.

Wherever possible, power on/off or rebooting the robot controller shall be performed with all persons outside the safeguarded space.



#### Note

Use a CARBON DIOXIDE (CO<sub>2</sub>) extinguisher in the event of a fire in the robot.

---

### Safety devices

The integrator is responsible for that the safety devices necessary to protect people working with the robot system are designed and installed correctly.

When integrating the robot with external devices to a robot system:

- The integrator of the robot system must ensure that emergency stop functions are interlocked in accordance with applicable standards.
- The integrator of the robot system must ensure that safety functions are interlocked in accordance with applicable standards.

---

### Other hazards

A robot may perform unexpected limited movement.



#### WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

The risk assessment should also consider other hazards arising from the application, such as, but not limited to:

- Water
- Compressed air
- Hydraulics

End-effector hazards require particular attention for applications which involve close human collaboration with the robot.

*Continues on next page*

# 1 Safety

---

## 1.4 Safety during installation and commissioning

*Continued*

---

### **Verify the safety functions**

Before the robot system is put into operation, verify that the safety functions are working as intended and that any remaining hazards identified in the risk assessment are mitigated to an acceptable level.

### 1.5 Safety during operation

#### Automatic operation

Verify the application in the operating mode manual reduced speed, before changing mode to automatic and initiating automatic operation.

#### Unexpected movement of robot arm



#### WARNING

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

A robot may perform unexpected limited movement.



#### WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

# 1 Safety

## 1.6.1 Safety during maintenance and repair

## 1.6 Safety during maintenance and repair

### 1.6.1 Safety during maintenance and repair

#### General

Corrective maintenance must only be carried out by personnel trained on the robot. Maintenance or repair must be done with all electrical, pneumatic, and hydraulic power switched off, that is, no remaining hazards.

Hazards due to stored mechanical energy in the manipulator for the purpose of counterbalancing axes must be considered before maintenance or repair.

Never use the robot as a ladder, which means, do not climb on the controller, manipulator, including motors, or other parts. There are hazards of slipping and falling. The robot might be damaged.


Make sure that there are no tools, loose screws, turnings, or other unexpected parts remaining after maintenance or repair work.

When the work is completed, verify that the safety functions are working as intended.

#### Hot surfaces

Surfaces can be hot after running the robot, and touching these may result in burns. Allow the surfaces to cool down before maintenance or repair.

#### Allergic reaction

Warning	Description	Elimination/Action
 Allergic reaction	When working with lubricants there is a risk of an allergic reaction.	Make sure that protective gear like goggles and gloves are always worn.


#### Gearbox lubricants (oil or grease)

When handling oil, grease, or other chemical substances the safety information of the respective manufacturer must be observed.










#### Note

Take special care when handling hot lubricants.

Warning	Description	Elimination/Action
 Hot oil or grease	Changing and draining gearbox oil or grease may require handling hot lubricant heated up to 90 °C.	Make sure that protective gear like goggles and gloves are always worn during this activity.

*Continues on next page*


Warning	Description	Elimination/Action
 <p><b>Allergic reaction</b></p>	When working with lubricants there is a risk of an allergic reaction.	Make sure that protective gear like goggles and gloves are always worn.
 <p><b>Possible pressure build-up in gearbox</b></p>	When opening the oil or grease plug, there may be pressure present in the gearbox, causing hot lubricant to spray from the opening.	Open the plug carefully and keep away from the opening. Do not overfill the gearbox when filling. Put oil absorbent cloth, bags or paper at appropriate locations to catch any oil residues. Use appropriate protective gear such as heat-resistant gloves, goggles/protective visor, or a body suit if necessary.
 <p><b>Do not overfill</b></p>	Overfilling of gearbox lubricant can lead to internal over-pressure inside the gearbox which in turn may: <ul style="list-style-type: none"> <li>• damage seals and gaskets</li> <li>• completely press out seals and gaskets</li> <li>• prevent the robot from moving freely.</li> </ul>	Make sure not to overfill the gearbox when filling it with oil or grease. After filling, verify that the level is correct.
 <p><b>Do not mix types of oil</b></p>	Mixing types of oil may cause severe damage to the gearbox.	When filling gearbox oil, do not mix different types of oil unless specified in the instructions. Always use the type of oil specified for the product.
 <p><b>Oil residues</b></p>	Oil residues might be present in a drained gearbox and spilled when separating a motor and gearbox during repair.	Make sure that protective gear like goggles/protective visor, gloves and arm protection are always worn during this activity. Put oil absorbent cloth, bags or paper at appropriate locations to catch any oil residues.
 <p><b>Heat up the oil</b></p>	Warm oil drains quicker than cold oil.	Run the robot before changing the gearbox oil, if possible.
 <p><b>Specified amount depends on drained volume</b></p>	The specified amount of oil or grease is based on the total volume of the gearbox. When changing the lubricant, the amount refilled may differ from the specified amount, depending on how much has previously been drained from the gearbox.	After filling, verify that the level is correct.

*Continues on next page*

# 1 Safety

## 1.6.1 Safety during maintenance and repair

Continued

Warning	Description	Elimination/Action
 Contaminated oil in gearboxes	For lifetime reasons always drain as much oil as possible from the gearbox. The magnetic oil plugs will gather residual metal chips.	

### Hazards related to batteries

Under rated conditions, the electrode materials and liquid electrolyte in the batteries are sealed and not exposed to the outside.

There is a hazard in case of abuse (mechanical, thermal, electrical) which leads to the activation of safety valves and/or the rupture of the battery container. As a result under certain circumstances, electrolyte leakage, electrode materials reaction with moisture/water or battery vent/explosion/fire may follow.

Do not short circuit, recharge, puncture, incinerate, crush, immerse, force discharge or expose to temperatures above the declared operating temperature range of the product. Risk of fire or explosion.

Operating temperatures are listed in [Operating conditions on page 42](#).

See safety instructions for the batteries in *Material/product safety data sheet - Battery pack (3HAC043118-001)*.

### Unexpected movement of robot arm



#### WARNING

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

A robot may perform unexpected limited movement.



#### WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

### Related information

See also the safety information related to installation and operation.



### 1.6.2 Emergency release of the robot axes

#### Description

In an emergency situation, the brakes on a robot axis can be released manually by pushing a brake release button.

How to release the brakes is described in the section:

- [Moving the carriage manually on page 101](#).

The robot may be moved manually on smaller robot models, but larger models may require using an overhead crane or similar equipment.

#### Increased injury

Before releasing the brakes, make sure that the weight of the manipulator does not result in additional hazards, for example, even more severe injuries on a trapped person.



#### **DANGER**

When releasing the holding brakes, the robot axes may move very quickly and sometimes in unexpected ways.

Make sure no personnel is near or beneath the robot.

# 1 Safety

---

## 1.6.3 Brake testing

### 1.6.3 Brake testing

---

#### When to test

During operation, the holding brake of each axis normally wears down. A test can be performed to determine whether the brake can still perform its function.

---

#### How to test

The function of the holding brake of each axis motor may be verified as described below:

- 1 Run each axis to a position where the combined weight of the manipulator and any load is maximized (maximum static load).
- 2 Switch the motor to the MOTORS OFF.
- 3 Inspect and verify that the axis maintains its position.

If the manipulator does not change position as the motors are switched off, then the brake function is adequate.



#### Note

It is recommended to run the service routine *BrakeCheck* as part of the regular maintenance, see the operating manual for the robot controller.

For robots with the option SafeMove, the *Cyclic Brake Check* routine is recommended. See the manual for SafeMove in [References on page 9](#).

## 1.7 Safety during troubleshooting

### General

When troubleshooting requires work with power switched on, special considerations must be taken:

- Safety circuits might be muted or disconnected.
- Electrical parts must be considered as *live*.
- The manipulator can move unexpectedly at any time.



#### DANGER

Troubleshooting on the controller while powered on must be performed by personnel trained by ABB or by ABB field engineers.



#### CAUTION

Risk of hot surfaces that can cause burns.

A risk assessment must be done to address both robot and robot system specific hazards.



#### WARNING

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

A robot may perform unexpected limited movement.



#### WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

### Related information

See also the safety information related to installation, operation, maintenance, and repair.

# 1 Safety

---

## 1.8 Safety during decommissioning

### 1.8 Safety during decommissioning

---

#### General

See section [Decommissioning on page 259](#).

If the robot is decommissioned for storage, take extra precaution to reset safety devices to delivery status.

---

#### Unexpected movement of robot arm



#### WARNING

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

A robot may perform unexpected limited movement.



#### WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

## 2 Track description

### 2.1 About IRT 510


#### Introduction

The IRT 510 is a linear track motion which is driven by the OmniCore V line controllers and programmed using the FlexPendant. It supports to work with IRB 1520, IRB 1600, IRB 2600 and IRB 4600 by providing carriage tables to fit the robots on. The IRT 510 expands the movement pattern of the robot with an extra degree of programmable freedom.

The IRT 510 can be categorized as follows:

- By cover type: covered track and standard track  
The difference between the two is that the covered track has top covers, rail covers and two end covers while the standard track only has rail covers on both sides of the track.
- By carriage quantity: single carriage track and double carriage track  
With a single carriage, which is the standard track variant, one robot can be installed on the track alone or with an extra plate that is used for arc welding applications. With double carriages, two robots can be installed and each of the two can have an extra plate.
- By cable chain type: standard track and mirrored track  
Mirrored tracks are the tracks installed in an opposite way, which can be identified by the installation mode of the cable chain. For single carriage tracks, the cable chain(s) of the track can be standard or mirrored. For double carriage tracks, one of the two cable chains is standard and the other is mirrored.

#### Main components



xx2400001004

Pos	Description	Pos	Description
A	Rack cover	G	Section
B	Cable chain	H	Leveling screw

*Continues on next page*

## 2 Track description

---

### 2.1 About IRT 510

*Continued*

Pos	Description	Pos	Description
C	Carriage	I	Top cover
D	Mechanical stop	J	Top cover support
E	Linear guide	K	End cover
F	Rack		



#### **CAUTION**

Do not step on the cable chain or top cover; otherwise, injure and/or damage to the product may occur.

## 2.2 Technical data

### Protection standards

Protection type	Protection class
Standard	IP65 <sup>i</sup>

<sup>i</sup> For mechanical parts and main electrical connections.

### Explosive environments

The IRT 510 cannot be located or operated in an explosive environment.

### Requirements, foundation

The table shows the requirements for the foundation where the weight of the installed robot is included.

Requirement	Value	Note
Flatness of foundation surface	1 mm/m (movement direction) 0.5 mm/m (Perpendicular to movement direction) Overall height difference $\leq 10$ mm	Flat foundations give better repeatability of the resolver calibration compared to original settings on delivery from ABB. The value for levelness aims at the circumference of the anchoring points in the robot base.

### Weight

#### Formula for IRT 510 weight calculation

Carriage quantity	Weight (Unit: kg; $N$ indicates the number of sections)
Robot	$W = 232 + 202 \times N$
Robot with extra plate	$W = 375 + 202 \times N$
Robot + Robot	$W = 232 \times 2 + 202 \times N$
Root + Robot with extra plate	$W = (232 + 375) + 202 \times N$
Robot with extra plate + Robot with extra plate	$W = 375 \times 2 + 202 \times N$

#### Weight of single carriage track

Sections (pcs) Value of $N$ in the formula	Joined sections in transportation	Weight (kg)	
		Robot	Robot with extra plate
2	1	636	779
3	1	838	981
4	1	1040	1183
5	1	1242	1385
6	1	1444	1587
7	1	1646	1789
8	1	1848	1991

*Continues on next page*

## 2 Track description

### 2.2 Technical data

Continued

Sections (pcs) Value of <i>N</i> in the formula	Joined sections in transportation	Weight (kg)	
		Robot	Robot with extra plate
9	1	2050	2193
10	2	2252	2395
11	2	2454	2597
12	2	2656	2799
13	2	2858	3001
14	2	3060	3203
15	2	3262	3405
16	2	3464	3607
17	2	3666	3809
18	3	3868	4011
19	3	4070	4213
20	3	4272	4415
21	3	4474	4617

#### Weight of double carriage track

Sections (pcs) Value of <i>N</i> in the formula	Joined sections in transportation	Weight (kg)		
		Robot + Robot	Robot + Robot with extra plate	Robot with extra plate + Robot with extra plate
4	1	1272	1415	1558
5	1	1474	1617	1760
6	1	1676	1819	1962
7	1	1878	2021	2164
8	1	2080	2223	2366
9	1	2282	2425	2568
10	2	2484	2627	2770
11	2	2686	2829	2972
12	2	2888	3031	3174
13	2	3090	3233	3376
14	2	3292	3435	3578
15	2	3494	3637	3780
16	2	3696	3839	4184
17	2	3898	4041	3982
18	3	4100	4243	4386
19	3	4302	4445	4588
20	3	4504	4647	4790
21	3	4706	4849	4992

Continues on next page



### Weight of pedestal

Pedestal height (mm) <sup>i</sup>	Weight (kg)
250	70
500	95
750	165
1000	190


<sup>i</sup> Heights 500, 750 and 1000 are unavailable for IRB 4600.

### Weight, robot

For the weight of each supported robot, see the corresponding product manual of the robot.

### Forces

Maximum floor loads in relation to the base coordination system are indicated per each foot of the section, see the following figure.



xx140000039

Robot	Endurance load in operation (kN)		Max. load at emergency stop (kN)	
	Fxy	Fz	Fxy	Fz
IRB 1600 without pedestal	±0.75	1.25±2.25	±1.75	2.0±4.0
IRB 1600 with 1000 mm pedestal	±0.75	2.5±4.5	±1.75	3.0±9.0
IRB 2600 without pedestal	±1.5	2.5±4.0	±3.5	3.0±7.0
IRB 2600 with 1000 mm pedestal	±1.5	3.0±5.5	±3.5	3.0±11.0
IRB 4600 without pedestal	±1.5	3.0±7.0	±3.5	3.0±14.5

Continues on next page

## 2 Track description

### 2.2 Technical data

Continued

Robot	Endurance load in operation (kN)		Max. load at emergency stop (kN)	
	Fxy	Fz	Fxy	Fz
IRB 4600 with 250 mm pedestal	±1.5	3.0±7.0	±3.5	3.0±15.0



#### Note

If doing fatigue calculations with combined tension (Fz) and shear loads (Fxy), the shear loads (Fxy) are allowed to be reduced with a factor 0.7.

### Airborne noise level

The sound pressure level outside the working space.

Track type	Level
IRT 510	< 76 dB (A) / 1m

### Power consumption at max load

Type	Description
Track	1.63 KW <sup>i</sup>
Robot	Within specification for respective robot.

<sup>i</sup> The track power consumption is measured on the condition of IRT 510 with a largest supported robot, that is, IRB 4600-60/2.05.  
The actual power consumption may vary according to the actual installed robot and site conditions.  
A power consumption measurement of a track with robot could be done with a simulated cycle in RobotStudio.

### Storage conditions

The table shows the allowed storage conditions for the robot:

Parameter	Value
Maximum ambient humidity	Maximum 95% at constant temperature.

### Operating conditions


The table shows the allowed operating conditions for the robot:

Parameter	Value
Minimum ambient temperature	+5 °C <sup>i</sup> (41 °F)
Maximum ambient temperature	+ 50 °C (122 °F)
Maximum ambient humidity	Maximum 95% at constant temperature.

<sup>i</sup> At low environmental temperature < 10° C is, as with any other machine, a warm-up phase recommended to be run with the robot. Otherwise there is a risk that the robot stops or run with lower performance due to temperature dependent oil- and grease viscosity.

2.3 Dimensions

Track



xx140000180

Item	Description	Value (mm)		
		Robot	Robot with extra plate	External cable chain
A	Total width with external cable chain	1048		N/A
B	Total width	700		N/A
C	Height	N/A		490
D		N/A	435	N/A
E		450	N/A	N/A
F	Width from the outer edge of external cable chain to its nearby foot center	406		N/A
G	Width (foot print)	584		N/A
H	Carriage table length	1048	2209	N/A
J	Distance between edges of the rack and mechanical stop	75.5		N/A
K	End cover	115		N/A
M	Distance between the rack edge and its nearest foot	250		N/A
N	Distance between two feet	500		N/A
Q	Section length	1000		N/A
P	Width from the center of first foot to the center of carriage table at calibration position	824.5	N/A	N/A
R		N/A	1824.5	N/A
S	Length of the external cable chain that exceeds the end of the track	N/A		0-490 <sup>i</sup>

Continues on next page

## 2 Track description

### 2.3 Dimensions

Continued

Item	Description	Value (mm)		
		Robot	Robot with extra plate	External cable chain
L1	Total length of the track with internal cable chain	$230 + (N \times 1000)^{ii}$ In which, $N$ indicates the number of sections		N/A
L2	Total length of the track without external cable chain or with external cable chain but the chain does not exceed the end of the track <sup>iii</sup>	$230 + (N \times 1000)^{ii}$ In which, $N$ indicates the number of sections		N/A
	Total length of the track with one external cable chain exceeding the end of the track <sup>iii</sup>	$720 + (N \times 1000)^{ii}$ In which, $N$ indicates the number of sections		N/A
	Total length of the track with double external cable chains exceeding the end of the track <sup>iii</sup>	$1210 + (N \times 1000)^{ii}$ In which, $N$ indicates the number of sections		N/A

- <sup>i</sup> For robot with extra plate, the external cable chain cannot exceed the end of the track.
- <sup>ii</sup> The total length of IRT 510 depends on the quantity of modules, each of which is 1,000 mm long. IRT 510 can be assembled with a minimum of 2 modules and a maximum of 110 modules.
- <sup>iii</sup> For details about the track with or without external cable chain and how the external cable chain exceeds the end of the track, see [Double carriage track on page 48](#).


#### Carriage table

The carriage table fits to various robot models and is symmetrically designed for different manipulator mounting orientations (in line, 90 degrees, 180 degrees and 270 degrees) regardless of the table orientation.

Use the hole configuration for the manipulator when designing fixtures to be used on the track. The following figures show the dimensions of the carriage table in mm. A double carriage track has two carriage tables in the same dimensions.


Continues on next page

Eight M10 holes circled in the following figure are available for fastening the fixture on the carriage table.



xx140000467

Two holes circled in the following figure at each side of the carriage table are available for ground cables.



xx1500001610

Continues on next page


## 2 Track description

### 2.3 Dimensions

Continued

#### Extra plate

The following figure shows the dimensions of the extra plate in mm.



xx140000462

#### Robot pedestal

The robot pedestal is designed to fix the robot.

The pedestal has two height models, 250 mm and 500 mm. You can choose a suitable pedestal or a pedestal combination according to the actual requirements. The following height models can be provided by the pedestal/pedestal combination: 250 mm, 500 mm, 750 mm and 1,000 mm.



#### Note

500 mm, 750 mm and 1,000 mm risers are not applicable to IRB 4600.

## 2.4 Travel length


### Overview

The travel length of the IRT 510 varies according to the quantity of carriages and robots fitted on the track.

Carriage quantity	Robot quantity	Travel length (m) <sup>i</sup>
Single carriage	Robot	0.8 to 19.8 (in steps of 1 m)
	Robot with extra plate	1.7 to 18.7 (in steps of 1 m)
Double carriages	Robot + Robot	1.6 to 18.6 (in steps of 1 m)
	Robot + Robot with extra plate	1.4 to 17.4 (in steps of 1 m)
	Robot with extra plate + Robot with extra plate	1.3 to 16.3 (in steps of 1 m)

<sup>i</sup> Travel length is the maximum distance that the carriage(s) can move.

### Single carriage track



xx240000632

Item	Description
L	Total length of linear guide (in mm) = 230 + 1000 x N, in which N indicates the number of sections.
A	Travel length (in mm)


*Continues on next page*

## 2 Track description

### 2.4 Travel length

Continued

#### Double carriage track



xx240000633

Item	Description
L	Total length of linear guide (in mm) = $230 + 1000 \times N$ , in which $N$ indicates the number of sections.
A	Travel length (in mm) of one carriage on the robot track Note: The two carriages on the robot track have the same travel length.
C1	Carriage 1 This carriage is always in standard mounting.
C2	Carriage 2 This carriage is always in mirrored mounting.



## 2.5 The unit is sensitive to ESD

---

### Description

ESD (electrostatic discharge) is the transfer of electrical static charge between two bodies at different potentials, either through direct contact or through an induced electrical field. When handling parts or their containers, personnel not grounded may potentially transfer high static charges. This discharge may destroy sensitive electronics.

### Safe handling

Use one of the following alternatives:

- Use a wrist strap.

Wrist straps must be tested frequently to ensure that they are not damaged and are operating correctly.

- Use an ESD protective floor mat.

The mat must be grounded through a current-limiting resistor.

- Use a dissipative table mat.

The mat should provide a controlled discharge of static voltages and must be grounded.

**This page is intentionally left blank**

## 3 Installation and commissioning

### 3.1 Introduction to installation

#### General

Following table lists the main installation and setup procedures that need to be carried out before starting working with IRT 510.

	Action	Reference
1	Unpack the track.	Compare the delivery checklist to the identification plates and verify for acceptance according to <a href="#">Unpacking on page 52</a> .
2	Lift the track sections to the position according to layout.	<a href="#">Lifting on page 57</a>
3	If the track is longer than 9 m, assemble the sections.	<a href="#">Assembling the track sections (for tracks longer than 9 m) on page 68</a>
4	Secure the track.	<ul style="list-style-type: none"> <li>• <a href="#">Orienting and securing on page 76</a></li> <li>• <a href="#">Positioning the stand on page 79</a></li> </ul>
5	Align and level the track.	<a href="#">Geometric alignment of IRT 510 on page 84</a> .
6	Assemble the pedestal (if any), manipulator and cable tray.	<ul style="list-style-type: none"> <li>• <a href="#">Assembling the pedestal (option) on page 87</a></li> <li>• <a href="#">Assembling the manipulator and cable tray on page 89</a></li> </ul>
7	Install the cable chain and connect all cables, and connect voltage to the system after verifying the covers and cable chain.	<a href="#">Electrical installation on page 108</a>
8	Start up the system and load software to the system.	<a href="#">Software installation on page 116</a>
9	Update the revolution counters.	<a href="#">Update revolution counters on page 257</a>

#### Safety information

Before any installation work is commenced, all safety information must be observed. There are general safety aspects that must be read through, as well as more specific safety information that describes the danger and safety risks when performing the procedures. Read the chapter [Safety on page 15](#) before performing any service work.



#### Note

If the IRT 510 is connected to power, always make sure that the IRT 510 is connected to protective earth and a residual current device (RCD) before starting any installation work.

For more information see:

- [Product manual - OmniCore V250XT Type B](#)
- [Product manual - OmniCore V400XT](#)
- [Connection points on page 108](#).

## 3 Installation and commissioning

### 3.2 Unpacking

### 3.2 Unpacking

#### Acceptance inspection



#### Tip


Always try to determine if the goods are as ordered, and that the package is not damaged before unpacking.

The IRT 510 has been pre-assembled in ABB factory. For delivery and storage's convenience, it would be divided into several segments as an unit depending on the length of the track when delivered.

The track is wrapped in plastic. Unpack the track and inspect for any visible transport damage. If the track is damaged, contact ABB.

#### Delivery contents

As standard, the IRT 510 includes several segments depending on the length. To identify the delivery, inspect the identification plates as shown in the following figure and compare them to the delivery note.



xx1500000228

1	ABB logo
2	Rating label
3	Calibration label
4	Lifting label
5	Warning label
6	Instruction plate

*Continues on next page*

### Cleaning

Before transportation, the IRT 510 has been protected against rust by a thin film of oil that has been applied before packing. Upon receiving the track, wipe off any surplus using a lint-free cloth.



#### Note


Do not clean any of the pre-lubricated linear guide and rack.

### Storing the spare/not in use cable chain

There are two methods for storing spare/not in use cable chains.

#### Method 1: folded in half

For complete chains with strapping in place and the strapping plates attached to the chains, the chain can only be folded in half. The chain can either be folded so that the chain is lying on itself or laid on its side.



xx130000884

*Continues on next page*


### 3 Installation and commissioning

#### 3.2 Unpacking

Continued

##### Method 2: rolled up

For complete chains with or without strapping in place or strapping in place and the strapping plate not connected to the chain, the chain can be rolled up and stored lying on its side.



xx130000885

##### Moving the cable chain from storage

To move the chain from storage to track, see [Lifting cable chain on page 63](#).

##### Required space for installation



##### Note

Following tables only list the space that is required by the track body. Additional spaces might be required at the ends of the track at the installation site. Always consider possible additional required spaces when planing the layout.

##### Formula for required space

Use the following formula to calculate the required space for the track:

$$\text{Required space (mm)} = 230 + (1000 \times N)$$

In which,  $N$  indicates the number of sections.

##### Required space for installation of single carriage track - without external cable chain

The following table describes the required spaces for the installation of the tracks in different travel lengths without the external cable chain.

Travel length (m) <sup>i</sup>		Sections (pcs)	Required space for installation (m) <sub>ii iii</sub>
Robot	Robot with extra plate	Value of $N$	
0.8	N/A	2	2.23
1.8	N/A	3	3.23
2.8	1.7	4	4.23
3.8	2.7	5	5.23
4.8	3.7	6	6.23

Continues on next page

Travel length (m) <sup>i</sup>		Sections (pcs)	Required space for installation (m) <sup>ii iii</sup>
Robot	Robot with extra plate	Value of <i>N</i>	
5.8	4.7	7	7.23
6.8	5.7	8	8.23
7.8	6.7	9	9.23
8.8	7.7	10	10.23
9.8	8.7	11	11.23
10.8	9.7	12	12.23
11.8	10.7	13	13.23
12.8	11.7	14	14.23
13.8	12.7	15	15.23
14.8	13.7	16	16.23
15.8	14.7	17	17.23
16.8	15.7	18	18.23
17.8	16.7	19	19.23
18.8	17.7	20	20.23
19.8	18.7	21	21.23

<sup>i</sup> The travel length is described in [Travel length on page 47](#).

<sup>ii</sup> The measurement for the required space is valid when not using the external cable chain.

<sup>iii</sup> How to calculate the required space is described in [Formula for required space on page 54](#).

#### Required space for installation of double carriage track - without external cable chain

The following table describes the required spaces for the installation of double carriage tracks in different travel lengths without the external cable chain.

Travel length (m) <sup>i</sup>			Sections (pcs)	Required space for installation (m) <sup>ii iii</sup>
Robot + Robot	Robot + Robot with extra plate	Robot with extra plate + Robot with extra plate	Value of <i>N</i>	
1.6	N/A	N/A	4	4.23
2.6	1.4	N/A	5	5.23
3.6	2.4	1.3	6	6.23
4.6	3.4	2.3	7	7.23
5.6	4.4	3.3	8	8.23
6.6	5.4	4.3	9	9.23
7.6	6.4	5.3	10	10.23
8.6	7.4	6.3	11	11.23
9.6	8.4	7.3	12	12.23
10.6	9.4	8.3	13	13.23
11.6	10.4	9.3	14	14.23
12.6	11.4	10.3	15	15.23

*Continues on next page*

### 3 Installation and commissioning

---

#### 3.2 Unpacking

*Continued*

Travel length (m) <sup>i</sup>			Sections (pcs)	Required space for installation (m) <sup>ii iii</sup>
Robot + Robot	Robot + Robot with extra plate	Robot with extra plate + Robot with extra plate	Value of <i>N</i>	
13.6	12.4	11.3	16	16.23
14.8	13.4	12.3	17	17.23
15.6	14.4	13.3	18	18.23
16.6	15.4	14.3	19	19.23
17.6	16.4	15.3	20	20.23
18.6	17.4	16.3	21	21.23

<sup>i</sup> The travel length is described in [Travel length on page 47](#).

<sup>ii</sup> The measurement for the required space is valid when not using the external cable chain.

<sup>iii</sup> How to calculate the required space is described in [Formula for required space on page 54](#).



## 3.3 Lifting

### 3.3.1 Preparations before lifting

#### Safety information



#### CAUTION

Read through the safety instructions carefully before lifting the track IRT 510.






#### WARNING

Never lift the track IRT 510 in segments longer than 9 m. If the track is longer than 9 m, the track has to be disassembled into smaller segments.

Never lift the track IRT 510 using an overhead crane without first removing the cover plates.

#### Preparation

Before lifting the track, always move the carriage to the center position and remove the pre-mounted covers.

	Action	Illustration/Note
1	Remove the M6 socket head cap screws holding the covers using standard tools.	 <p>xx1500000127</p> <p>A M6x12 Screw DIN6921, 9ADA181-11 (7pcs)</p>
2	<p>If the carriage is not in the centered position, move it by hand to the midpoint of the track.</p> <p> <b>WARNING</b></p> <p>Never attempt to lift the track if the carriage is not in the centered position.</p>	 <p>xx1500000129</p> <p>For details, see <a href="#">Moving the carriage manually on page 101</a>.</p>

## 3 Installation and commissioning

### 3.3.2 Lifting and moving the track

### 3.3.2 Lifting and moving the track

#### Lifting weight

Prepare proper lifting tools according to the lifting weight. For the accurate weight, read the identification plates on the track IRT 510. The positions of the identification plates are described in [Delivery contents on page 52](#).

The weights are also listed in [Weight of single carriage track on page 39](#) and [Weight of double carriage track on page 40](#).




#### WARNING

Never lift the track IRT 510 in segments longer than 9 m. If the track is longer than 9 m, the track has to be disassembled into smaller segments.

Never lift the track IRT 510 using an overhead crane without first removing the cover plates.

#### Lifting zones



xx140000234




#### WARNING

Never place lifting straps wider than a combined angle of max. 60°.

*Continues on next page*

#### 2-9 sections lift

The figure shows the stand feet on the track IRT 510 where the lifting straps should be placed.



xx150000593

Track length	Lifting stand foot from left	Lifting stand foot from right
9 sections	(7) distance 2918 mm	(7) distance 2918 mm
8 sections	(6) distance 2418 mm	(6) distance 2418 mm
7 sections	(5) distance 1918 mm	(5) distance 1918 mm
6 sections	(4) distance 1418 mm	(4) distance 1418 mm
5 sections	(3) distance 918 mm	(3) distance 918 mm
4 sections	(3) distance 918 mm	(3) distance 918 mm
3 sections	(2) distance 418 mm	(2) distance 418 mm
2 sections	(1) distance 82 mm	(1) distance 82 mm

*Continues on next page*

### 3 Installation and commissioning

---


#### 3.3.2 Lifting and moving the track

*Continued*

---

#### Lifting using fork lift

Proceed as follows to lift the track IRT 510 using the fork lift.




xx150000591

---

#### Lifting using an overhead crane

Proceed as follows to lift the track IRT 510 using an overhead crane.




xx150000592

*Continues on next page*

#### Moving the track using roller dollies

Lift the IRT 510 according to lifting instructions, and place roller dollies under the stand's ground plates. Depending on the length of the track, the number of roller dollies varies. See table for information.



xx150000594


*Continues on next page*

### 3 Installation and commissioning

#### 3.3.2 Lifting and moving the track

Continued

The type of roller dolly and the placement of the two types is shown in the following illustration and table.



xx150000595

Track length	Roller dollies with steering	Fixed roller dollies
9 sections	4 pcs	2 pcs
8 sections	4 pcs	2 pcs
7 sections	4 pcs	2 pcs
6 sections	4 pcs	2 pcs
5 sections	4 pcs	-
4 sections	4 pcs	-
3 sections	4 pcs	-
2 sections	4 pcs	-


3.3.3 Lifting cable chain

Overview

This section describes the lifting method for spare/not in use cable chains. For the cable chains that are delivered together with the track, they are lifted together with the track.

Illustration, cable chain and cable tray made of sheet metal

The figure shows the cable chain and the cable trays designed for the internal and external cable chains.



xx140000479


Item	Description
A	Cable chain end unit
B	Cable chain pitch, with divider
C	Cable chain pitch, no divider
D	Cable chain, 10 links

*Continues on next page*

### 3 Installation and commissioning

#### 3.3.3 Lifting cable chain

Continued



xx1400000522

Item	Description
A	Cable tray, 1 m
B	External chain raiser
C	External tray 1.45 m unit
D	External tray bracket unit

#### Plan the job

Cable chains are easily damaged through improper handling. Chains longer than 4 meters are heavy and cumbersome to move. In order to prevent personal injury and damage to the chain, make sure to pay attention while handling.

Read the procedure thoroughly before installing the chain and plan the job in advance, in regard to the actual installation site.

To move the chain from storage to track, use one of the methods described in this section. Method 2 requires an overhead crane.





#### Required equipment

Equipment	Art. No.	Note
Lifting slings, standard	-	Quantity depends on track length. Required if using lifting method 1.
Lifting sling, extra wide (50 mm)	-	Required if using lifting method 2.
Overhead crane	-	

Continues on next page



#### Method 1: lifting the cable chain that is folded in half

	Action	Illustration/Note
1	 <b>CAUTION</b> Without cables, the internal cable chain weighs 3.4 kg / meter and the external cable chain weighs 8 kg / meter. All lifting accessories used must be sized accordingly!	
2	Place the chain so that it is folded in half lying flat.	
3	Place lifting slings on the two ends and in the middle. If the folded chain is longer than 4 meters then extra lifting slings should be placed so that the chain is supported every two meters.   <b>Note</b> This illustration for the procedure is for lifting external cable chain. Procedure for lifting internal cable chain is the same with this procedure.	 xx1300000887
4	Lift the cable chain to the installation position above the cable tray. The chain should be placed so that both ends are in the middle of the track.	 xx1400001937
5	There is no space for the lifting slings to stay fitted to the chain once it is lowered into the tray, therefore these must be removed before the cable chain is placed inside the tray.  Lower the fixed and movable ends first, then continue lowering bit by bit until the complete chain is fitted into the tray, while at the same time removing the lifting slings one by one.	

 **CAUTION**

Make sure that the cable chain cannot come into contact with any moving parts.

#### Method 2: lifting the cable chain that is rolled

This procedure requires an overhead crane.

 **CAUTION**

Without cables, the internal cable chain weights 3.4 kg / meter and the external cable chain weights 8 kg / meter. All lifting accessories used must be sized accordingly!

Continues on next page

### 3 Installation and commissioning


#### 3.3.3 Lifting cable chain

Continued





#### Note

For external cable chain, in order to keep the correct length for long chains that are to be rolled, the strapping plate as well as the first cover and clips are removed. Refit these parts during installation.



xx1400001938

	Action	Illustration/Note
1	With the chain lying on its side, secure the loose end to ensure that the chain can not unroll during the lift.	 <p>xx1300000888</p>
2	Lift the chain so that it is standing upright and insert a wide lifting sling (50 mm) through the center of the chain.	 <p>xx1300000889</p>
3	Lift the cable chain to the installation position above the cable tray. The chain should be placed so that both ends are in the middle of the track.	
4	Lower the cable chain into the cable tray. The ends of the chain should be in the middle of the track.	

Continues on next page



#### **CAUTION**

Make sure that the cable chain cannot come into contact with any moving parts.

### 3 Installation and commissioning

#### 3.4.1 Assembling the track sections (for tracks longer than 9 m)

### 3.4 On-site installation

#### 3.4.1 Assembling the track sections (for tracks longer than 9 m)

##### Required equipment

###### Standard tools

Quantity	Tool
1	Ring-open-end spanner 8 - 22 mm
1	Small flat tip screwdriver
1	Torque wrench 10 -140 Nm
1	Ratchet head for torque wrench 1/2"


###### Special tools

Quantity	Description	Art. No.	Note
1	Installation tool kit	3HAC091295-001	Ordered with option 4203-1 and includes Leveling tool, Locking nut adjustment tool and Calibration pin.

##### Procedures of assembly

The track is separated into 9 meter track segments when delivered. Tracks longer than 9 meters are divided and delivered in segments as described in [Weight on page 39](#) and [Required space for installation on page 54](#). Use the following procedure to assemble the sections of the IRT 510.

##### Positioning the sections

	Action	Illustration/Note
1	Mark up the required position of each IRT 510 section on floor.	 <b>Note</b> Make sure that the floor is clean before the assembly.
2	Position the pre-assembled track sections according to the markup.	
3	Level the 9-meter track sections with the M60 leveling screws as described in <a href="#">Geometric alignment of IRT 510 on page 84</a> .	







*Continues on next page*

### 3 Installation and commissioning

#### 3.4.1 Assembling the track sections (for tracks longer than 9 m)

*Continued*

#### Assembling sections




	Action	Illustration/Note
1	<p>Remove the bolts.</p> <p> <b>Note</b></p> <p>To avoid the carriages from derailing during shipping, a bolt is fastened to the end of the linear guide rails on both sides of the track. These bolts act as temporary stops and must be removed before assembling the two halves.</p>	 <p>xx1500003181</p> <p>xx1400001955</p>
2	<p>Fit one track section to the other at a position between the rack and linear guide.</p>	 <p>xx1400000469</p>
3	<p>Fit two positioning pins (A) using a hammer. In order to reach the same acceptable accuracy as in the manufacturing process, the joint bracket is drilled with two Ø 16-mm through holes and must be inserted with the two pins during assembling.</p>	
4	<p>Connect the sections with joint brackets (D) by fitting screws (B) and plate washers (C). Set the screw joint loosely.</p> <p> <b>Note</b></p> <p>Do not tighten the screws yet.</p>	 <p>xx1400001935</p> <p>A Ø 16 mm positioning pin (2 pcs)          B M12x40 Hex socket head cap screw, 3HAB3409-67 (10 pieces on each side)          C Plate washer, 3HAC045077-001          D Joint bracket, 3HEA801652-001</p>

*Continues on next page*

### 3 Installation and commissioning

#### 3.4.1 Assembling the track sections (for tracks longer than 9 m)

Continued

	Action	Illustration/Note
5	Fit racks on sections using screws and washers. Use a torque wrench. See <a href="#">Screw joints on page 266</a> .	 <p>xx140000227</p> <ul style="list-style-type: none"> <li>A M10x40 Hex socket head cap screw, 3HAB3409-50</li> <li>B Ø17xØ11x2 Washer, 3HAB4233-1</li> <li>C Rack</li> </ul>
6	Install the racks. When the alignment is correct, tighten the screws one by one.	<p>Tightening torque: 70 Nm</p> <p> <b>Note</b></p> <p>Use the clamping and mounting racks at the ends of the rack section to make sure that the racks are tightly pushed against the section and perfectly aligned with each other.</p> <p>Use standard tools, slightly tighten.</p>
7	Use a brush to lubricate the racks.	
8	Fit the linear guides on sections by fitting the screws and plain washer.	 <p>xx140000228</p> <ul style="list-style-type: none"> <li>A Linear guide. 1000 mm: 3HAC045755-001, 500 mm: 3HAC045755-002</li> <li>B Ø 12 x Ø 32 x 4 Plain washer for rail, 3HAC047749-001</li> <li>C M12x35 Hex socket head cap screw, 3HAB3409-66</li> </ul> <p>Tightening torque: 125 Nm</p>
9	Slightly tighten all the screws of the linear guides and finalize the horizontal alignment of the IRBT 2005 as described in <a href="#">Geometric alignment of IRT 510 on page 84</a> .	




Continues on next page

### 3 Installation and commissioning

#### 3.4.1 Assembling the track sections (for tracks longer than 9 m)

*Continued*

##### Inspecting clearance between linear guides

	Action	Illustration/Note
1	Unscrew one block from the carriage and use it to verify the linear guide alignment: if the linear guides are correctly aligned, you should sense no "step" while passing the railways junction. If a step is felt, push the rail against the section and verify that there is no clearance between the rails.	
2	If clearance is found to be over 0.7 mm, adjust the fixing screws of the linear guides to limit the clearance into allowed scope.	 <b>Note</b> The installation holes of the linear guides are of the oval shape which allows the fine tuning of the linear guides in the x direction.
3	Secure the square locking washers with screws.   <b>Note</b> Start fixing lock washers from the rear end.	 xx1400001751 A M10x20 Hex socket counter-sunk screw DIN7991, 3HAC051482-001 B Square locking washer, 3HEA802935-001 C Upper right mark Tightening torque: 35 Nm
4	When the alignment is correct, tighten the fixing screws of linear guides one by one.	Tightening torque: 125 Nm
5	If necessary, re-assemble the block in the carriage bracket. For how to disassemble and assemble ball bearing blocks, see <a href="#">Replacing the ball bearing blocks on page 172</a> .	Tightening torque: 70 Nm
6	Use a brush to lubricate the linear guides.	

##### Tightening the join brackets

	Action	Illustration/Note
1	Tighten the joint brackets with the fixing screws.	Tightening torque: 100 Nm

*Continues on next page*

### 3 Installation and commissioning

#### 3.4.1 Assembling the track sections (for tracks longer than 9 m)

Continued





#### Removing sections if too long

Use this procedure to remove sections if the track is too long, until the required track length is achieved.



#### Tip

If sections need to be removed during the first-time assembly after delivery, it is OK to remove from any track segment. If sections need to be removed from an existed track, it is recommended to remove from the track end.

	Action	Illustration/Note
1	If required, press the brake release button to manually move the carriage sideways.	See <a href="#">Moving the carriage manually on page 101</a> .
2	Remove cover screws.	 <p>xx1500003251</p>
3	Remove the covers of the sections to be removed.   <b>Note</b>  End covers need to be removed only when sections are to be removed from the track end.	 <p>xx1500003252</p>
4	Remove the square locking washers and screws, which clamp the linear guides at the junction.	 <p>xx1500003253</p>



Continues on next page




### 3 Installation and commissioning

#### 3.4.1 Assembling the track sections (for tracks longer than 9 m)

*Continued*

	Action	Illustration/Note
5	Remove the top cover support, linear guides, the joint brackets and the rack by removing the screws.	 <p>xx1500003254</p> <ul style="list-style-type: none"> <li>A Top cover support</li> <li>B Rack</li> <li>C Joint bracket</li> <li>D Linear guides</li> </ul>
6	Remove the excessive section.	 <p>xx1500003255</p>
7	Connect the shortened section modules with the next section module. See <a href="#">Assembling sections on page 69</a> .	

#### Fitting covers



	Action	Illustration/Note
1	Fit the top cover support with screws.	 <p>xx1400000229</p> <ul style="list-style-type: none"> <li>A M6x16 Screw DIN6921, 9ADA181-12</li> <li>Tightening torque: 10 Nm</li> <li>B Top cover support</li> </ul>

*Continues on next page*

### 3 Installation and commissioning

#### 3.4.1 Assembling the track sections (for tracks longer than 9 m)

Continued


	Action	Illustration/Note
2	Secure the two bumpers at the end of the track by screws and washers.	 <p data-bbox="991 660 1098 678">xx140000230</p> <ul style="list-style-type: none"> <li data-bbox="1026 689 1358 719">A Bumper, 3HEA801665-001</li> <li data-bbox="1026 725 1390 779">B M12x40 Hex socket head cap screw, 3HAB3409-206</li> <li data-bbox="1062 786 1350 815">Tightening torque: 79 Nm</li> <li data-bbox="1026 822 1358 851">C Hexagon nut, 9ADA267-11</li> </ul>
3	Release the carriage brake and push the carriage manually along the length of its stroke. Verify that the cable chain lies in the center of the track and does not collide with any other fixed parts. See section <a href="#">Moving the carriage manually on page 101</a> for instructions on how to release the motor brake.	
4	Fit the rack covers (C) on top of the section with screws (A) and fix the top cover (B) on the top cover support with screws (A).	 <p data-bbox="991 1373 1098 1391">xx140000231</p> <ul style="list-style-type: none"> <li data-bbox="1026 1402 1350 1456">A M6x12 Screw DIN6921, 9ADA181-11 (7 pcs)</li> <li data-bbox="1062 1462 1350 1491">Tightening torque: 10 Nm</li> <li data-bbox="1026 1498 1310 1527">B Top cover of the track</li> <li data-bbox="1026 1534 1321 1563">C Rack cover of the track</li> </ul>

Continues on next page

### 3 Installation and commissioning

#### 3.4.1 Assembling the track sections (for tracks longer than 9 m)

*Continued*

	Action	Illustration/Note
5	Fit the top screw of the end covers if this option is ordered.	 <p data-bbox="1023 633 1129 651">xx1400001828</p> <p data-bbox="1054 667 1378 786">A M6x12 Screw DIN6921, 9ADA181-11 (7 pcs) Tightening torque: 10 Nm B End cover of the track</p>
6	Release the carriage brake again and push the carriage manually along the length of its stroke. Verify that no covers come into contact with the moving carriage.	

## 3 Installation and commissioning

---

### 3.4.2 Orienting and securing

### 3.4.2 Orienting and securing

---

#### Foundation

##### Robustness

The foundation must withstand the static loads caused by the weight of the equipment and the dynamic loads generated by the movement of the carriage and the manipulator. The minimum thickness of the concrete floor is 160 mm.

The concrete quality class must be at least C20/25 (or B25) to insure a good resistance of the anchor. Class C30/37 (or B35) is advisable.

The concrete compressive strength can be tested according to the European norm EN 206-1.

##### Inclination and flatness

The leveling of the track is done by screwing / unscrewing the M60 screws. However, in order to insure a good leveling, the foundation must be designed so that the IRT 510 can be fitted without the incline exceeding 0.5 mm/m in the direction of travel and 0.2 mm/m across this. The leveling screws can also compensate a poor flatness of the slab and small bumps up to 10 mm. However, the surface under the leveling screw must be flat. A concrete surfacing grinder should be used to correct the flatness locally if necessary.

##### Maximum payload

The following table shows the maximum load that can be placed on the top plate of a carriage. At this maximum load, the following load would be distributed to each leveling screw.

Load	IRT 510
Max. load	The weight of IRT 510 payload + pedestal + 50 kg
Load on each leveling screw	Max. load/(2 x N), N is the number of sections

For weight of robots, see the product manual for the respective robot.

##### Maximum floor load

See the maximum floor loads in section [Forces](#).

---

#### Mounting bolts to foundation

Chemical anchor bolts, bolting towards steel foundation, are recommended to secure the track IRT 510 to the floor. However, the mounting bolts are not supplied since they must be selected on the basis of the material the foundation is made of.

Choose mounting bolts so that they:

- Are suitable for the foundation.
- Can bear the dynamic loads.
- Are able to bear the combined dynamic loads that can occur when the manipulator and carriage move.
- Fit in the holes in the stand, Ø18.5 mm.


*Continues on next page*

### 3 Installation and commissioning

#### 3.4.2 Orienting and securing

*Continued*

#### Dimension of stands



xx1400001434

The table describes the value of N in the figure above with different travel lengths.

Travel length	Total length of the stand	Quantity N
2.8 / 1.6 m	4 m	4
3.8 / 2.6 m	5 m	5
4.8 / 3.6 m	6 m	6
etc.		

*Continues on next page*


### 3 Installation and commissioning

#### 3.4.2 Orienting and securing

Continued

#### Leveling screws

The stands have leveling screws for adjusting the level of the track.



xx140000649

Item	Art.	Art. No.	Note
A	Lifting threaded block M60x2,00	3HAW108201422	Leveling screw
B	Slotted nut KM12 for leveling screw	3HAWC100857	Fitting nut
C	-	-	Stand

#### Attachment screws to base



Attachment screws are not provided on delivery. Following table lists the recommended specification for the attachment screws. Users need to prepare the corresponding screws according to the actual application.

Foundation condition <sup>i</sup>	Recommended screw/washer specification
Steel structure	Screw: M16x50, ISO 4762, class 12.9 Washer: M16, DIN6796 Tightening torque: 300 Nm
Concrete floor	Screw: M16x190 (HAS 5.8, Hilti), valid length no less than 125 mm Tightening torque: 80 Nm

<sup>i</sup> The type and dimension of screws depend on the foundation conditions. See description for maximum floor loads in [Forces](#).

#### 3.4.3 Positioning the stand

##### Positioning the stands


	Action	Illustration/Note
1	<p>Position the sections in the intended work site. If more than one section is used, assemble them as described in <a href="#">Assembling the track sections (for tracks longer than 9 m) on page 68</a>.</p>	 <p>xx1400001410</p>
2	<p>Adjust the horizontal level of the IRT 510 with the M60 leveling screw using the leveling tool.</p>	<p>Leveling tool, Included in Installation tool kit (3HAC091295-001).</p>  <p>xx1400000463</p> <p><b>A</b> Leveling screw</p>
3	<p>Make sure that all the leveling screws are touching the floor.</p>	

Continues on next page



### 3 Installation and commissioning

#### 3.4.3 Positioning the stand

Continued

	Action	Illustration/Note
4	Tighten the M60 fitting nuts using the nut adjustment tool.	<p>Locking nut adjustment tool, Included in Installation tool kit (3HAC091295-001). Tightening torque: 25 Nm</p>  <p>xx140000464</p> <p>A Fitting nut</p>

#### Securing the sections

	Action	Illustration/Note
1	Prepare proper attachment screws according to actual foundation condition.	See <a href="#">Attachment screws to base on page 78</a> .
2	<p>Drill a hole in the floor through the leveling screw: <math>\varnothing 18.5</math> mm, at least 125 mm deep.</p> <p> <b>Note</b></p> <p>It is recommended to use metric drills M16. If British Drills are used, the hole needs to be enlarged.</p>	 <p>xx140000582</p>



Continues on next page



### 3 Installation and commissioning

#### 3.4.3 Positioning the stand

*Continued*




	Action	Illustration/Note
3	Brush the inside of the hole.	 <p data-bbox="973 907 1085 929">xx140000583</p>
4	Remove the dust after brushing the hole with a vacuum cleaner.	 <p data-bbox="973 1534 1085 1556">xx140000584</p>

*Continues on next page*


### 3 Installation and commissioning

#### 3.4.3 Positioning the stand

Continued

	Action	Illustration/Note
5	Introduce a glass capsule in the hole after verifying that the liquid inside the capsule is fluid.	 <p data-bbox="941 907 1045 929">xx140000585</p>
6	Insert the HILTI tool supplied with the anchor kit in the chuck of a handheld electric punch drill. Insert the triangular extremity of the threaded rod in the HILTI tool.	
7	Insert the rod in the hole and start the rotation + punching at 1000 rpm. The capsule will break and the rotating rod is mixing the melange.   <b>Note</b> The hardening time before tightening depends on the ambient temperature: 2 hours < 10 °C ambient 1 hour < 20 °C ambient 40 minutes > 20 °C ambient.	 <p data-bbox="941 1691 1045 1713">xx140000586</p>
8	If necessary, refine the adjustment of the track leveling using the M60 screws, and then tighten the M16 notched nuts. See <a href="#">Geometric alignment of IRT 510 on page 84</a> .	

Continues on next page

	Action	Illustration/Note
9	Use the supplied washers, then tighten the nuts.	 <p data-bbox="970 904 1078 920">xx140000587</p> <p data-bbox="970 936 1257 965">Tightening torque: 80 Nm</p>



#### WARNING

It is of the utmost importance that all screw joints be tightened with the correct torque. Failure to do so may result in damage to the equipment or personal.

### 3 Installation and commissioning

#### 3.4.4 Geometric alignment of IRT 510

#### 3.4.4 Geometric alignment of IRT 510

Align the track geometrically with a laser level



#### Note


The origin of coordinates is located in the manipulator's base zero.

The geometric alignment of the track is done in order to adjust the carriage horizontally along the entire travel length. Use a laser level.

#### Required equipment

Equipment	Art. No.	Note
Laser level	-	

#### Directions



xx1400001830

#### Track alignment in different directions



#### Note


The origin of coordinates is located in the manipulator's base zero.

*Continues on next page*

#### Alignment in Z direction

The figure shows the possible variation along the Z-axis.

The track should be laser aligned to within 0.2 mm from the origin per meter, along the entire X-axis.




xx1400001473

#### Alignment in Y direction


The figure shows the possible variation along the Y-axis.

The track should be laser aligned to within 0.5 mm from the origin per meter, along the entire X-axis.



xx1400001474

#### Leveling screw adjustment method


	Action	Illustration/Note
1	Screw the leveling screw (A) in or out to raise or lower the machining in question.	 <p data-bbox="898 1899 1007 1921">xx1400000463</p> <p data-bbox="930 1933 1134 1962">A Leveling screw</p>

*Continues on next page*

### 3 Installation and commissioning

#### 3.4.4 Geometric alignment of IRT 510

*Continued*

	Action	Illustration/Note
2	Tighten the fitting nut when the level of the complete track is adjusted.	 <p data-bbox="863 846 975 869">xx140000464</p> <p data-bbox="898 878 1054 909">A Fitting nut</p>

#### 3.4.5 Assembling the pedestal (option)

##### Overview

The pedestal, if ordered, is not mounted to the track at delivery.  
Install the pedestal to the track according to this section.

##### Required equipment



Equipment	Article number	Note
Lifting eye, M16	-	2 pcs
Lifting slings	-	Lifting capacity according to pedestal weight.

##### Weight of pedestal

Pedestal height (mm) <sup>i</sup>	Weight (kg)
250	70
500	95
750	165
1000	190

<sup>i</sup> Heights 500, 750 and 1000 are unavailable for IRB 4600.

##### Assembling the pedestal


	Action	Note
1	Fit guide sleeves to the track. Pay attention to the location.	Guide sleeve (2 pcs)  xx2000001768
2	Fit lifting eyes to the pedestal.	Lifting eye, M16 (2 pcs)
3	Lift the pedestal to the mounting position using lifting slings and lower the pedestal to the track.	The following is a pedestal example.  xx2000001769

*Continues on next page*

### 3 Installation and commissioning

#### 3.4.5 Assembling the pedestal (option)

*Continued*

	<b>Action</b>	<b>Note</b>
4	Secure the pedestal with attachment screws and washers.	<p>Hex socket head cap screw M16x60, Steel 12.9 Gle 603 (6 pcs) Plain washer 17x30x3, Steel-A3F (6 pcs) Tightening torque: 250 Nm</p>  <p>xx2000001770</p>



### 3.4.6 Assembling the manipulator and cable tray


#### 3.4.6.1 Assembling the manipulator

##### Overview

When IRT 510 is associated with an IRB robot, it behaves like an integrated 7th axis. However, the robot controller must fulfill some requirements to get an optimum integration. IRT 510 has been designed for ABB OmniCore V line controller. For how to link the robot to the track and how to orient the manipulator, see [Software installation on page 116](#).

##### Cable chain orientation

There are two orientations to fit the cable chain.



##### Robot capacity

The following table shows the robot capability of IRT 510.

Standard pedestals are generally allowed between the IRT 510 carriage and the robot but their height is limited and dependent on the type of the IRT 510 and the type of robot.

*Continues on next page*

### 3 Installation and commissioning

#### 3.4.6.1 Assembling the manipulator

Continued

The following table defines what types of pedestals are applicable for the corresponding robot. x means that the pedestal is applicable.

Robot	250 mm pedestal	500 mm pedestal	750 mm pedestal	1000 mm pedestal
IRB 1520	x	x	x	x
IRB 1600	x	x	x	x
IRB 2600	x	x	x	x
IRB 4600	x	N/A	N/A	N/A


#### Installing the insulation kit

Insulation kits are delivered with the IRT 510 when arc welding options 4212-X or 4226-X are selected. The type of the actual delivered insulation kit depends on the selected robot type.

#### Required parts and quantity

Robot type	Parts in insulation kit							
	Bottom insulation washer with pin hole		Bottom insulation washer w/o pin hole		Top insulation washer		Top washer	
	Part No.	Qty.	Part No.	Qty.	Part No.	Qty.	Part No.	Qty.
IRB 1520	3HAC063356-001	2	3HAC063357-001	2	3HAC063358-001	4	3HAC063359-001	4
IRB 1600	3HAC063350-001	2	3HAC063351-001	1	3HAC063354-001	3	3HAC063355-001	3
IRB 2600/4600	3HAC063350-001	2	3HAC063351-001	1	3HAC063352-001	3	3HAC063353-001	3

#### Procedure



Robot type	Installation illustration
IRB 1520	 <p>xx2200001616</p>

Continues on next page

### 3 Installation and commissioning

#### 3.4.6.1 Assembling the manipulator

*Continued*

Robot type	Installation illustration
IRB 1600	 <p data-bbox="671 965 783 987">xx2200001617</p>
IRB 2600/4600	 <p data-bbox="671 1664 783 1686">xx2200001618</p>

	Action
1	Place the bottom insulation washers with pin hole (1) on the mounting plate (C) of the track or the pedestal installed on the track.
2	Place the bottom insulation washers w/o pin hole (2) on the mounting plate (C) of the track or the pedestal installed on the track.
3	Lift the robot to the mounting position on the track using necessary lifting tools. Position the robot and make sure the attachment holes on the robot base (B) are aligned with the bottom insulation washers. See the figures in previous table for reference.

*Continues on next page*

### 3 Installation and commissioning

---

#### 3.4.6.1 Assembling the manipulator

*Continued*

	Action
4	Put top insulation washers (3) and top washers (4), and then secure the robot with M16 bolts (A).

#### 3.4.6.2 Mounting of manipulator on the track









##### General

The manipulator can be mounted in four directions, 0 degrees (in line), 90 degrees, 180 degrees, and 270 degrees with the cable chain standard or mirrored. Other mounting orientations are not allowed. The world coordinate system is shown in the following figures.

##### Robot orientation with standard cable chain

Following figures illustrate the manipulator mounted in different directions with the standard cable chain.

The positive X direction is the positive motion direction of the track. The positive Y direction is the direction of the cabling outlet on the carriage.


<p>0 degrees (in line)</p>	 <p>xx1400001911</p>	 <p>WORLD</p> <p>xx1500000928</p>
<p>+90 degrees</p>	 <p>xx1400001912</p>	 <p>WORLD</p> <p>xx1500000928</p>
<p>+180 degrees</p>	 <p>xx1400001909</p>	 <p>WORLD</p> <p>xx1500000928</p>
<p>+270 degrees</p>	 <p>xx1400001910</p>	 <p>WORLD</p> <p>xx1500000928</p>

*Continues on next page*

### 3 Installation and commissioning

#### 3.4.6.2 Mounting of manipulator on the track









Continued



#### Robot orientation with mirrored cable chain

Following figures illustrate the manipulator mounted in different directions with the mirrored cable chain.

The positive X direction is the positive motion direction of the track. The positive Y direction is the opposite direction of the cabling outlet on the carriage.


<p>0 degrees (in line)</p>	 <p>xx150000631</p>	 <p>WORLD</p> <p>xx150000927</p>
<p>+90 degrees</p>	 <p>xx150000632</p>	 <p>WORLD</p> <p>xx150000927</p>
<p>+180 degrees</p>	 <p>xx150000633</p>	 <p>WORLD</p> <p>xx150000927</p>
<p>+270 degrees</p>	 <p>xx150000634</p>	 <p>WORLD</p> <p>xx150000927</p>

Continues on next page

### 3 Installation and commissioning


#### 3.4.6.2 Mounting of manipulator on the track

*Continued*



#### Assembly position

The following figure shows guide bushing assembly positions on the carriage table of the robot track.



xx1400002680

A	Guide bushing fitting hole for IRB 1520
B	Guide bushing fitting hole for IRB 1600/2600/4600

### 3 Installation and commissioning



#### 3.4.6.3 Changing manipulator orientation

#### 3.4.6.3 Changing manipulator orientation

##### Required equipment

Quantity	Tool
1	Socket head cap 2.5-17 mm

##### Procedures of changing the orientation of robot without pedestal

	Action	Illustration/Note
1	Remove the securing screws and plain washers in the holes of robot base.	 <p>xx1400002679</p> <p>A M16x70 hexagon socket head cap screws class 12.9 (6 pcs) Tightening torque: 250 Nm</p> <p>B Plain washer (6 pcs)</p>
2	Lift the robot to other position.	For how to lift the robot, according to robot product manual.
3	Fit two guide bushings to the hole on the carriage table of the robot track according to the orientation of robot. For the guide bushing assembly positions, see <a href="#">Assembly position on page 95</a> .	 <p>xx1400002681</p> <p>A Guide bushing</p>
4	Guide the robot gently, using the screws while lowering it into its fitting position.	Make sure the robot base is correctly fitted onto the guide bushings.


Continues on next page



### 3 Installation and commissioning

#### 3.4.6.3 Changing manipulator orientation

*Continued*


	Action	Illustration/Note
5	Fit the securing screws and plain washers in the attachment holes of the base.	 <p>180°</p> <p>xx1400002682</p>
6	Tighten the bolts in a criss-cross pattern to ensure that the base is not distorted.	

#### Procedures of changing the orientation of robot with pedestal



#### Note

The robot is installed on the pedestal with a fixed orientation. To change the orientation of robot with the pedestal, remove the robot from the pedestal first and then adjust the pedestal orientation.


	Action	Illustration/Note
1	Remove the securing screws and plain washers in the holes of robot base.	 <p>XX1500000490</p> <p>A M16x60 Hex socket head cap screw, 3HAB3409-86 (6 pcs)</p> <p>B Ø30xØ17x3 plain washer, 3HAA1001-186 (6 pcs)</p>
2	Lift the robot from the pedestal to other position.	For how to lift the robot, according to robot product manual.

*Continues on next page*

### 3 Installation and commissioning

#### 3.4.6.3 Changing manipulator orientation


Continued

	Action	Illustration/Note
3	Remove the screws and plain washers in the holes of the pedestal.	 <p data-bbox="992 638 1098 656">xx1500000485</p> <p data-bbox="1026 667 1393 723">A M16x60 Hex socket head cap screw, 3HAB3409-86 (6 pcs)</p> <p data-bbox="1026 728 1353 784">B Ø30xØ17x3 plain washer, 3HAA1001-186 (6 pcs)</p>
4	Fit two guide bushings to the hole on the carriage table of the robot track according to the orientation of robot. For the guide bushing assembly positions, see <a href="#">Assembly position on page 95</a> .	
5	Guide the pedestal gently, using the screws while lowering it into its fitting position.	Make sure the pedestal is correctly fitted onto the guide bushings.
6	Refit the securing screws and plain washers in the attachment holes of the pedestal.	
7	Lift the robot back and gently put it onto the pedestal. Refit the securing screws and plain washers in the attachment holes of the robot base.	
8	Tighten the bolts in a criss-cross pattern to ensure that the base is not distorted.	

#### 3.4.6.4 Assembling the cable tray


##### Overview

The cable tray made for the cable chain is made of sheet metals, fastened to the track machining by screws directly or to brackets and thereby forming a tray.



xx1400001579


For track travel length shorter than 5 m, the cable tray is plain. While for track travel length equal to 5 m or larger than 5 m, a slope tray is needed to reduce the friction between the cable chain when the moving end of the cable chain moves passing the fixed end.



xx1400001580

##### Installing the cable tray

##### Installing the external cable tray



	Action	Illustration/Note
1	Fix the connection bracket for the external cable tray on the top plate of the carriage by screws.	 <p>xx1400001936</p> <p><b>A</b> M10x30 Hex socket head cap screw, 3HAB3409-51 (4 pcs)</p> <p>Tightening torque: 47 Nm</p>

*Continues on next page*

### 3 Installation and commissioning

#### 3.4.6.4 Assembling the cable tray

Continued

	Action	Illustration/Note
2	Fit the bottom bracket for external cable tray to the track.	 xx1400001582
3	Place the cable tray onto the brackets.	 xx1400001583
4	Fasten the external cable tray with screws.	M6x12 Torx counters. head screw, 9ADA624-5 Tightening torque: 10 Nm

#### 3.4.7 Moving the carriage manually



#### CAUTION


The carriage must never be moved manually if the motor or the drive unit are removed from the track.

#### Releasing the brake

The carriage can be moved manually by connecting the power cable to the controller and then releasing the brake.

It is recommended that the carriage is manually pushed along its complete stroke after being installed and before running the track using the controller. This is to ensure that there is no risk of collision other equipment in the vicinity of the track.

If there is no voltage to the motor, 24 VDC can be connected directly to the motor as described in [Releasing the brake with external 24V DC on page 101](#).

	Action	Note/Illustration
1	Connect all cables to the controller as described in <a href="#">Electrical installation on page 108</a> .	
2	Start up the controller as described in <a href="#">Connectors on the OmniCore controller on page 111</a> .	
3	Press the two buttons shows in the figure at the same time.	 <p>xx2400000592</p>
4	Push the carriage by hand to the desired location.	

#### Releasing the brake with external 24V DC

If there is no voltage to the motor, 24V DC can be connected directly to the motor.


	Action
1	Unplug the motor power cable from the power static harness that runs to the IRT 510 motor.
2	Using pins, connect the +24VCC to the A pin (see figure).
3	Connect the 0VCC to the B pin.

*Continues on next page*

### 3 Installation and commissioning

#### 3.4.7 Moving the carriage manually

*Continued*



xx240000593



#### Note

Painting: Half black color. Except the mounting surface.



#### Note

Mating connectors are not offered.



#### WARNING

The motor breaks on the IRT 510 are phase dependent. Fault connection can cause damage to vital parts.

### 3.4.8 Connecting long tracks


#### Track extension

The track extension is an extension to an existing track. There are two types of track extension: covered track extension and standard track extension.

#### Procedures of long track connection

##### Removing one end section of the track

A track motion has two end sections (A and B in the following figure). Remove one of the end section as required.



xx1400002676

	Action	Illustration/Note
1	Remove the top cover and rack cover of the end section.	
2	Remove the top cover support, joint bracket, and mechanical stop, and the last 0.5 m linear guides and racks on the end section. In this case, the extension section can be connected directly to the stand of the end section without removing the whole end section.	<p>xx1400002678 A Stand of end section</p>

##### Connecting the extension section to existing track





	Action	Illustration/Note
1	Lift the extension section to desired location. Part of the section should be inserted between the rack and linear guide on the original track section.	See <a href="#">Lifting on page 57</a> .
2	Release the brake of extension section.	See <a href="#">Moving the carriage manually on page 101</a> .
3	Push the carriage by hand to show the rack and linear guide of extension section.	

*Continues on next page*

### 3 Installation and commissioning

#### 3.4.8 Connecting long tracks

Continued

	Action	Illustration/Note
4	Removed the cover on extension section if the section is covered track extension.	
5	Remove the bolts that are used as temporary stops on both sides of the extension section.   <b>WARNING</b>  A track that is divided in sections has a bolt fastened to the end of the linear guides on both sides of the track in order to avoid the carriages from derailing during shipping.  The bolts act as temporary stops and <b>must be removed</b> before assembling the sections.	
6	Connect the section with joint brackets (A) by fitting screws (B) and plate washers(C). Set the screw joint loosely.   <b>Note</b>  Do not tighten the screws yet.	 <p>xx1500000500</p> <ul style="list-style-type: none"> <li>A Joint bracket, 3HEA801652-001</li> <li>B M12x40 Hex socket head cap screw, 3HAB3409-67 (12 pieces on each side)</li> <li>C Plate washer, 3HAC045077-001</li> </ul>
7	Install the racks. Fit the companion rack fix block and companion rack to the section and the rack to make sure the racks are positioned correctly in vertical plane.	 <p>xx1400002156</p> <ul style="list-style-type: none"> <li>A Companion rack fix block, 3HAC054531-001</li> <li>B Companion rack, 3HAC054532-001</li> </ul>




Continues on next page



### 3 Installation and commissioning

#### 3.4.8 Connecting long tracks

*Continued*


	Action	Illustration/Note
8	Fit the rack clamping tools at both ends of the rack to make sure that the racks are aligned with each other.	 <p data-bbox="1023 680 1129 698">xx2200001171</p> <p data-bbox="1023 712 1437 741">Rack clamping tool: 3HAW107700357</p>
9	Push the rack against the section mounting surface, make sure the alignments are correct and then tighten the screws one by one.	<p data-bbox="1023 757 1305 786">Tightening torque: 70 Nm</p> <p data-bbox="1023 801 1166 860">  <b>Note</b> </p> <p data-bbox="1023 875 1437 1010">Use the clamping and mounting racks at the ends of the rack section to make sure that the racks are tightly pushed against the section and perfectly aligned with each other.</p> <p data-bbox="1023 1016 1417 1046">Use standard tools, slightly tighten.</p>
10	Use a brush to lubricate the racks.	
11	Fit the linear guides and inspect linear guides gap.	
12	If the gap is found to be over 0.7 mm, you should adjust the gap of adjacent linear guide or more linear guide until gap between all linear guides are less than 0.7 mm.	
13	Fit the linear guides on sections by fitting the screws and plain washer.	 <p data-bbox="1023 1675 1129 1693">xx1400000228</p> <p data-bbox="1054 1709 1401 1787"> <b>A</b> Linear guide. 1000 mm: 3HAC045755-001, 500 mm: 3HAC045755-002         </p> <p data-bbox="1054 1794 1401 1845"> <b>B</b> Ø12xØ32x4 Washer for rail, 3HAC047749-001         </p> <p data-bbox="1054 1852 1422 1904"> <b>C</b> M12x35 Hex socket head cap screw, 3HAB3409-66         </p> <p data-bbox="1023 1910 1321 1939">Tightening torque: 125 Nm</p>

*Continues on next page*


### 3 Installation and commissioning

#### 3.4.8 Connecting long tracks

Continued

	Action	Illustration/Note
14	 <b>Note</b> Use the rail pressing tool to make sure that the linear guides are pushed against the section mounting surface. Make sure the lower edge of the linear guide rests against the mating surface of the section without gap.	

#### Refitting the end section of the track

	Action	Illustration/Note
1	Refit top cover support, linear guides, joint brackets, mechanical stop, and the rack at the end side.  <b>Note</b> You should make sure the rack alignments are correct and the linear guides gap all less than 0.7 mm.	
2	Refit all the covers to be refitted.	

#### Securing the connected long track to the floor

- 1 After assembly, all the leveling screws should touch the floor. Adjust if necessary and tighten the locking nut. See [Positioning the stands on page 79](#).
- 2 Move the carriage all along the track way, and verify the leveling with a leveling device or a laser tracker. The levelness of the top plate must be satisfying in the translation direction, but also cross section. For how to adjust the leveling of the track, see [Geometric alignment of IRT 510 on page 84](#). If you have moved the carriage manually, you probably need to initialize the resolver position, see [Update revolution counters on page 257](#).
- 3 Drill the holes in the floor through the leveling screws opening and install the anchors and secure the sections to the floor. See [Securing the sections on page 80](#).

### 3.4.9 Restricting the working range

---

#### Mechanical stops

There are no adjustable mechanical stops on the IRT 510. This needs to be considered during a risk assessment of the complete installation, the track can however be ordered in different lengths.

## 3 Installation and commissioning

### 3.5.1 Cable connections

## 3.5 Electrical installation

### 3.5.1 Cable connections

#### Introduction


The wiring diagrams are described in section [Circuit diagrams on page 281](#).

#### Cable run

Cabling between the control equipment and the track should be run through cable conduits on the floor.

#### Connection points

The following illustrates the cable connections.



xx1400001286

A	Robot or conveyor power cable
B	Signal cables
C	IRT power cables
D	Flexible cable harness from the carriage <ul style="list-style-type: none"><li>• Power cables for track, robot, etc. (A,C, etc.)</li><li>• Motor, manipulator signal cables (B)</li><li>• Other cables: cable grounding and hoses etc.</li></ul>
E	Connectors connecting cable harness from the carriage and cable harness from the controller.
F	Floor cables from the controller <ul style="list-style-type: none"><li>• Power cable, available for controller</li><li>• Signal cable, available for controller</li></ul>
G	Controller

*Continues on next page*

The IRT 510 is controlled through the robot integrated SMB card. The IRT 510 flexible signal cable should be connected from the motor resolver connector to the FB7 on the robot base. The IRT 510 flexible power cable should be connected from the motor power connector to the IRT 510 fixed power harness, and then the IRT 510 fixed power cable should be connected to the X7 socket on the OmniCore controller.




#### CAUTION

The floor cables must be grounded based on the requirements described in section [Circuit diagrams on page 281](#). Single-stranded copper wires with a diameter larger than 7 mm are recommended to be used as customer grounding cables, which will connect the cable grounding (Art. No.: 3HAC046927) of the track.

#### Fixing bracket for brake release box

Connectors that connecting cable harness from the carriage (flexible cables) with cable harness from the controller (floor cables) are located on the brake release box that is recommended to be properly fixed using a bracket for safety concerns. You can prepare a bracket referring to the following drawing or design a bracket based on actual site layout.



xx240000906

L	Bracket height, depending on the actual application requirement, from the foundation to the lower screw holes for mounting the brake release box.
---	---

*Continues on next page*


### 3 Installation and commissioning

---

#### 3.5.1 Cable connections

*Continued*

Following figure shows an installation example of the brake release box on the fixing bracket, which requires four M6x25 screws to secure the brake release box (tightening torque: 10 Nm).



xx240000907

### 3.5.2 Connectors on the OmniCore controller

#### General

The following section describes the connectors on the respective front panels of the OmniCore controller. See details in the product manual of the controller.




#### CAUTION

Always inspect the connector for dirt or damage before connecting it to the controller. Clean or replace any damaged parts.

#### Connectors on OmniCore V250XT controllers

The following details the connection interface on the OmniCore V250XT controller.



xx2200001457

*Continues on next page*

### 3 Installation and commissioning

---

#### 3.5.2 Connectors on the OmniCore controller

*Continued*


	Description
A	Incoming mains switch
B	Motors on lamp
C	Ethernet outlet connector, MGMT (Management)
D	FlexPendant connector (HMI)
E	Motor connector
F	Manipulator signal connector (SMB)
G	Cable grommet assembly
H	Incoming mains connector
I	Ethernet outlet connector, LAN3
J	Ethernet outlet connector, WAN
K	Cable grommet for Connected Services antenna (3G/4G/WiFi)
L	ADU (additional drive unit) connector

*Continues on next page*



#### Connectors on OmniCore V400XT controllers

The following details the connection interface on the OmniCore V400XT controller.



xx2300002001

	Description
A	Incoming mains switch
B	Motors on lamp
C	Ethernet outlet connector, MGMT (Management)
D	FlexPendant connector (HMI)
E	Motor connector
F	Manipulator signal connector (SMB)
G	Cable grommet assembly
H	Incoming mains connector
I	Ethernet outlet connector, LAN3

*Continues on next page*

### 3 Installation and commissioning

---

#### 3.5.2 Connectors on the OmniCore controller


*Continued*

	Description
J	Ethernet outlet connector, WAN
K	Cable grommet for Connected Services antenna (3G/4G/WiFi)
L	ADU (additional drive unit) connector, 1-3
M	ADU (additional drive unit) connector, 4-6

### 3.5.3 Inspection of cables and covers prior to start-up

#### Procedures of inspecting cables and covers

Use this procedure to inspect and adjust cables and covers before the track is commissioned.

	Action	Illustration/Note
1	Make sure there is no risk of collision between the cables and covers and the covers are well tightened.	
2	<p>Make sure all cables are well secured and without risk for premature wear against plates or additional equipment.</p> <p>The cables exiting the chain, on both the moving and fixed end, need to be strapped individually at least twice in order to strain relief correctly. If there are not enough holes available in the connection plates for individual strapping, the cables should be secured in such a way that they can not move.</p>	 <p>xx1400001676</p> <p><b>A</b> Cable straps</p> <p>Suitable cable ties are specified in <a href="#">Required equipment on page 245</a>.</p>
3	Make sure no floor cables are in risk of collision with moving parts.	

#### Guide channel inspection

Inspection	Yes	No
Guide channel free of foreign objects?		
Channel internal width > 2 mm and < 6 mm than chain outside width?		
Channel joints arranged flush and unobstructed?		
Guide channel running parallel to the moving end guide?		

## 3 Installation and commissioning

---

### 3.6.1 Starting the system for the first time

## 3.6 Software installation

### 3.6.1 Starting the system for the first time

---

#### General

Make sure that all steps of the physical installation is completed, see [On-site installation on page 68](#).

How to start the controller for the first time after the physical installation has been completed is described in *Operating manual - OmniCore*.

---

#### System status after startup

After startup, only the manipulator is configured in the controller. It will not be possible to jog or program using the track.

To activate the track, it is necessary to use RobotStudio to update the system with the track settings and download the updated system to the robot controller, see [Creating and downloading a system on page 117](#).

### 3.6.2 Creating and downloading a system

#### Introduction

The PC application RobotStudio is used for creating and downloading systems to the controller.

For more information, see *Operating manual - RobotStudio*.


#### Before modifying the system

Before modifying the system it is recommended to take a backup of the system and put all axes of the robot and any external axes are in their zero positions.

#### Creating a system

In RobotWare 7, the track motion is loaded as an Add-In, which can be downloaded from the **Gallery** in RobotStudio. The track motion Add-In does not require a license.

Use this procedure to create and modify the system.



	Action
1	Open RobotStudio and create a new Station.
2	On the <b>Home</b> tab, choose <b>Virtual Controller &gt; New controller</b> to create a new virtual controller accordingly.
3	On the <b>Controller</b> tab, choose <b>Installation &gt; Modify Installation</b> to modify the system.
4	In the displayed window, click <b>Available</b> list on the <b>Software</b> tab, add the <i>RobotWare</i> and <i>TrackMotion</i> product software by clicking <b>Include</b> .
5	On the <b>Options</b> tab, click <b>Edit</b> in the <b>Licenses Files</b> area.
6	In the displayed <b>Manage Licenses</b> window, remove the virtual license and add the license for RobotWare. The track motion does not require a license.
7	On the <b>Options</b> tab, in the <b>Controller variant</b> group under the <b>Controller</b> category, select the controller type and add the additional drive unit (ADU) that controls your track motion.
8	On the <b>Options</b> tab, in the <b>IRT 510</b> group under the <b>Tracks</b> category, select and modify the options that suits your track motion.
9	Click <b>Apply</b> to accept the changes.   <b>Tip</b> If the PC is connected to the controller, then the system can be transferred using <i>Installation Utilities</i> , see <i>Operating manual - Integrator's guide OmniCore</i> , and then there is on need to create a package and transfer it with a USB memory.
10	Click <b>Create Package...</b> to save the installation package to a destination folder.
11	Copy the installation package to a USB memory.
12	Insert the USB memory to the FlexPendant that connected to the controller.
13	Click <b>Setting -&gt; Backup &amp; Recovery-&gt; RobotWare Installation Utilities -&gt; Start Installer -&gt; Install RobotWare System</b> to start the installation of the new system on the controller.
14	Delete the old system before installing the new system.
15	Select the new system installation package from the USB memory and start the installation.

*Continues on next page*

### 3 Installation and commissioning

#### 3.6.2 Creating and downloading a system

Continued

	Action
16	Click <b>Done</b> to finish the installation of the new system.
17	Click <b>Start RobotWare System -&gt; Start</b> to restart the controller.
18	<p>Load the necessary system parameters, system modules, and program modules from the backup and restart the controller.</p> <p> <b>Note</b></p> <p>Do not restore the old motor configuration file <i>moc.cfg</i>, this will remove the track motion settings. Instead, use <b>Load parameters and replace duplicates</b> from the <b>Configuration</b> window on the <b>FlexPendant Control Panel</b>.</p>
19	Update the revolution counters, see <a href="#">Update revolution counters on page 257</a> .
20	<p>Set the software limits for the track, see <a href="#">Setting upper and lower software limits for the track on page 119</a>.</p> <p> <b>Note</b></p> <p>Note that the default length of the track is set very short, for safety reasons, and has to be updated to the correct length.</p>
21	Verify that the selected robot orientation on the track matches the physical configuration, see <a href="#">Mounting of manipulator on the track on page 93</a> .

For more detailed instructions on using the dialog **Modify Installation**, see *Operating manual - Integrator's guide OmniCore*.

### 3.6.3 Setting upper and lower software limits for the track

#### Introduction

The upper and lower software limits of the track are software limits that prevent the track from being jogged beyond the mechanical limit of the track. They are the physical displacement distance from the zero position to the limit position in meters. This depends on the length of the track, and the location of the calibration pin (also referred to as the zero position of the track).

The limits are defined in the system parameters, in the topic *Motion*, type *Arm*. The upper limit is called *Upper Joint Bound*, and the lower limit is called *Lower Joint Bound*. Both are expressed in meters.

In the following example, the upper limit is set to 5.8 m and the lower limit is set to -0.5 m.

```
ARM : -upper_joint_bound 5.8 -lower_joint_bound -0.5
```

#### Changing the limits



#### WARNING

This is an important safety feature to prevent damage to the track. Make sure that the track direction has first been set and the track has been calibrated before performing this step, see [Fine calibration on page 256](#).

Use this procedure to change the limits in the RobotStudio.

	Action	Note
1	Open the RobotStudio and choose <b>Configura-tion &gt; Motion</b> on the <b>Controller</b> ribbon.	
2	Under <b>Topics</b> , tap <b>Motion</b> .	
3	In the displayed window, choose <b>Arm</b> from the <b>Type</b> pane.	
4	Select the mechanical unit.	
5	Change the values for the parameters <b>Upper joint bound</b> and <b>Lower Joint bound</b> .	
6	Tap <b>OK</b> to save the change and then restart the controller.	

#### Examples of correct values for the software limits

The following tables show configuration values for *Upper Joint Bound* and *Lower Joint Bound* for a number of different configurations.

#### Single robot carriage

Track L (mm)	Modules	Travel L (m)	Upper Joint Bound (m)	Lower Joint Bound (m)
2230	2	0.85	0.35	-0.5
3230	3	1.85	1.35	-0.5
4230	4	2.85	2.35	-0.5

*Continues on next page*

### 3 Installation and commissioning

#### 3.6.3 Setting upper and lower software limits for the track

*Continued*

Track L (mm)	Modules	Travel L (m)	Upper Joint Bound (m)	Lower Joint Bound (m)
5230	5	3.85	3.35	-0.5
6230	6	4.85	4.35	-0.5
7230	7	5.85	5.35	-0.5
8230	8	6.85	6.35	-0.5
9230	9	7.85	7.35	-0.5
10230	10	8.85	8.35	-0.5
11230	11	9.85	9.35	-0.5
12230	12	10.85	10.35	-0.5
13230	13	11.85	11.35	-0.5
14230	14	12.85	12.35	-0.5
15230	15	13.85	13.35	-0.5
16230	16	14.85	14.35	-0.5
17230	17	15.85	15.35	-0.5
18230	18	16.85	16.35	-0.5
19230	19	17.85	17.35	-0.5
20230	20	18.85	18.35	-0.5
21230	21	19.85	19.35	-0.5

Single robot carriage with extra plate

Total L (mm)	Modules	Travel L (m)	Upper Joint Bound (m)	Lower Joint Bound (m)
4230	4	1.69	1.35	-0.34
5230	5	2.69	2.35	-0.34
6230	6	3.69	3.35	-0.34
7230	7	4.69	4.35	-0.34
8230	8	5.69	5.35	-0.34
9230	9	6.69	6.35	-0.34
10230	10	7.69	7.35	-0.34
11230	11	8.69	8.35	-0.34
12230	12	9.69	9.35	-0.34
13230	13	10.69	10.35	-0.34
14230	14	11.69	11.35	-0.34
15230	15	12.69	12.35	-0.34
16230	16	13.69	13.35	-0.34
17230	17	14.69	14.35	-0.34
18230	18	15.69	15.35	-0.34
19230	19	16.69	16.35	-0.34
20230	20	17.69	17.35	-0.34

*Continues on next page*



### 3 Installation and commissioning

#### 3.6.3 Setting upper and lower software limits for the track

*Continued*

Total L (mm)	Modules	Travel L (m)	Upper Joint Bound (m)	Lower Joint Bound (m)
21230	21	18.69	18.35	-0.34

#### Double robot carriages

Total L (mm)	Modules	Travel L (m)	Upper Joint Bound (m)	Lower Joint Bound (m)
4230	4	1.60	1.1	-0.5
5230	5	2.60	2.1	-0.5
6230	6	3.60	3.1	-0.5
7230	7	4.60	4.1	-0.5
8230	8	5.60	5.1	-0.5
9230	9	6.60	6.1	-0.5
10230	10	7.60	7.1	-0.5
11230	11	8.60	8.1	-0.5
12230	12	9.60	9.1	-0.5
13230	13	10.60	10.1	-0.5
14230	14	11.60	11.1	-0.5
15230	15	12.60	12.1	-0.5
16230	16	13.60	13.1	-0.5
17230	17	14.60	14.1	-0.5
18230	18	15.60	15.1	-0.5
19230	19	16.60	16.1	-0.5
20230	20	17.60	17.1	-0.5
21230	21	18.60	18.1	-0.5

#### Double robot carriages both with extra plate

Total L (mm)	Modules	Travel L (m)	Upper Joint Bound (m)	Lower Joint Bound (m)
6230	6	1.28	0.94	-0.34
7230	7	2.28	1.94	-0.34
8230	8	3.28	2.94	-0.34
9230	9	4.28	3.94	-0.34
10230	10	5.28	4.94	-0.34
11230	11	6.28	5.94	-0.34
12230	12	7.28	6.94	-0.34
13230	13	8.28	7.94	-0.34
14230	14	9.28	8.94	-0.34
15230	15	10.28	9.94	-0.34
16230	16	11.28	10.94	-0.34
17230	17	12.28	11.94	-0.34

*Continues on next page*

### 3 Installation and commissioning

#### 3.6.3 Setting upper and lower software limits for the track

*Continued*

Total L (mm)	Modules	Travel L (m)	Upper Joint Bound (m)	Lower Joint Bound (m)
18230	18	13.28	12.94	-0.34
19230	19	14.28	13.94	-0.34
20230	20	15.28	14.94	-0.34
21230	21	16.28	15.94	-0.34

#### Single robot carriage and single robot carriage with extra plate






Track L (mm)	Modules	Travel L (m)	Robot Upper Joint Bound (m)	Robot Lower Joint Bound (m)	Extra plate Upper Joint Bound (m)	Extra plate Lower Joint Bound (m)
5230	5	1.44	0.9	-0.5	1.1	-0.34
6230	6	2.44	1.9	-0.5	2.1	-0.34
7230	7	3.44	2.9	-0.5	3.1	-0.34
8230	8	4.44	3.9	-0.5	4.1	-0.34
9230	9	5.44	4.9	-0.5	5.1	-0.34
10230	10	6.44	5.9	-0.5	6.1	-0.34
11230	11	7.44	6.9	-0.5	7.1	-0.34
12230	12	8.44	7.9	-0.5	8.1	-0.34
13230	13	9.44	8.9	-0.5	9.1	-0.34
14230	14	10.44	9.9	-0.5	10.1	-0.34
15230	15	11.44	10.9	-0.5	11.1	-0.34
16230	16	12.44	11.9	-0.5	12.1	-0.34
17230	17	13.44	12.9	-0.5	13.1	-0.34
18230	18	14.44	13.9	-0.5	14.1	-0.34
19230	19	15.44	14.9	-0.5	15.1	-0.34
20230	20	16.44	15.9	-0.5	16.1	-0.34
21230	21	17.44	16.9	-0.5	17.1	-0.34

#### Identifying the upper and lower limits by experiment

If the actual value of the limit is not known, it is possible to jog the track to the desired limit position, and then read the limit value from the FlexPendant.

	Action	Note
1	Before beginning, make sure that the revolution counter for the IRT 510 is updated.	

*Continues on next page*

	Action	Note
2	<p>The upper and lower limit monitoring is active when in manual mode, thus it is first necessary increase the current limit to beyond the mechanical stop. This will then allow the track to be jogged without error up to the desired limit position.</p> <pre>ARM : -upper_joint_bound 11 - lower_joint_bound -1</pre> <p> <b>WARNING</b></p> <p>If the actual track length is 10 meters in the positive direction of movement, and -0.060 meter in the negative direction, then first set the upper bound to 11 meters and the lower bound to -1 meters.</p>	
3	Restart the controller.	
4	<p>Jog the mechanical unit to the desired limit position as shown in the figure.</p> <p> <b>Note</b></p> <p>A minimum distance of 20 mm should be used between where the software limit is set and the actual mechanical stop.</p>	 <p>xx1400001923</p>
5	<p>In the jogging window, read the current position for the track.</p> <p> <b>Note</b></p> <p>The distance is shown in millimeters.</p>	
6	<p>Update the limit value in the MOC file. (In this example it is 9950.1 mm.)</p> <pre>ARM: -upper_joint_bound 9.950 - lower_joint_bound -1</pre>	
7	Restart the controller.	
8	<p>Set the jogging speed to 20% and test the software limit.</p> <p>If the software limit has been set correctly, the following error should be generated, see the figure.</p> <p> <b>WARNING</b></p> <p>This step should be carried out with great care. If the software limit has not been set correctly the mechanical unit may hit the mechanical hard stop.</p>	

*Continues on next page*

### 3 Installation and commissioning

---

#### 3.6.3 Setting upper and lower software limits for the track

*Continued*

	Action	Note
9	Repeat the previous steps for the other limit.	

## 3.6.4 Base frame configuration

### 3.6.4.1 Introduction

#### General

To ensure that the robot works properly in linear on its track, it is necessary that the orientation of the robot relative to the track is properly declared.

If the customer installation differs from the default selections available in Modify Installation, it might be necessary to change the orientation of the robot relative to the track according to the examples below, see [Configuration examples on page 127](#).

#### Mounting directions

The manipulator can be mounted in four directions, in line, 90 degrees, 180 degrees and 270 degrees with the cable chain standard or mirrored, shown in the following figures. Other mounting orientations are not allowed.


For more information, see [Mounting of manipulator on the track on page 93](#).

#### System parameters

This is a brief description of the parameters used when configuring the base frame for robots on track. For more information, see the respective parameter in *Technical reference manual - System parameters*.

#### Robot

These parameters belongs to the type *Robot* in the topic *Motion*.

Parameter	Description
Base Frame x Base Frame y Base Frame z	<i>Base Frame x,y,z</i> defines the direction of the robot base frame position in relation to the world frame (in meters).
Base Frame q1 Base Frame q2 Base Frame q3 Base Frame q4	<i>Base Frame q1-q4</i> defines the quaternions of the robot base frame orientation in relation to the world frame.
Gamma Rotation	<p><i>Gamma Rotation</i> defines the orientation of the robot foot on the travel carriage.</p> <p> <b>Note</b></p> <p>The <i>Gamma Rotation</i> parameter is useful only for robots on track when the 7 axes high performance motion parameter is set. This parameter is not used for all robot types.</p>

#### Single

These parameters belongs to the type *Single* in the topic *Motion*.

Parameter	Description
Base Frame x Base Frame y Base Frame z	<i>Base Frame x,y,z</i> defines the direction of the track base frame position in relation to the world frame (in meters).

*Continues on next page*

### 3 Installation and commissioning

---

#### 3.6.4.1 Introduction


*Continued*

Parameter	Description
Base Frame q1 Base Frame q2 Base Frame q3 Base Frame q4	<i>Base Frame q1-q4</i> defines the quaternions of the track base frame orientation in relation to the world frame.
Use Joint	<i>Use Joint</i> defines which joint data to use for the track.

### 3.6.4.2 Configuration examples

#### Standard cable chain


IRB 0° (in line) in relation to the World coordinate system



- Positive travel direction x in World coordinates
- Standard travel direction

Parameter	Robot ( <i>ROB_1</i> )	Track ( <i>TRACK_1</i> )
Base Frame q1	1	1
Base Frame q2	0	0
Base Frame q3	0	0
Base Frame q4	0	0
Gamma Rotation	0	-
Use Joint	-	track1

IRB rotated 90° in relation to the World coordinate system



- Positive travel direction x in World coordinates
- Standard travel direction

Parameter	Robot ( <i>ROB_1</i> )	Track ( <i>TRACK_1</i> )
Base Frame q1	0.707107	1
Base Frame q2	0	0
Base Frame q3	0	0
Base Frame q4	0.707107	0
Gamma Rotation	1.570796	-
Use Joint	-	track1


*Continues on next page*

### 3 Installation and commissioning

#### 3.6.4.2 Configuration examples

Continued


IRB rotated 180° in relation to the World coordinate system



- Positive travel direction x in World coordinates
- Standard travel direction

Parameter	Robot ( <i>ROB_1</i> )	Track ( <i>TRACK_1</i> )
Base Frame q1	0	1
Base Frame q2	0	0
Base Frame q3	0	0
Base Frame q4	1	0
Gamma Rotation	3.141593	-
Use Joint	-	track1

IRB rotated 270° in relation to the World coordinate system



- Positive travel direction x in World coordinates
- Standard travel direction


Parameter	Robot ( <i>ROB_1</i> )	Track ( <i>TRACK_1</i> )
Base Frame q1	0.707107	1
Base Frame q2	0	0
Base Frame q3	0	0
Base Frame q4	-0.707107	0
Gamma Rotation	-1.570796	-
Use Joint	-	track1

Continues on next page



#### Mirrored cable chain


IRB in line 0° in relation to the World coordinate system



- Positive travel direction x in World coordinates
- Mirrored travel direction

Parameter	Robot ( <i>ROB_1</i> )	Track ( <i>TRACK_1</i> )
Base Frame q1	1	1
Base Frame q2	0	0
Base Frame q3	0	0
Base Frame q4	0	0
Gamma Rotation	0	-
Use Joint	-	track1-lin

IRB rotated 90° in relation to the World coordinate system



- Positive travel direction x in World coordinates
- Mirrored travel direction

Parameter	Robot ( <i>ROB_1</i> )	Track ( <i>TRACK_1</i> )
Base Frame q1	0.707107	1
Base Frame q2	0	0
Base Frame q3	0	0
Base Frame q4	0.707107	0
Gamma Rotation	1.570796	-
Use Joint	-	track1-lin


*Continues on next page*

### 3 Installation and commissioning

#### 3.6.4.2 Configuration examples

Continued


IRB rotated 180° in relation to the World coordinate system



- Positive travel direction x in World coordinates
- Mirrored travel direction

Parameter	Robot ( <i>ROB_1</i> )	Track ( <i>TRACK_1</i> )
Base Frame q1	0	1
Base Frame q2	0	0
Base Frame q3	0	0
Base Frame q4	1	0
Gamma Rotation	3.141593	-
Use Joint	-	track1-lin

IRB rotated 270° in relation to the World coordinate system



- Positive travel direction x in World coordinates
- Mirrored travel direction

Parameter	Robot ( <i>ROB_1</i> )	Track ( <i>TRACK_1</i> )
Base Frame q1	0.707107	1
Base Frame q2	0	0
Base Frame q3	0	0
Base Frame q4	-0.707107	0
Gamma Rotation	-1.570796	-
Use Joint	-	track1-lin

### 3.6.5 Configuration of additional load

---

#### Introduction

It is important that the load which is carried by the track is correct defined. There is no need for the user to make any updates of the system parameters. The definition of the following equipment is handled by the system, via Modify Installation, during the boot process.

- The standard pedestals with the height of 250 mm, 500 mm, 1000 mm and 1750 mm.
- The additional carriage plate.
- The robot.

However, if for example an arc welding power source is fitted on the additional carriage plate, then the system parameter *Arm Load t1\_load\_1* must be updated with the correct center of gravity and mass.

### 3 Installation and commissioning

#### 3.7.1 Replacing the grease cartridge in grease pump MEMOLUB® EPS




### 3.7 Lubrication

#### 3.7.1 Replacing the grease cartridge in grease pump MEMOLUB® EPS

##### Overview

This section is based on the MEMOLUB® EPS user manual. It details how to replace the grease cartridge.

##### Removing the grease cartridge

	Action	Illustration/Note
1	Remove the carriage side covers.	 xx1500001620
2	Disconnect the cartridge power cable from the connector bracket on the carriage.	 xx1500000130
3	Screw the complete cartridge counterclockwise to remove it from its holder on the carriage.	 xx1500000131

##### Opening the grease pump


	Action	Illustration/Note
1	Place the grease pump on a flat and clean surface.	

*Continues on next page*


### 3 Installation and commissioning

#### 3.7.1 Replacing the grease cartridge in grease pump MEMOLUB® EPS

Continued


	Action	Illustration/Note
2	Push firmly with one hand on top of the grease pump. With the other hand, hold the black base and turn counterclockwise.	 <p>xx1400001570</p>
3	Pull the transparent housing and open it.	

#### Closing the grease pump

	Action	Illustration/Note
1	Hold the cranked black base, put on the transparent housing and turn it clockwise.	 <p>xx1400001571</p>
2	When the closed position is reached you should hear a "click".	

#### Installing a new grease cartridge

Respect the following instructions to replace the grease cartridge:

	Action	Illustration/Note
1	Open the MEMOLUB® as described before.	
2	Pull-up the black rubber seal. Fill-in the MEMOLUB® with a manual grease pump. This manual operation is required only if the MEMOLUB® has been used without a cartridge, if the previous cartridge has run out of grease. Place the pump nipple at the entry of the MEMOLUB®, and pump until you see grease coming out at the outlet. Two strokes of the manual pump are usually enough.	 <p>xx1400001572</p>

Continues on next page

### 3 Installation and commissioning

#### 3.7.1 Replacing the grease cartridge in grease pump MEMOLUB® EPS

Continued

	Action	Illustration/Note
3	Remove the paper disc from the replacement cartridge. Fill-in the required dates: "Started" and "Replace before". The "replace before" date is depending on the MEMOLUB® program. Put the paper disc back in place in order to see the instructions when the MEMOLUB® is closed.	 <p data-bbox="992 663 1098 680">xx1400001574</p>
4	Press softly on the cartridge until the grease comes out, to avoid injecting air into the pump.	 <p data-bbox="992 1034 1098 1052">xx1400001575</p>
5	Place the cartridge at the inlet of the pump, verify that the cartridge is correctly inserted in the inlet of the pump.	 <p data-bbox="992 1415 1098 1433">xx1400001577</p>
6	Place the spring and the compression disc inside the transparent bell. Put the bell back in place and verify that the compression disc is correctly lying on the top of the cartridge surface.	 <p data-bbox="992 1818 1098 1836">xx1400001576</p>
7	Close the MEMOLUB® as described before.	

Continues on next page

#### Test the grease pump MEMOLUB® (verify function)



#### CAUTION

It is important that you run this test cycle only if a cartridge is in place, otherwise you will fill the pump with air.

To verify that the grease pump is working well after a maintenance operation, press one of the 3 connectors located on the base during a few seconds. The grease pump is starting a dispensing cycle. The completion of the cycle means that the battery and the control board of the grease pump are working well.



xx1400001578

### 3 Installation and commissioning

#### 3.7.2 Configuration of grease pump MEMOLUB®

#### 3.7.2 Configuration of grease pump MEMOLUB®




##### Overview

This section is based on the MEMOLUB® installation instructions. It details how to configure the grease pump MEMOLUB®.

##### Configuration

The grease pump MEMOLUB® is set through combination of 3 plastic rings: black (Ø50 mm), white (Ø44 mm) and red (Ø38 mm).

The table shows the frequency of strokes and the duration of a 240 mm cartridge at different combinations.

50 mm  xx1600001020	44 mm  xx1600001021	38 mm  xx1600001022	Frequency hour(s)	Duration of a 240 mm cartridge month(s)
x			48	24
	x		24	12
x	x		16	8
		x	12	6
x		x	6	3
	x	x	2	1
x	x	x	1	1/2

##### Set of rings

The figure shows the 3 rings disassembled from the grease pump MEMOLUB®.



xx1600001023



## 3.8 Commissioning

### 3.8.1 Check list for IRT 510 before commissioning

#### Cables/hoses

Verify that...	Description
No stretch of the power and signal cables for the motor.	It is common to see these cables stretched, stood on, or with other cables resting on them.
Inspect the shielding	Stretched cables will inevitably affect the shielding and cause feedback issues and other damage.
No movement of the cable	If there is movement in the cables then they could get trapped and damaged.
Verify the length	If the length is excessive, it indicates that the orientation of robot is different to what was initially ordered. If cables have excessive length and are not strapped at all, cables could easily get caught and damaged in the dead stop.
Fixed position with straps.	If the cables are not fixed properly then they can easily get caught and damaged.
Is shielding visible?	Cables need to be tied to prevent this from happening. Spare ABB cable also needs to be tied out of the way.
Cables secured and not hanging loosely.	Robot cables need securing because they are loose down to the cable chain and could easily get damaged.

#### Cable chain

Verify that...	Description
Working correct in the entire length	Does the robot carrier run up and down the entire length of track without hitting the trunking, guarding etc?
No damage	Is there any damage to the cable chain such as step damage, twisted sections or brackets, etc?
Correct cable hoses length inside.	Ensure cables are not twisted, too tight or too loose inside cable chain.
Correctly secured with ties both ends and white marked.	Ensure that each cable is individually cable tied and identified using white marker to indicate movement.
Fixed position with straps.	If the cables are not fixed properly then they can easily get caught and damaged.
Each cable is individually tied and marked up correctly	-

#### Cable tray

Verify that...	Description
No wear against in or outside of the cable tray	Is there any wear on the inside or outside of the cable chain from being twisted and rubbing against cable tray?
Correctly tightened	Has the channel been secured correctly to the provided brackets?

*Continues on next page*

### 3 Installation and commissioning

#### 3.8.1 Check list for IRT 510 before commissioning

*Continued*

Verify that...	Description
No step damage	Is there any step damage to any of the cable chain channel or support brackets, are they twisted causing cable chain to wear?
Verify fixing screws	Has the fixing screws been attached to the cable tray?

#### Lubrication system

Verify that...	Description
Sufficient quantity of grease in the can	When the low level light is on then the grease unit needs to be filled.
No leakage at the pump/under the track/ball bearing blocks	Ensure that each connection for the grease pipe work is not damaged or leaking grease.

#### Guiderail and ball bearing blocks

Verify that...	Description
Make sure that all ball bearing blocks and also the entire travel length of the guiderail receive grease in a proper quantity.	This can be verified by inspecting each individual bearing to ensure there is grease visible around them and by inspecting the guiderails also.
In case of suspected problem look after jumping marks at the end of each section.	When carrying out visual inspection it is also very important to feel along guiderails where the ball elements run to ensure that there are not any markings.

#### Track foundation

Verify that...	Description
Correct size bolts used	-
Track feet correctly packed to the floor	Stretched cables will inevitably affect the shielding and cause feedback issues and other damage.
Secured without movement	If there is movement in the cables then they could get trapped and damaged.

#### Gear rack

Verify that...	Description
The space and level between the gear racks is appropriate	-
All bolts are fitted	-
The torque on the bolts is appropriate	-

#### Guiderail

Verify that...	Description
Verify the space and the level between the guiderails	-
Verify that the locking washers have the mark up in the right corner	Must ensure correct as these washers determine the guiderails are mechanically level across the track sections.

*Continues on next page*

### 3 Installation and commissioning

#### 3.8.1 Check list for IRT 510 before commissioning

*Continued*

Verify that...	Description
Verify the torque on the bolts	-

#### Connection bracket

Verify that...	Description
Verify that all brackets are in correct position	Brackets which connect track sections are dowelled and number identified to prevent incorrect fitting.
Verify that all bolts and the locking pins are fitted and have the right torque.	-

## 3 Installation and commissioning

---

### 3.9 Test run after installation, maintenance, or repair

### 3.9 Test run after installation, maintenance, or repair

---

#### Safe handling

Use the following procedure after installation, maintenance, or repair, before initiating motion.



#### **DANGER**

Initiating motion without fulfilling the following aspects, may increase the risk for injury or cause damage to the robot.

	Action
1	Remove all tools and foreign objects from the robot and its working area.
2	Verify that the robot is properly secured to its position by all screws, before it is powered up.
3	Verify that any safety equipment installed to secure the position or restrict the robot motion during service activity is removed.
4	Verify that the fixture and work piece are well secured, if applicable.
5	Verify that all safety equipment is installed, as designed for the application.
6	Verify that no personnel are inside the safeguarded space.
7	If maintenance or repair has been done, verify the function of the part that was maintained.
8	Verify the application in the operating mode manual reduced speed.

#### Collision risks



#### **CAUTION**

When programming the movements of the robot, always identify potential collision risks before initiating motion.

---

# 4 Maintenance

## 4.1 Introduction

---

### Structure of this chapter

This chapter describes all the maintenance activities recommended for the IRT 510.

It is based on the maintenance schedule found at the beginning of the chapter. The schedule contains information about required maintenance activities including intervals, and refers to procedures for the activities.

Each procedure contains all the information required to perform the activity, including required tools and materials.

The procedures are gathered in different sections and divided according to the maintenance activity.

---

### Safety information

Observe all safety information before conducting any maintenance work.

There are general safety aspects that must be read through, as well as more specific safety information that describes the danger and safety risks when performing the procedures. Read the chapter [Safety on page 15](#) before performing any maintenance work.

The maintenance must be done by qualified personnel in accordance with the safety requirements set forth in the applicable national and regional standards and regulations.



#### Note

If the IRT 510 is connected to power, always make sure that the IRT 510 is connected to protective earth and a residual current device (RCD) before starting any maintenance work.

For more information see:

- *Product manual - OmniCore V250XT Type B*
- *Product manual - OmniCore V400XT*
- [Connection points on page 108](#).

## 4 Maintenance

---

### 4.2.1 Specification of maintenance intervals

## 4.2 Maintenance schedule and expected component life

### 4.2.1 Specification of maintenance intervals

---

#### Introduction

The intervals are specified in different ways depending on the type of maintenance activity to be carried out and the working conditions of the IRT 510:

- Calendar time: specified in months regardless of whether the system is running or not.
- Operating time: specified in operating hours. More frequent running means more frequent maintenance activities.

Robots with the functionality *Service Information System* activated can show active counters in the device browser in RobotStudio, or on the FlexPendant.

## 4.2.2 Maintenance schedule

### General

The track must be maintained regularly to ensure proper function. The maintenance activities and intervals are specified in the table below.

Non-predictable situations also give rise to inspections of the track. Any damage must be attended to immediately.

The inspection intervals *do not* specify the life of each component. Values for these are specified in the section [Expected component life on page 146](#)

### Activities and intervals, standard equipment

The table below specifies the required maintenance activities and intervals.

Maintenance activity	Equipment	Interval
Inspection and cleaning (when necessary)	Rack and linear guides	Every 100 km or every 1 month
Inspection	Cable chain	Every 3 months
Inspection	Felt gear	Every 3 months
Inspection	Cables and connectors at robot base, track motor and interchange to floor cable	Every 12 months
Inspection	Mechanical stops	Every 12 months
Inspection	Gear wheel, gearbox and backlash	Every 12 months
Inspection	Fitting bolts	Every 12 months
Adjustment of leveling	Complete track	Every 12 months <sup>i</sup>
Replacement	Linear guide	When expected life is reached or if disturbances occur.
Replacement	Ball bearing blocks	When linear guides are replaced.
Replacement	Felt gear, gear wheel, gearbox and racks	When play can not be adjusted to specified <sup>ii</sup> level.
Replacement	Glide shoes <sup>iii</sup>	When gliding surface thickness is 1.5 mm or less. <sup>iv</sup>
Check the level	Automatic lubrication system	Every 1 month or sensor alert (options 4216-1 or 4230-1 Grease detection sensor) <sup>v</sup> .

<sup>i</sup> Leveling shall be checked every 12 months. Leveling adjustment is required only when there is subsidence happened, which affects the track levelling.

<sup>ii</sup> The play is specified in [Adjusting the gearbox backlash on page 219](#).

<sup>iii</sup> Glide shoes have been introduced to simplify and reduce the time associated with changing links.

<sup>iv</sup> The first glide shoes to wear out will be located at the point where the chain first makes contact with itself during operation.

<sup>v</sup> The connector is available only when the options 4216-1 or 4230-1 Grease detection sensor is chosen. To make the sensor alert effective, the customer has to connect the sensor to the control device and configure the alert by self.

With the sensor connected and activated,

- For grease splitter with 6 outputs, the signal configured for the lubrication detection sensor changes value when the dispatcher pumps every 5 times.
- For grease splitter with 8 outputs, the signal configured for the lubrication detection sensor changes value when the dispatcher pumps every 6 times.

*Continues on next page*

## 4 Maintenance

---

### 4.2.2 Maintenance schedule

*Continued*

The pumping times can be modified according to actual application. If the pumping doesn't work as configured, the alert reports.



### 4.2.3 Gearbox oil

---

#### Where to find information about gearbox oil

Please see *Technical reference manual - Lubrication in gearboxes (3HAC042927-001)* for information about gearbox oil.

## 4 Maintenance

### 4.2.4 Expected component life

### 4.2.4 Expected component life

#### General

The expected life of a specific component of the robot can vary greatly depending on how hard it is run.

#### Expected component life

Component	Expected life <sup>i</sup>	Note
Cables	2,000,000 cycles <sup>ii</sup>	See note <sup>iii</sup>
Cable chain <sup>iv</sup>	Whichever occurs first: 2,000,000 cycles <sup>v</sup> or 18,000,000 gliding meters <sup>vi</sup> + addition 18,000,000 gliding meters if gliding shoes are changed .	
Gearbox	40,000 hours	
Ball bearing blocks	80,000,000 meters	

- <sup>i</sup> The expected life of all componets is provided based on the typical cycle.  
A typical cycle includes the robot IRB 2600 and track movement, starting from the initial position (A) and going to maximum extension (B), and back (A). The cycle is a 12-meter movement (from A to B to A, two 6-meter strokes) in 1 minute with the maximum acceleration  $2.5 \text{ m/s}^2$  and maximum payload 1.2 tons. Deviations from this cycle will result in differences in expected life!
- <sup>ii</sup> The track is dimensioned for a life of 4 years (302,400 cycles per year) in a normal application
- <sup>iii</sup> The expected life can also be affected by assemblage of cabling other than standard options.
- <sup>iv</sup> Due to process cycle variation and varying lengths of tracks the chains' lifetime is calculated on two parameters, gliding meters and bending cycles. When maximum limit of either parameter is reached the complete chain and or cables should be replaced.  
In order to maximize the chains lifetime ensure to optimize the software and cell layout to reduce the amount of travel and cycles.
- <sup>v</sup> A cycle is comprised of two strokes / changes in direction.
- <sup>vi</sup> A gliding meter is described as the chain making contact with itself or the glide bars. Chains on tracks shorter than 6 meters travel distance do not have gliding contact.

4.3 Activities 100 km or 1 month


4.3.1 Cleaning the racks

General

The racks should be inspected every 100 km or 1 month. If dirtiness or debris is found, follow the instructions to clean.

Location

The racks are located as shown in figure.



xx140000461

A	Rack
---	------

Required equipment

When you clean the racks, it is necessary to lubricate the racks manually. Use one of the recommended lubricants:

Equipment	Note
Lubricant	TOTAL CERAN CA
Lubricant	TOTAL Multis EP 0
Lint free cloth	

Continues on next page



## 4 Maintenance

### 4.3.1 Cleaning the racks

*Continued*

#### Lubricating the racks

Use this procedure to lubricate the racks and pinion.

	Action	Illustration/Note
1	Remove IRT 510 upper covers and rack covers.	 <p>xx140000231</p> <p>A Screw DIN6921 M6x12 B Top cover of the track C Rack cover of the track</p>
2	Inspect the racks and the pinion, clean them if necessary.	 <b>Note</b> Use lint free cloth.
3	Use a brush to lubricate the racks.	
4	Refit the covers.	


### 4.3.2 Cleaning the linear guides

#### General

The linear guides should be inspected every 100 km or 1 month. If dirtiness or debris is found, follow the instructions to clean

#### Location of linear guides

The linear guides are located as shown in figure.



xx140000466

A	linear guides
---	---------------

#### Required equipment

When you clean the linear guides, it is necessary to lubricate them manually. Use one of the recommended lubricants:

Equipment	Note
Lubricant	TOTAL CERAN CA
Lubricant	TOTAL Multis EP 0
Lint free cloth	

*Continues on next page*



## 4 Maintenance

### 4.3.2 Cleaning the linear guides

*Continued*

#### Cleaning the linear guides

Use this procedure to clean and, if necessary, lubrication of the linear guides.

	Action	Illustration/Note
1	Remove IRT 510 upper covers and rack covers.	 <p>xx140000231</p> <p>A Screw DIN6921 M6x12 B Top cover of the track C Rack cover of the track</p>
2	Inspect the linear guides, clean them if necessary.	 <b>Note</b> Use lint free cloth.
3	If you have cleaned them, use a brush to lubricate the linear guides.	
4	Move the carriage back and forth and repeat step 3.	
5	Refit the covers.	

4.4 Activities 1 month

4.4.1 Inspecting the automatic lubrication system


Overview

There is an automatic lubrication system in IRT 510. An electric pump will deliver the correct quantity of grease from a cartridge to the ball bearing blocks and to the pinion at required time intervals (one cycle per day). The grease is pushed in the piping by the pump; a valve is sequencing the distribution to each port.

The level of the lubricant should be inspected once a month, even though the system should apply the lubricant equally over a longer period.

Location of lubrication system

The lubrication system is located as shown in the figure.



xx140000478

Pos	Description
A	Lubrication pump EPS 240
B	Polyamide tube 4x6
C	Straight adaptor F1/4-D8
D	Polyamide tube 6x8
E	Male stud elbow (white brass) D8 G1/4
F	Male stud elbow (white brass) D6 G1/8
G	Male stud straight (white brass) D6 G1/8
H	Y fitting D6-D6
I	Inline fitting-D6
J	Felt gear set
K	Grease package 240 CC

Continues on next page

## 4 Maintenance

### 4.4.1 Inspecting the automatic lubrication system


*Continued*

#### Required equipment

##### Required tool

Equipment	Art. No.	Note
Standard toolkit	-	Content is defined in section <a href="#">Standard tools on page 270</a> .
Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below.		These procedures include references to the tools required.

##### Required lubricant

 **WARNING**


Use lithium soap flowable grease, class NLGI 0, with a mineral oil base, doped with EP (extreme pressure) additives. The base oil viscosity must be ISO VG68 to ISO VG 100.

Grease doped with EP additives is absolutely necessary, due to high loads on blocks.

Equipment	Note
Lubricant	TOTAL CERAN CA
Lubricant	TOTAL Multis EP 0


#### Inspecting the grease level and inspecting the pipes

Use this procedure to inspect the grease level and inspect the pipes of the lubrication system.

	Action	Illustration/Note
1	Locate the cartridge.	
2	Check the level of lubricant, if necessary replace the cartridge. For information about cartridge replacement, see <a href="#">Replacing the grease cartridge in grease pump MEMOL-UB® EPS on page 132</a> .	 <p>xx1400001754</p> <p><b>A</b> Checking lubrication cup level through the notch</p>

*Continues on next page*



	Action	Illustration/Note
3	Check that no pipe has been damaged, and that the grease is arriving to each block and at the pinion lube tube.	 <p data-bbox="973 604 1077 627">xx1400001585</p>

#### Checking the performance

The automatic lubrication system should be checked that it can work properly. For information about checking Memolub function, see [Test the grease pump MEMOLUB® \(verify function\) on page 135](#).

## 4 Maintenance

---

### 4.4.2 Emergency stop and stroke limit system

#### 4.4.2 Emergency stop and stroke limit system

---

##### General

It is recommended to ensure the emergency stop and stroke limit system effectiveness every month.

##### Motor brake

The procedure below details how to ensure the effectiveness of the motor brake in case of emergency stop.

	Action	Illustration/Note
1	Ensure that the IRT 510 is powered, but not moving.	
2	Press the emergency stop button.	
3	The brake is applied; you should hear the noise in the motor area.	
4	Try to push the carriage manually.	
5	If the brake is correctly applied, it is not possible to move the carriage manually.	
6	Proceed with the required validations in the control system to switch back to auto mode.	

##### Verification of the effectiveness of the stroke limit system

A software limit prevents the carriage from moving beyond its acceptable upper and lower stroke limits.

The procedure below details how to ensure the software stroke limit is working correctly:

	Action	Illustration/Note
1	Switch the controller to manual mode.	
2	With the FlexPendant, try to jog the carriage to both ends.	
3	If the software limits are functional, it should not be possible to go beyond the defined upper or lower end position, and it should not be possible to reach the hard stops.	

### 4.4.3 Inspecting the cables and connectors



#### WARNING

Turn off all electric power and pneumatic pressure supplies to the robot and for IRT 510.

#### Inspecting the cables

Use this procedure to check the cables.

	Action	Illustration/Note
1	Check if any cables have been damaged through wear or pinching. If damaged then replace the cable.	
2	Check if any cables rub against sharp edges. If so, route the cable so that it runs freely.	Replace the cable, remove the cause of the wear, or route the cable in a different way.
3	Check strain relief of cables and hoses. Marking should be close to the corresponding strap. If not, pull the hose/cable to the correct position and strap it.	

#### Inspecting the connectors

Check that the connectors at the robot base, track motor and interchange to the floor cable are firmly secured and that there is no damage of cable outlet.

#### Inspecting the cable chain

Once a month check that the cable track shows no trace of excessive wear due to rub on a fixed part. If one element is damaged, it is possible to replace it without removing the whole chain from IRT 510.

## 4 Maintenance


### 4.5.1 Inspecting the cable chain

## 4.5 Activities 3 months

### 4.5.1 Inspecting the cable chain

#### Location of harness

The track cable harness is totally located in the cable chain.



xx1400001286

A	Customer cables
B	Track motor and manipulator power cables
C	Signal cables for the manipulator and IRBT 2005 track motor
D	Cable chain
F	Floor cables from the controller
G	Controller

#### Required equipment

Equipment	Art. No.	Note
Visual inspection	-	
Cable ties	21662055-3	Needed if the cable strapping needs to be improved. Use heavy duty cable ties with minimum width: 4.9 mm.
Locking liquid	-	Loctite 243 Used if loose screws are detected.

*Continues on next page*

#### Checking the emergency stop


	Action	Illustration/Note
1	Allow the track to stop.	
2	Press the emergency stop button.	
3	Try to start the track.	

#### Inspecting the connection plates

	Action	Illustration/Note
1	Check and rectify the cables are tied on the connection plates tightly and neatly.	

#### Inspecting the cable chain

##### Inspecting the cables

	Action	Illustration/Note
1	Move the carriage to one end and open the covers on the outside bend.	
2	Check that the cables are in the neutral axis (center line of the link) of the chain as shown in the figure.  If cables are found to be too loose or too tight then they need to be adjusted.	 <p>xx1200000518</p>
3	Repeat the check of the cables in the neutral axis with the carriage in the middle and at the other end.	
4	Make an overall inspection of the cables. If a cable is found to corkscrew it needs to be replaced immediately. If cables have worn through the outer cover they must be replaced. Some dust can be expected from the cables as they rub against the dividers in the chain.	

*Continues on next page*


## 4 Maintenance

### 4.5.1 Inspecting the cable chain

*Continued*

#### Location of the glide shoes

The figure shows the location of the glide shoes on the cable chain.



xx1400002683

#### Inspecting the glide shoes

	Action	Illustration/Note
1	<p>Check the thickness of the glide shoes. If it is less than 1.5 mm the glide shoes must be replaced.</p> <p>Normally only the glide shoes in the area that make first contact when the chain transitions into gliding mode need to be checked. However due to process cycle variation in factories it is recommended to check all the glide shoes for the first inspection and note the point of wear for the next inspection.</p>	
2	<p>Make an overall inspection of the glide shoes. Replace broken or missing shoes.</p>	See <a href="#">Refitting the glide shoes on page 242</a> .

#### Inspecting the strapping

	Action	Illustration/Note
1	<p>Check that strapping is in place. Each cable is required to be individually strapped down, and not bunched together.</p> <p>If insufficient holes are available in the connection plates for individual strapping with cable ties, the cables should be secured in such a way that they cannot move.</p> <p>Only use heavy duty cable ties, specified in <a href="#">Required equipment on page 156</a>. If strapping has been replaced ensure that a paint pen is used to mark both sides of the cable tie.</p>	

*Continues on next page*

#### Inspecting the fasteners

	Action	Illustration/Note
1	Check bolts and screws on the attaching plates and brackets. If found to be loose they need to be removed, have locking liquid applied to them and then be refitted and tightened.	Loctite 243


## 4 Maintenance

### 4.5.2 Inspecting the felt gear

### 4.5.2 Inspecting the felt gear

#### Location of felt gear

The felt gear is located as shown in figure.



xx1400002641

A	Gearbox
B	Felt gear

#### Required equipment

Equipment	Art. No.	Note
Standard toolkit	-	Content is defined in section <a href="#">Standard tools on page 270</a> .

#### Inspecting the felt gear

	Action	Illustration/Note
1	Inspect the felt gear. If damaged, replace it. See <a href="#">Replacing the felt gear on page 223</a> .	



## 4.6 Activities 12 months

### 4.6.1 Inspecting the cables and connectors

#### Required equipment

Equipment	Art. No.	Note
Visual inspection	-	

#### Inspecting the connectors

Use this procedure to check the connectors.

	Action	Illustration/Note
1	Check that the connectors at the robot base, track motor and interchange to the floor cable are correctly fitted and that there is no risk of loose connections.	

#### Inspecting the cables

Use this procedure to check the cables.

	Action	Illustration/Note
1	Check if any cables have been damaged through wear or pinching. If damaged then replace the cable.	
2	Check if any cables rub against sharp edges. If so, route the cable so that it runs freely.	See cable routing in <a href="#">Replacing the cables on page 243</a> .
3	Check strain relief of cables and hoses. Marking should be close to the corresponding strap. If not, pull the hose/cable to the correct position and strap it.	

#### Fault finding

The following information is provided to assist fault finding.

Cables that have failed due to incorrect installation typically show the following symptoms:

- Knotting of conductors underneath the cable jacket.
- Cables twist around one another within a cable carriage system.
- Cables are sticking out between the cable carriage crossbars and getting caught in the bend radius.
- Cables entangled with other cables and crossbars tearing them apart.
- Loss of conductivity through simple breaking of cable conductors.

Common causes of cable failure when operating in a cable chain:

- Cables used are not designed for use in continuous flexing operation.
- Cables are packed too tight inside the carriage cavities.
- Cables are not properly adjusted (see [Inspection of cables and covers prior to start-up on page 115](#)).


## 4 Maintenance

### 4.6.2 Inspecting the mechanical stops

#### 4.6.2 Inspecting the mechanical stops

##### Location of mechanical stops

The mechanical stops are located as shown in figure.



xx1400001282

A	Mechanical stops left
B	Mechanical stops right

##### Required equipment

Equipment	Art. No.	Note
Visual inspection	-	

##### Inspecting the mechanical stops


Use this procedure to inspect the mechanical stops.

Action	Illustration/Note
1 Visually inspect the bumpers on mechanical stops for damage.	<p>xx1400001283</p> <p>A Bumper B Mechanical stop</p>
2 If the mechanical stops are damaged, replace them.	

### 4.6.3 Inspecting the gear wheel, gearbox and backlash

#### Location of gear wheel and gearbox

The gear wheel and gearbox are located as shown in figure.



xx1400001284

A	Gear wheel
B	Gearbox

#### Required equipment

Equipment	Art. No.	Note
Standard toolkit	-	Content is defined in section <a href="#">Standard tools on page 270</a> .

#### Inspecting the gear wheel, gearbox and backlash

Use this procedure to inspect the gear wheel, gearbox and backlash.

	Action	Illustration/Note
1	Loosen the carriage from the drive train bracket.	
2	Remove the drive train.	
3	Inspect the backlash, gear wheel and gearbox.	
4	If backlash is improper, adjust it. See <a href="#">Adjusting the gearbox backlash on page 219</a> .	

*Continues on next page*

## 4 Maintenance

### 4.6.3 Inspecting the gear wheel, gearbox and backlash

*Continued*


	Action	Illustration/Note
5	If gear wheel or gearbox is damaged, replace it. See <a href="#">Replacing the gear wheel on page 206</a> and <a href="#">Replacing the gearbox on page 194</a> .	

#### Verification of the tightening torque

Every year, remove the necessary IRBT 2005 and carriage side covers and make sure that the tightening torque of the eight M10x40 class 12.9 hex socket head cap screws that secure the gear to the bracket is 70 Nm.

#### Location of tightening screws

The eight screws are located as shown in figure.



xx1400001285

A Eight M10x40 hex socket head cap screws, class 12.9. 3HAB3409-50

#### Required equipment

Equipment	Art. No.	Note
Standard toolkit	-	Content is defined in section <a href="#">Standard tools on page 270</a> .

#### Inspecting the tightening torque of screws

Use this procedure to inspect the tightening torque of the eight M10x40 hex socket head cap screws.

	Action	Illustration/Note
1	Remove the necessary track covers and carriage side covers.	
2	Use a torque wrench to check that the tightening torque of the screws that secure the gear to the bracket is 70 Nm.	Screw specification: M10x40 hexagon socket head cap screw, class 12.9

### 4.6.4 Adjusting the leveling

---

#### Adjusting the leveling

Leveling shall be checked every 12 months. Leveling adjustment is required only when there is subsidence happened, which affects the track levelling.

Follow the procedure in [Geometric alignment of IRT 510 on page 84](#) to adjust the leveling on the track.

**This page is intentionally left blank**

# 5 Repair

## 5.1 Introduction

### Structure of this chapter

This chapter describes repair activities for the IRT 510. Each procedure contains the information required to perform the activity, for example spare parts numbers, required special tools, and materials.



#### WARNING

Repair activities not described in this chapter must only be carried out by ABB.

### Report replaced units



#### Note

When replacing a part on the IRT 510, report to your local ABB the serial number, the article number, and the revision of both the replaced unit and the replacement unit.

This is particularly important for safety equipment to maintain the safety integrity of the installation.

### Safety information

Make sure to read through the chapter [Safety on page 15](#) before commencing any service work.



#### Note

If the IRT 510 is connected to power, always make sure that the IRT 510 is connected to protective earth and a residual current device (RCD) before starting any repair work.

For more information see:

- *Product manual - OmniCore V250XT Type B*
- *Product manual - OmniCore V400XT*

## 5 Repair

### 5.2 Cut the paint or surface on the robot before replacing parts

### 5.2 Cut the paint or surface on the robot before replacing parts


#### General

Follow the procedures in this section whenever breaking the paint of the robot during replacement of parts.

#### Required equipment

Equipment	Spare parts	Note
Cleaning agent		Ethanol
Knife		
Lint free cloth		
Touch up paint Standard/Foundry Plus	3HAC067974-001	Graphite White

#### Removing


	Action	Description
1	Cut the paint with a knife in the joint between the part that will be removed and the structure, to avoid that the paint cracks.	 xx230000950
2	Carefully grind the paint edge that is left on the structure to a smooth surface.	



### 5.3 Replacing the linear guides

#### Location of linear guides

The figure below shows the location of the linear guides:



xx1400001288

A	1000 mm linear guide
B	500 mm linear guide

#### Required equipment

Equipment	Note
Linear guides	Spare part number is specified in <a href="#">Spare parts on page 279</a> .
Standard toolkit	Content is defined in section <a href="#">Standard tools on page 270</a> .
Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below.	These procedures include references to the tools required.

#### Removing the linear guides

Use this procedure to remove the linear guides.



Action	Illustration/Note
1 Remove all necessary IRT 510 top covers (B) and rack covers (C) around the linear guide to be replaced by removing screws (A).	<p>xx1400000231</p>

Continues on next page

## 5 Repair


### 5.3 Replacing the linear guides

Continued




	Action	Illustration/Note
2	Remove the square locking washers and screws, which clamp the to-be-removed linear guides.	 <p data-bbox="936 645 1050 667">xx1500003253</p>
3	Remove the linear guide by removing the screws and washers.	 <p data-bbox="936 1093 1050 1115">xx1400000228</p> <p data-bbox="975 1122 1406 1261"> <b>A</b> Linear guide  <b>B</b> Ø 12xØ 32x4 Washer for rail, I3HAC047749-001  <b>C</b> M12x35 Hex socket head cap screw, 3HAB3409-66         </p>

### Refitting the linear guides

Use this procedure to refit the linear guides.

	Action	Illustration/Note
1	Fit the linear guide by securing the screws and plain washers. Use standard tools, slightly tighten.	 <p data-bbox="936 1848 1050 1870">xx1400000228</p> <p data-bbox="975 1877 1406 2018"> <b>A</b> Linear guide  <b>B</b> Ø 12xØ 32x4 Washer for rail, 3HAC047749-001  <b>C</b> M12x35 Hex socket head cap screw, 3HAB3409-66         </p>

Continues on next page

	Action	Illustration/Note
2	Fit the square locking washer with screws. Use standard tools, slightly tighten.	 <p>xx1400001751</p> <ul style="list-style-type: none"> <li>A M10x20 Hex socket countersunk screw DIN7991, 3HAC051482-001</li> <li>B Square locking washer, 3HEA802935-001</li> <li>C Ensure this mark is on the upper right corner of the lock washer</li> </ul>
3	Feel with a finger at the section joint to check the alignment of the linear guide: if the linear guides are correctly aligned, you should sense no "step" while passing the linear guide's junction.	 <p>xx1400001752</p> <ul style="list-style-type: none"> <li>A Ball bearing block</li> <li>B Linear guide</li> </ul>
4	If "step" is felt, loose linear guides slightly and use a plastic hammer striking the linear guides slightly along the direction of the track until gaps between all linear guides are less than 0.7 mm.	
5	Make sure that the guide rail is aligned, and then tighten the screw to locking washer.	<p>Once you have tightened a screw, mark it with a white marker.</p> <p>Tightening torque: 45 Nm</p>  <p>xx1400001752</p>
6	Tighten the hex socket head cap screws M12x35.	Tightening torque: 125 Nm
7	Fit the covers.	


## 5 Repair

### 5.4 Replacing the ball bearing blocks

### 5.4 Replacing the ball bearing blocks

#### Location of ball bearing blocks

The figure below shows the location of the ball bearing blocks and other key parts:



xx140000459

Item	Name
A	Ball bearing blocks
B	Carriage bracket
C	linear guide
D	Mechanical stop
E	End cover




#### Required equipment

Equipment	Note
Ball bearings block	Spare part number is specified in <a href="#">Spare parts on page 279</a> .
Standard toolkit	The content is defined in <a href="#">Standard tools on page 270</a> .
Jack > 2t	
Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below.	These procedures include references to the tools required.

*Continues on next page*

Removing the ball bearing block

Use this procedure to remove the ball bearing block.



	Action	Illustration/Note
1	Remove the necessary carriage side cover, rack covers, the end cover (if present) and the mechanical stop.	
2	 <b>WARNING</b> Turn off all electric power and pneumatic pressure supplies to the robot and for IRT 510.	
3	Disconnect the lubrication tube connector for the ball bearing block.	 <p data-bbox="970 1220 1077 1243">xx1400001679</p> <p data-bbox="1005 1249 1348 1276">A Lubrication tube connector</p>
4	Use a jack to secure the height of the carriage plate (don't rise it more than 1 mm).   <b>WARNING</b> Rising the carriage more than 1 mm can seriously damage the remaining three ball bearing blocks.	

Continues on next page

## 5 Repair

### 5.4 Replacing the ball bearing blocks

Continued

	Action	Illustration/Note
5	Remove the screws and washers.	 <p data-bbox="938 651 1050 674">xx1400001701</p> <p data-bbox="975 680 1390 741">A Ø17xØ11x2 Washer, 3HAB4233-1 (8 pcs)</p> <p data-bbox="975 745 1406 801">B M10x30 Hex socket head cap screw, 3HAB3409-51 (8 pcs)</p>
6	Let the ball bearing block slide out of the bracket and linear guide.	 <p data-bbox="938 1171 1050 1193">xx1400001702</p>





### Refitting the ball bearing block

	Action	Illustration/Note
1	Remove the standard screws delivered with the block and replace with the grease pipe fitting taken from the old block.	

Continues on next page

5.4 Replacing the ball bearing blocks

*Continued*




	Action	Illustration/Note
2	<p>Insert the new ball bearing block (A) onto the rail meanwhile the black plastic protection (B) is pushed out.</p>	 <p>xx1400001704</p> <p>A Ball bearing block B Plastic protection</p> <p> <b>Note</b></p> <p>Do not remove the black plastic protection of the bearings until you slide the block onto the rail. They will come out automatically.</p> <p> <b>Note</b></p> <p>The fittings (B) must be on the inside of the carriage, and the machined reference surface (A) must be on the upper face of the block.</p>  <p>A Machined reference surface B Fittings C The other surface of the block has no reference line.</p>

*Continues on next page*

## 5 Repair

### 5.4 Replacing the ball bearing blocks

Continued


	Action	Illustration/Note
3	Let the bearings block slide into the bracket and tighten the screws and washers.	 <p data-bbox="943 651 1050 674">xx1400001701</p> <p data-bbox="975 685 1390 741">A Ø17xØ11x2 Washer, 3HAB4233-1 (8 pcs)</p> <p data-bbox="975 748 1406 804">B M10x30 Hex socket head cap screw, 3HAB3409-51 (8 pcs)</p> <p data-bbox="1011 810 1299 833">Tightening torque: 70 Nm</p>
4	Remove the jack.	
5	Reconnect the lubrication pipe connector to the fitting of the ball bearing block.	 <p data-bbox="943 1406 1050 1429">xx1400001679</p> <p data-bbox="975 1440 1310 1462">A Lubrication pipe connector</p>
6	Refit the mechanical stop and the covers.	
7	Calibrate the track if the ball bearing block at the drive unit bracket has been replaced.	See <a href="#">Fine calibration on page 256</a> .
8	 <p data-bbox="560 1630 667 1659"><b>DANGER</b></p> <p data-bbox="464 1693 933 1827">Make sure all safety requirements are met when performing the first test run. These are further detailed in the section <a href="#">Test run after installation, maintenance, or repair on page 140</a>.</p>	



## 5.5 Replacing the racks

### Location of the rack

The racks are located as shown in the figure.



xx140000461

A	Rack
---	------

### Required equipment

Equipment	Art. No.	Note
Rack		Spare part number is specified in <a href="#">Spare parts on page 279</a> .
Standard toolkit		The content is defined in <a href="#">Standard tools on page 270</a> .
Companion rack fix block	3HAC054531-001	
Companion rack	3HAC054532-001	
Rack clamping tool	3HAW107700357	
Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below.	-	These procedures include references to the tools required.

*Continues on next page*


## 5 Repair

### 5.5 Replacing the racks

*Continued*


#### Removing the racks

Use the procedure to remove the racks.




	Action	Illustration/Note
1	Remove the necessary carriage side cover, rack covers, the end cover (if present) and the mechanical stop.	
2	Remove screws and plain washers that hold the rack to the sections.	 <p data-bbox="995 891 1098 909">xx140000227</p> <ul style="list-style-type: none"> <li data-bbox="1027 922 1394 976">A M10x40 Hex socket head cap screw, 3HAB3409-50</li> <li data-bbox="1027 981 1315 1034">B Ø 17xØ 11x2 Washer, 3HAB4233-1</li> <li data-bbox="1027 1039 1123 1070">C Rack</li> </ul>

#### Refitting the racks

Use the procedure to refit the racks:

	Action	Illustration/Note
1	Fit the rack with the screws and washers. Do not tighten the screws yet.	 <p data-bbox="995 1637 1098 1655">xx140000227</p> <ul style="list-style-type: none"> <li data-bbox="1027 1668 1378 1722">A M10x40 hexagon head bolt, class 12.9</li> <li data-bbox="1027 1727 1299 1758">B Ø17xØ11x2 washers</li> <li data-bbox="1027 1762 1123 1794">C Rack</li> </ul>

*Continues on next page*

	Action	Illustration/Note
2	Fit the alignment tool to the section and the rack to make sure the racks are positioned correctly in vertical plane.	 <p>xx1400002156</p>
3	Fit the rack clamping tools at both ends of the rack to make sure that the racks are aligned with each other.	 <p>xx2200001171</p> <p>Rack clamping tool: 3HAW107700357</p>
4	Push the rack against the section mounting surface, make sure the alignments are correct and then tighten the screws one by one.	Tightening torque: 70 Nm
5	Loosen the screws of the rack located next to the replaced rack, fit the clamping tool to the junction in order to align the loosened rack to the rack located next to it and then re-tighten the screws. Repeat with following racks until all racks are aligned with each other.	
6	Once you have tightened a screw, mark it with a white marker.	 <p>xx1400001752</p>
7	Refit the covers.	


## 5 Repair

### 5.6 Replacing the mechanical stops

### 5.6 Replacing the mechanical stops

#### Location of mechanical stops

The mechanical stops are located at both end of the track. Two mechanical stops are used on each side of the track end to buffer the impact from the carriage if the carriage moves outside of the software limit of the track.



xx140000499

A	Mechanical stops, left
B	Mechanical stops, right


#### Required equipment

Equipment	Note
Mechanical stops	Spare part number is specified in <a href="#">Spare parts on page 279</a> .
Standard toolkit	The content is defined in <a href="#">Standard tools on page 270</a> .

*Continues on next page*


**Removing the mechanical stops**

Use this procedure to remove the mechanical stops.

	Action	Illustration/Note
1	If the mechanical stops (B) are damaged, remove the mechanical stop by removing hexagon nuts (A) and screws (C).	 <p>xx1400002686</p> <p>A M20 hexagon nut, 9ADA267-11            B Mechanical stop            C M20x100 Hex socket head cap screw, 3HAB3409-206</p>

**Refitting the mechanical stops**

Use this procedure to refit the mechanical stops.

	Action	Illustration/Note
1	Fit the screws (C) and nuts (A).	 <p>xx1400002686</p> <p>A M20 hexagon nut, 9ADA267-11            B Mechanical stop            C M20x100 Hex socket head cap screw, 3HAB3409-206            Tightening torque: 90 Nm</p>

## 5 Repair

### 5.7.1 Replacing the motor

## 5.7 Replacing the motor, gearbox and gear wheel


### 5.7.1 Replacing the motor

#### Location of motor and gear

Users can choose to change the whole geared motor unit to reduce down time or only change the malfunctioned gear or motor. It is recommended to have two technicians to work together.

To replace the motor and/or the gear, it is possible to remove the motor bracket from the top plate and then push the carriage away. It is recommended to have two technicians to work together.

The figure below shows how to push the carriage away from the motor bracket and expose the motor, gearbox, gear wheel, felt gear and cable chain connection point. This makes the following components accessible for maintenance:






xx1400002684

Item	Name
A	Cable chain - remains stationery
B	Motor - remains stationery
C	Carriage - pushed away
D	Motor bracket - remains stationery
E	Gear wheel - remains stationery
F	Felt gear - remains stationery
G	Gearbox - remains stationery

*Continues on next page*

Required equipment

Equipment	Art. No.	Note
Standard toolkit	-	The content is defined in <a href="#">Standard tools on page 270</a> .
Torque wrench	-	The tightening torque of the M10x40 hex socket head cap screw that secure the gear to the bracket is 70 Nm. There are also specific tightening torques for the motor shaft and gear assembly. See the details in maintenance instructions.
M6 screws of different lengths. For example: M6x10, M6x15, M6x35 1 thick washer inside diameter 6 mm 1 spacer 30 mm long, inside diameter no smaller than the pin diameter (10 mm), and outside diameter no bigger than the thick washer outside diameter.	-	For the cylindrical pin extraction. The following figures are for your reference about how to use the equipment.  xx150000635  xx150000636  xx150000637

Continues on next page



## 5 Repair

### 5.7.1 Replacing the motor


*Continued*

#### Removing the motor

##### Preparation






	Action	Illustration/Note
1	 <b>WARNING</b> Turn off all electric power and pneumatic pressure supplies to the robot and for IRT 510.	
2	Remove the side cover of the carriage.	 xx1400001587 <b>A</b> M6x12 Screw DIN6921, 9ADA181-11 (4 pcs)

##### Loosening the carriage from the drive train bracket

	Action	Illustration/Note
1	Remove the bracket for brake release. Cut the cable ties that secure the brake release cables.	
2	Loosen the screws. Use a ratchet wrench.	 xx1400001588 <b>A</b> M12x40 Hex socket head cap screws, 3HAB3409-67 (4 pcs)

*Continues on next page*






	Action	Illustration/Note
3	<p>Extraction of the cylindrical pin: Place the spacer on the cylindrical pin, insert the longest screw with the thick washer and screw it to start extracting the pin. Use shorter screws when necessary.</p>	 <p>xx1400001589</p> <p>A 10x32 cylindrical pin</p> <p>For details about how to use the equipment for cylindrical pin extraction, see <a href="#">Required equipment on page 183</a>.</p>
4	<p>Stop when the cylindrical pin is extracted from the top plate.</p> <p> <b>Note</b></p> <p>It is not necessary to extract the pin from the bracket.</p>	 <p>xx1400001590</p> <p>A <math>\Phi</math>10x32 cylindrical pin with threaded hole, 3HAC043986-001</p>
5	<p>Remove the screws and plain washers. Use a ratchet wrench.</p>	 <p>xx1400001591</p> <p>A M12x40 Hex socket head cap screw, 3HAB3409-67 (4 pcs)</p> <p>B <math>\text{\O}</math>21x<math>\text{\O}</math>13x2 Washer, 3HAA1001-632 (4 pcs)</p>
6	<p>Disconnect the lubrication tube from the fitting of the ball bearing block to release the tube from the drive train bracket (the tube will be pushed away along with the carriage).</p>	 <p>xx1400001592</p> <p>A Lubrication tube connector</p>

Continues on next page


## 5 Repair

### 5.7.1 Replacing the motor




Continued

	Action	Illustration/Note
7	<p>Disconnect the lubrication tube connector from the fitting of the pinion (the tube will be pushed away along with the carriage). Remove the top cover if necessary.</p>	 <p>xx1400001596</p> <p><b>A</b> Lubrication tube connector</p>
8	<p>Disconnect the cables from the tooling or robot fitted on the carriage. Remove the upper part of the cable tray so that the connectors can pass through.</p>	 <p>xx1400001593</p>
9	<p>Push the carriage away from the drive train bracket. The bracket, gear and pinion, motor, cable chain support and cable chain, stay stationary.</p>	 <p><b>Note</b></p> <p>Pay attention to the cables and their connectors: You must guide them through the cable tray while you push the carriage away.</p>

### Removing the drive train

	Action	Illustration/Note
1	<p>Remove the covers above the drive train.</p>	 <p>xx1400000231</p>

Continues on next page




	Action	Illustration/Note
2	The drive train is now accessible.	 <p>xx1400001610</p> <ul style="list-style-type: none"> <li>A Motor</li> <li>B Gear</li> <li>C Cable chain connection plate</li> <li>D Motor bracket</li> <li>E Pinion</li> </ul>
3	Fit two eye bolts on the drive train for lifting.	 <p>xx1400001626</p> <ul style="list-style-type: none"> <li>A M8 eye bolt (2 pcs)</li> </ul>
4	Disconnect the power and resolver connectors from the motor. Guide the cables in the tray area.	 <p>xx1400001625</p>

Continues on next page

## 5 Repair



### 5.7.1 Replacing the motor

Continued

	Action	Illustration/Note
5	For the mirrored cable chain orientation, remove the cable chain support by removing the two screws.	 <p>xx1400002143</p>
6	Remove all but two of the drive train installation screws and plain washers.	
7	Attach lifting chains to the eye bolts and unload the weight of the drive train using an overhead crane.	
8	Remove the remaining two screws from the drive train.	
9	<p>Remove the drive train from the bracket.</p> <p> <b>CAUTION</b></p> <p>The drive train weighs 33 kg. All lifting accessories used must be sized accordingly!</p>	 <p>xx1400001627</p> <p>A Ø 17xØ 11x2 washer, 3HAB4233-1 B M10x40 hex socket head cap installation screw, 3HAB3409-50 C Cable chain support</p>

Continues on next page

Removing the motor

	Action	Illustration/Note
1	Place the removed drive train in a vertical position, with the driving side facing downwards.	 <p>xx1400001628</p>
2	Remove the motor by unscrewing the screws and removing washers.	 <p>xx1400001639</p> <p>A M8x30 Hex socket head cap screw, 9ADA183-38 (4 pcs) B Ø13xØ8.4x1.6 plain washer, 9ADA312-7 (4 pcs)</p>

Continues on next page




## 5 Repair

### 5.7.1 Replacing the motor


Continued

#### Refitting the motor





#### Refitting the motor

	Action	Illustration/Note
1	<p>Fit the new motor on the gearbox unit with screws and washers.</p> <p> <b>Tip</b></p> <p>The motor integrates the driving pinion (article No. 3HAC047333-001) and O-ring (article No. 3HAB3772-110) as a complete spare part.</p>	 <p>xx1400001639</p> <p><b>A</b> M8x30 hex socket head cap screws, 9ADA183-38 (4 pcs). Tightening torque: 15 Nm</p> <p><b>B</b> Ø13xØ8.4x1.6 plain washer, 9ADA312-7 (4 pcs)</p> <p> <b>Note</b></p> <p>The correct orientation of the motor is with the connectors pointing outwards, as shown in the figure.</p>

#### Refitting the drive train

	Action	Illustration/Note
1	<p>Fit the locating cylindrical pin to the motor using a rubber mallet. Insert it completely.</p>	 <p>xx1400001637</p> <p><b>A</b> Ø10x32 Cylindrical pin with threaded hole, 3HAC043986-001</p>

Continues on next page

	Action	Illustration/Note
2	<p> <b>CAUTION</b></p> <p>The motor weighs 11 kg. All lifting accessories used must be sized accordingly!</p> <p>Attach the lifting chains to the eye bolts on the motor and lift the motor into position on the track with guidance from the locating cylindrical pin.</p>	
3	<p>Fit the drive train on the drive train bracket with the screws and plain washers.</p> <p> <b>Note</b></p> <p>Do not tighten the screws yet.</p>	 <p>xx1400001627</p> <p>A Ø 17xØ 11x2 washer, 3HAB4233-1</p> <p>B M10x40 hex socket head cap installation screw, 3HAB3409-50 (8 pcs)</p> <p>C Cable chain support</p>
4	<p>Adjust the backlash of the gear motor. For how to adjust the gear motor backlash, see <a href="#">Adjusting the gearbox backlash on page 219</a>.</p>	
5	<p>Tighten the screws and plain washers in sequence shown in the illustration.</p>	 <p>xx1400001630</p> <p>Tightening torque: 70 Nm</p>
6	<p>For the mirrored cable chain orientation, refit the cable chain support with two screws.</p>	
7	<p>Reconnect the power and signal cables to the motor.</p>	





Continues on next page

## 5 Repair

### 5.7.1 Replacing the motor



Continued

#### Reinstalling the carriage to the drive train bracket

	Action	Illustration/Note
1	Push the carriage back above the drive train.	
2	Fit the carriage to the drive train bracket with the screws.   <b>Note</b>  Do not tighten the screws yet.	  <small>xx1400001588</small>  <b>A M12x40 Hex socket head cap screws, 3HAB3409-67 (4 pcs)</b>
3	Adjust the position of the carriage until the cylindrical pin in the 10 mm positioning hole of the drive train bracket can be inserted into the positioning hole in the top plate of the carriage.	  <small>xx1400001589</small>  <b>A Ø10x32 Cylindrical pin with threaded hole, 3HAC043986-001</b>
4	Tighten the screws.	Tightening torque: 100 Nm
5	Connect the lubrication tube connectors of the ball bearing block.	  <small>xx1400001592</small>  <b>A Lubrication tube connector</b>

Continues on next page



	Action	Illustration/Note
6	Connect the lubrication tube connector of the pinion.	 <p>xx1400001596</p> <p><b>A</b> Lubrication tube connector</p>
7	Connect the cables from the tooling or robot fitted on the carriage. If necessary, remove the upper part of the cable tray so that the connectors can pass through.	
8	Refit the bracket for brake release and secure brake release cables with cable ties.	
9	Refit the side cover of the carriage.	 <p>xx1400001587</p> <p><b>A</b> M6x12 Screw DIN6921, 9ADA181-11 (4 pcs)</p>
10	Refit the top cover.	

## 5 Repair

### 5.7.2 Replacing the gearbox


#### 5.7.2 Replacing the gearbox

##### Location of motor and gear

Users can choose to change the whole geared motor unit to reduce down time or only change the malfunctioned gear or motor. It is recommended to have two technicians to work together.

To replace the motor and/or the gear, it is possible to remove the motor bracket from the top plate and then push the carriage away. It is recommended to have two technicians to work together.

The figure below shows how to push the carriage away from the motor bracket and expose the motor, gearbox, gear wheel, felt gear and cable chain connection point. This makes the following components accessible for maintenance:






xx1400002684

Item	Name
A	Cable chain - remains stationery
B	Motor - remains stationery
C	Carriage - pushed away
D	Motor bracket - remains stationery
E	Gear wheel - remains stationery
F	Felt gear - remains stationery
G	Gearbox - remains stationery

##### Required equipment

Equipment	Art. No.	Note
Standard toolkit	-	The content is defined in <a href="#">Standard tools on page 270</a> .

*Continues on next page*

Equipment	Art. No.	Note
Torque wrench	-	<p>The tightening torque of the M10x40 hex socket head cap screw that secure the gear to the bracket is 70 Nm.</p> <p>There are also specific tightening torques for the motor shaft and gear assembly. See the details in maintenance instructions.</p>
<p>M6 screws of different lengths. For example: M6x10, M6x15, M6x35</p> <p>1 thick washer inside diameter 6 mm</p> <p>1 spacer 30 mm long, inside diameter no smaller than the pin diameter (10 mm), and outside diameter no bigger that the thick washer outside diameter.</p>	-	<p>For the cylindrical pin extraction. The following figures are for your reference about how to use the equipment.</p>  <p>xx150000635</p>  <p>xx150000636</p>  <p>xx150000637</p>

Continues on next page



## 5 Repair

### 5.7.2 Replacing the gearbox


*Continued*

#### Removing the gearbox






##### Preparation

	Action	Illustration/Note
1	 <b>WARNING</b> Turn off all electric power and pneumatic pressure supplies to the robot and for IRT 510.	
2	Remove the side cover of the carriage.	 <p>xx1400001587</p> <p>A M6x12 Screw DIN6921, 9ADA181-11 (4 pcs)</p>

##### Loosening the carriage from the drive train bracket

	Action	Illustration/Note
1	Remove the bracket for brake release. Cut the cable ties that secure the brake release cables.	
2	Loosen the screws. Use a ratchet wrench.	 <p>xx1400001588</p> <p>A M12x40 Hex socket head cap screws, 3HAB3409-67 (4 pcs)</p>

*Continues on next page*




	Action	Illustration/Note
3	<p>Extraction of the cylindrical pin: Place the spacer on the cylindrical pin, insert the longest screw with the thick washer and screw it to start extracting the pin. Use shorter screws when necessary.</p>	 <p>xx1400001589</p> <p>A 10x32 cylindrical pin</p> <p>For details about how to use the equipment for cylindrical pin extraction, see <a href="#">Required equipment on page 194</a>.</p>
4	<p>Stop when the cylindrical pin is extracted from the top plate.</p> <p> <b>Note</b></p> <p>It is not necessary to extract the pin from the bracket.</p>	 <p>xx1400001590</p> <p>A <math>\Phi</math>10x32 cylindrical pin with threaded hole, 3HAC043986-001</p>
5	<p>Remove the screws and plain washers. Use a ratchet wrench.</p>	 <p>xx1400001591</p> <p>A M12x40 Hex socket head cap screw, 3HAB3409-67 (4 pcs)</p> <p>B <math>\varnothing</math>21x<math>\varnothing</math>13x2 Washer, 3HAA1001-632 (4 pcs)</p>
6	<p>Disconnect the lubrication tube from the fitting of the ball bearing block to release the tube from the drive train bracket (the tube will be pushed away along with the carriage).</p>	 <p>xx1400001592</p> <p>A Lubrication tube connector</p>

Continues on next page


## 5 Repair

### 5.7.2 Replacing the gearbox




Continued

	Action	Illustration/Note
7	<p>Disconnect the lubrication tube connector from the fitting of the pinion (the tube will be pushed away along with the carriage). Remove the top cover if necessary.</p>	 <p>xx1400001596</p> <p><b>A</b> Lubrication tube connector</p>
8	<p>Disconnect the cables from the tooling or robot fitted on the carriage. Remove the upper part of the cable tray so that the connectors can pass through.</p>	 <p>xx1400001593</p>
9	<p>Push the carriage away from the drive train bracket. The bracket, gear and pinion, motor, cable chain support and cable chain, stay stationary.</p>	 <p><b>Note</b></p> <p>Pay attention to the cables and their connectors: You must guide them through the cable tray while you push the carriage away.</p>

### Removing the drive train

	Action	Illustration/Note
1	<p>Remove the covers above the drive train.</p>	 <p>xx1400000231</p>

Continues on next page




	Action	Illustration/Note
2	The drive train is now accessible.	 <p>xx1400001610</p> <ul style="list-style-type: none"> <li>A Motor</li> <li>B Gear</li> <li>C Cable chain connection plate</li> <li>D Motor bracket</li> <li>E Pinion</li> </ul>
3	Fit two eye bolts on the drive train for lifting.	 <p>xx1400001626</p> <ul style="list-style-type: none"> <li>A M8 eye bolt (2 pcs)</li> </ul>
4	Disconnect the power and resolver connectors from the motor. Guide the cables in the tray area.	 <p>xx1400001625</p>

Continues on next page

## 5 Repair

### 5.7.2 Replacing the gearbox



Continued

	Action	Illustration/Note
5	For the mirrored cable chain orientation, remove the cable chain support by removing the two screws.	 <p>xx1400002143</p>
6	Remove all but two of the drive train installation screws and plain washers.	
7	Attach lifting chains to the eye bolts and unload the weight of the drive train using an overhead crane.	
8	Remove the remaining two screws from the drive train.	
9	<p>Remove the drive train from the bracket.</p> <p> <b>CAUTION</b></p> <p>The drive train weighs 33 kg. All lifting accessories used must be sized accordingly!</p>	 <p>xx1400001627</p> <p>A Ø 17xØ 11x2 washer, 3HAB4233-1            B M10x40 hex socket head cap installation screw, 3HAB3409-50            C Cable chain support</p>

Continues on next page



Removing the gearbox

	Action	Illustration/Note
1	Place the removed drive train in a vertical position, with the driving side facing downwards.	 <p>xx1400001628</p>
2	Remove the motor by unscrewing the four M8x30 hex socket head cap screws (Art. No. 9ADA183-38).	 <p>xx1400001639</p>

Refitting the gearbox

Refitting the gearbox



	Action	Illustration/Note
1	Inject lubricant into the gearbox until it is filled.	

Continues on next page



## 5 Repair

### 5.7.2 Replacing the gearbox




Continued

	Action	Illustration/Note
2	<p>Fit the motor to the new gearbox with screws and washers.</p> <p> <b>Tip</b></p> <p>The motor integrates with the driving pinion and O-ring as a complete spare part.</p>	 <p>xx1400001639</p> <p><b>A</b> M8x30 M8x30 hex socket head cap screw, 9ADA183-38</p> <p><b>B</b> 13x8.4x1.6 washer, 9ADA312-7</p> <p>Tightening torque: 24 Nm</p>

### Refitting the drive train

	Action	Illustration/Note
1	<p>Fit the locating cylindrical pin to the motor using a rubber mallet. Insert it completely.</p>	 <p>xx1400001637</p> <p><b>A</b> Ø10x32 Cylindrical pin with threaded hole, 3HAC043986-001</p>
2	<p> <b>CAUTION</b></p> <p>The motor weighs 11 kg. All lifting accessories used must be sized accordingly!</p> <p>Attach the lifting chains to the eye bolts on the motor and lift the motor into position on the track with guidance from the locating cylindrical pin.</p>	

Continues on next page

	Action	Illustration/Note
3	<p>Fit the drive train on the drive train bracket with the screws and plain washers.</p> <p> <b>Note</b> Do not tighten the screws yet.</p>	 <p>xx1400001627</p> <p>A Ø 17xØ 11x2 washer, 3HAB4233-1 B M10x40 hex socket head cap installation screw, 3HAB3409-50 (8 pcs) C Cable chain support</p>
4	<p>Adjust the backlash of the gear motor. For how to adjust the gear motor backlash, see <a href="#">Adjusting the gearbox backlash on page 219</a>.</p>	
5	<p>Tighten the screws and plain washers in sequence shown in the illustration.</p>	 <p>xx1400001630</p> <p>Tightening torque: 70 Nm</p>
6	<p>For the mirrored cable chain orientation, refit the cable chain support with two screws.</p>	
7	<p>Reconnect the power and signal cables to the motor.</p>	

Reinstalling the carriage to the drive train bracket






	Action	Illustration/Note
1	<p>Push the carriage back above the drive train.</p>	

Continues on next page


## 5 Repair

### 5.7.2 Replacing the gearbox

Continued

	Action	Illustration/Note
2	Fit the carriage to the drive train bracket with the screws.   <b>Note</b>  Do not tighten the screws yet.	 <p>xx1400001588</p> <p><b>A</b> M12x40 Hex socket head cap screws, 3HAB3409-67 (4 pcs)</p>
3	Adjust the position of the carriage until the cylindrical pin in the 10 mm positioning hole of the drive train bracket can be inserted into the positioning hole in the top plate of the carriage.	 <p>xx1400001589</p> <p><b>A</b> Ø10x32 Cylindrical pin with threaded hole, 3HAC043986-001</p>
4	Tighten the screws.	Tightening torque: 100 Nm
5	Connect the lubrication tube connectors of the ball bearing block.	 <p>xx1400001592</p> <p><b>A</b> Lubrication tube connector</p>
6	Connect the lubrication tube connector of the pinion.	 <p>xx1400001596</p> <p><b>A</b> Lubrication tube connector</p>

Continues on next page

	<b>Action</b>	<b>Illustration/Note</b>
7	<p>Connect the cables from the tooling or robot fitted on the carriage.</p> <p>If necessary, remove the upper part of the cable tray so that the connectors can pass through.</p>	
8	<p>Refit the bracket for brake release and secure brake release cables with cable ties.</p>	
9	<p>Refit the side cover of the carriage.</p>	 <p>xx1400001587</p> <p><b>A M6x12 Screw DIN6921, 9ADA181-11 (4 pcs)</b></p>
10	<p>Refit the top cover.</p>	

## 5 Repair

### 5.7.3 Replacing the gear wheel


### 5.7.3 Replacing the gear wheel

#### Location of motor and gear

Users can choose to change the whole geared motor unit to reduce down time or only change the malfunctioned gear or motor. It is recommended to have two technicians to work together.

To replace the motor and/or the gear, it is possible to remove the motor bracket from the top plate and then push the carriage away. It is recommended to have two technicians to work together.

The figure below shows how to push the carriage away from the motor bracket and expose the motor, gearbox, gear wheel, felt gear and cable chain connection point. This makes the following components accessible for maintenance:






xx1400002684

Item	Name
A	Cable chain - remains stationery
B	Motor - remains stationery
C	Carriage - pushed away
D	Motor bracket - remains stationery
E	Gear wheel - remains stationery
F	Felt gear - remains stationery
G	Gearbox - remains stationery

#### Required equipment

Equipment	Art. No.	Note
Standard toolkit	-	The content is defined in <a href="#">Standard tools on page 270</a> .

*Continues on next page*

Equipment	Art. No.	Note
Torque wrench	-	<p>The tightening torque of the M10x40 hex socket head cap screw that secure the gear to the bracket is 70 Nm.</p> <p>There are also specific tightening torques for the motor shaft and gear assembly. See the details in maintenance instructions.</p>
<p>M6 screws of different lengths. For example: M6x10, M6x15, M6x35</p> <p>1 thick washer inside diameter 6 mm</p> <p>1 spacer 30 mm long, inside diameter no smaller than the pin diameter (10 mm), and outside diameter no bigger that the thick washer outside diameter.</p>	-	<p>For the cylindrical pin extraction. The following figures are for your reference about how to use the equipment.</p>  <p>xx150000635</p>  <p>xx150000636</p>  <p>xx150000637</p>

Continues on next page



## 5 Repair

### 5.7.3 Replacing the gear wheel


*Continued*

#### Removing the gear wheel

##### Preparation






	Action	Illustration/Note
1	 <b>WARNING</b> Turn off all electric power and pneumatic pressure supplies to the robot and for IRT 510.	
2	Remove the side cover of the carriage.	 xx1400001587 <b>A</b> M6x12 Screw DIN6921, 9ADA181-11 (4 pcs)

##### Loosening the carriage from the drive train bracket

	Action	Illustration/Note
1	Remove the bracket for brake release. Cut the cable ties that secure the brake release cables.	
2	Loosen the screws. Use a ratchet wrench.	 xx1400001588 <b>A</b> M12x40 Hex socket head cap screws, 3HAB3409-67 (4 pcs)

*Continues on next page*






	Action	Illustration/Note
3	<p>Extraction of the cylindrical pin: Place the spacer on the cylindrical pin, insert the longest screw with the thick washer and screw it to start extracting the pin. Use shorter screws when necessary.</p>	 <p>xx1400001589</p> <p>A 10x32 cylindrical pin</p> <p>For details about how to use the equipment for cylindrical pin extraction, see <a href="#">Required equipment on page 206</a>.</p>
4	<p>Stop when the cylindrical pin is extracted from the top plate.</p> <p> <b>Note</b></p> <p>It is not necessary to extract the pin from the bracket.</p>	 <p>xx1400001590</p> <p>A <math>\Phi</math>10x32 cylindrical pin with threaded hole, 3HAC043986-001</p>
5	<p>Remove the screws and plain washers. Use a ratchet wrench.</p>	 <p>xx1400001591</p> <p>A M12x40 Hex socket head cap screw, 3HAB3409-67 (4 pcs)</p> <p>B <math>\text{Ø}21 \times \text{Ø}13 \times 2</math> Washer, 3HAA1001-632 (4 pcs)</p>
6	<p>Disconnect the lubrication tube from the fitting of the ball bearing block to release the tube from the drive train bracket (the tube will be pushed away along with the carriage).</p>	 <p>xx1400001592</p> <p>A Lubrication tube connector</p>

Continues on next page


## 5 Repair

### 5.7.3 Replacing the gear wheel




Continued

	Action	Illustration/Note
7	<p>Disconnect the lubrication tube connector from the fitting of the pinion (the tube will be pushed away along with the carriage). Remove the top cover if necessary.</p>	 <p>xx1400001596</p> <p><b>A</b> Lubrication tube connector</p>
8	<p>Disconnect the cables from the tooling or robot fitted on the carriage. Remove the upper part of the cable tray so that the connectors can pass through.</p>	 <p>xx1400001593</p>
9	<p>Push the carriage away from the drive train bracket. The bracket, gear and pinion, motor, cable chain support and cable chain, stay stationary.</p>	 <p><b>Note</b></p> <p>Pay attention to the cables and their connectors: You must guide them through the cable tray while you push the carriage away.</p>

### Removing the drive train

	Action	Illustration/Note
1	<p>Remove the covers above the drive train.</p>	 <p>xx1400000231</p>

Continues on next page




	Action	Illustration/Note
2	The drive train is now accessible.	 <p>xx1400001610</p> <ul style="list-style-type: none"> <li>A Motor</li> <li>B Gear</li> <li>C Cable chain connection plate</li> <li>D Motor bracket</li> <li>E Pinion</li> </ul>
3	Fit two eye bolts on the drive train for lifting.	 <p>xx1400001626</p> <ul style="list-style-type: none"> <li>A M8 eye bolt (2 pcs)</li> </ul>
4	Disconnect the power and resolver connectors from the motor. Guide the cables in the tray area.	 <p>xx1400001625</p>

Continues on next page

## 5 Repair



### 5.7.3 Replacing the gear wheel

Continued

	Action	Illustration/Note
5	For the mirrored cable chain orientation, remove the cable chain support by removing the two screws.	 <p>xx1400002143</p>
6	Remove all but two of the drive train installation screws and plain washers.	
7	Attach lifting chains to the eye bolts and unload the weight of the drive train using an overhead crane.	
8	Remove the remaining two screws from the drive train.	
9	<p>Remove the drive train from the bracket.</p> <p> <b>CAUTION</b></p> <p>The drive train weighs 33 kg. All lifting accessories used must be sized accordingly!</p>	 <p>xx1400001627</p> <p>A Ø 17xØ 11x2 washer, 3HAB4233-1 B M10x40 hex socket head cap installation screw, 3HAB3409-50 C Cable chain support</p>

Continues on next page

Removing the motor

	Action	Illustration/Note
1	Place the removed drive train in a vertical position, with the driving side facing downwards.	 <p>xx1400001628</p>
2	Remove the motor by unscrewing the screws and removing washers.	 <p>xx1400001639</p> <p>A M8x30 Hex socket head cap screw, 9ADA183-38 (4 pcs) B Ø13xØ8.4x1.6 plain washer, 9ADA312-7 (4 pcs)</p>


Continues on next page

## 5 Repair

### 5.7.3 Replacing the gear wheel


*Continued*

#### Removing the gear wheel

	Action	Illustration/Note
1	Remove the screws from gear wheel.	 <p data-bbox="986 757 1093 779">xx1400002644</p> <p data-bbox="1018 788 1388 846">A M10x35 Hex socket head cap screw, 3HAB3409-52</p> <p data-bbox="1018 851 1388 900">B Pinion on rack, 3HAC047375-001</p>




#### Refitting the gear wheel

#### Refitting the gear wheel

	Action	Illustration/Note
1	Tighten the screws.	 <p data-bbox="790 1608 896 1630">xx1400002645</p> <p data-bbox="821 1639 1396 1697">A M10x35 Hex socket head cap screw, 3HAB3409-52</p> <p data-bbox="858 1702 1145 1729">Tightening torque: 70 Nm</p> <p data-bbox="821 1733 1228 1760">B Pinion on rack, 3HAC047375-001</p>

*Continues on next page*

Refitting the motor

	Action	Illustration/Note
1	<p>Fit the new motor on the gearbox unit with screws and washers.</p> <p> <b>Tip</b></p> <p>The motor integrates the driving pinion (article No. 3HAC047333-001) and O-ring (article No. 3HAB3772-110) as a complete spare part.</p>	 <p>xx1400001639</p> <p><b>A</b> M8x30 hex socket head cap screws, 9ADA183-38 (4 pcs). Tightening torque: 15 Nm</p> <p><b>B</b> Ø13xØ8.4x1.6 plain washer, 9ADA312-7 (4 pcs)</p> <p> <b>Note</b></p> <p>The correct orientation of the motor is with the connectors pointing outwards, as shown in the figure.</p>




Continues on next page

## 5 Repair



### 5.7.3 Replacing the gear wheel

Continued

#### Refitting the motor

	Action	Illustration/Note
1	<p>Fit the new motor on the gearbox unit with screws and washers.</p> <p> <b>Tip</b></p> <p>The motor integrates the driving pinion (article No. 3HAC047333-001) and O-ring (article No. 3HAB3772-110) as a complete spare part.</p>	 <p>xx1400001639</p> <p><b>A</b> M8x30 hex socket head cap screws, 9ADA183-38 (4 pcs). Tightening torque: 15 Nm</p> <p><b>B</b> Ø13xØ8.4x1.6 plain washer, 9ADA312-7 (4 pcs)</p> <p> <b>Note</b></p> <p>The correct orientation of the motor is with the connectors pointing outwards, as shown in the figure.</p>




#### Reinstalling the carriage to the drive train bracket

	Action	Illustration/Note
1	Push the carriage back above the drive train.	
2	<p>Fit the carriage to the drive train bracket with the screws.</p> <p> <b>Note</b></p> <p>Do not tighten the screws yet.</p>	 <p>xx1400001588</p> <p><b>A</b> M12x40 Hex socket head cap screws, 3HAB3409-67 (4 pcs)</p>

Continues on next page



5.7.3 Replacing the gear wheel  
Continued


	Action	Illustration/Note
3	Adjust the position of the carriage until the cylindrical pin in the 10 mm positioning hole of the drive train bracket can be inserted into the positioning hole in the top plate of the carriage.	 <p>xx1400001589</p> <p>A Ø10x32 Cylindrical pin with threaded hole, 3HAC043986-001</p>
4	Tighten the screws.	Tightening torque: 100 Nm
5	Connect the lubrication tube connectors of the ball bearing block.	 <p>xx1400001592</p> <p>A Lubrication tube connector</p>
6	Connect the lubrication tube connector of the pinion.	 <p>xx1400001596</p> <p>A Lubrication tube connector</p>
7	Connect the cables from the tooling or robot fitted on the carriage. If necessary, remove the upper part of the cable tray so that the connectors can pass through.	
8	Refit the bracket for brake release and secure brake release cables with cable ties.	

Continues on next page

## 5 Repair


### 5.7.3 Replacing the gear wheel

Continued

	Action	Illustration/Note
9	Refit the side cover of the carriage.	 <p>xx1400001587</p> <p>A M6x12 Screw DIN6921, 9ADA181-11 (4 pcs)</p>
10	Refit the top cover.	

### 5.8 Adjusting the gearbox backlash

#### Required equipment

Equipment	Art. No.	Illustration
Backlash adjustment tool	3HAC054528-001	


#### Adjusting the gearbox backlash

Use this procedure to adjust the gearbox backlash.



**Note**

All fixing screws of the gearbox must be loosened before adjusting the backlash.





Action	Illustration/Note
1 Tighten the locking screws (A), (B) and (C).	 <p>xx1400001661</p> <ul style="list-style-type: none"> <li>A Locking screw</li> <li>B Locking screw</li> <li>C Locking screw</li> </ul> <p>Tightening torque: 70 Nm</p>

*Continues on next page*

## 5 Repair





### 5.8 Adjusting the gearbox backlash

Continued

	Action	Illustration/Note
2	Push the carriage by hand until the gear wheel is in contact with the next cog on the gear rack.	 <p>xx1400001631 X+ direction</p>
3	Fit the indicator clock until the tip of the indicator (B) is in vertical contact with the gear motor unit.	 <p>xx1400001632 A Reset button B Tip of the indicator</p>
4	Reset the indicator clock by pressing the reset button (A).	
5	Push the carriage or the drive unit by hand in the opposite direction until the gear wheel is in contact with the next cog on the gear rack.	 <p>xx1400001633 X- direction</p>
6	Check the reading on the indicator clock.	 <b>Note</b> The indicator should show data between 0.07-0.13 mm.
7	Push the carriage 1000 mm.	X+ direction
8	Continue with step 2 to step 7.	

Continues on next page

5.8 Adjusting the gearbox backlash  
Continued


	Action	Illustration/Note
9	If the gap is OK, tighten the locking screws (A), (B) and (C) in figure.	 <p>xx1400001661</p> <p>A Locking screw B Locking screw C Locking screw</p> <p>Tightening torque: 70 Nm</p>
10	If the gap is not OK, loosen locking screws (A), (B) and (C) to adjust the gear motor using the adjustment tool. Then repeat step 1 to step .	 <p>xx1500000406</p> <p>A Pinion far from rack B Pinion close to rack</p> <p> <b>Tip</b></p> <p>If the data is too large, lift the gear motor a little and then secure the three lock screws. If the data is too small, lower the gear motor a little and then secure the three lock screws.</p> <p> <b>Note</b></p> <p>During adjustment, note that the cable chain should be assembled and cables to motor should be connected.</p>

Continues on next page

## 5 Repair

### 5.8 Adjusting the gearbox backlash

Continued

	Action	Illustration/Note
11	Tighten all the screws and plain washer in a spread sequence.	 <p data-bbox="991 685 1098 703">xx1400001630</p> <p data-bbox="1026 719 1390 770">A M10x40 Hex socket head cap screw, 3HAB3409-50</p> <p data-bbox="1026 777 1294 828">B Ø17xØ11x2 Washer, 3HAB4233-1</p> <p data-bbox="991 837 1273 864">Tightening torque: 70 Nm</p>
12	Calibrate the track. Use previously measured reference values for the zero position.	See <a href="#">Fine calibration on page 256</a> .

## 5.9 Replacing the felt gear


### 5.9.1 Replacing the felt gear

#### Location of motor and gear

Users can choose to change the whole geared motor unit to reduce down time or only change the malfunctioned gear or motor. It is recommended to have two technicians to work together.

To replace the motor and/or the gear, it is possible to remove the motor bracket from the top plate and then push the carriage away. It is recommended to have two technicians to work together.

The figure below shows how to push the carriage away from the motor bracket and expose the motor, gearbox, gear wheel, felt gear and cable chain connection point. This makes the following components accessible for maintenance:



xx1400002684

Item	Name
A	Cable chain - remains stationary
B	Motor - remains stationary
C	Carriage - pushed away
D	Motor bracket - remains stationary
E	Gear wheel - remains stationary
F	Felt gear - remains stationary
G	Gearbox - remains stationary




*Continues on next page*

## 5 Repair

### 5.9.1 Replacing the felt gear

*Continued*

#### Required equipment



Equipment	Art. No.	Note
Standard toolkit	-	The content is defined in <a href="#">Standard tools on page 270</a> .
Torque wrench	-	The tightening torque of the M10x40 hex socket head cap screw that secure the gear to the bracket is 70 Nm. There are also specific tightening torques for the motor shaft and gear assembly. See the details in maintenance instructions.
M6 screws of different lengths. For example: M6x10, M6x15, M6x35 1 thick washer inside diameter 6 mm 1 spacer 30 mm long, inside diameter no smaller than the pin diameter (10 mm), and outside diameter no bigger than the thick washer outside diameter.	-	For the cylindrical pin extraction. The following figures are for your reference about how to use the equipment.  xx150000635  xx150000636  xx150000637

*Continues on next page*




Removing the felt gear

Preparation

	Action	Illustration/Note
1	 <b>WARNING</b> Turn off all electric power and pneumatic pressure supplies to the robot and for IRT 510.	
2	Remove the side cover of the carriage.	 <p>xx1400001587</p> <p>A M6x12 Screw DIN6921, 9ADA181-11 (4 pcs)</p>

Loosening the carriage from the drive train bracket





	Action	Illustration/Note
1	Remove the bracket for brake release. Cut the cable ties that secure the brake release cables.	
2	Loosen the screws. Use a ratchet wrench.	 <p>xx1400001588</p> <p>A M12x40 Hex socket head cap screws, 3HAB3409-67 (4 pcs)</p>

Continues on next page





## 5 Repair

### 5.9.1 Replacing the felt gear

Continued

	Action	Illustration/Note
3	<p>Extraction of the cylindrical pin:</p> <p>Place the spacer on the cylindrical pin, insert the longest screw with the thick washer and screw it to start extracting the pin.</p> <p>Use shorter screws when necessary.</p>	 <p>xx2400001005</p> <p>A 10x32 cylindrical pin</p> <p>For details about how to use the equipment for cylindrical pin extraction, see <a href="#">Required equipment on page 224</a>.</p>
4	<p>Stop when the cylindrical pin is extracted from the top plate.</p> <p> <b>Note</b></p> <p>It is not necessary to extract the pin from the bracket.</p>	 <p>xx1400001590</p> <p>A <math>\Phi</math>10x32 cylindrical pin with threaded hole, 3HAC043986-001</p>
5	<p>Remove the screws and plain washers.</p> <p>Use a ratchet wrench.</p>	 <p>xx1400001591</p> <p>A M12x40 Hex socket head cap screw, 3HAB3409-67 (4 pcs)</p> <p>B <math>\Phi</math>21x<math>\Phi</math>13x2 Washer, 3HAA1001-632 (4 pcs)</p>

Continues on next page

	Action	Illustration/Note
6	<p>Disconnect the lubrication tube from the fitting of the ball bearing block to release the tube from the drive train bracket (the tube will be pushed away along with the carriage).</p>	 <p>xx1400001592</p> <p><b>A</b> Lubrication tube connector</p>
7	<p>Disconnect the lubrication tube connector from the fitting of the pinion (the tube will be pushed away along with the carriage). Remove the top cover if necessary.</p>	 <p>xx1400001596</p> <p><b>A</b> Lubrication tube connector</p>
8	<p>Disconnect the cables from the tooling or robot fitted on the carriage. Remove the upper part of the cable tray so that the connectors can pass through.</p>	 <p>xx1400001593</p>
9	<p>Push the carriage away from the drive train bracket. The bracket, gear and pinion, motor, cable chain support and cable chain, stay stationary.</p>	<p> <b>Note</b></p> <p>Pay attention to the cables and their connectors: You must guide them through the cable tray while you push the carriage away.</p>

Removing the felt gear


	Action	Illustration/Note
1	<p>For the standard cable chain orientation, remove the cable chain support by removing the two screws.</p>	

Continues on next page

## 5 Repair


### 5.9.1 Replacing the felt gear

*Continued*

	Action	Illustration/Note
2	Disconnect the lubrication tube from the felt gear tube connector.	 <p data-bbox="986 629 1098 651">xx1400002642</p> <p data-bbox="1018 663 1390 775"> <b>A</b> Felt gear lubrication tube connector  <b>B</b> M8x20 Hex socket head cap screw, on felt gear bracket         </p>
3	Remove the screw from the felt gear bracket.	
4	Remove the felt gear from the bracket.	





### Refitting the felt gear

Refitting the felt gear

	Action	Illustration/Note
1	Tighten the screw as shown in the illustration.	 <p data-bbox="791 1626 903 1648">xx1400002643</p> <p data-bbox="791 1659 1406 1720"> <b>A</b> Felt gear lubrication tube connector  <b>B</b> M8x20 Hex socket head cap screw, on felt gear bracket         </p>
2	Refit the lubrication tube to the felt gear tube connector.	
3	For the standard cable chain orientation, refit the cable chain support with two screws.	

*Continues on next page*

Reinstalling the carriage to the drive train bracket



	Action	Illustration/Note
1	Push the carriage back above the drive train.	
2	Fit the carriage to the drive train bracket with the screws.   <b>Note</b> Do not tighten the screws yet.	 <small>xx1400001588</small> <b>A</b> M12x40 Hex socket head cap screws, 3HAB3409-67 (4 pcs)
3	Adjust the position of the carriage until the cylindrical pin in the 10 mm positioning hole of the drive train bracket can be inserted into the positioning hole in the top plate of the carriage.	 <small>xx2400001005</small> <b>A</b> Ø10x32 Cylindrical pin with threaded hole, 3HAC043986-001
4	Tighten the screws.	Tightening torque: 100 Nm
5	Connect the lubrication tube connectors of the ball bearing block.	 <small>xx1400001592</small> <b>A</b> Lubrication tube connector

Continues on next page

## 5 Repair

### 5.9.1 Replacing the felt gear

Continued


	Action	Illustration/Note
6	Connect the lubrication tube connector of the pinion.	 <p>xx1400001596</p> <p>A Lubrication tube connector</p>
7	Connect the cables from the tooling or robot fitted on the carriage. If necessary, remove the upper part of the cable tray so that the connectors can pass through.	
8	Refit the bracket for brake release and secure brake release cables with cable ties.	
9	Refit the side cover of the carriage.	 <p>xx1400001587</p> <p>A M6x12 Screw DIN6921, 9ADA181-11 (4 pcs)</p>
10	Refit the top cover.	

5.10 Replacing the cable chain and cables

5.10.1 Replacing the cable chain

Location of the cable chain

The figure shows the cable chain and the cable tray designed for the cable chain.



xx1400000742

A	Cable chain
B	Sheet metal
C	Sloped sheet metal used when the track travel length is no less than 5 m

Required equipment

Equipment	Note
Cable chain	Spare part number is specified in <a href="#">Spare parts on page 279</a> .
Cable chain parts	Spare part number is specified in <a href="#">Spare parts on page 279</a> .
Locking liquid	Loctite 243
Plastic clips	Replace if damaged.
NYLOC nuts	Replace with new nuts, if removed. NYLOC nuts can only be used once.
Standard toolkit	Content is defined in section <a href="#">Standard tools on page 270</a> .
Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below.	These procedures include references to the tools required.
Circuit diagram	See <a href="#">Circuit diagrams on page 281</a> .

Moving away the carriage



	Action	Illustration/Note
1	Remove all cover plates.	

Continues on next page

## 5 Repair



### 5.10.1 Replacing the cable chain

*Continued*

	Action	Illustration/Note
2	Move the carriage so that the drive train and the grease distribution block is away from the fixed end of the cable chain.	
3	 <b>WARNING</b> Turn off all electric power and pneumatic pressure supplies to the robot and for the track.	
4	Remove the brake release unit and cut the straps that hold the brake release cables to the carriage.	
5	Remove the bracket at the cable outlet.	
6	Loosen the carriage from the drive train bracket by removing the screws.	
7	Move away the carriage to access the movable end of the cable chain.  <b>CAUTION</b> Be careful not to damage the brake release cables.	





### Removing the cable chain

#### Removing the internal cable chain

	Action	Illustration/Note
1	Remove all cover plates.	
2	Move the carriage in order to have it positioned just above the fixed point of the cable chain.	
3	 <b>WARNING</b> Turn off all electric power and pneumatic pressure supplies to the robot and IRT 510.	
4	Take a note of how the cabling is strapped on the carriage. Pay special attention to how the IRB power cable is routed.	
5	Make a marking on the moving end of the chain to show its location relative to the connecting plate. This will facilitate alignment during refitting.	 xx1400001676

*Continues on next page*



	Action	Illustration/Note
6	<p>Disconnect the power and signal cable, and the media hose, on the carriage.</p> <p> <b>CAUTION</b></p> <p>Cooling water may run out. Protect the connectors from getting wet.</p>	
7	<p>Disconnect the connectors for power, signal and media hose at the fixing end of the cable chain.</p> <p> <b>Note</b></p> <p>Water may spill out.</p>	
8	<p>Cut off straps that securing the cables to the connection plate on the carriage.</p>	
9	<p>Move away the carriage.</p>	<p>See <a href="#">Moving away the carriage on page 231</a>.</p>
10	<p>Remove the four screws and four plain washers that hold the moving end of the cable chain to the connecting plate on the carriage.</p>	 <p>xx1400000523</p> <p><b>A</b> M6x20 Hex socket head cap screw, 9ADA183-25</p> <p><b>B</b> Ø12xØ6.4x1.6 Plain washer, 9ADA312-6</p>
11	<p>Remove screws at the fixed end of the cable chain.</p>	 <p>xx1400001980</p> <p><b>A</b> M6x20 Hex socket head cap screw, 9ADA183-25</p>
12	<p>Pull the complete cable chain out.</p>	





Continues on next page

## 5 Repair


### 5.10.1 Replacing the cable chain

*Continued*

#### Removing the external cable chain

	Action	Illustration/Note
1	Move the carriage so that the drive train and the grease distribution block is away from the fixed end of the cable chain.	
2	 <b>WARNING</b> Turn off all electric power and pneumatic pressure supplies to the robot and IRT 510.	
3	Take a note of how the cabling is strapped on the carriage. Pay special attention to how the IRB power cable is routed.	
4	Remove the strapping that ties the cabling to the carriage.	
5	Disconnect the power and signal cable, and the media hose on the carriage.   <b>CAUTION</b> Cooling water may run out. Protect the connectors from getting wet.	
6	Disconnect the connectors for power, signal and media at the floor end of the cable chain.   <b>Note</b> Water may spill out.	
7	Make a marking on the moving end of the chain to show its location relative to the connecting plate. This will facilitate alignment during refitting.	 xx1400002001
8	Cut off straps that securing the cables to the connection plates on the carriage.	
9	Cut off straps that securing the cables to the connection plate on the external cable tray.	
10	Loosen the two screws that hold the cable chain to the connecting plate on the carriage.	
11	Loosen the two screws of the fixed end of the cable chain.	

*Continues on next page*



	Action	Illustration/Note
12	Roll out the cable chain away from the carriage.   <b>Tip</b>  Roll the cable chain and bundle it to be able to lift it away. If it is short it can be two folded and lifted away.	

**Lifting the cable chain**

Lift the cable chain and make the two connectors of the cable chain above the middle of the track track. For how to lift the cable chain, see [Lifting cable chain on page 63](#).

**Refitting the cable chain**

**Refitting the internal cable chain**





	Action	Illustration/Note
1	Remove top covers of the track.	
2	Secure the movable end of the cable chain by securing the four screws and four plain washers that hold the moving end of the cable chain to the connecting plate on the carriage.	 <p>xx140000523</p> <p><b>A</b> M6x20 Hex socket head cap screw, 9ADA183-25</p> <p><b>B</b> Ø12xØ6.4x1.6 Plain washer, 9ADA312-6</p>
3	Secure the fixing end of the cable chain on the cable tray by screws.	 <p>xx1400001980</p> <p><b>A</b> M6x20 Hex socket head cap screw, 9ADA183-25</p>

Continues on next page

## 5 Repair

### 5.10.1 Replacing the cable chain






Continued

	Action	Illustration/Note
4	Connect the power and signal cable, and the media hose on the carriage.   <b>CAUTION</b>  Cooling water may run out if there is a media hose. Protect the connectors from getting wet.	
5	Connect the connectors for power, signal and media hose at the fixing end of the cable chain.	
6	Move back the carriage.	See <a href="#">Moving back the carriage on page 238</a> .
7	Securing the cables to the connection plate on the carriage with cable straps.  Make sure the cable route is the same with before.	
8	Check that all cable(s) and/or hose(s) are not installed too tight or too loose inside the carriage system. Optimally, aim for the neutral axis (center line of the link) of the chain as shown in the figure.  To ensure that the cables are in the neutral axis, move the carriage to one end and open the links in the bend of the chain. Adjust cable length as necessary, move the carriage to the opposite side and recheck.	 xx1200000518
9	Connect power cable and signal cable on the carriage.   <b>Note</b>  It is essential to start with the stiffest cable and to strap it into position in order to have room for it without interference from the rest of the harness. See the illustration.	 xx1400001755
10	Connect fixing side cabling and hoses with floor cables.	
11	Refit top covers.	

### Refitting the external cable chain

	Action	Illustration/Note
1	Move the carriage to the gliding side of the cable tray.	

Continues on next page

	Action	Illustration/Note
2	<p>Place the cable chain into the cable tray. If using lifting slings, ensure that these are removed before lowering the chain into the tray so as not to bend the tray.</p> <p> <b>CAUTION</b></p> <p>Cable chains are easily damaged through improper handling. See <a href="#">Lifting cable chain on page 63</a> for important information about how to handle and lift the cable chain into the cable tray.</p>	
3	<p>Fasten the two screws that hold the cable chain to the connecting plate on the carriage.</p>	
4	<p>Fasten the two screws of the fixed end of the cable chain.</p>	
5	<p>Bound straps that securing the cables to the connection plates on the carriage.</p> <p>Make sure the relative position of the cables to the connection plate is the same with before.</p>	 <p>xx1400002001</p>
6	<p>Bound straps that securing the cables to the connection plate on the external cable tray.</p> <p>Make sure the relative position of the cables to the connection plate is the same with before.</p>	
7	<p>Check that all cable(s) and/or hose(s) are not installed too tight or too loose inside the carriage system. Optimally, aim for the neutral axis (center line of the link) of the chain as shown in the figure.</p> <p>To ensure that the cables are in the neutral axis, move the carriage to one end and open the links in the bend of the chain. Adjust cable length as necessary, move the carriage to the opposite side and recheck.</p>	 <p>xx1200000518</p>
8	<p>Connect power cable and signal cable on the carriage.</p> <p> <b>Note</b></p> <p>It is essential to start with the stiffest cable and to strap it into position in order to have room for it without interference from the rest of the harness.</p>	 <p>xx1400001755</p>

Continues on next page

## 5 Repair

### 5.10.1 Replacing the cable chain


*Continued*

	Action	Illustration/Note
9	Connect fixing side cabling and hoses with floor cables.	

Test run

	Action	Illustration/Note
1	Switch on the power.	
2	Run a few strokes in jogging mode and check that the chain is gliding properly upon itself and is correctly adjusted sideways.	
3	Run the system at low speed and insure that everything runs freely and smoothly without the chain, cables and/or hoses binding.	
4	Adjust the chain position or alignment, if needed.	
5	Adjust the position and length of cables and/or hoses, if needed.	
6	If adjustments are made, repeat steps 3 to 5.	
7	Tighten all screws.	
8	The track is now ready to be powered up to full speed and duty cycle. Check the tightening torque on fastening screws after 500 cycles. Adjust, if needed. The use of serrated lock washers, snap rings and other locking means is not permitted in this part of the track.	

### Moving back the carriage

	Action	Illustration/Note
1	Move back the carriage and secure it to the drive train bracket with the screws.	
2	Refit the brake release unit and strap the brake release cables to the carriage.	
3	Refit the covers.	See <a href="#">Fitting covers on page 73</a> .
4	Mark the cables with a paint pen on both sides of the strapping.	
5	 <b>DANGER</b> Make sure all safety requirements are met when performing the first test run. These are further detailed in the section <a href="#">Test run after installation, maintenance, or repair on page 140</a> .	
6	Perform a test run before powering up the track to full speed and duty cycle.	See <a href="#">Test run on page 249</a> .

*Continues on next page*

**Adjusting the cable tray for spare part chains that are longer than the original**

Chains longer than the original chain can be installed on single carriage tracks. In order to do this the fixed point of the chain will need to be moved, to allow for the extra length. Ensure that the replacement chain is not longer than twice the track length.

**Principle of creating more space for a longer cable chain**

The cable chain is fastened to the fixing connector at the middle of the cable tray. By moving the fixing connector forwards, and thereby moving the fixed point forwards, more space is created in the cable tray to suit for a longer cable chain.

More brackets and sheet metals may need to be swapped around if the chain is excessively long.

**Adjusting the cable tray**

	Action	Illustration/Note
1	Remove the old cable chain.	See <a href="#">Removing the cable chain on page 232</a> .
2	Fit the new cable chain to the cable tray.	See <a href="#">Lifting cable chain on page 63</a> .
3	Attach the cable chain at both the fixed and moving end.	
4	Move the carriage back and forth to both mechanical stops to ensure the chain is the correct length.	
5	Complete the installation of the new cable chain.	See <a href="#">Refitting the cable chain on page 235</a> .


## 5 Repair

### 5.10.2 Replacing the side links and glide shoes

#### 5.10.2 Replacing the side links and glide shoes

##### Location of the side links

The figure shows the location of the side links on the cable chain.



xx1400001677


A	Side link
---	-----------

*Continues on next page*



**Location of the glide shoes**

The figure shows the location of the glide shoes on the cable chain.



xx1400001678

A	Gliding shoe
---	--------------

**Required equipment**

Equipment	Note
Side link	Spare part number is specified in <a href="#">Spare parts on page 279</a> .
Glide shoes	Spare part number is specified in <a href="#">Spare parts on page 279</a> .
Standard toolkit	Content is defined in section <a href="#">Standard tools on page 270</a> .

**Removing the side link**


	Action	Illustration/Note
1	Bend the links until two marks on the side line up.	<p>xx1300000939</p>

Continues on next page



## 5 Repair

### 5.10.2 Replacing the side links and glide shoes

Continued

	Action	Illustration/Note
2	Separate the two links by inserting a screwdriver and pushing down until the links separate.	 <p data-bbox="986 517 1091 533">xx130000940</p>

#### Refitting the side link

	Action	Illustration/Note
1	Position the links so that the two marks on the side line up. Press the links together until they snap together.	 <p data-bbox="986 882 1091 898">xx130000941</p>
2	Rotate the link to "close" it.	 <p data-bbox="986 1126 1091 1142">xx130000942</p>


#### Refitting the glide shoes

	Action	Illustration/Note
1	Remove the glide shoes by pushing in the clips with a screwdriver and then pulling out the glide shoes.	
2	Refit the glide shoes by pushing it into place until it snaps.	

### 5.10.3 Replacing the cables

#### Location of cables

The following illustrates the cable layout



xx1400001286

A	Robot or conveyor power cable
B	Signal cables
C	IRT power cables
D	Flexible cable harness from the carriage <ul style="list-style-type: none"> <li>• Power cables for track, robot etc. (A,C, etc.)</li> <li>• Motor, manipulator signal cables (B)</li> <li>• Other cables: hoses etc.</li> </ul>
E	Connectors connecting cable harness from the carriage and cable harness from the controller.
F	Floor cables from the controller <ul style="list-style-type: none"> <li>• Power cable, available for controller</li> <li>• Signal cable, available for controller</li> </ul>
G	Controller


*Continues on next page*

## 5 Repair

### 5.10.3 Replacing the cables

Continued

If the IRT 510 is used together with IRB 1600, IRB 2600 or IRB 4600, and the CP/CS option is also selected, the cables must be arranged according to the following layout.



xx2400001006

A	Outer bend (view seen from movable end)
B	Inner bend (view seen from movable end)
C	Robot signal cable, 3HAC029834-XXX
D	Track power cable, 3HAC088222-XXX
E	Robot power cable, 3HAC046924-XXX
F	CP cable
G	Options: <ul style="list-style-type: none"> <li>• CP/CS parallel, 3HEA801277-XXX</li> <li>• CP/CS DeviceNet, 3HEA801279-XXX</li> <li>• CP/CS EtherNet/ProfiNet, 3HAC032951-XXX</li> </ul>
H	CS cable
J	Grounding cable
K	Option: Air hose CP/CS, 3HAC046923-XXX (available when option 4215-X or 4229-X is selected)
L	Option: Sensor for auto-lubrication, 3HAC078308-001 / 3HAC078287-001 / 3HAC078309-001 / 3HAC078306-001 (available when option 4216-1 or 4230-1 is selected)



Cable layout in the track with extra plate is similar with previous layouts. While more extra plate-related cables are added and routed through cable chain.

Continues on next page

## Required equipment

Equipment	Art. No.	Note
Cables	Spare part number is specified in <a href="#">Spare parts on page 279</a> .	Cables must be designed for use in continuous flexing operation.
Cable chain parts	Spare part number is specified in <a href="#">Spare parts on page 279</a> .	
Cable ties	21662055-3	Use heavy duty cable ties with minimum width: 4.9 mm.
Standard toolkit	-	Content is defined in section <a href="#">Standard tools on page 270</a> .
Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below.		These procedures include references to the tools required.
Circuit diagram	-	See <a href="#">Circuit diagrams on page 281</a> .

## Moving away the carriage

	Action	Illustration/Note
1	Remove all cover plates.	
2	Move the carriage so that the drive train and the grease distribution block is away from the fixed end of the cable chain.	
3	 <b>WARNING</b> Turn off all electric power and pneumatic pressure supplies to the robot and for the track.	
4	Remove the brake release unit and cut the straps that hold the brake release cables to the carriage.	
5	Remove the bracket at the cable outlet.	
6	Loosen the carriage from the drive train bracket by removing the screws.	
7	Move away the carriage to access the movable end of the cable chain.   <b>CAUTION</b> Be careful not to damage the brake release cables.	

## Removing the cable




	Action	Illustration/Note
1	Disconnect the motor cables and cut the cable straps.	

Continues on next page

## 5 Repair

### 5.10.3 Replacing the cables

Continued

	Action	Illustration/Note
2	Loosen the movable end of the cable chain from the connecting plate by removing the screws.	
3	Unfold the bend so that the cable chain is flat.	
4	Lift the cable chain. For details, see <a href="#">Lifting cable chain on page 63</a> .	
5	Make a note of the placement of the damaged cable in the cable chain, before removing the cable. This will facilitate refitting.	 <p>xx1100000785</p>
6	Before removing damaged cables, measure the length of the damaged cable projecting from the end of the cable chain. This will facilitate refitting.	
7	<p>Remove the damaged cables from the tie wrap plates.</p> <p> <b>Tip</b></p> <p>Before removing damaged cables, note down the location on tie wrap plate. This will facilitate refitting.</p>	 <p>xx1400000479</p> <p>A Cable chain B Tie wrap plate C Separator for cables D Cable chain link</p>
8	Remove the cable to be replaced.	

Continues on next page

## Refitting the cable

**Note**

Correct placement of cables in the cable chain is vital and will prevent unnecessary wear of the cables. Also the following matters must be considered:

- Keep unlike components apart, that is separate power and signals.
- Keep unlike cable or hose jacket materials apart.
- Only put cables of similar size in the same compartments.
- Do not remove dividers.
- If replacing a cable, check that other cables are in good condition and that they are not twisted.
- Do not pack the cables too tight inside the carriage cavities.

**CAUTION**

Adding cables that are not covered in the standard layouts could seriously reduce the expected component life of the chain.




	Action	Illustration/Note
1	Strap the connectors together, in order to facilitate insertion of them under the carriage.	
2	Fold the cable chain and insert the moving end under the carriage to its support plate at the drive unit. In the same time, guide the connectors through the cable outlet at the side of the carriage.	
3	Fit the moving end of the cable chain to the connecting plate with four screws and washers.	
4	Refit the upper part of the cable tray to the cable outlet if it is dismantled.	
5	Reconnect the motor cables.	

Continues on next page

## 5 Repair


### 5.10.3 Replacing the cables

Continued

	Action	Illustration/Note
6	<p>Fit the new cable(s), use the same length projecting from the cable chain as for the damaged cable.</p>	 <p>xx1100000785</p> <p>See placement of all cables in <a href="#">Location of cables on page 243</a>.</p> <p><b>Note</b></p> <p>When installing cables or hoses into the carriage system, they should be laid into the carriage without twist. Cables or hoses should not be simply pulled off the reel. Instead, they should be properly uncoiled as shown in the figure below.</p>  <p>xx1200000517</p>
7	<p>Check that all cable(s) and/or hose(s) are not installed too tight or too loose inside the carriage system when clamping them into place. Optimally, aim for the neutral axis (center line of the link) of the chain as shown in the figure.</p> <p>To ensure that the cables are in the neutral axis, move the carriage to one end and open the links in the bend of the chain. Adjust cable length as necessary, move the carriage to the opposite side and recheck.</p>	 <p>xx1200000518</p> <p>Wrong: If cable bend radius is too big or installed incorrectly it forces the cable to push against the inner or outer sides of the chain.</p> <p>Right: if correctly installed the cable should fit comfortably in the chains cavity</p>


Continues on next page



	Action	Illustration/Note
8	Strap the new cable(s) and connect it/them to the moving end plate firstly.	 <p data-bbox="1023 678 1129 696">xx1400001676</p> <p data-bbox="1054 707 1235 734"><b>A Cable straps</b></p> <p data-bbox="1023 741 1406 797">Suitable cable ties are specified in <a href="#">Required equipment on page 245</a>.</p>

Test run

Use this procedure to check the installation of the cabling.

	Action	Illustration/Note
1	Run the system at low speed and insure that everything runs freely and smoothly without the carriage, cables and/or hoses binding.	
2	After 50 cycles, check that the cables and hoses are not installed too tight (stretched between carriage bars) or too loose (hanging on the carriage bars). Optimally, aim for the center line of the link of the carriage system, as shown in the figure. Strap the new cable(s) and connect it/them to the fix end plate if all cables are in the right position as shown in the picture. Strap the fix end if cables/hoses are in the right positon.	 <p data-bbox="1023 1261 1129 1279">xx1200000518</p>
3	Adjust the carriage position or alignment, if needed.	
4	Adjust the position and length of cables and/or hoses, if needed.	
5	If adjustments are made, repeat steps 1 to 4.	
6	Tighten all screws.	
7	The track is now ready to be powered up to full speed and duty cycle. Check the tightening torque on fastening screws after 500 cycles. Adjust, if needed. Periodically check to see if the cable strain relief is still in place.	

Moving back the carriage


	Action	Illustration/Note
1	Move back the carriage and secure it to the drive train bracket with the screws.	

Continues on next page

## 5 Repair

### 5.10.3 Replacing the cables


*Continued*

	Action	Illustration/Note
2	Refit the brake release unit and strap the brake release cables to the carriage.	
3	Refit the covers.	See <a href="#">Fitting covers on page 73</a> .
4	Mark the cables with a paint pen on both sides of the strapping.	
5	 <b>DANGER</b> Make sure all safety requirements are met when performing the first test run. These are further detailed in the section <a href="#">Test run after installation, maintenance, or repair on page 140</a> .	
6	Perform a test run before powering up the track to full speed and duty cycle.	See <a href="#">Test run on page 249</a> .

### 5.10.4 Replacing the lubrication sensor and sensor cable

#### Location of lubrication sensor and sensor cable

The figure shows the location of the lubrication sensor and its cable which is available if the IRT 510 has the option Grease Detection sensor selected.



xx2300001653

#### Required equipment

Equipment	Art. No.	Note
Lubrication sensor cable	Spare part number is specified in <a href="#">Spare parts on page 279</a> .	
Standard toolkit	-	Content is defined in section <a href="#">Standard tools on page 270</a> .
Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below.		These procedures include references to the tools required.
Circuit diagram	-	See <a href="#">Circuit diagrams on page 281</a> .

*Continues on next page*





## 5 Repair

### 5.10.4 Replacing the lubrication sensor and sensor cable

*Continued*

#### Removing the lubrication sensor and sensor cable





Use this procedure to remove the lubrication sensor and sensor cable.

	Action	Illustration/Note
1	Remove the necessary carriage side cover, rack covers, the end cover (if present) and the mechanical stop.	
2	 <b>WARNING</b> Turn off all electric power and pneumatic pressure supplies to the robot and for IRT 510.	
3	Unscrew and remove the sensor cable connector.	 xx2300001654
4	Loosen the two hexagon screws to release the lubrication sensor.	 xx2300001656
5	Remove the sensor from the distributor.	 xx2300001655

*Continues on next page*

Refitting the lubrication sensor and sensor cable

Use this procedure to refit the lubrication sensor and sensor cable.



	Action	Illustration/Note
1	<p>Place the two hexagon screws before refitting the sensor. Do not tighten yet.</p>	 <p>xx2300001656</p>
2	<p>Refit the sensor and orient it to a proper position.</p>	<p>Tightening torque: <math>\leq 13 \text{ Nm}</math></p>  <p>xx2300001655</p>
3	<p>Tighten the hexagon screw A to fix the sensor, and then tighten the hexagon screw B to secure the fixing.</p> <p> <b>Note</b></p> <p>Pay attention to the sensor orientation. If improper, loosen the screws to reorient the sensor and then tighten again.</p>	 <p>xx2300001689</p>

Continues on next page

## 5 Repair

### 5.10.4 Replacing the lubrication sensor and sensor cable

*Continued*

	Action	Illustration/Note
4	Reconnect and tighten the sensor cable connector by screwing it.	 <p>xx2300001654</p>
5	Refit the mechanical stop and the covers.	
6	Calibrate the track if the ball bearing block at the drive unit bracket has been replaced.	See <a href="#">Fine calibration on page 256</a> .
7	 <b>DANGER</b> Make sure all safety requirements are met when performing the first test run. These are further detailed in the section <a href="#">Test run after installation, maintenance, or repair on page 140</a> .	

# 6 Calibration

## 6.1 Overview

### General

This chapter includes general information about different calibration methods and also details procedures that do not require specific calibration equipment.

When the robot system must be recalibrated, it is done according to the documentation enclosed with the calibration tools.



#### WARNING

Make sure no persons are on IRT 510 when the carriage is in motion. Also make sure that IRT 510's cover plates are free from loose objects, otherwise they can get trapped between the carriage and the plates.



#### Note

IRT 510 does not need to be calibrated during restart. The resolvers only need to be calibrated when commissioning the system.

### When to calibrate

The system must be calibrated if any of the following situations occur.

#### The resolver values are changed

If resolver values are changed, the robot must be recalibrated using the calibration methods supplied by ABB. Calibrate the track carefully with standard calibration.

The resolver values will change when parts affecting the calibration position are replaced on the track, for example motors or parts of the transmission.

This is detailed in [Fine calibration on page 256](#).

#### The revolution counter memory is lost

If the revolution counter memory is lost, the counters must be updated. See [Update revolution counters on page 257](#). This will occur when:

- The battery is discharged
- A resolver error occurs
- The signal between a resolver and measurement board is interrupted
- A robot axis is moved with the control system disconnected

The revolution counters must also be updated after the robot and controller are connected at the first installation.

#### The track is rebuilt

If the track is rebuilt, for example after a crash or when the reach ability of the track is changed, it needs to be recalibrated for new resolver values.

This is detailed in [Fine calibration on page 256](#).

## 6 Calibration

### 6.2 Fine calibration

### 6.2 Fine calibration

#### General


This procedure must be applied at the first start or after mechanical intervention (motor change, gearbox).

#### Required equipment

Equipment	Art. No.	Note
Calibration tool	3HAC054533-001	Ø8 calibration pin

#### Procedure

Use the following procedure to calibrate the track with the FlexPendant.



	Action	Illustration/Note
1	Using the FlexPendant, jog the carriage close to the calibration gauge position.	
2	Move the track until the calibration notch on the carriage line up with the calibration hole on the section.	 <p>xx1400000570</p> <p>A: Calibration notch on the carriage B: Calibration hole on the section</p>
3	Insert the calibration pin. A dowel pin diameter 8mm can also be used.	
4	On the start screen of the FlexPendant, tap <b>Calibrate</b> . The calibration summary page for the mechanical unit is displayed.	
5	Tap the track to be calibrated.	
6	In the <b>Calibration Methods</b> menu, select <b>Calibration Parameters &gt; Fine Calibration</b> .	
7	Tap <b>Yes</b> to proceed.	
8	Select the corresponding checkbox in the <b>Selection</b> column.	
9	Tap <b>Calibrate</b> on the right corner. A dialog box is displayed warning that the operation cannot be undone.	
10	Tap <b>Calibrate</b> to proceed.	



## 6.3 Update revolution counters

## Procedure

Use the following procedure to update the revolution counters from the FlexPendant if revolution counter value is loss for the track.

	Action	Illustration/Note
1	Align the sharp edge of the moving part of the calibration marker with the line of the fixed part calibration marker.	 <p>xx1400000595</p> <p>A: Calibration sharp edge of the moving part B: Calibration sharp edge of the fixed part</p>
2	On the start screen of the FlexPendant, tap <b>Calibrate</b> . The calibration summary page for the mechanical unit is displayed.	
3	Tap the track for which revolution counters to be updated.	
4	In the <b>Calibration Methods</b> menu, select <b>Revolution Counters</b> .	
5	Select the corresponding checkbox in the <b>Selection</b> column.	
6	Tap <b>Update</b> on the right corner. A dialog box is displayed warning that the updating operation cannot be undone.	
7	Tap <b>Update</b> to proceed.	
8	 <b>CAUTION</b>  If a revolution counter is incorrectly updated, it will cause incorrect track positioning, which in turn may cause damage or injury!	

## 6 Calibration

---

### 6.4 Defining base frame

### 6.4 Defining base frame

---

#### General

To run coordinated axes, the base frame must be defined. See *Application manual - Additional axes (Coordinated track motion)*.

# 7 Decommissioning

## 7.1 Introduction to decommissioning

### Introduction

This section contains information to consider when taking a product, robot or controller, out of operation.

It deals with how to handle potentially dangerous components and potentially hazardous materials.



#### Note

The decommissioning process shall be preceded by a risk assessment.

### Disposal of materials used in the robot

All used grease/oils and dead batteries **must** be disposed of in accordance with the current legislation of the country in which the robot and the control unit are installed.

If the robot or the control unit is partially or completely disposed of, the various parts **must** be grouped together according to their nature (which is all iron together and all plastic together), and disposed of accordingly. These parts **must** also be disposed of in accordance with the current legislation of the country in which the robot and control unit are installed.

See also [Environmental information on page 260](#).

### Transportation

Prepare the robot or parts before transport, this to avoid hazards.

## 7 Decommissioning

### 7.2 Environmental information


## 7.2 Environmental information

### Introduction

ABB robots contain components in different materials. During decommissioning, all materials shall be dismantled, recycled, or reused responsibly, according to the relevant laws and industrial standards. Robots or parts that can be reused or upcycled helps to reduce the usage of natural resources.

### Disposal symbol

The following symbol indicates that the product must not be disposed of as common garbage. Handle each product according to local regulations for the respective content (see table below).



xx180000058

### Materials used in the product

The table specifies some of the materials in the product and their respective use throughout the product.

Dispose components properly according to local regulations to prevent health or environmental hazards.

Material	Example application
Aluminium	
Batteries, Lithium	Serial measurement board
Brass, zinc alloys	Calibration protection cap and plug and couplings, connectors and nuts in cable harness
Cast iron/nodular iron	
Circuit boards	Serial measurement unit, brake release unit
Copper	Cables, motors
Lithium	Battery
Magnesium	Wrist casting, upper arm, back cover, tool flange, etc
Neodymium	Brakes, motors
Oil, grease	Gearboxes
Plastic/rubber	

*Continues on next page*

Material	Example application
Steel	

#### Oil and grease

Where possible, arrange for oil and grease to be recycled. Dispose of via an authorized person/contractor in accordance with local regulations. Do not dispose of oil and grease near lakes, ponds, ditches, down drains, or onto soil. Incineration must be carried out under controlled conditions in accordance with local regulations.

Also note that:

- Spills can form a film on water surfaces causing damage to organisms. Oxygen transfer could also be impaired.
- Spillage can penetrate the soil causing ground water contamination.

**This page is intentionally left blank**

# 8 Reference information

## 8.1 Introduction

---

### General

This chapter includes general information, complementing the more specific information in the different procedures in the manual.

## 8 Reference information

---

### 8.2 Applicable standards

### 8.2 Applicable standards

---

#### General

The product is compliant with ISO 10218-1:2011, *Robots for industrial environments - Safety requirements - Part 1 Robots*, and applicable parts in the normative references, as referred to from ISO 10218-1:2011. In case of deviation from ISO 10218-1:2011, these are listed in the declaration of incorporation. The declaration of incorporation is part of the delivery.

---

#### Robot standards

Standard	Description
ISO 9283	Manipulating industrial robots – Performance criteria and related test methods
ISO 9787	Robots and robotic devices – Coordinate systems and motion nomenclatures
ISO 9946	Manipulating industrial robots – Presentation of characteristics

---

#### Other standards used in design

Standard	Description
IEC 60204-1	Safety of machinery - Electrical equipment of machines - Part 1: General requirements, normative reference from ISO 10218-1
IEC 61000-6-2	Electromagnetic compatibility (EMC) – Part 6-2: Generic standards – Immunity standard for industrial environments
IEC 61000-6-4	Electromagnetic compatibility (EMC) – Part 6-4: Generic standards – Emission standard for industrial environments
ISO 13849-1:2006	Safety of machinery - Safety related parts of control systems - Part 1: General principles for design, normative reference from ISO 10218-1



## 8.3 Unit conversion

### Converter table

Use the following table to convert units used in this manual.

Quantity	Units		
Length	1 m	3.28 ft.	39.37 in
Weight	1 kg	2.21 lb.	
Weight	1 g	0.035 ounces	
Pressure	1 bar	100 kPa	14.5 psi
Force	1 N	0.225 lbf	
Moment	1 Nm	0.738 lbf-ft	
Volume	1 L	0.264 US gal	

## 8 Reference information

---

### 8.4 Screw joints

### 8.4 Screw joints

---

#### General

This section describes how to tighten the various types of screw joints on ABB robots.

The instructions and torque values are valid for screw joints comprised of metallic materials and do *not* apply to soft or brittle materials.

---

#### UNBRAKO screws

UNBRAKO is a special type of screw recommended by ABB for certain screw joints. It features special surface treatment (Gleitmo as described below) and is extremely resistant to fatigue.

Whenever used, this is specified in the instructions, and in such cases, *no other type of replacement screw* is allowed. Using other types of screws will void any warranty and may potentially cause serious damage or injury.

---

#### Gleitmo treated screws

Gleitmo is a special surface treatment to reduce the friction when tightening the screw joint. It is recommended by ABB for M6-M20 screw joints. Screws treated with Gleitmo may be reused 3-4 times before the coating disappears. After this the screw must be discarded and replaced with a new one.

When handling screws treated with Gleitmo, protective gloves of nitrile rubber type should be used.

Generally, screws are lubricated with *Gleitmo 603* mixed with *Geomet 500* or *Geomet 702* in proportion 1:3. *Geomet* thickness varies according to screw dimensions, refer to the following.

Dimension	Lubricant	Geomet thickness
M6-M20 (any length except M20x60)	<i>Gleitmo 603 + Geomet 500</i>	3-5 µm
M6-M20 (any length except M20x60)	<i>Gleitmo 603 + Geomet 720</i>	3-5 µm
M20x60	<i>Gleitmo 603 + Geomet 500</i>	8-12 µm
M20x60	<i>Gleitmo 603 + Geomet 720</i>	6-10 µm

---

#### Screws lubricated in other ways

Screws lubricated with Molykote 1000 or Molykote P1900 should *only* be used when specified in the repair, maintenance or installation procedure descriptions.

In such cases, proceed as follows:

- 1 Apply lubricant to the screw thread.
- 2 Apply lubricant between the plain washer and screw head.
- 3 Screw dimensions of M8 or larger must be tightened with a torque wrench. Screw dimensions of M6 or smaller may be tightened without a torque wrench *if* this is done by trained and qualified personnel.

*Continues on next page*

Lubricant	Article number
Molykote 1000 (molybdenum disulphide grease)	3HAC042472-001
Molykote P1900 (molybdenum disulphide grease)	3HAC070875-001

### Tightening torque

Before tightening any screw, note the following:

- Determine whether a **standard** tightening torque or **special** torque is to be applied. The **standard torques** are specified in the following tables. Any **special torques** are specified in the repair, maintenance or installation procedure descriptions. **Any special torque specified overrides the standard torque!**
- Use the *correct tightening torque* for each type of screw joint.
- Only use *correctly calibrated* torque keys.
- *Always tighten the joint by hand*, and never use pneumatic tools.
- Use the *correct tightening technique*, that is *do not* jerk. Tighten the screw in a slow, flowing motion.
- Maximum allowed total deviation from the specified value is **10%**!

#### Tightening torque for oil-lubricated screws with slotted or cross-recess head screws

The following table specifies the recommended standard tightening torque for *oil-lubricated screws with slotted or cross-recess head screws*.



#### Note

A special torque specified in the repair, maintenance or installation procedure overrides the standard torque.

#### Tightening torque for oil-lubricated screws with allen head screws

The following table specifies the recommended standard tightening torque for *oil-lubricated screws with allen head screws*.



#### Note

A special torque specified in the repair, maintenance or installation procedure overrides the standard torque.

Dimension	Tightening torque (Nm)	Tightening torque (Nm)	Tightening torque (Nm)
	Class 8.8, oil-lubricated	Class 10.9, oil-lubricated	Class 12.9, oil-lubricated
M5	6	-	-
M6	10	-	-
M8	24	34	40
M10	47	67	80
M12	82	115	140
M16	200	290	340
M20	400	560	670

Continues on next page

## 8 Reference information

### 8.4 Screw joints

*Continued*

Dimension	Tightening torque (Nm) Class 8.8, oil-lubricated	Tightening torque (Nm) Class 10.9, oil-lubricated	Tightening torque (Nm) Class 12.9, oil-lubricated
M24	680	960	1150

Tightening torque for lubricated screws (Molykote, Gleitmo or equivalent) with allen head screws

The following table specifies the recommended standard tightening torque for *screws lubricated with Molykote 1000, Gleitmo 603 or equivalent with allen head screws.*



#### Note

A special torque specified in the repair, maintenance or installation procedure overrides the standard torque.

Dimension	Tightening torque (Nm) Class 10.9, lubricated <sup>i</sup>	Tightening torque (Nm) Class 12.9, lubricated <sup>i</sup>
M5		8
M6		14
M8	28	35
M10	55	70
M12	96	120
M16	235	300
M20	460	550
M24	790	950

<sup>i</sup> Lubricated with Molykote 1000, Gleitmo 603 or equivalent

## 8.5 Weight specifications


### Definition

In installation, repair, and maintenance procedures, weights of the components handled are sometimes specified. All components exceeding 22 kg (50 lbs) are highlighted in this way.

To avoid injury, ABB recommends the use of a lifting accessory when handling components with a weight exceeding 22 kg. A wide range of lifting accessories and devices are available for each manipulator model.

### Example

Following is an example of a weight specification in a procedure:

	Action	Note
	<p> <b>CAUTION</b></p> <p>The arm weighs 25 kg. All lifting accessories used must be sized accordingly.</p>	

## 8 Reference information

---

### 8.6 Standard tools

### 8.6 Standard tools

---

#### General

All service (repairs, maintenance, and installation) procedures contains lists of tools required to perform the specified activity.

All special tools required are listed directly in the procedures while all the tools that are considered standard are gathered in the standard toolkit and defined in the following table.

This way, the tools required are the sum of the standard toolkit and any tools listed in the instruction.

---

#### Contents, standard tools

Qty	Tool
1	Ring-open-end spanner 8-19 mm
1	Socket head cap 2.5-17 mm
1	Torx socket no: 20-60
1	Torque wrench 10-120 Nm
1	Ratchet head for torque wrench 1/2
1	Hex bit socket head cap no. 5 socket 1/2", bit length=20 mm
1	Hex bit socket head cap no. 6 socket 1/2", bit length=20 mm
1	Hex bit socket head cap no. 8 socket 1/2", bit length=20 mm
1	Plastic mallet
1	Small screwdriver

## 8.7 Special tools

### Extra toolkit

All service instructions contain lists of tools required to perform the specified activity. The required tools are a sum of standard tools defined in the section [Standard tools on page 270](#) and special tools listed directly in the instructions and also gathered in this section.

### Special tools




Qty	Tool	Art. No.	Note
2	Rack clamping tool	3HAW107700357	The actual clamping tool to be used should be prepared based on actual situation.
1	Backlash adjustment tool	3HAC054528-001	
1	Calibration pin	3HAC054533-001	
1	Companion rack	3HAC054532-001	
1	Companion rack fix block	3HAC054531-001	

*Continues on next page*

## 8 Reference information

### 8.7 Special tools

Continued

Qty	Tool	Art. No.	Note
1	Installation tool kit	3HAC091295-001	<p data-bbox="1115 315 1406 450">Ordered with option 4203-1 and includes Leveling tool, Locking nut adjustment tool and Calibration pin.</p> <p data-bbox="1115 465 1262 495">Leveling tool</p>  <p data-bbox="1115 871 1222 889">xx150000397</p> <p data-bbox="1115 927 1378 981">Locking nut adjustment tool</p>  <p data-bbox="1115 1207 1222 1225">xx240000904</p> <p data-bbox="1115 1263 1278 1292">Calibration pin</p>  <p data-bbox="1115 1496 1222 1514">xx140000186</p>
1	Laser tracker		



## 8.8 Lifting accessories and lifting instructions

---

### General

Many repair and maintenance activities require different pieces of lifting accessories, which are specified in each procedure.

The use of each piece of lifting accessories is *not* detailed in the activity procedure, but in the instruction delivered with each piece of lifting accessories.

The instructions delivered with the lifting accessories should be stored for later reference.




## 8 Reference information

### 8.9 HILTI adhesive anchor

### 8.9 HILTI adhesive anchor

#### Overview

#### HVU with HAS/HAS-E rod adhesive anchor

Mortar system	Benefits
 <p>Hilti HVU foil capsule</p>	<ul style="list-style-type: none"> <li>- suitable for non-cracked concrete C 20/25 to C 50/60</li> <li>- high loading capacity</li> <li>- suitable for dry and water saturated concrete</li> <li>- large diameter applications</li> <li>- high corrosion resistant</li> </ul>
 <p>HAS HAS-R HAS-HCR rod</p>	
 <p>HAS-E HAS-E R HAS-E HCR rod</p>	

xx140000489

For more details about the latest information of HILTI adhesive anchor, please visit <https://www.hilti.com/>.

#### Basic data (for a single anchor)

All data in this section applies to:

- Correct setting (See setting instruction)
- No edge distance and spacing influence
- Steel failure
- Base material thickness, as specified in the table
- One typical embedment depth, as specified in the table
- One anchor material, as specified in the tables
- Concrete C 20/25,  $f_{ck,cube} = 25 \text{ N/mm}^2$
- Temperate range I (min. base material temperature  $-40^\circ\text{C}$ , max. long term/short term base material temperature:  $+24^\circ\text{C}/40^\circ\text{C}$ )
- Installation temperature range  $-5^\circ\text{C}$  to  $+40^\circ\text{C}$

M16 anchor	
Typical embedment depth [mm] <sup>1</sup>	125
Base material thickness [mm]	210
Carbon steel, strength class	5.8
Mean ultimate resistance:concrete C 20/25 – $f_{ck,cube} = 25 \text{ N/mm}^2$ , anchor HAS Tensile $NR_{u,m} \text{ HAS}$ [kN]	75,6
Mean ultimate resistance:concrete C 20/25 – $f_{ck,cube} = 25 \text{ N/mm}^2$ , anchor HAS Shear $VR_{u,m} \text{ HAS}$ [kN]	37,8
Characteristic resistance: concrete C 20/25 – $f_{ck,cube} = 25 \text{ N/mm}^2$ , anchor HAS Tensile $NR_k \text{ HAS}$ [kN]	60,0
Design resistance: concrete C 20/25 – $f_{ck,cube} = 25 \text{ N/mm}^2$ , anchor HAS Shear $VR_k \text{ HAS}$ [kN]	36,0

Continues on next page

<b>M16 anchor</b>	
Recommended loads <sup>ii</sup> : concrete C 20/25 – f <sub>ck,cube</sub> = 25 N/mm <sup>2</sup> , anchor HAS Tensile NRd HAS [kN]	40,0
Recommended loads: concrete C 20/25 – f <sub>ck,cube</sub> = 25 N/mm <sup>2</sup> , anchor HAS Shear VRd HAS [kN]	28,8

- <sup>i</sup> The allowed range of embedment depth is shown in the setting details. The corresponding load values can be calculated according to the simplified design method.
- <sup>ii</sup> With overall partial safety factor for action = 1,4. The partial safety factors for action depend on the type of loading and shall be taken from national regulations.

#### Basic design tensile resistance

##### Design steel resistance $N_{Rd,s}$

		Data according ETA-05/0255, issue 2011-06-23							
Anchor size		M8	M10	M12	M16	M20	M24	M27	M30
$N_{Rd,s}$	HAS-(E)(F) 5.8 [kN]	11,3	17,3	25,3	48,0	74,7	106,7	-	-
	HAS-(E)(F) 8.8 [kN]	18,0	28,0	40,7	76,7	119,3	170,7	231,3	281,3
	HAS-(E)-R [kN]	12,3	19,8	28,3	54,0	84,0	119,8	75,9	92,0
	HAS-(E)-HCR [kN]	18,0	28,0	40,7	76,7	119,3	106,7	-	-

##### Design combined pull-out and concrete cone resistance $N_{Rd,p} = N_{Rd,p}^0 \cdot f_{B,p} \cdot f_{h,p}$

		Data according ETA-05/0255, issue 2011-06-23							
Anchor size		M8	M10	M12	M16	M20	M24	M27	M30
Typical embedment depth $h_{ef,typ}$ [mm]		80	90	110	125	170	200	210	270
$N_{Rd,p}^0$	Temperature range I [kN]	16,7	23,3	33,3	40,0	76,7	93,3	133,3	166,7
$N_{Rd,p}^0$	Temperature range II [kN]	13,3	16,7	26,7	33,3	50,0	76,7	93,3	113,3
$N_{Rd,p}^0$	Temperature range III [kN]	6,0	8,0	10,7	16,7	26,7	40,0	50,0	50,0

xx1400000488

#### Service temperature range

Hilti HVU adhesive may be applied in the temperature ranges given below. An elevated base material temperature may lead to a reduction of the design bond resistance.

Temperature range	Base material temperature	Maximum long term base material temperature <sup>i</sup>	Maximum short term base material temperature <sup>ii</sup>
Temperature range 1	-40 °C to +40 °C	+24 °C	+40 °C
Temperature range 2	-40 °C to +80 °C	+50 °C	+80 °C
Temperature range 3	-40 °C to +120 °C	+72 °C	+120 °C

- <sup>i</sup> Long-term elevated base material temperatures are roughly constant over significant periods of time.
- <sup>ii</sup> Short-term elevated base material temperatures are those that occur over brief intervals, e.g. as a result of diurnal cycling.

*Continues on next page*

## 8 Reference information

### 8.9 HILTI adhesive anchor

Continued

#### Material

##### Mechanical properties of HAS

			Data according ETA-05/0255, issue 2011-06-23							
Anchor size			M8	M10	M12	M16	M20	M24	M27	M30
Nominal tensile strength $f_{uk}$	HAS-(E)(F) 5.8	[N/mm <sup>2</sup> ]	500	500	500	500	500	500	-	-
	HAS-(E)(F) 8.8	[N/mm <sup>2</sup> ]	800	800	800	800	800	800	800	800
	HAS-(E)R	[N/mm <sup>2</sup> ]	700	700	700	700	700	700	500	500
	HAS-(E)HCR	[N/mm <sup>2</sup> ]	800	800	800	800	800	700	-	-
Yield strength $f_{yk}$	HAS-(E)(F) 5.8	[N/mm <sup>2</sup> ]	400	400	400	400	400	400	-	-
	HAS-(E)(F) 8.8	[N/mm <sup>2</sup> ]	640	640	640	640	640	640	640	640
	HAS-(E)R	[N/mm <sup>2</sup> ]	450	450	450	450	450	450	210	210
	HAS-(E)HCR	[N/mm <sup>2</sup> ]	640	640	640	640	640	400	-	-
Stressed cross-section $A_s$	HAS	[mm <sup>2</sup> ]	32,8	52,3	76,2	144	225	324	427	519
Moment of resistance $W$	HAS	[mm <sup>3</sup> ]	27,0	54,1	93,8	244	474	809	1274	1706

##### Material quality

Part	Material
Threaded rod HAS-(E)(F) M8-M24	Strength class 5.8, $A_5 > 8\%$ ductile steel galvanized $\geq 5 \mu\text{m}$ (F) hot dipped galvanized $\geq 45 \mu\text{m}$ ,
Threaded rod HAS-(E)F M8-M30	Strength class 8.8, $A_5 > 8\%$ ductile steel galvanized $\geq 5 \mu\text{m}$ , (F) hot dipped galvanized $\geq 45 \mu\text{m}$ ,
Threaded rod HAS-(E)R	Stainless steel grade A4, $A_5 > 8\%$ ductile strength class 70 for $\leq$ M24 and class 50 for M27 to M30, 1.4401; 1.4404; 1.4578; 1.4571; 1.4439; 1.4362
Threaded rod HAS-(E)HCR	High corrosion resistant steel, 1.4529; 1.4565 strength $\leq$ M20: $R_m = 800 \text{ N/mm}^2$ , $R_{p0.2} = 640 \text{ N/mm}^2$ , $A_5 > 8\%$ ductile M24: $R_m = 700 \text{ N/mm}^2$ , $R_{p0.2} = 400 \text{ N/mm}^2$ , $A_5 > 8\%$ ductile
Washer ISO 7089	Steel galvanized, hot dipped galvanized,
	Stainless steel, 1.4401; 1.4404; 1.4578; 1.4571; 1.4439; 1.4362
	High corrosion resistant steel, 1.4529; 1.4565
Nut EN ISO 4032	Strength class 8, steel galvanized $\geq 5 \mu\text{m}$ , hot dipped galvanized $\geq 45 \mu\text{m}$ ,
	Strength class 70, stainless steel grade A4, 1.4401; 1.4404; 1.4578; 1.4571; 1.4439; 1.4362
	Strength class 70, high corrosion resistant steel, 1.4529; 1.4565

xx1400000490

#### Installation


##### Installation equipment

Anchor size	M16
Rotary hammer	TE 2 - TE 16
Other tools	blow out pump or compressed air gun, setting tools

Continues on next page

Installation

Dry and water-saturated concrete, hammer drilling



xx140000487

For detailed information on installation see instruction for use given with the package of the product.

For technical data for anchors in diamond drilled holes contact the Hilti Technical advisory service.

Curing time for general conditions

Temperature of the base material	Curing time before anchor can be fully loaded
20 °C to 40 °C	20 minutes
10 °C to 19 °C	30 minutes
0 °C to 9 °C	1 hour
-5 °C to - 1 °C	5 hour

**This page is intentionally left blank**

## 9 Spare parts

### 9.1 Spare part lists and illustrations

---

#### Location

Spare parts and exploded views are not included in the manual but delivered as a separate document for registered users on myABB Business Portal, [www.abb.com/myABB](http://www.abb.com/myABB).



#### Tip

All documents can be found via myABB Business Portal, [www.abb.com/myABB](http://www.abb.com/myABB).

**This page is intentionally left blank**



## 10 Circuit diagrams

### Overview

The circuit diagrams are not included in this manual, but are available for registered users on myABB Business Portal, [www.abb.com/myABB](http://www.abb.com/myABB).

See the article numbers in the tables below.

### Track

Product	Article numbers for circuit diagrams
<i>Circuit diagram - IRT 510</i>	<i>3HAC091050-001</i>

### Controllers

Product	Article numbers for circuit diagrams
<i>Circuit diagram - OmniCore V250XT</i>	<i>3HAC074000-008</i>
<i>Circuit diagram - OmniCore V400XT</i>	<i>3HAC082020-008</i>

### Robots

Product	Article numbers for circuit diagrams
<i>Circuit diagram - IRB 1520</i>	<i>3HAC039498-007</i>
<i>Circuit diagram - IRB 1600/1660</i>	<i>3HAC021351-003</i>
<i>Circuit diagram - IRB 2600</i>	<i>3HAC029570-007</i>
<i>Circuit diagram - IRB 4600</i>	<i>3HAC029038-003</i>

**This page is intentionally left blank**

# Index

## A

allergenic material, 26  
 aluminum  
   disposal, 260  
 ambient humidity  
   operation, 42  
   storage, 42  
 ambient temperature  
   operation, 42  
   storage, 42  
 assessment of hazards and risks, 26

## B

base frame, 125  
 batteries  
   disposal, 260  
 brakes  
   testing function, 34

## C

cabinet lock, 27  
 calibration  
   when to calibrate, 255  
 carbon dioxide extinguisher, 27  
 cast iron  
   disposal, 260  
 circuit boards  
   disposal, 260  
 climbing on robot, 30  
 copper  
   disposal, 260

## E

environmental information, 260  
 ESD  
   damage elimination, 49  
   sensitive equipment, 49

## F

fire extinguishing, 27  
 foundation  
   requirements, 39

## G

grease, 30  
   disposal, 260

## H

hanging  
   installed hanging, 26  
 hazard levels, 17  
 hazardous material, 260  
 height  
   installed at a height, 26  
 hot surfaces, 30  
 HRA, 26  
 humidity  
   operation, 42  
   storage, 42

## I

integrator responsibility, 26

## L

labels

robot, 19  
 lifting accessory, 269  
 limitation of liability, 15  
 lithium  
   disposal, 260  
 Lithium  
   disposal, 260  
 lock and tag, 27  
 lubricants, 30

## M

magnesium  
   disposal, 260

## N

national regulations, 26  
 neodymium  
   disposal, 260  
 nodular iron  
   disposal, 260

## O

oil, 30  
   disposal, 260  
 operating conditions, 42  
 original spare parts, 15

## P

pedestal  
   installed on pedestal, 26  
 personnel  
   requirements, 16  
 plastic  
   disposal, 260  
 PPE, 16  
 product standards, 264  
 protective equipment, 16  
 protective wear, 16

## R

recycling, 260  
 regional regulations, 26  
 release brakes, 33  
 replacements, report, 167  
 report replacements, 167  
 requirements on foundation, 39  
 responsibility and validity, 15  
 risk of burns, 30  
 robot  
   labels, 19  
   symbols, 19  
 rubber  
   disposal, 260

## S

safety  
   brake testing, 34  
   ESD, 49  
   fire extinguishing, 27  
   release robot axes, 33  
   signals, 17  
   signals in manual, 17  
   symbols, 17  
   symbols on robot, 19  
   test run, 140  
 safety devices, 27  
 safety signals

- in manual, 17
- safety standards, 264
- screw joints, 266
- setting the base frame, 125
- shipping, 259
- signals
  - safety, 17
- standards, 264
- steel
  - disposal, 261
- storage conditions, 42
- symbols
  - safety, 17
- system integrator requirements, 26

## T

- temperatures

- operation, 42
- storage, 42
- testing
  - brakes, 34
- transportation, 259
- troubleshooting
  - safety, 35

## U

- upcycling, 260
- users
  - requirements, 16

## V

- validity and responsibility, 15

## W

- weight, 41





**ABB AB**

**Robotics & Discrete Automation**

S-721 68 VÄSTERÅS, Sweden

Telephone +46 10-732 50 00

**ABB AS**

**Robotics & Discrete Automation**

Nordlysvegen 7, N-4340 BRYNE, Norway

Box 265, N-4349 BRYNE, Norway

Telephone: +47 22 87 2000

**ABB Engineering (Shanghai) Ltd.**

Robotics & Discrete Automation

No. 4528 Kangxin Highway

PuDong New District

SHANGHAI 201319, China

Telephone: +86 21 6105 6666

**ABB Inc.**

**Robotics & Discrete Automation**

1250 Brown Road

Auburn Hills, MI 48326

USA

Telephone: +1 248 391 9000

**[abb.com/robotics](http://abb.com/robotics)**