

ROBOTICS

Product manual

IRB 660



Trace back information:
Workspace 22C version a9
Checked in 2022-09-28
Skribenta version 5.5.019

Product manual
IRB 660 - 180/3.15
IRB 660 - 250/3.15

IRC5, OmniCore

Document ID: 3HAC025755-001

Revision: AB

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damage to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2006-2022 ABB. All rights reserved.
Specifications subject to change without notice.

Table of contents

| | |
|---|-----------|
| Overview of this manual | 9 |
| Product documentation | 16 |
| How to read the product manual | 18 |
| 1 Safety | 19 |
| 1.1 Safety information | 19 |
| 1.1.1 Limitation of liability | 19 |
| 1.1.2 Requirements on personnel | 20 |
| 1.2 Safety signals and symbols | 21 |
| 1.2.1 Safety signals in the manual | 21 |
| 1.2.2 Safety symbols on manipulator labels | 23 |
| 1.3 Robot stopping functions | 29 |
| 1.4 Safety during installation and commissioning | 30 |
| 1.5 Safety during operation | 33 |
| 1.6 Safety during maintenance and repair | 34 |
| 1.6.1 Safety during maintenance and repair | 34 |
| 1.6.2 Emergency release of the robot axes | 37 |
| 1.6.3 Brake testing | 38 |
| 1.7 Safety during troubleshooting | 39 |
| 1.8 Safety during decommissioning | 40 |
| 2 Installation and commissioning | 41 |
| 2.1 Introduction to installation and commissioning | 41 |
| 2.2 Unpacking | 42 |
| 2.2.1 Pre-installation procedure | 42 |
| 2.2.2 Working range and type of motion | 46 |
| 2.2.3 Risk of tipping/stability | 48 |
| 2.2.4 The unit is sensitive to ESD | 49 |
| 2.3 On-site installation | 50 |
| 2.3.1 Lifting robot with fork lift | 50 |
| 2.3.2 Lifting robot with roundslings | 55 |
| 2.3.3 Lifting robot with lifting accessory (recommended lifting method) | 58 |
| 2.3.4 Manually releasing the brakes | 60 |
| 2.3.5 Lifting the base plate | 62 |
| 2.3.6 Securing the base plate | 63 |
| 2.3.7 Orienting and securing the robot | 68 |
| 2.3.8 Fitting equipment on robot | 71 |
| 2.3.9 Safety lamp (option for IRC5) | 75 |
| 2.3.10 Loads fitted to the robot, stopping time and braking distances | 76 |
| 2.3.11 Extended working range, axis 1 (option) | 77 |
| 2.4 Restricting the working range | 79 |
| 2.4.1 Axes with restricted working range | 79 |
| 2.4.2 Mechanically restricting the working range of axis 1 | 80 |
| 2.5 Robot in cold environments | 82 |
| 2.5.1 Start of robot in cold environments | 82 |
| 2.6 Electrical connections | 83 |
| 2.6.1 Robot cabling and connection points | 83 |
| 2.6.2 Customer connectors on the manipulator | 86 |
| 2.7 Test run after installation, maintenance, or repair | 88 |
| 3 Maintenance | 89 |
| 3.1 Introduction | 89 |
| 3.2 Maintenance schedule and expected component life | 90 |
| 3.2.1 Specification of maintenance intervals | 90 |
| 3.2.2 Maintenance schedule | 91 |
| 3.2.3 Expected component life | 93 |

Table of contents

| | | |
|----------|---|------------|
| 3.3 | Inspection activities | 94 |
| 3.3.1 | Inspecting the oil level in axis-1 gearbox | 94 |
| 3.3.2 | Inspecting, oil level gearbox axes 2 - 3 | 96 |
| 3.3.3 | Inspecting, oil level gearbox axis 6 | 99 |
| 3.3.4 | Inspecting, balancing device bearings and piston rod guide ring | 101 |
| 3.3.5 | Inspecting, cable harness | 105 |
| 3.3.6 | Inspecting the information labels | 108 |
| 3.3.7 | Inspecting the axis-1 mechanical stop pin | 110 |
| 3.3.8 | Inspecting the additional mechanical stops | 112 |
| 3.3.9 | Inspection, dampers | 114 |
| 3.3.10 | Inspecting the signal lamp (option) | 116 |
| 3.4 | Replacement/changing activities | 118 |
| 3.4.1 | Type of lubrication in gearboxes | 118 |
| 3.4.2 | Changing oil, axis-1 gearbox | 119 |
| 3.4.3 | Changing oil, gearbox axes 2 and 3 | 122 |
| 3.4.4 | Changing oil, gearbox axis 6 | 126 |
| 3.4.5 | Replacing the SMB battery | 128 |
| 3.5 | Lubrication activities | 132 |
| 3.5.1 | Lubricating balancing device bearings and piston rod | 132 |
| 3.6 | Cleaning activities | 135 |
| 3.6.1 | Cleaning the IRB 660 | 135 |
| 4 | Repair | 137 |
| 4.1 | Introduction | 137 |
| 4.2 | General procedures | 138 |
| 4.2.1 | Performing a leak-down test | 138 |
| 4.2.2 | Mounting instructions for bearings | 139 |
| 4.2.3 | Mounting instructions for sealings | 141 |
| 4.2.4 | Cut the paint or surface on the robot before replacing parts | 144 |
| 4.2.5 | The brake release buttons may be jammed after service work | 145 |
| 4.3 | Complete robot | 146 |
| 4.3.1 | Replacing cable harness, lower end (axes 1-3) | 146 |
| 4.3.2 | Replacing the cable harness, upper end (incl. axis 6) | 154 |
| 4.3.3 | Replacing the base, including axis 1 gearbox | 160 |
| 4.4 | Upper and lower arm | 168 |
| 4.4.1 | Replacing the turning disk | 168 |
| 4.4.2 | Replacement of tilthouse unit | 172 |
| 4.4.3 | Replacement of upper arm | 186 |
| 4.4.4 | Replacement of linkage - upper rod | 196 |
| 4.4.5 | Replacing the linkage - lower rod | 200 |
| 4.4.6 | Replacement of linkage - link | 204 |
| 4.4.7 | Replacing the parallel rod | 211 |
| 4.4.8 | Replacing the complete lower arm | 216 |
| 4.4.9 | Replacement of parallel arm | 224 |
| 4.5 | Frame and base | 231 |
| 4.5.1 | Replacing the balancing device | 231 |
| 4.5.2 | Replacing the SMB unit | 239 |
| 4.5.3 | Replacing the brake release board | 242 |
| 4.6 | Motors | 246 |
| 4.6.1 | Replacing motor, axis 1 | 246 |
| 4.6.2 | Replacing motors, axes 2 and 3 | 253 |
| 4.6.3 | Replacing motor, axis 6 | 264 |
| 4.7 | Gearboxes | 271 |
| 4.7.1 | Replacing the axis 1 gearbox | 271 |
| 4.7.2 | Replacing the gearbox, axes 2- 3 | 282 |
| 4.7.3 | Replacing gearbox axis 6 | 294 |

| | | |
|----------|---|------------|
| 5 | Calibration | 301 |
| 5.1 | Introduction to calibration | 301 |
| 5.1.1 | Introduction and calibration terminology | 301 |
| 5.1.2 | Calibration methods | 302 |
| 5.1.3 | When to calibrate | 303 |
| 5.2 | Synchronization marks and axis movement directions | 304 |
| 5.2.1 | Synchronization marks and synchronization position for axes | 304 |
| 5.2.2 | Calibration movement directions for all axes | 305 |
| 5.3 | Updating revolution counters | 306 |
| 5.3.1 | Updating revolution counters on IRC5 robots | 306 |
| 5.3.2 | Updating revolution counters on OmniCore robots | 310 |
| 5.4 | Calibrating with Axis Calibration method | 312 |
| 5.4.1 | Description of Axis Calibration | 312 |
| 5.4.2 | Calibration tools for Axis Calibration | 315 |
| 5.4.3 | Installation locations for the calibration tools | 317 |
| 5.4.4 | Axis Calibration - Running the calibration procedure | 319 |
| 5.4.5 | Reference calibration | 323 |
| 5.5 | Verifying the calibration | 325 |
| 5.6 | Checking the synchronization position | 326 |
| 6 | Decommissioning | 329 |
| 6.1 | Introduction to decommissioning | 329 |
| 6.2 | Environmental information | 330 |
| 6.3 | Scrapping of robot | 332 |
| 6.4 | Decommissioning of balancing device | 333 |
| 7 | Reference information | 337 |
| 7.1 | Introduction | 337 |
| 7.2 | Applicable standards | 338 |
| 7.3 | Unit conversion | 339 |
| 7.4 | Screw joints | 340 |
| 7.5 | Weight specifications | 343 |
| 7.6 | Standard tools | 344 |
| 7.7 | Special tools | 345 |
| 7.8 | Lifting accessories and lifting instructions | 347 |
| 8 | Spare part lists | 349 |
| 8.1 | Spare part lists and illustrations | 349 |
| 9 | Circuit diagrams | 351 |
| 9.1 | Circuit diagrams | 351 |
| | Index | 353 |

This page is intentionally left blank

Overview of this manual

About this manual

This manual contains instructions for:

- mechanical and electrical installation of the robot
- maintenance of the robot
- mechanical and electrical repair of the robot.

The manual also contains reference information for all procedures detailed in the manual.

Usage

This manual should be used during:

- installation, from lifting the robot to its work site and securing it to the foundation, to making it ready for operation
- maintenance work
- repair work.

Who should read this manual?

This manual is intended for:

- installation personnel
- maintenance personnel
- repair personnel.

Prerequisites

Maintenance/repair/installation personnel working with an ABB Robot must:

- be trained by ABB and have the required knowledge of mechanical and electrical installation/repair/maintenance work.

Product manual scope

The manual covers covers all variants and designs of the IRB 660. Some variants and designs may have been removed from the business offer and are no longer available for purchase.

Organization of chapters

The manual is organized in the following chapters:

| Chapter | Contents |
|--------------------------------|--|
| Safety | Safety information that must be read through before performing any installation or service work on robot. Contains general safety aspects as well as more specific information about how to avoid personal injuries and damage to the product. |
| Installation and commissioning | Required information about lifting and installation of the robot. |
| Maintenance | Step-by-step procedures that describe how to perform maintenance of the robot. Based on a maintenance schedule that may be used in the work of planning periodical maintenance. |

Continues on next page

Overview of this manual

Continued

| Chapter | Contents |
|------------------------|---|
| Repair | Step-by-step procedures that describe how to perform repair activities of the robot. Based on available spare parts. |
| Calibration | Calibration procedures and general information about calibration. |
| Decommissioning | Environmental information about the robot and its components. |
| Reference information | Useful information when performing installation, maintenance or repair work. Includes lists of necessary tools, additional documents, safety standards etc. |
| Spare part / part list | Complete spare part list of the robot components, shown in exploded views. |
| Exploded views | Detailed illustrations of the robot with reference numbers to the part list. |
| Circuit diagram | Reference to the circuit diagram for the robot. |

References

General

| Document name | Document ID |
|--|-----------------------|
| <i>Product manual, spare parts - IRB 660</i> | <i>3HAC049102-001</i> |
| <i>Circuit diagram - IRB 660</i> | <i>3HAC025691-001</i> |
| <i>Technical reference manual - Lubrication in gearboxes</i> | <i>3HAC042927-001</i> |
| <i>Safety manual for robot - Manipulator and IRC5 or OmniCore controllerⁱ</i> | <i>3HAC031045-001</i> |

ⁱ This manual contains all safety instructions from the product manuals for the manipulators and the controllers.

OmniCore robots

| Document name | Document ID |
|---|-----------------------|
| <i>Product specification - IRB 660</i> | <i>3HAC081955-001</i> |
| <i>Product manual - OmniCore V250XT</i> | <i>3HAC073447-001</i> |
| <i>Operating manual - OmniCore</i> | <i>3HAC065036-001</i> |
| <i>Technical reference manual - System parameters</i> | <i>3HAC065041-001</i> |

IRC5 robots

| Document name | Document ID |
|--|-----------------------|
| <i>Product specification - IRB 660</i> | <i>3HAC023932-001</i> |
| <i>Product manual - IRC5</i> IRC5 with main computer DSQC 639. | <i>3HAC021313-001</i> |
| <i>Product manual - IRC5</i> IRC5 with main computer DSQC1000. | <i>3HAC047136-001</i> |
| <i>Operating manual - IRC5 with FlexPendant</i> | <i>3HAC050941-001</i> |
| <i>Operating manual - Calibration Pendulum</i> | <i>3HAC16578-1</i> |
| <i>Operating manual - Service Information System</i> | <i>3HAC050944-001</i> |
| <i>Application manual - Additional axes and stand alone controller</i> | <i>3HAC051016-001</i> |

Continues on next page

| Document name | Document ID |
|--|----------------|
| Technical reference manual - System parameters | 3HAC050948-001 |
| Application manual - CalibWare Field | 3HAC030421-001 |

Revisions

| Revision | Description |
|----------|--|
| - | First edition |
| A | Detailed illustrations added in some procedures. Art. no. on tools added. Chapter "Replacement of tilthouse unit" has been changed, in order to make it easier to follow the procedure. |
| B | Changes made in: <ul style="list-style-type: none"> Prerequisites in section Overview Oil change in section Maintenance This revision also includes the following additions and/or changes: <ul style="list-style-type: none"> The section "<i>Type of oil in gearboxes</i>" in chapter Maintenance has been updated according to changes made in oil types and intervals for oil change. Section "<i>Replacement of Cable harness lower end</i>" in chapter Repair has been updated. Section "<i>Replacement of Parallel rod</i>" in chapter Repair has been updated. Section "<i>Replacement of Balancing device</i>" in chapter Repair has been updated. Section "<i>Replacement of Gearbox axis 6</i>" in chapter Repair has been updated. Values for tightening torque on M24 screws in chapter Reference information, added. New revision on Circuit diagrams. |
| C | This revision includes the following additions and/or changes: <ul style="list-style-type: none"> Section "<i>Securing the robot</i>" in Installation chapter has been removed. Content is not applicable to IRB 660. Section "<i>What is an emergency stop?</i>" added to chapter Safety Section "<i>Maintenance schedule</i>" in chapter Maintenance: Intervals for inspection activities and oilchanges have been revised Section "<i>Maintenance schedule</i>" in chapter Maintenance: Overhaul of robot is new Section "<i>Maintenance schedule</i>" in chapter Maintenance: The information about Service Information System (SIS) has been updated Section "<i>Maintenance schedule</i>" in chapter Maintenance: Intervals for replacement of battery pack changed Section "<i>Expected lifetime</i>" in chapter Maintenance: The lifetime of certain parts has been revised Section "<i>Cleaning of robot</i>" updated |
| D | This revision includes the following additions and/or changes: <ul style="list-style-type: none"> Instruction for how to inspect oil level corrected, see Inspecting, oil level gearbox axis 6 on page 99. Circuit diagrams are not included in this document but delivered as separate files. See Circuit diagrams on page 351. List of safety standards updated. Decommissioning chapter added. The lifetime of certain parts has been updated, see Expected component life on page 93. |

Continues on next page

| Revision | Description |
|----------|--|
| | <p>The chapter <i>Safety</i> updated with:</p> <ul style="list-style-type: none"> • Updated safety signal graphics for the levels <i>Danger</i> and <i>Warning</i>, see Safety signals in the manual on page 21. • New safety labels on the manipulators, see Safety symbols on manipulator labels on page 23. • Revised terminology: <i>robot</i> replaced with <i>manipulator</i>. |
| E | <p>This revision includes the following updates:</p> <ul style="list-style-type: none"> • Maximum deviation changed, see Securing the base plate on page 63. |
| F | <p>This revision includes following updates:</p> <ul style="list-style-type: none"> • Added index words throughout the manual. • Inspection method of oil level in gearbox, axis 6, is changed, see Inspecting, oil level gearbox axis 6 on page 99. • Position numbers in figure corrected, see Location of dampers on page 114. • Removed information about lubricating attachment screws, removed tightening torque and screw dimension for axis 2 and 3 and added screw dimension for axis 1, see Inspecting the additional mechanical stops on page 112. • Changed tightening torque of fork lift adapters, from 60 Nm to 270 Nm, see Lifting robot with fork lift on page 52. • Changed article numbers of robot power cables, see Robot cable, power on page 84. • Information about restricting and extending the working range of axis 1 is now separated, see Mechanically restricting the working range of axis 1 on page 80 and the new section Extended working range, axis 1 (option) on page 77. Also added signal about option 561-1 in section Inspecting the axis-1 mechanical stop pin on page 110. • Added detailed information about how to decommission the balancing device, see Decommissioning of balancing device on page 333. • Added new safety symbols, see Safety symbols on manipulator labels on page 23. |
| G | <p>This revision includes the following updates:</p> <ul style="list-style-type: none"> • A new block, about general illustrations, added in section How to read the product manual on page 18. • Added a KM10 socket to the list of required equipment and the instructions when replacing the lower rod, see section Replacing the linkage - lower rod on page 200. The tool is also added to the list of Special tools in the Reference chapter. • Added instructions for securing parallel arm and lower arm to each other before removing the lower arm, see Replacing the complete lower arm on page 216. • Added guide sleeves to hold the axes 2/3 sealing in place when re-fitting the lower arm, see Replacing the complete lower arm on page 216. • Made minor corrections and improvements in the complete instruction for how to replace the lower arm system, see Replacing the complete lower arm on page 216. • Made minor corrections and improvements in the complete instruction for how to replace the parallel arm, see Replacement of parallel arm on page 224. • Made minor corrections and improvements in the complete instruction for how to replace the axis 1 gearbox, see Replacing the axis 1 gearbox on page 271. |

| Revision | Description |
|----------|---|
| | <ul style="list-style-type: none"> Some general tightening torques have been changed/added, see updated values in Screw joints on page 340. Added information about batteries. |
| H | <p>This revision includes the following updates:</p> <ul style="list-style-type: none"> The maximum allowed deviation in levelness of the base plate is changed, see Securing the base plate on page 63. Reference to Hilti standard added to the foundation recommendation for the base plate and class designation for foundation is changed to European standard C25/C30 (previously Swedish standard K25/K30), see Securing the base plate on page 63. Corrections and improvements are made in the instruction for how to replace the axis-2 and axis-3 gearbox, see Replacing the gearbox, axes 2- 3 on page 282. All data about type of lubrication in gearboxes is moved from the manual to a separate lubrication manual, see Type and amount of oil in gearboxes on page 118. Added spare part numbers for the customer connection kits and the base plate, see Spare parts - option in Product manual, spare parts - IRB 660. A new SMB unit and battery is introduced, with longer battery life-time. |
| J | <p>This revision includes the following updates:</p> <ul style="list-style-type: none"> New article number for painted motor added to spare parts, see Spare parts - frame to lower arm in Product manual, spare parts - IRB 660. Spare part number on item 102, 104 and 107, frame to base changed. See Spare parts - frame to Base in Product manual, spare parts - IRB 660. Added information about risks when scrapping a decommissioned robot, see Scrapping of robot on page 332. Spare parts and exploded views are not included in this document but delivered as a separate document. See Product manual, spare parts - IRB 660. Article number for lubrication tool changed, see Lubricating balancing device bearings and piston rod on page 132 |
| K | <p>This revision includes the following updates:</p> <ul style="list-style-type: none"> The maximum allowed deviation in levelness of the base plate and foundation is changed, see Securing the base plate on page 63. Added tightening torque for R1.SMB and 7th axis connector, see Replacing cable harness, lower end (axes 1-3) on page 146. Minor corrections. |
| L | <p>This revision includes the following updates:</p> <ul style="list-style-type: none"> Lifting tools updated (guide pin 3HAC7601-086 and guide pin 3HAC7601-087 removed) Special tools updated (Pressing, inner ring 3HAC023112-008 removed) Illustrations of SMB battery RMU improved. |
| M | <p>Published in release R16.2. The following updates are done in this revision:</p> <ul style="list-style-type: none"> Drawing of base plate is not available for purchase, faulty information removed in Securing the base plate on page 63. Corrections due to updates in terminology. New standard calibration method is introduced (Axis Calibration). See Calibration on page 301. Information about grounding point added. See Robot cabling and connection points on page 83. |

Continues on next page

| Revision | Description |
|----------|--|
| N | <p>Published in release R17.2. The following updates are made in this revision:</p> <ul style="list-style-type: none"> • Caution about removing metal residues added in sections about SMB boards. • Information about minimum resonance frequency added. • Bending radius for static floor cables added. • Updated list of applicable standards. • Added text regarding overhaul in section specification of maintenance intervals. • Updated the section Start of robot in cold environments on page 82. • Updated information regarding replacement of brake release board. • Updated information regarding disconnecting and reconnecting battery cable to serial measurement board. • Updated information regarding replacing of balancing device. • Definition of reference calibration clarified. |
| P | <p>Published in release R18.1. The following updates are made in this revision:</p> <ul style="list-style-type: none"> • Information added about fatigue to Axis Calibration tool, see Calibration tools for Axis Calibration on page 315. • Added sections in General procedures on page 138. • Safety restructured. • New spare part number brake release board (was DSQC563). • Note added to calibration chapter to emphasize the requirement of equally dressed robot when using previously created reference calibration values. • Information about myABB Business Portal added. |
| Q | <p>Published in release R18.2. The following updates are done in this revision:</p> <ul style="list-style-type: none"> • Added locating hole position in mounting flange view. |
| R | <p>Published in release R18.2. The following updates are done in this revision:</p> <ul style="list-style-type: none"> • Updated references. |
| S | <p>Published in release 19B. The following updates are made in this revision:</p> <ul style="list-style-type: none"> • New touch up color Graphite White available. See Cut the paint or surface on the robot before replacing parts on page 144. • Tightening torque for oil plug axis 6 changed to 20 Nm. • New adapter for axis-3 shaft replacement and updated article number for KM12 socket for axis-3 and axis-2 shaft replacements. See Replacement of upper arm on page 186. |
| T | <p>Published in release 19C. The following updates are made in this revision:</p> <ul style="list-style-type: none"> • Added information regarding the support rings of the upper arm housing, see Replacement of upper arm on page 186. |
| U | <p>Published in release 19D. The following updates are made in this revision:</p> <ul style="list-style-type: none"> • Added press tool for installation of support rings in the upper arm housing, see Replacement of upper arm on page 186. • Sealing compound Permatex No. 3 replaced by Trans7 from Trans Clear. |
| V | <p>Published in release 20A. The following updates are made in this revision:</p> <ul style="list-style-type: none"> • Clarified and added information in mounting instructions for rotating sealings, see Mounting instructions for sealings on page 141. • Clarified text about position of robot and added table with dependencies between axes during Axis Calibration. • Changed tightening torque for axis-2 and axis-3 shaft, see Replacement of upper arm on page 186 and increased the torque span for standard torque wrench, see Standard tools on page 344. |
| W | <p>Published in release 20C. The following updates are made in this revision:</p> <ul style="list-style-type: none"> • Changed tightening torques on the wrist oil plugs. |

Continues on next page

| Revision | Description |
|----------|--|
| | <ul style="list-style-type: none"> Removed lifting tool for axis-2 and axis-3 gearbox from the special tools list (lifting method was changed in previous revision). |
| X | <p>Published in release 21B. The following updates are made in this revision:</p> <ul style="list-style-type: none"> Lubrication tool number changed, see Replacement of linkage - link on page 204. New number and instruction for press tool, parallel arm, see Replacement of parallel arm on page 224. New number and instruction for press tool, , see Replacement of tilthouse unit on page 172 . New number and instruction for press tool, linkage - link, see Replacement of linkage - link on page 204. Number for Lubrication tool number changed, see Required equipment on page 133. Text regarding fastener quality is updated, see Fastener quality on page 74. |
| Y | <p>Published in release 21C. The following updates are made in this revision:</p> <ul style="list-style-type: none"> Info about option Extended working range included, see Extended working range, axis 1 (option) on page 77. |
| Z | <p>Published in release 21D. The following updates are made in this revision:</p> <ul style="list-style-type: none"> New section regarding customer connectors added, see Customer connectors on the manipulator. |
| AA | <p>Published in release 22A. The following updates are done in this revision:</p> <ul style="list-style-type: none"> Updated information about Gleitmo treated screws, see Screw joints on page 340. Removed information about position switches as they are no longer available. |
| AB | <p>Published in release 22C. The following updates are done in this revision:</p> <ul style="list-style-type: none"> Added information for the OmniCore robot controller. Corrected article number for lubrication tool intended for lubrication of balancing device bearings and piston rod. Incorrect number 3HAC5222-1 is replaced with correct number 3HAC5222-2. |

Product documentation

Categories for user documentation from ABB Robotics

The user documentation from ABB Robotics is divided into a number of categories. This listing is based on the type of information in the documents, regardless of whether the products are standard or optional.



Tip

All documents can be found via myABB Business Portal, www.abb.com/myABB.

Product manuals

Manipulators, controllers, DressPack/SpotPack, and most other hardware is delivered with a **Product manual** that generally contains:

- Safety information.
- Installation and commissioning (descriptions of mechanical installation or electrical connections).
- Maintenance (descriptions of all required preventive maintenance procedures including intervals and expected life time of parts).
- Repair (descriptions of all recommended repair procedures including spare parts).
- Calibration.
- Troubleshooting
- Decommissioning.
- Reference information (safety standards, unit conversions, screw joints, lists of tools).
- Spare parts list with corresponding figures (or references to separate spare parts lists).
- References to circuit diagrams.

Technical reference manuals

The technical reference manuals describe reference information for robotics products, for example lubrication, the RAPID language, and system parameters.

Application manuals

Specific applications (for example software or hardware options) are described in **Application manuals**. An application manual can describe one or several applications.

An application manual generally contains information about:

- The purpose of the application (what it does and when it is useful).
- What is included (for example cables, I/O boards, RAPID instructions, system parameters, software).
- How to install included or required hardware.
- How to use the application.

Continues on next page

- Examples of how to use the application.

Operating manuals

The operating manuals describe hands-on handling of the products. The manuals are aimed at those having first-hand operational contact with the product, that is production cell operators, programmers, and troubleshooters.

How to read the product manual

Reading the procedures

The procedures contain references to figures, tools, material, and so on. The references are read as described below.

References to figures

The procedures often include references to components or attachment points located on the manipulator/controller. The components or attachment points are marked with *italic text* in the procedures and completed with a reference to the figure where the current component or attachment point is shown.

The denomination in the procedure for the component or attachment point corresponds to the denomination in the referenced figure.

The table below shows an example of a reference to a figure from a step in a procedure.

| | Action | Note/Illustration |
|----|---|--|
| 8. | Remove the <i>rear attachment screws, gearbox</i> . | Shown in the figure Location of gearbox on page xx . |

References to required equipment

The procedures often include references to equipment (spare parts, tools, etc.) required for the different actions in the procedure. The equipment is marked with *italic text* in the procedures and completed with a reference to the section where the equipment is listed with further information, that is article number and dimensions.

The designation in the procedure for the component or attachment point corresponds to the designation in the referenced list.

The table below shows an example of a reference to a list of required equipment from a step in a procedure.

| | Action | Note/Illustration |
|----|--|--|
| 3. | Fit a new <i>sealing, axis 2</i> to the gearbox. | Art. no. is specified in Required equipment on page xx . |

Safety information

The manual includes a separate safety chapter that must be read through before proceeding with any service or installation procedures. All procedures also include specific safety information when dangerous steps are to be performed.

Read more in the chapter [Safety on page 19](#).

Illustrations

The robot is illustrated with general figures that does not take painting or protection type in consideration.

Likewise, certain work methods or general information that is valid for several robot models, can be illustrated with illustrations that show a different robot model than the one that is described in the current manual.

1 Safety

1.1 Safety information

1.1.1 Limitation of liability

Limitation of liability

Any information given in this manual regarding safety must not be construed as a warranty by ABB that the industrial robot will not cause injury or damage even if all safety instructions are complied with.

The information does not cover how to design, install and operate a robot system, nor does it cover all peripheral equipment that can influence the safety of the robot system.

In particular, liability cannot be accepted if injury or damage has been caused for any of the following reasons:

- Use of the robot in other ways than intended.
- Incorrect operation or maintenance.
- Operation of the robot when the safety devices are defective, not in their intended location or in any other way not working.
- When instructions for operation and maintenance are not followed.
- Non-authorized design modifications of the robot.
- Repairs on the robot and its spare parts carried out by in-experienced or non-qualified personnel.
- Foreign objects.
- Force majeure.

Spare parts and equipment

ABB supplies original spare parts and equipment which have been tested and approved. The installation and/or use of non-original spare parts and equipment can negatively affect the safety, function, performance, and structural properties of the robot. ABB is not liable for damages caused by the use of non-original spare parts and equipment.

1 Safety

1.1.2 Requirements on personnel

1.1.2 Requirements on personnel

General

Only personnel with appropriate training are allowed to install, maintain, service, repair, and use the robot. This includes electrical, mechanical, hydraulics, pneumatics, and other hazards identified in the risk assessment.

Persons who are under the influence of alcohol, drugs or any other intoxicating substances are not allowed to install, maintain, service, repair, or use the robot.

The plant liable must make sure that the personnel is trained on the robot, and on responding to emergency or abnormal situations.

Personal protective equipment

Use personal protective equipment, as stated in the instructions.

1.2 Safety signals and symbols

1.2.1 Safety signals in the manual







Introduction to safety signals

This section specifies all safety signals used in the user manuals. Each signal consists of:

- A caption specifying the hazard level (DANGER, WARNING, or CAUTION) and the type of hazard.
- Instruction about how to reduce the hazard to an acceptable level.
- A brief description of remaining hazards, if not adequately reduced.

Hazard levels

The table below defines the captions specifying the hazard levels used throughout this manual.


| Symbol | Designation | Significance |
|---|-------------------------------|---|
|  | DANGER | Signal word used to indicate an imminently hazardous situation which, if not avoided, will result in serious injury. |
|  | WARNING | Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in serious injury. |
|  | ELECTRICAL SHOCK | Signal word used to indicate a potentially hazardous situation related to electrical hazards which, if not avoided, could result in serious injury. |
|  | CAUTION | Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in slight injury. |
|  | ELECTROSTATIC DISCHARGE (ESD) | Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in severe damage to the product. |
|  | NOTE | Signal word used to indicate important facts and conditions. |

Continues on next page

1 Safety

1.2.1 Safety signals in the manual

Continued

| Symbol | Designation | Significance |
|---|-------------|---|
|  | TIP | Signal word used to indicate where to find additional information or how to do an operation in an easier way. |

1.2.2 Safety symbols on manipulator labels

Introduction to symbols

This section describes safety symbols used on labels (stickers) on the manipulator. Symbols are used in combinations on the labels, describing each specific warning. The descriptions in this section are generic, the labels can contain additional information such as values.



Note

The symbols on the labels on the product must be observed. Additional symbols added by the integrator must also be observed.




Types of symbols

Both the manipulator and the controller are marked with symbols, containing important information about the product. This is important for all personnel handling the robot, for example during installation, service, or operation.

The safety labels are language independent, they only use graphics. See [Symbols on safety labels on page 23](#).

The information labels can contain information in text.

Symbols on safety labels






| Symbol | Description |
|---|--|
|  xx0900000812 | Warning! Warns that an accident <i>may</i> occur if the instructions are not followed that can lead to serious injury, possibly fatal, and/or great damage to the product. It applies to warnings that apply to danger with, for example, contact with high voltage electrical units, explosion or fire risk, risk of poisonous gases, risk of crushing, impact, fall from height, etc. |
|  xx0900000811 | Caution! Warns that an accident may occur if the instructions are not followed that can result in injury and/or damage to the product. It also applies to warnings of risks that include burns, eye injury, skin injury, hearing damage, crushing or slipping, tripping, impact, fall from height, etc. Furthermore, it applies to warnings that include function requirements when fitting and removing equipment where there is a risk of damaging the product or causing a breakdown. |
|  xx0900000839 | Prohibition Used in combinations with other symbols. |

Continues on next page





1 Safety

1.2.2 Safety symbols on manipulator labels

Continued

| Symbol | Description |
|---|--|
|  xx0900000813 | See user documentation Read user documentation for details. Which manual to read is defined by the symbol: <ul style="list-style-type: none">• No text: <i>Product manual</i>.• EPS: <i>Application manual - Electronic Position Switches</i>. |
|  xx0900000816 | Before disassembly, see product manual |
|  xx0900000815 | Do not disassemble Disassembling this part can cause injury. |
|  xx0900000814 | Extended rotation This axis has extended rotation (working area) compared to standard. |
|  xx0900000808 | Brake release Pressing this button will release the brakes. This means that the robot arm can fall down. |






Continues on next page

| Symbol | Description |
|---|--|
|  <p>xx0900000810</p>   <p>3HAC 057068-001</p> <p>xx1500002402</p> | <p>Tip risk when loosening bolts The robot can tip over if the bolts are not securely fastened.</p> |
|  <p>xx0900000817</p> | <p>Crush Risk of crush injuries.</p> |







1 Safety

1.2.2 Safety symbols on manipulator labels

Continued

| Symbol | Description |
|--|---|
|  xx0900000818  xx1300001087 | Heat Risk of heat that can cause burns. (Both signs are used) |
|  xx0900000819  xx1000001141  xx1500002616 | Moving robot The robot can move unexpectedly. |

Continues on next page






| Symbol | Description |
|---|--|
|  <p>xx0900000820</p> <p>xx1000001140</p> | <p>Brake release buttons</p> |
|  <p>xx0900000821</p> | <p>Lifting bolt</p> |
|  <p>xx1000001242</p> | <p>Chain sling with shortener</p> |
|  <p>xx0900000822</p> | <p>Lifting of robot</p> |
|  <p>xx0900000823</p> | <p>Oil Can be used in combination with prohibition if oil is not allowed.</p> |
|  <p>xx0900000824</p> | <p>Mechanical stop</p> |

Continues on next page

1 Safety

1.2.2 Safety symbols on manipulator labels

Continued

| Symbol | Description |
|---|--|
|  xx1000001144 | No mechanical stop |
|  xx0900000825 | Stored energy Warns that this part contains stored energy. Used in combination with <i>Do not disassemble</i> symbol. |
|  xx0900000826 | Pressure Warns that this part is pressurized. Usually contains additional text with the pressure level. |
|  xx0900000827 | Shut off with handle Use the power switch on the controller. |
|  xx1400002648 | Do not step Warns that stepping on these parts can cause damage to the parts. |

1.3 Robot stopping functions

Protective stop and emergency stop

The protective stops and emergency stops are described in the product manual for the controller.

For more information see:

- *Product manual - OmniCore V250XT*
- *Product manual - IRC5*
- *Product manual - IRC5 Panel Mounted Controller*

1 Safety

1.4 Safety during installation and commissioning

1.4 Safety during installation and commissioning

National or regional regulations

The integrator of the robot system is responsible for the safety of the robot system.

The integrator is responsible that the robot system is designed and installed in accordance with the safety requirements set forth in the applicable national and regional standards and regulations.

The integrator of the robot system is required to perform a risk assessment.

Layout

The robot integrated to a robot system shall be designed to allow safe access to all spaces during installation, operation, maintenance, and repair.

If robot movement can be initiated from an external control panel then an emergency stop must also be available.

If the manipulator is delivered with mechanical stops, these can be used for reducing the working space.

A perimeter safeguarding, for example a fence, shall be dimensioned to withstand the following:

- The force of the manipulator.
- The force of the load handled by the robot if dropped or released at maximum speed.
- The maximum possible impact caused by a breaking or malfunctioning rotating tool or other device fitted to the robot.

The maximum TCP speed and the maximum velocity of the robot axes are detailed in the section *Robot motion* in the product specification for the respective manipulator.

Consider exposure to hazards, such as slipping, tripping, and falling.

Hazards due to the working position and posture for a person working with or near the robot shall be considered.

Hazards due to noise emission from the robot needs to be considered.

Consider hazards from other equipment in the robot system, for example, that guards remain active until identified hazards are reduced to an acceptable level.

Allergenic material

See [Environmental information on page 330](#) for specification of allergenic materials in the product, if any.

Securing the robot to the foundation

The robot must be properly fixed to its foundation/support, as described in the respective product manual.

When the robot is installed at a height, hanging, or other than mounted directly on the floor, there will be additional hazards.

Continues on next page

Electrical safety

Incoming mains must be installed to fulfill national regulations.

The power supply wiring to the robot must be sufficiently fused and if necessary, it must be possible to disconnect it manually from the mains power.

The power to the robot must be turned off with the main switch and the mains power disconnected when performing work inside the controller cabinet. Lock and tag shall be considered.

Harnesses between controller and manipulator shall be fixed and protected to avoid tripping and wear.

Wherever possible, power on/off or rebooting the robot controller shall be performed with all persons outside the safeguarded space.



Note

Use a CARBON DIOXIDE (CO₂) extinguisher in the event of a fire in the robot.

Safety devices

The integrator is responsible for that the safety devices necessary to protect people working with the robot system are designed and installed correctly.

When integrating the robot with external devices to a robot system:

- The integrator of the robot system must ensure that emergency stop functions are interlocked in accordance with applicable standards.
- The integrator of the robot system must ensure that safety functions are interlocked in accordance with applicable standards.

Other hazards

A robot may perform unexpected limited movement.



WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

The risk assessment should also consider other hazards arising from the application, such as, but not limited to:

- Water
- Compressed air
- Hydraulics

End-effector hazards require particular attention for applications which involve close human collaboration with the robot.

Continues on next page

1 Safety

1.4 Safety during installation and commissioning

Continued

Pneumatic or hydraulic related hazards



Note

The pressure in the complete pneumatic or hydraulic systems must be released before service and maintenance.

All components in the robot system that remain pressurized after switching off the power to the robot must be marked with clearly visible drain facilities and a warning sign that indicates the hazard of stored energy.

Loss of pressure in the robot system may cause parts or objects to drop.

Dump valves should be used in case of emergency.

Shot bolts should be used to prevent tools, etc., from falling due to gravity.

All pipes, hoses, and connections have to be inspected regularly for leaks and damage. Damage must be repaired immediately.

Verify the safety functions

Before the robot system is put into operation, verify that the safety functions are working as intended and that any remaining hazards identified in the risk assessment are mitigated to an acceptable level.

1.5 Safety during operation

Automatic operation

Verify the application in the operating mode manual reduced speed, before changing mode to automatic and initiating automatic operation.

Unexpected movement of robot arm



WARNING

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

A robot may perform unexpected limited movement.



WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

1 Safety

1.6.1 Safety during maintenance and repair

1.6 Safety during maintenance and repair

1.6.1 Safety during maintenance and repair

General

Corrective maintenance must only be carried out by personnel trained on the robot. Maintenance or repair must be done with all electrical, pneumatic, and hydraulic power switched off, that is, no remaining hazards.

Hazards due to stored mechanical energy in the manipulator for the purpose of counterbalancing axes must be considered before maintenance or repair.

Never use the robot as a ladder, which means, do not climb on the controller, manipulator, including motors, or other parts. There are hazards of slipping and falling. The robot might be damaged.


Make sure that there are no loose screws, turnings, or other unexpected parts remaining after work on the robot has been performed.

When the work is completed, verify that the safety functions are working as intended.

Hot surfaces

Surfaces can be hot after running the robot, and touching these may result in burns. Allow the surfaces to cool down before maintenance or repair.

Allergic reaction

| Warning | Description | Elimination/Action |
|--|---|---|
|  Allergic reaction | When working with lubricants there is a risk of an allergic reaction. | Make sure that protective gear like goggles and gloves are always worn. |


Gearbox lubricants (oil or grease)

When handling oil, grease, or other chemical substances the safety information of the respective manufacturer must be observed.










Note

Take special care when handling hot lubricants.

| Warning | Description | Elimination/Action |
|--|--|--|
|  Hot oil or grease | Changing and draining gearbox oil or grease may require handling hot lubricant heated up to 90 °C. | Make sure that protective gear like goggles and gloves are always worn during this activity. |

Continues on next page


| Warning | Description | Elimination/Action |
|--|---|---|
|  Allergic reaction | When working with lubricants there is a risk of an allergic reaction. | Make sure that protective gear like goggles and gloves are always worn. |
|  Possible pressure build-up in gearbox | When opening the oil or grease plug, there may be pressure present in the gearbox, causing lubricant to spray from the opening. | Open the plug carefully and keep away from the opening. Do not overfill the gearbox when filling. |
|  Do not overfill | Overfilling of gearbox lubricant can lead to internal over-pressure inside the gearbox which in turn may: <ul style="list-style-type: none"> • damage seals and gaskets • completely press out seals and gaskets • prevent the robot from moving freely. | Make sure not to overfill the gearbox when filling it with oil or grease. After filling, verify that the level is correct. |
|  Do not mix types of oil | Mixing types of oil may cause severe damage to the gearbox. | When filling gearbox oil, do not mix different types of oil unless specified in the instructions. Always use the type of oil specified for the product. |
|  Oil residues | Oil residues might be present in a drained gearbox and spilled when separating a motor and gearbox during repair. | Make sure that protective gear like goggles/protective visor, gloves and arm protection are always worn during this activity. Put oil absorbent cloth or paper at appropriate locations to catch any oil residues. |
|  Heat up the oil | Warm oil drains quicker than cold oil. | Run the robot before changing the gearbox oil, if possible. |
|  Specified amount depends on drained volume | The specified amount of oil or grease is based on the total volume of the gearbox. When changing the lubricant, the amount refilled may differ from the specified amount, depending on how much has previously been drained from the gearbox. | After filling, verify that the level is correct. |

Continues on next page

1 Safety

1.6.1 Safety during maintenance and repair

Continued

| Warning | Description | Elimination/Action |
|--|--|--------------------|
|  Contaminated oil in gearboxes | For lifetime reasons always drain as much oil as possible from the gearbox. The magnetic oil plugs will gather residual metal chips. | |

Hazards related to batteries

Under rated conditions, the electrode materials and liquid electrolyte in the batteries are sealed and not exposed to the outside.

There is a hazard in case of abuse (mechanical, thermal, electrical) which leads to the activation of safety valves and/or the rupture of the battery container. As a result under certain circumstances, electrolyte leakage, electrode materials reaction with moisture/water or battery vent/explosion/fire may follow.

Do not short circuit, recharge, puncture, incinerate, crush, immerse, force discharge or expose to temperatures above the declared operating temperature range of the product. Risk of fire or explosion.

Operating temperatures are listed in [Operating conditions, robot on page 44](#).

See safety instructions for the batteries in *Material/product safety data sheet - Battery pack (3HAC043118-001)*.

Unexpected movement of robot arm



WARNING

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

A robot may perform unexpected limited movement.



WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

Related information

See also the safety information related to installation and operation.

1.6.2 Emergency release of the robot axes

Description

In an emergency situation, the brakes on a robot axis can be released manually by pushing a brake release button.

How to release the brakes is described in the section:

- [Manually releasing the brakes on page 60](#).

The robot may be moved manually on smaller robot models, but larger models may require using an overhead crane or similar equipment.

Increased injury

Before releasing the brakes, make sure that the weight of the manipulator does not result in additional hazards, for example, even more severe injuries on a trapped person.



DANGER

When releasing the holding brakes, the robot axes may move very quickly and sometimes in unexpected ways.

Make sure no personnel is near or beneath the robot.

1 Safety

1.6.3 Brake testing

1.6.3 Brake testing

When to test

During operation, the holding brake of each axis normally wears down. A test can be performed to determine whether the brake can still perform its function.

How to test

The function of the holding brake of each axis motor may be verified as described below:

- 1 Run each axis to a position where the combined weight of the manipulator and any load is maximized (maximum static load).
- 2 Switch the motor to the MOTORS OFF.
- 3 Inspect and verify that the axis maintains its position.

If the manipulator does not change position as the motors are switched off, then the brake function is adequate.



Note

It is recommended to run the service routine *BrakeCheck* as part of the regular maintenance, see the operating manual for the robot controller.

For robots with the option SafeMove, the *Cyclic Brake Check* routine is recommended. See the manual for SafeMove in [References on page 10](#).

1.7 Safety during troubleshooting

General

When troubleshooting requires work with power switched on, special considerations must be taken:

- Safety circuits might be muted or disconnected.
- Electrical parts must be considered as *live*.
- The manipulator can move unexpectedly at any time.



DANGER

Troubleshooting on the controller while powered on must be performed by personnel trained by ABB or by ABB field engineers.



CAUTION

Risk of hot surfaces that can cause burns.

A risk assessment must be done to address both robot and robot system specific hazards.



WARNING

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

A robot may perform unexpected limited movement.



WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

Related information

See also the safety information related to installation, operation, maintenance, and repair.

1 Safety

1.8 Safety during decommissioning

1.8 Safety during decommissioning

General

See section [Decommissioning on page 329](#).

If the robot is decommissioned for storage, take extra precaution to reset safety devices to delivery status.

Unexpected movement of robot arm



WARNING

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

A robot may perform unexpected limited movement.



WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

2 Installation and commissioning

2.1 Introduction to installation and commissioning

General

This chapter contains assembly instructions and information for installing the IRB 660 at the working site.

See also the product manual for the robot controller.

The installation must be done by qualified installation personnel in accordance with the safety requirements set forth in the applicable national and regional standards and regulations.

Safety information

Before any installation work is commenced, all safety information must be observed. There are general safety aspects that must be read through, as well as more specific safety information that describes the danger and safety risks when performing the procedures. Read the chapter [Safety on page 19](#) before performing any installation work.



Note

Always connect the IRB 660 and the robot to protective earth and residual current device (RCD) before connecting to power and starting any installation work.

For more information see:

- *Product manual - OmniCore V250XT*
- *Product manual - IRC5*
- *Product manual - IRC5 Panel Mounted Controller*

2 Installation and commissioning

2.2.1 Pre-installation procedure

2.2 Unpacking

2.2.1 Pre-installation procedure

Introduction


This section is intended for use when unpacking and installing the robot for the first time. It also contains information useful during later re-installation of the robot.

Prerequisites for installation personnel

Installation personnel working with an ABB product must:

- be trained by ABB and have the required knowledge of mechanical and electrical installation/maintenance/repair work
- conform to all national and local codes.

Checking the pre-requisites for installation

| | Action |
|----|---|
| 1 | Make a visual inspection of the packaging and make sure that nothing is damaged. |
| 2 | Remove the packaging. |
| 3 | Check for any visible transport damage.  Note Stop unpacking and contact ABB if transport damages are found. |
| 4 | Clean the unit with a lint-free cloth, if necessary. |
| 5 | Make sure that the lifting accessory used (if required) is suitable to handle the weight of the robot as specified in: Weight, robot on page 42 |
| 6 | If the robot is not installed directly, it must be stored as described in: Storage conditions, robot on page 44 |
| 7 | Make sure that the expected operating environment of the robot conforms to the specifications as described in: Operating conditions, robot on page 44 |
| 8 | Before taking the robot to its installation site, make sure that the site conforms to: <ul style="list-style-type: none">• Loads on foundation, robot on page 43• Protection classes, robot on page 45• Requirements, foundation on page 44 |
| 9 | Before moving the robot, please observe the stability of the robot: Risk of tipping/stability on page 48 |
| 10 | When these prerequisites are met, the robot can be taken to its installation site as described in section: On-site installation on page 50 |
| 11 | Install required equipment, if any. <ul style="list-style-type: none">• Safety lamp (option for IRC5) on page 75 |

Weight, robot

The table shows the weight of the robot.

| Robot model | Weight |
|-------------|---------|
| IRB 660 | 1750 kg |

Continues on next page




Note

The weight does not include tools and other equipment fitted on the robot.

Loads on foundation, robot

The illustration shows the directions of the robots stress forces.

The directions are valid for all floor mounted, suspended and inverted robots.



xx1100000521

| | |
|----------|---|
| F_{xy} | Force in any direction in the XY plane |
| F_z | Force in the Z plane |
| T_{xy} | Bending torque in any direction in the XY plane |
| T_z | Bending torque in the Z plane |

The table shows the various forces and torques working on the robot during different kinds of operation.



Note

These forces and torques are extreme values that are rarely encountered during operation. The values also never reach their maximum at the same time!



WARNING

The robot installation is restricted to the mounting options given in following load table(s).

Floor mounted

| Force | Endurance load (in operation) | Max. load (emergency stop) |
|----------|-------------------------------|----------------------------|
| Force xy | ± 8.0 kN | ± 11.7 kN |

Continues on next page

2 Installation and commissioning


2.2.1 Pre-installation procedure

Continued

| Force | Endurance load (in operation) | Max. load (emergency stop) |
|-----------|-------------------------------|----------------------------|
| Force z | 18.0 ±4.9 kN | 18.0 ±8.2 kN |
| Torque xy | ± 23.2 kNm | ± 31.2 kNm |
| Torque z | ± 7.7 kNm | ± 9.9 kNm |

Requirements, foundation

The table shows the requirements for the foundation where the weight of the installed robot is included:

| Requirement | Value | Note |
|--------------------------------|--|---|
| Flatness of foundation surface | 0.3 mm | Flat foundations give better repeatability of the resolver calibration compared to original settings on delivery from ABB. The value for levelness aims at the circumstance of the anchoring points in the robot base. |
| Maximum tilt | 5° | |
| Minimum resonance frequency | 22 Hz  Note It may affect the manipulator lifetime to have a lower resonance frequency than recommended. | The value is recommended for optimal performance. Due to foundation stiffness, consider robot mass including equipment. ⁱ For information about compensating for foundation flexibility, see the application manual of the controller software, section <i>Motion Process Mode</i> . |

ⁱ The minimum resonance frequency given should be interpreted as the frequency of the robot mass/inertia, robot assumed stiff, when a foundation translational/torsional elasticity is added, i.e., the stiffness of the pedestal where the robot is mounted. The minimum resonance frequency should not be interpreted as the resonance frequency of the building, floor etc. For example, if the equivalent mass of the floor is very high, it will not affect robot movement, even if the frequency is well below the stated frequency. The robot should be mounted as rigid as possible to the floor.

Disturbances from other machinery will affect the robot and the tool accuracy. The robot has resonance frequencies in the region 10 – 20 Hz and disturbances in this region will be amplified, although somewhat damped by the servo control. This might be a problem, depending on the requirements from the applications. If this is a problem, the robot needs to be isolated from the environment.

Storage conditions, robot

The table shows the allowed storage conditions for the robot:

| Parameter | Value |
|--|--|
| Minimum ambient temperature | -25° C |
| Maximum ambient temperature | +55° C |
| Maximum ambient temperature (less than 24 hrs) | +70° C |
| Maximum ambient humidity | 95% at constant temperature (gaseous only) |

Operating conditions, robot

The table shows the allowed operating conditions for the robot:

| Parameter | Value |
|-----------------------------|-------------------|
| Minimum ambient temperature | 0° C ⁱ |

Continues on next page

| Parameter | Value |
|-----------------------------|-----------------------------|
| Maximum ambient temperature | +50° C |
| Maximum ambient humidity | 95% at constant temperature |

ⁱ During cold start (0° C - 5° C), see [Start of robot in cold environments on page 82](#).

Protection classes, robot

The table shows the available protection types of the robot, with the corresponding protection class.

| Protection type | Protection class ¹ |
|---------------------------------------|-------------------------------|
| Manipulator, protection type Standard | IP 67 |

2 Installation and commissioning

2.2.2 Working range and type of motion


2.2.2 Working range and type of motion

Working range

The following figures show the working ranges of the robot variants. The extreme positions of the robot arm are specified at the wrist center (dimensions in mm).

IRB 660 - 180/3.15 and IRB 660 - 250/3.15

The illustration below shows the unrestricted working range of IRB 660 - 180/3.15 and IRB 660 - 250/3.15.



xx0500002274

| | |
|---|-------------------|
| H | Mechanical stop |
| J | Max working range |

| | Position x (mm) | Position z (mm) | Angle axis 2 (degrees) | Angle axis 3 (degrees) |
|---|-----------------|-----------------|------------------------|------------------------|
| A | 1910 | 1833 | 0 | 0 |
| B | 972 | 1966 | -42 | -20 |
| C | 895 | 870 | -42 | 28 |
| D | 866 | 207 | 50 | 120 |
| E | 1160 | -505 | 85 | 120 |
| F | 3139 | 315 | 85 | 15 |
| G | 2809 | 1837 | 50 | -20 |

Continues on next page

Type of motion

The table below specifies the types and ranges of the robot motion in every axis.

| Axis | Type of motion | Range of motion |
|------|-----------------|-----------------|
| 1 | Rotation motion | -180° to +180° |
| 2 | Arm motion | -42° to +85° |
| 3 | Arm motion | -20° to +120° |
| 2-3 | Arm motion | 20° to 160° |
| 6 | Turn motion | -300° to +300° |

2 Installation and commissioning

2.2.3 Risk of tipping/stability

2.2.3 Risk of tipping/stability


Risk of tipping

Do not change the robot position before securing it to the foundation.

The shipping position is the most stable position.

Shipping and transportation position

This figure shows the robot in its shipping position and transportation position.



xx0500002275



WARNING

The robot will be mechanically unstable if not properly secured to the foundation.

2.2.4 The unit is sensitive to ESD

Description

ESD (electrostatic discharge) is the transfer of electrical static charge between two bodies at different potentials, either through direct contact or through an induced electrical field. When handling parts or their containers, personnel not grounded may potentially transfer high static charges. This discharge may destroy sensitive electronics.

Safe handling

Use one of the following alternatives:

- Use a wrist strap.

Wrist straps must be tested frequently to ensure that they are not damaged and are operating correctly.

- Use an ESD protective floor mat.

The mat must be grounded through a current-limiting resistor.

- Use a dissipative table mat.

The mat should provide a controlled discharge of static voltages and must be grounded.

2 Installation and commissioning

2.3.1 Lifting robot with fork lift

2.3 On-site installation

2.3.1 Lifting robot with fork lift


General

The robot may be moved using a fork lift, provided that available special aids are used.

This section describes how to attach the fork lift equipment to the robot.

Attachment points on robot

The attachment points for the fork lift equipment are shown in this figure.



xx0500002276

| | |
|---|---|
| A | Attachment points on adapter and horizontal attachment screws |
| B | Attachment points, horizontal attachment screws |
| C | Attachment points, vertical attachment screws |



Required equipment

| Equipment, etc. | Art. no. | Note |
|--|----------------|---|
| Fork lift set, incl. all required hardware | 3HAC023044-001 | See figure <i>Fork lift set, 3HAC023044-001 on page 51</i> . |
| Standard toolkit | - | Content is defined in section <i>Standard tools on page 344</i> . |

Continues on next page

Fork lift set, 3HAC023044-001

The fork lift set 3HAC023044-001, is fitted to the robot as shown in the figure below.



xx0500002277

| | |
|---|---|
| A | Fork lift pocket (2 pcs, one long and one short) |
| B | Adapter (2 pcs) |
| C | Horizontal attachment screws (4 pcs / fork lift pocket) |
| D | Attachment screw for adapter (1 pc / adapter) |
| E | Vertical attachment screws (2 pcs) |

Continues on next page



2 Installation and commissioning

2.3.1 Lifting robot with fork lift

Continued

Lifting robot with fork lift

This section details how to secure the fork lift set to the robot in order to lift and move the robot using the fork lift **ONLY!**





| | Action | Note |
|---|---|---|
| 1 | <p>If a cooling fan for the axis 1 motor is used, it must be removed in order to use the fork lift device!</p> <p>Position the robot as shown in the figure to the right!</p> | <p>Release the brakes if required as detailed in section Manually releasing the brakes on page 60.</p>  <p>xx0500002275</p> |
| 2 | <p>Fit the two adapters to the robot and secure.</p> | <p>Attachment points are shown in figure Attachment points on robot on page 50. Attachment screws, 2 pcs, M16 x 90. Tightening torque: 270 Nm.</p> |
| 3 | <p>Strap up axis 2 motor cable on the adapter.</p> |  <p>xx0500002278</p> <ul style="list-style-type: none"> A: Strap, velcro |

Continues on next page

2 Installation and commissioning

2.3.1 Lifting robot with fork lift

Continued






| | Action | Note |
|---|---|---|
| 4 |  CAUTION The fork lift pocket weighs 60 kg! | |
| 5 | <p>Secure the longer <i>fork lift pocket</i> to the adapter and frame with four of the horizontal <i>attachment screws</i> and <i>washers</i>.</p>  Note The screws, which are attached horizontally and vertically, are identical. However, they are tightened with different torque! | <p>Always use original screws (or replacements of equivalent quality: M16, quality 12.9)!</p> <p>Attachment points on the robot are shown in figure Attachment points on robot on page 50.</p>  <p>xx0500002279</p> <p>A Horizontal attachment screws, 4 pcs, M16 x 60. Tightening torque: 60 Nm.</p> <p>B Adapter</p> |
| 6 | <p>Make sure the securing screw is removed from the fork lift pocket! It is only used for robot model IRB 6650S.</p> |  <p>xx0700000655</p> <p>A Securing screw</p> |

Continues on next page

2 Installation and commissioning

2.3.1 Lifting robot with fork lift

Continued

| | Action | Note |
|----|--|---|
| 7 | <p>Secure fork lift pocket to robot with two <i>vertical attachment screws</i> and washers.</p> <p> Note</p> <p>Vertically and the horizontally attached screws are identical, but tightened with different torques!</p> |  <p>xx0500002284</p> <p>A Vertical attachment screws, 2 pcs, M16x60. Tightening torque: 270 Nm.</p> <p>Always use original screws (or replacements of equivalent quality: M16, quality 12.9)!</p> <p>Attachment points on robot are shown in figure Attachment points on robot on page 50.</p> |
| 8 | <p> CAUTION</p> <p>The fork lift pocket weighs 22 kg!</p> | |
| 9 | <p>Secure the shorter fork lift pocket on the other side of the robot with the four remaining <i>horizontal attachment screws</i>.</p> | <p>4 pcs, M16x60. Tightening torque: 60 Nm.</p> <p>Always use original screws (or replacements of equivalent quality: M16, quality 12.9)!</p> <p>Attachment points on robot are shown in figure Attachment points on robot on page 50.</p> |
| 10 | <p>Double-check that pockets are properly secured to the robot! Insert fork lift forks into the pockets.</p> | |
| 11 | <p> CAUTION</p> <p>The IRB 660 robot weighs 1750 kg. All lifting accessories used must be sized accordingly!</p> | |
| 12 | <p>Carefully lift the robot and move it to its installation site.</p> | |
| 13 | <p> WARNING</p> <p>Personnel must not, under any circumstances, be present under the suspended load!</p> | |
| | <p>Refit the cooling fan to the motor, if any.</p> | |

2.3.2 Lifting robot with roundslings



General

The robot can be lifted with roundslings according to this section.

Sling specification

| Sling type | Qty | Lifting capacity | Length / Note |
|----------------------------|-------|------------------|---|
| Chain sling with shortener | 4 pcs | 4 000 kg | 0.605 m 0.8 m 1.0 m (2 pcs) |
| Roundsling, robot | 4 pcs | 2 000 kg | 2 m |
| Roundsling, upper arm | 1 pc | 2 000 kg | 1 m 2 m Secures against rotation. |

Lifting with roundslings

| | Action | Note |
|---|--|------|
| 1 | Position robot in a secure transport position. | |
| 2 | Attach roundslings to robot according to figure Attachment points on page 56 . | |
| 3 |  CAUTION The IRB 660 robot weighs 1750 kg. All lifting accessories used must be sized accordingly! | |
| 4 |  WARNING Personnel must not, under any circumstances, be present under the suspended load! | |

Continues on next page

2 Installation and commissioning


2.3.2 Lifting robot with roundslings

Continued

Attachment points

This figure shows how to attach the roundslings to the robot.

The illustration is similar with the label attached to the robot's frame.



xx0500002285

| | |
|---|---|
| A | Chain sling with shortener |
| B | Roundsling, robot |
| C | Roundsling, upper arm. Used to secure against rotation. |

Continues on next page

2 Installation and commissioning

2.3.2 Lifting robot with roundslings

Continued

| | |
|---|------------------------------|
| D | <i>Note!</i> No sharp edges! |
| E | Shackle |

2 Installation and commissioning

2.3.3 Lifting robot with lifting accessory (recommended lifting method)

2.3.3 Lifting robot with lifting accessory (recommended lifting method)

General

This section contains a general overview of how to lift the complete robot using special lifting accessory.


Illustration, lifting accessory

The following figure shows the principle for how to use and lift the entire robot with lifting accessory. For a more detailed instruction, see the user instructions enclosed with the accessory.



Note

The user manual may be out of date. The latest revision is available for download via myABB Business Portal, www.abb.com/myABB.



xx0500002460

| | |
|---|---|
| A | Eye for lifting accessory |
| B | Swivelling lifting eyes, 3 pcs |
| C | Chain |
| D | Lifting sling, short. Secures against rotation. |
| E | Lifting slings, long |
| F | Hook |

Continues on next page

Required equipment

| Equipment | Article number | Note |
|--------------------------|----------------|--|
| Lifting accessory, robot | 3HAC15607-1 | Includes user instructions 3HAC15971-2 |

Slings attached directly onto robot

This section details how to lift and move the robot using lifting slings when these are attached directly onto the robot frame.



Note

Please refer to the enclosed user instruction for instruction how to place the manipulator in an correct position. Attempting to lift a manipulator in any other position may result in the robot tipping over, causing severe damage or injury!

| | Action | Note |
|---|---|--|
| 1 | Run the overhead crane to a position above the robot. | |
| 2 | Position the robot as detailed in enclosed instruction! | Article number is specified in Required equipment on page 59 . Release the brakes, if required, as detailed in section Manually releasing the brakes on page 60 . |
| 3 | Note If the robot is equipped with forklift pockets, it is necessary to remove these in order to reach the lower holes in the frame. These are used to attach the <i>hooks</i> of the lifting slings. | Shown in the figure Illustration, lifting accessory on page 58 . |
| 4 | Fit the <i>lifting accessory</i> to the robot as described in the enclosed instruction! | Article number is specified in Required equipment on page 59 . |
| 5 | CAUTION The IRB 660 robot weighs 1750 kg. All lifting accessories used must be sized accordingly! | |
| 6 | WARNING Personnel must not, under any circumstances, be present under the suspended load! | |
| 7 | Raise overhead crane to lift the robot. | Make sure all hooks and attachments maintain their correct positions while lifting the robot! Always move the robot at very low speeds, making sure it does not tip. |

2 Installation and commissioning

2.3.4 Manually releasing the brakes

2.3.4 Manually releasing the brakes

Introduction to manually releasing the brakes

This section describes how to release the holding brakes for the motors of each axis.


Location of brake release unit

The internal brake release unit is located as shown in the figure.



Note

Axes 4 and 5 do not exist!



xx0500002286

Releasing the brakes

This procedure details how to release the holding brakes when the robot is equipped with an internal brake release unit.

| | Action | Note |
|---|---|---|
| 1 | <p>The internal brake release unit is equipped with buttons for controlling the axes brakes. The buttons are numbered according to the numbers of the axes.</p> <p> Note</p> <p>Axes 4 and 5 do not exist!</p> <p>If the robot is not connected to the controller, power must be supplied to the connector R1.MP according to the section Supplying power to connector R1.MP on page 61.</p> | <p>Buttons are shown in figure Location of brake release unit on page 60.</p> |
| 2 | <p> DANGER</p> <p>When releasing the holding brakes, the robot axes may move very quickly and sometimes in unexpected ways.</p> <p>Make sure no personnel is near or beneath the robot.</p> | |

Continues on next page

2 Installation and commissioning



2.3.4 Manually releasing the brakes

Continued

| | Action | Note |
|---|---|------|
| 3 | Release the holding brake on a particular robot axis by pressing the corresponding button on the internal brake release unit. The brake will function again as soon as the button is released. | |

Supplying power to connector R1.MP

If the robot is not connected to the controller, power must be supplied to connector R1.MP on the robot, in order to enable the brake release buttons.

| | Action | Note |
|---|---|---|
| 1 |  DANGER Incorrect connections, such as supplying power to the wrong pin, may cause all brakes to be released simultaneously! | |
| 2 | Supply 0V on pin 12 and 24V on pin 11. |  xx0600002937 |

2 Installation and commissioning


2.3.5 Lifting the base plate

2.3.5 Lifting the base plate

Required equipment

| Equipment | Article number | Note |
|------------------|----------------|---------------------|
| Lifting eye, M16 | 3HAC14457-4 | 3 pcs |
| Lifting slings | | Length: approx. 2 m |



Hole configuration



xx0200000096


| | |
|---|--|
| A | Attachment holes for lifting eyes (x3) |
|---|--|

Lifting, base plate

| | Action | Note |
|---|--|---|
| 1 |  CAUTION The base plate weighs 353 kg. All lifting accessories used must be sized accordingly. | |
| 2 | Fit lifting eyes in specified holes. | Shown in figure Hole configuration on page 62 . |
| 3 | Fit lifting slings to the eyes and to the lifting accessory.  CAUTION Lift and move the base plate very slowly. If the base plate starts to swing it is a risk for injuries or damage. | |

2.3.6 Securing the base plate

Base plate, dimensions



xx1000001053



E, F, G, H Common tolerance zone (accuracy all over the base plate from one contact surface to the other)

Continues on next page

2 Installation and commissioning

2.3.6 Securing the base plate

Continued



xx1000001054


■

| | |
|---|---|
| - | Four holes for alternative clamping, 4x Ø18 |
| A | Color: RAL 9005. Thickness: 80-100 µm |

Continues on next page

Base plate, orienting grooves and leveling bolts

The illustration below shows the orienting grooves and attachment holes for leveling bolts in the base plate.



xx1500000312

| | |
|---|---|
| A | Orienting grooves (3 pcs) |
| B | Levelling bolts, attachment holes (4 pcs) |

Continues on next page


2 Installation and commissioning

2.3.6 Securing the base plate

Continued

Base plate, guide sleeve holes

The illustration below shows the orienting grooves and guide sleeve holes in the base plate.



xx030000045

| | |
|---|----------------------------|
| A | Guide sleeve holes (2 pcs) |
|---|----------------------------|

Required equipment


| Equipment | Article number | Note |
|--|----------------|--|
| Base plate | 3HAC12937-9 | Includes <ul style="list-style-type: none"> • guide sleeves, 3HAC12937-3 • levelling screws, 9ADA120-79 • attachment screws and washers for securing the robot to the base plate. |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Base plate

This section details how to secure the base plate to the foundation.

| | Action | Note |
|---|---------------------------------------|------|
| 1 | Make sure the foundation is levelled. | |

Continues on next page

| | Action | Note |
|---|---|---|
| 2 |  CAUTION The base plate weighs 353 kg! All lifting equipment used must be sized accordingly! | |
| 3 | Position base plate in relation to the robot work location using the grooves in the base plate. | Shown in figure Base plate, orienting grooves and leveling bolts on page 65 . |
| 4 | Lift the base plate to its mounting position. | Detailed in section Lifting the base plate on page 62 . |
| 5 | Use the base plate as a template and drill attachment holes as required by the selected bolt dimension. | Attachment holes: 16 pcs. |
| 6 | Fit the base plate and use the levelling bolts to level the base plate. | Shown in figure Base plate, orienting grooves and leveling bolts on page 65 . |
| 7 | If required, fit strips of sheet metal underneath the base plate to fill any gaps. | |
| 8 | Secure the base plate to the foundation with screws and sleeves. | |
| 9 | Recheck the four contact surfaces on the base plate to make sure the base plate is levelled and flat. If it is not, use pieces of sheet metal or similar to bring the base plate to a levelled position. | Maximum allowed deviation all over the base plate, from one contact surface to the other: 0.3 mm. |

2 Installation and commissioning

2.3.7 Orienting and securing the robot


2.3.7 Orienting and securing the robot

General

This section details how to orient and secure the robot to the base plate in order to run the robot safely.

Illustration, robot fitted to base plate

This illustration shows the robot base fitted to the base plate.



xx0300000566

| | |
|---|---|
| A | Robot attachment bolts and washers, 8 pcs (M24 x 140) |
| B | Orienting grooves in the robot base and in the base plate |
| C | Levelling screws |
| D | Base plate attachment screws |

Attachment screws



The table below specifies the type of securing screws and washers to be used for securing the robot to the base plate/foundation.

| | |
|--------------------------------------|---|
| Suitable screws, lightly lubricated: | M24 x 140 |
| Quality: | Quality 8.8 |
| Suitable washer: | Thickness: 4 mm Outer diameter: 44 mm Inner diameter: 25 mm |
| Tightening torque: | 725 Nm |

Continues on next page

Securing the robot

Use this procedure to secure robot to base plate after fitting plate to the foundation.

| | Action | Note |
|---|---|--|
| 1 | Lift the robot. | See section Lifting robot with lifting accessory (recommended lifting method) on page 58 . See section Lifting robot with round-slings on page 55 . |
| 2 | Move robot to the vicinity of its installation location. | |
| 3 | Fit two guide sleeves to the <i>guide sleeve holes</i> in the base plate. | Shown in figure Base plate, guide sleeve holes on page 66 .  Note One of the guide sleeve holes is elongated! |
| 4 | Guide the robot gently using two M24 screws while lowering it into its mounting position. | Make sure the robot base is correctly fitted onto the guide sleeves! |
| 5 | Fit the <i>bolts and washers</i> in the base attachment holes. | Specified in Attachment screws on page 68 . Shown in figure Illustration, robot fitted to base plate on page 68 .  Note Lightly lubricate screws before assembly! |
| 6 | Tighten bolts in a criss-cross pattern to ensure that the base is not distorted. | |

Continues on next page


2 Installation and commissioning

2.3.7 Orienting and securing the robot

Continued

Hole configuration, base


This illustration shows the hole configuration used when securing the robot.



xx0600002628

Cross section, guide sleeve hole

This illustration shows the cross section of the guide sleeve holes.



xx0600002629

2.3.8 Fitting equipment on robot

General

The robot features mounting holes for additional equipment.

Access to any of the following mounting holes may be obstructed by any additional cabling, equipment, etc., fitted by the robot user. Make sure the required mounting holes are accessible when planning the robot cell.



Note

All equipment and cables used on the robot, must be designed and fitted not to damage the robot and/or its parts.



Note

No extra equipment may be fitted on the lower arm of the robot.

Illustration, fitting of extra equipment on upper arm

The illustration below shows the mounting holes available for fitting extra equipment on the upper arm.

For fitting of extra vacuum hose all holes shall be used (6 pcs). These holes can only be used for extra vacuum hose!

The max. weight of the vacuum hose and fastening device on the upper arm, is calculated to 10 kg.

Max. extra weight on the upper arm:

- IRB 660 - 180/3.15 = 35 kg
- IRB 660 - 250/3.15 = 35 kg

Note! The weight of the extra equipment on the upper arm must be deducted from the maximal handling capacity.


Continues on next page

2 Installation and commissioning

2.3.8 Fitting equipment on robot

Continued

Example: If 35 extra kg is put on the upper arm, this means that the robot only can handle $180 - 35 = 145$ kg or $250 - 35 = 215$ kg (depending on model).




xx0500002289

| | |
|---|----------------------------|
| A | Fitting holes, M10 (2 pcs) |
| B | Fitting holes, M10 (2 pcs) |
| C | Fitting holes, M10 (2 pcs) |

Illustration, fitting of extra equipment on frame

The illustration below shows the mounting holes available for fitting extra equipment on the frame.




xx0500002505

Continues on next page

Illustration, fitting on turning disk

The illustration below shows the mounting holes available for fitting equipment on the turning disk.



xx0500002292


| | |
|---|------------------|
| - | Mounting flange. |
|---|------------------|

Continues on next page

2 Installation and commissioning

2.3.8 Fitting equipment on robot

Continued



xx1800001377

| | |
|---|--------------------------------|
| - | Mounting flange in bottom view |
| A | Locating hole |
| B | Tool coordinate system |

Fastener quality

When fitting tools on the tool flange, only use screws with quality 12.9. For other equipment use suitable screws and tightening torque for your application.

2.3.9 Safety lamp (option for IRC5)

Description

A signal lamp with a yellow fixed light can be mounted on the robot, as a safety device.

Installation

See the assembly instruction delivered with the signal lamp.

Function

The lamp is active in MOTORS ON mode.

Further information

Further information about the MOTORS ON/MOTORS OFF mode may be found in the product manual for the controller.

2 Installation and commissioning

2.3.10 Loads fitted to the robot, stopping time and braking distances

2.3.10 Loads fitted to the robot, stopping time and braking distances

General

Any loads mounted on the robot must be defined correctly and carefully (with regard to the position of center of gravity and mass moments of inertia) in order to avoid jolting movements and overloading motors, gears and structure.



CAUTION

Incorrectly defined loads may result in operational stops or major damage to the robot.

References

Load diagrams, permitted extra loads (equipment) and their positions are specified in the product specification. The loads must be defined in the software.

- *Operating manual - IRC5 with FlexPendant*

Stopping time and braking distances

The performance of the motor brake depends on if there are any loads attached to the robot. For more information, see product specification for the robot.

2.3.11 Extended working range, axis 1 (option)

Overview

The working range of axis 1 can be extended on a floor-mounted robot, from the default range limited by mechanical stops. The working range can be extended to $\pm 220^\circ$.



CAUTION


The option *Extended work range* enables an extension of the working range for axis 1, through a software configuration. With this option installed, the working range can exceed the range limited by the mechanical stop on axis 1. The working range shall be limited through the option SafeMove.

A risk analysis must be done to ensure that no risks remain when using option *Extended work range*, to limit the working range, and before removing the mechanical stops.

For information about the option SafeMove, see *Application manual - Functional safety and SafeMove*.

If the mechanical stop is removed, then the manipulator should have a marking for this, for example, a label. If the robot is delivered with the option *Extended work range*, then such a label is included on delivery.

Extending the working range

| | Action | Note/Illustration |
|---|--|--|
| 1 | Configure the safety setup and verify it by test. | |
| 2 | Hold the mechanical stop pin in a firm grip, and remove it by unscrewing the attachment screw. |  <p>xx2100001706</p> |
| 3 | In RobotWare, redefine the working range limitations in the system parameters, topic <i>Motion</i> . The Arm parameters <i>Upper Joint Bound</i> and <i>Lower Joint Bound</i> can be changed to the values corresponding to the actual installation. | With the option <i>Extended working range</i> , the maximum value for the system parameters <i>Upper Joint Bound</i> and <i>Lower Joint Bound</i> is 3.84 respectively -3.84. The values are in radians, that is 3.84 radians = 220 degrees. |

Related information

The system parameters are described in detail in the reference manual, see [References on page 10](#).

Continues on next page

2 Installation and commissioning

2.3.11 Extended working range, axis 1 (option)

Continued

For more information about SafeMove, see *Application manual - Functional safety and SafeMove2 (IRC5)* or *Application manual - Functional safety and SafeMove (OmniCore)*.

2.4 Restricting the working range

2.4.1 Axes with restricted working range

General

When installing the robot, make sure that it can move freely within its entire working space. If there is a risk that it may collide with other objects, its working space should be limited.

The working range of the following axes may be restricted:

- Axis 1, hardware (mechanical stop)

As standard configuration, axis 1 is allowed to move $\pm 180^\circ$. The working range may however be increased to $\pm 220^\circ$ with option 561-1 *Extended working range axis 1*. Note that this option also requires installation of option 810-1 *Electronic position switch*.

This section describes how to install hardware that restricts the working range.



Note

Adjustments must also be made in the robot configuration software (system parameters). References to relevant manuals are included in the installation procedures.

2 Installation and commissioning

2.4.2 Mechanically restricting the working range of axis 1


2.4.2 Mechanically restricting the working range of axis 1

General

The working range of axis 1 is limited by fixed mechanical stops and adjustment of the system parameter configuration. The working range can be reduced by adding additional mechanical stops giving 7.5 or 15 graduation, between 22.5° and 135° in both directions.

Mechanical stops, axis 1

The illustration shows the mounting position of the stop pin and one of the additional mechanical stops available for axis 1.



xx0300000049

| | |
|---|----------------------------|
| A | Additional mechanical stop |
| B | Stop pin |



Required equipment

| Equipment, etc. | Article number | Note |
|---|----------------|--|
| Mechanical stop for axis 1, 7.5° | 3HAC11076-1 | Includes attachment screws and an assembly drawing. |
| Mechanical stop for axis 1, 15° | 3HAC11076-2 | Includes attachment screws and an assembly drawing. |
| Standard toolkit | - | |
| <i>Technical reference manual - System parameters</i> | - | Article number is specified in section References on page 10 . |

Continues on next page

Installation, mechanical stops axis 1

Use this procedure to fit the additional mechanical stops to axis 1 of the robot. An assembly drawing is also enclosed with the product.

| | Action | Note |
|---|---|---|
| 1 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply to the robot • hydraulic pressure supply to the robot • air pressure supply to the robot Before entering the robot working area. | |
| 2 | Fit the additional mechanical stop to the frame according to the figure Mechanical stops, axis 1 on page 80 . | Tightening torque: 120 Nm. |
| 3 | Adjust the software working range limitations (system parameter configuration) to correspond to the mechanical limitations. | The system parameters that must be changed (<i>Upper joint bound</i> and <i>Lower joint bound</i>) are described in <i>Technical reference manual - System parameters</i> . |
| 4 |  WARNING If the mechanical stop pin is deformed after a hard collision, it must be replaced! Deformed <i>movable stops</i> and/or <i>additional stops</i> as well as deformed <i>attachment screws</i> must also be replaced after a hard collision. | |

2 Installation and commissioning

2.5.1 Start of robot in cold environments

2.5 Robot in cold environments

2.5.1 Start of robot in cold environments

Introduction

This section describes how to start the robot in a cold environment if it is not starting the normal way.

Problems with starting the robot

Event message from Motion Supervision

Use this procedure if an event message indicates a problem with Motion supervision at start-up. More information about Motion Supervision is found in *Technical reference manual - System parameters*.

| | Action | Note |
|---|---|------|
| 1 | Turn off Motion Supervision. | |
| 2 | Start the robot. | |
| 3 | When the robot has reached normal working temperature, the Motion Supervision can be turned on again. | |

Robot stopping with other event message

Use this procedure if the robot is not starting.

| | Action | Note |
|---|---|---|
| 1 | Start the robot with its normal program but with reduced speed. | The speed can be regulated with the RAPID instruction <code>VelSet</code> . |

Adjusting the speed and acceleration during warm-up

Depending on how cold the environment is and what program is being used, the speed might need to be ramped up until reached maximum. The table shows examples of how to adjust the speed:

| Work cycles | AccSet | Speed/velocity |
|-------------------------|----------|-------------------|
| 3 Work cycles | 20, 20 | v100 (100 mm/s) |
| 5 Work cycles | 40, 40 | v400 (400 mm/s) |
| 5 Work cycles | 60, 60 | v600 (600 mm/s) |
| 5 Work cycles | 100, 100 | v1000 (1000 mm/s) |
| More than 5 Work cycles | 100, 100 | Max. |

If the program consists of large wrist movements, it is possible that the reorientation velocity, which is always high in predefined velocities, needs to be included in the ramping up.

2.6 Electrical connections

2.6.1 Robot cabling and connection points

Introduction

Connect the robot and controller to each other after securing them to the foundation. The lists below specify which cables to use for each respective application.



CAUTION

Connect the male and female connectors perfectly aligned horizontally to avoid any kind of tilt or skew.



CAUTION

Verify that the robot serial number is according to the number(s) in the *Declaration of Incorporation (DoI)*.

Main cable categories

All cables between the robot and controller are divided into the following categories:

| Cable category | Description |
|-------------------------------|---|
| Robot cables | Handles power supply to and control of the robot's motors as well as feedback from the serial measurement board. Specified in the table Robot cables on page 83 . |
| Customer cables (option) | Handles communication with equipment fitted on the robot by the customer, low voltage signals and high voltage power supply + protective ground. The customer cables also handle databus communication. See the product manual for the controller, see document number in References on page 10 . |
| External axes cables (option) | Handles power supply to and control of the external axes' motors as well as feedback from the servo system. See <i>Application manual - Additional axes and stand alone controller (IRC5)</i> , document number in References on page 10 . |

Robot cables

These cables are included in the standard delivery. They are completely pre-manufactured and ready to plug in.

| Cable sub-category | Description | Connection point, cabinet | Connection point, robot |
|--------------------|--|---|-------------------------|
| Robot cable, power | Transfers drive power from the drive units in the control cabinet to the robot motors. | XS1 (IRC5 controllers) X1 (OmniCore controllers) | R1.MP |

Continues on next page

2 Installation and commissioning

2.6.1 Robot cabling and connection points

Continued

| Cable sub-category | Description | Connection point, cabinet | Connection point, robot |
|----------------------|--|---|-------------------------|
| Robot cable, signals | Transfers resolver data from and power supply to the serial measurement board. | XS2 (IRC5 controllers) X2 (OmniCore controllers) | R1.SMB |

Robot cable, power


| Cable | Art. no. |
|--------------------------|----------------|
| Robot cable, power: 7 m | 3HAC026787-001 |
| Robot cable, power: 15 m | 3HAC026787-002 |
| Robot cable, power: 22 m | 3HAC026787-003 |
| Robot cable, power: 30 m | 3HAC026787-004 |

Robot cable, signals

| Cable | Art. no. |
|------------------------------------|------------|
| Robot cable signal, shielded: 7 m | 3HAC7998-1 |
| Robot cable signal, shielded: 15 m | 3HAC7998-2 |
| Robot cable signal, shielded: 22 m | 3HAC7998-3 |
| Robot cable signal, shielded: 30 m | 3HAC7998-4 |

Bending radius for static floor cables

The minimum bending radius is 10 times the cable diameter for static floor cables.




xx1600002016

| | |
|---|--------------|
| A | Diameter |
| B | Diameter x10 |

Continues on next page

Grounding and bonding point on manipulator

There is a grounding/bonding point on the manipulator base. The grounding/bonding point is used for potential equalizing between control cabinet, manipulator and any peripheral devices.



xx1600001007

2 Installation and commissioning

2.6.2 Customer connectors on the manipulator


2.6.2 Customer connectors on the manipulator

Introduction

The customer cables are routed internally with the manipulator cable harness. For more information and specifications for the connections. See section *Customer connections* in the Product Specification.

Location of customer connectors on manipulator

Customer connectors, base




xx2100002206

| Pos | Name | Description |
|-----|-------------|--|
| A | R3.FB7 | For the 7-axis connector on the manipulator base |
| B | FE | Grounding point |
| C | R1.CP/CS | Customer power/signal |
| D | R1.ETHERNET | Bus communication Ethernet IP |
| E | R1.PROC2 | Process connector on the manipulator base. |
| F | R1.PROC1 | Process connector on the manipulator base |

Continues on next page

Customer connectors, wrist



xx2100002207

| Pos | Name | Description |
|-----|---------------------------|---|
| A | R2.CP/CS/CBUS R2.PROC1 | Customer power/signal connector Process connector on the manipulator wrist |
| B | R2.PROC2 | Process connector on the manipulator wrist |
| C | R1.ETHERNET | Bus communication Ethernet IP |
| D | FE | Grounding point |

2 Installation and commissioning

2.7 Test run after installation, maintenance, or repair

2.7 Test run after installation, maintenance, or repair

Safe handling

Use the following procedure after installation, maintenance, or repair, before initiating motion.



DANGER

Initiating motion without fulfilling the following aspects, may increase the risk for injury or cause damage to the robot.

| | Action |
|---|--|
| 1 | Remove all tools and foreign objects from the robot and its working area. |
| 2 | Verify that the robot is properly secured to its position by all screws, before it is powered up. |
| 3 | Verify that any safety equipment installed to secure the position or restrict the robot motion during service activity is removed. |
| 4 | Verify that the fixture and work piece are well secured, if applicable. |
| 5 | Verify that all safety equipment is installed, as designed for the application. |
| 6 | Verify that no personnel are inside the safeguarded space. |
| 7 | If maintenance or repair has been done, verify the function of the part that was maintained. |
| 8 | Verify the application in the operating mode manual reduced speed. |

Collision risks



CAUTION

When programming the movements of the robot, always identify potential collision risks before initiating motion.

3 Maintenance

3.1 Introduction

Structure of this chapter

This chapter describes all the maintenance activities recommended for the IRB 660.

It is based on the maintenance schedule found at the beginning of the chapter. The schedule contains information about required maintenance activities including intervals, and refers to procedures for the activities.

Each procedure contains all the information required to perform the activity, including required tools and materials.

The procedures are gathered in different sections and divided according to the maintenance activity.

Safety information

Observe all safety information before conducting any service work.

There are general safety aspects that must be read through, as well as more specific safety information that describes the danger and safety risks when performing the procedures. Read the chapter [Safety on page 19](#) before performing any service work.

The maintenance must be done by qualified personnel in accordance with the safety requirements set forth in the applicable national and regional standards and regulations.



Note

If the IRB 660 is connected to power, always make sure that the IRB 660 is connected to protective earth and a residual current device (RCD) before starting any maintenance work.

For more information see:

- *Product manual - OmniCore V250XT*
- *Product manual - IRC5*
- *Product manual - IRC5 Panel Mounted Controller*
- [Robot cabling and connection points on page 83.](#)

3 Maintenance

3.2.1 Specification of maintenance intervals

3.2 Maintenance schedule and expected component life

3.2.1 Specification of maintenance intervals

Introduction

The intervals are specified in different ways depending on the type of maintenance activity to be carried out and the working conditions of the IRB 660:

- Calendar time: specified in months regardless of whether the system is running or not.
- Operating time: specified in operating hours. More frequent running means more frequent maintenance activities.
- SIS: specified by the robot's SIS (Service Information System). A typical value is given for a typical work cycle, but the value will differ depending on how hard each part is run.

The SIS used in M2004 is further described in the *Operating manual - Service Information System (IRC5)* or *Operating manual - OmniCore*.

The SIS used in OmniCore is further described in the *Operating manual - OmniCore*.

Robots with the functionality *Service Information System* activated can show active counters in the device browser in RobotStudio, or on the FlexPendant.

Overhaul

Depending on application and operational environment a complete overhaul may be necessary in average around 40000 hours.

ABB Connected Services and its Assessment tools can help you to identify the real stress level of your robot, and define the optimal ABB support to maintain your robot working.

Contact your local ABB Customer Service to get more information.

3.2.2 Maintenance schedule

General

The robot must be maintained regularly to ensure proper function. The maintenance activities and intervals are specified in the table below.

Non-predictable situations also give rise to inspections of the robot. Any damage must be attended to immediately.

The inspection intervals *do not* specify the life of each component. Values for these are specified in the section [Expected component life on page 93](#)

Instructions for how to perform the different maintenance activities are found in sections:

- [Inspection activities on page 94](#)
- [Replacement/changing activities on page 118](#)
- [Cleaning activities on page 135](#)

Activities and intervals, standard equipment

The table below specifies the required maintenance activities and intervals.

| Maintenance activity | Equipment | Interval |
|----------------------|---|---|
| Cleaning | Robot | - |
| Inspection | Axis-1 gearbox, oil level | Every: <ul style="list-style-type: none"> • 12 months |
| Inspection | Axes-2 and -3 gearboxes, oil level | Every: <ul style="list-style-type: none"> • 12 months |
| Inspection | Axis-6 gearbox, oil level | Every: <ul style="list-style-type: none"> • 12 months |
| Inspection | Balancing device | Every: <ul style="list-style-type: none"> • 12 months |
| Inspection | Robot harness | Every: <ul style="list-style-type: none"> • 12 monthsⁱ |
| Inspection | Information labels | Every: <ul style="list-style-type: none"> • 12 months |
| Inspection | Mechanical stop, axis 1 | Every: <ul style="list-style-type: none"> • 12 months |
| | Mechanical stop, axis 3 (only applicable for IRB 760 - 445/3.2) | Every: <ul style="list-style-type: none"> • 12 months |
| Inspection | Dampers | Every: <ul style="list-style-type: none"> • 12 months |
| Changing | Axis-1 gear oil | First change when DTC ⁱⁱ reads: <ul style="list-style-type: none"> • 6,000 hours Second change when DTC ⁱⁱ reads: <ul style="list-style-type: none"> • 24,000 hours Following changes: <ul style="list-style-type: none"> • Every 24,000 hours |

Continues on next page

3 Maintenance

3.2.2 Maintenance schedule

Continued

| Maintenance activity | Equipment | Interval |
|----------------------|--|---|
| Changing | Axis 2 gear oil | First change when DTC ⁱⁱ reads: <ul style="list-style-type: none"> • 6,000 hours Second change when DTC ⁱⁱ reads: <ul style="list-style-type: none"> • 24,000 hours Following changes: <ul style="list-style-type: none"> • Every 24,000 hours |
| Changing | Axis-3 gear oil | First change when DTC ⁱⁱ reads: <ul style="list-style-type: none"> • 6,000 hours Second change when DTC ⁱⁱ reads: <ul style="list-style-type: none"> • 24,000 hours Following changes: <ul style="list-style-type: none"> • Every 24,000 hours |
| Changing | Axis-6 gear oil | First change when DTC ⁱⁱ reads: <ul style="list-style-type: none"> • 6,000 hours Second change when DTC ⁱⁱ reads: <ul style="list-style-type: none"> • 24,000 hours Following changes: <ul style="list-style-type: none"> • Every 24,000 hours |
| Overhaul | Robot | 40,000 hours |
| Replacement | Battery pack, measurement system of type RMU101 or RMU102 (3-pole battery contact) | 36 months or battery low alert ⁱⁱⁱ |
| Replacement | Battery pack, measurement system with 2-pole battery contact, e.g. DSQC633A | Battery low alert ^{iv} |
| Lubrication | Balancing device bearings | Every 12,000 hours |

ⁱ Replace when damage or cracks are detected or life limit is approaching as specified in section [Expected component life on page 93](#).

ⁱⁱ DTC = Duty Time Counter. Shows the operational time of the robot.

ⁱⁱⁱ The battery low alert (38213 **Battery charge low**) is displayed when the battery needs to be replaced. The recommendation to avoid an unsynchronized robot is to keep the power to the controller turned on until the battery is to be replaced.
See the replacement instruction for more details.

^{iv} The battery low alert (38213 **Battery charge low**) is displayed when remaining backup capacity (robot powered off) is less than 2 months. The typical lifetime of a new battery is 36 months if the robot is powered off 2 days/week or 18 months if the robot is powered off 16 h/day. The lifetime can be extended with a battery shutdown service routine. See the operating manual for the robot controller for instructions.

Activities and intervals, optional equipment

The table below specifies the required maintenance activities and intervals for common optional equipment. The maintenance of other external equipment for the robot is detailed in separate documentation.

| Maintenance activity | Equipment | Interval |
|----------------------|-----------------------------------|---------------------|
| Inspection | Signal lamp | Every: 12 months |
| Inspection | Additional mechanical stop axis 1 | Every: 12 months |

3.2.3 Expected component life

General

The expected life of a specific component of the robot can vary greatly depending on how hard it is run.

Expected component life - protection type Standard

| Component | Expected life | Note |
|---|----------------------------|--|
| Cable harness Normal usage ⁱ | 40,000 hours ⁱⁱ | Not including: <ul style="list-style-type: none"> • Possible SpotPack harnesses • Optional upper arm harnesses |
| Cable harness Extreme usage ⁱⁱⁱ | 20,000 hours ⁱⁱ | Not including: <ul style="list-style-type: none"> • Possible SpotPack harnesses • Optional upper arm harnesses |
| Balancing device | 40,000 hours ^{iv} | |
| Gearboxes ^v | 40,000 hours | |

ⁱ Examples of "normal usage" in regard to movement: most material handling applications. See the note in the Product specification about warranty, when running the robot in a cold environment (0°C to 5°C).

ⁱⁱ Severe chemical or thermal environments, or similar environments, can result in shortened life expectancy.

ⁱⁱⁱ Examples of "extreme usage" in regard to movement: press tending, very severe palletizing applications, major use of axis 1 movement.

^{iv} The given life for the balancing device is based on a test cycle of 4,000,000 cycles that starts from the initial position and goes to maximum extension, and back. Deviations from this cycle will result in differences in expected life!

^v Depending on application, the lifetime can vary. The Service Information System (SIS) that is integrated in the robot software can be used as guidance when planning gearbox service for the individual robot. This applies to gearboxes on axes 1, 2, 3 and 6. The lifetime of gearbox axes 4 and 5 is not calculated by SIS (See the *Operating manual - Service Information System*). In some applications, such as Foundry or Washing, the robot can be exposed to chemicals, high temperature or humidity, which can have an effect on the lifetime of the gearboxes. Contact the local **ABB Robotics Service team** for more information.

The SIS for an IRC5 system is described in the *Operating manual - Service Information System*.

3 Maintenance


3.3.1 Inspecting the oil level in axis-1 gearbox

3.3 Inspection activities

3.3.1 Inspecting the oil level in axis-1 gearbox

Location of gearbox


The axis-1 gearbox is located between the frame and base. See oil plugs in the following figure.



xx0500002479

| | |
|---|---------------------------|
| A | Oil plug, inspection |
| B | Gearbox, axis 1 |
| C | Oil plug filling |
| D | Motor, axis 1 |
| E | Drain hose (Behind cover) |

Required equipment




| Equipment | Art. no. | Note |
|------------------|---|--|
| Lubricating oil | See <i>Type and amount of oil in gearboxes on page 118.</i> |  Note Do not mix with other oils! |
| Standard toolkit | - | Content is defined in section <i>Standard tools on page 344.</i> |

Continues on next page

| Equipment | Art. no. | Note |
|--|----------|--|
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Inspecting the oil level in axis-1 gearbox

Use this procedure to inspect the oil level in the axis-1 gearbox.

| | Action | Note |
|---|---|---|
| 1 |  WARNING Handling gearbox oil involves several safety risks, see Gearbox lubricants (oil or grease) on page 34 . | |
| 2 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the safeguarded space. | |
| 3 | Make sure that the oil temperature is $+25^{\circ}\text{C} \pm 10^{\circ}\text{C}$. | This is a precaution to reduce the temperature dependency of the measurement. |
| 4 | Open the <i>oil plug, inspection</i> . | Shown in figure Location of gearbox on page 94 . |
| 5 | Measure the oil level. Required oil level: max. 10 mm below the oil plug hole. |  <p>xx1400002785</p> <p>A Oil plug hole B Required oil level C Gearbox oil</p> |
| 6 | Adjust the oil level, if required. | Where to find type of oil and total amount is detailed in Type of lubrication in gearboxes on page 118 . Further information about how to fill with oil is found in section Changing oil, axis-1 gearbox on page 119 . |
| 7 | Refit the oil plug. | Tightening torque: |


3 Maintenance

3.3.2 Inspecting, oil level gearbox axes 2 - 3

3.3.2 Inspecting, oil level gearbox axes 2 - 3

Location of gearbox, axes 2-3


The gearboxes axes 2-3 are located in the lower arm rotational center, underneath the motor attachment.



xx0500002482

| | |
|---|----------------------------------|
| A | Gearbox, axis 2 |
| B | Oil plug, draining |
| C | Oil plug, filling |
| D | Ventilation hole, gearbox axis 2 |


Continues on next page



xx0500002483


| | |
|---|----------------------------------|
| A | Gearbox, axis 3 |
| B | Oil plug, draining |
| C | Oil plug, filling |
| D | Ventilation hole, gearbox axis 3 |

Required equipment

| Equipment etc. | Art.no. | Note |
|---|---|--|
| Lubricating oil | See <i>Type and amount of oil in gearboxes on page 118.</i> |  Note Do not mix with other oils! |
| Standard toolkit | - | Content is defined in section <i>Standard tools on page 344.</i> |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below | | These procedures include references to the tools required. |

Inspecting, oil level gearbox 2 - 3

Use this procedure to inspect the oil level in gearbox axes 2 - 3.


| | Action | Note |
|---|---|------|
| 1 |  WARNING Handling gearbox oil involves several safety risks, see <i>Gearbox lubricants (oil or grease) on page 34.</i> | |

Continues on next page

3 Maintenance

3.3.2 Inspecting, oil level gearbox axes 2 - 3


Continued

| | Action | Note |
|---|---|---|
| 2 |  DANGER Turn off all: <ul style="list-style-type: none">• electric power supply• hydraulic pressure supply• air pressure supply to the robot, before entering the safeguarded space. | |
| 3 | Open <i>oil plug, filling</i> | See Location of gearbox, axes 2-3 on page 96 . |
| 4 | Measure oil level at the oil plug, filling. Required oil level: max. 5 mm below oil plug hole. | |
| 5 | Add <i>oil</i> if required. | Art.no. is specified in Required equipment on page 97 . Filling of oil is detailed further in section Changing oil, gearbox axes 2 and 3 on page 122 . |
| 6 | Refit oil plug, filling. | Tightening torque: 24 Nm. |

3.3.3 Inspecting, oil level gearbox axis 6

Location of gearbox

The axis 6 gearbox is located in the tilthouse unit as shown in this figure.



xx0500002484

| | |
|---|--------------------|
| A | Gearbox, axis 6 |
| B | Oil plug, filling |
| C | Oil plug, draining |

Required equipment

| Equipment | Art. no. | Note |
|--|------------|--|
| Lubricating oil | 3HAC0860-1 | Optimol Optigear BM 100 |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Continues on next page



3 Maintenance

3.3.3 Inspecting, oil level gearbox axis 6

Continued

Inspection, oil level axis-6 gearbox


Use this procedure to inspect the oil level in the axis-6 gearbox.

| | Action | Note |
|---|---|--|
| 1 |  WARNING Handling gearbox oil involves several safety risks, see Gearbox lubricants (oil or grease) on page 34 . | |
| 2 |  DANGER Turn off all: <ul style="list-style-type: none">• electric power supply• hydraulic pressure supply• air pressure supply to the robot, before entering the safeguarded space. | |
| 3 | Open <i>oil plug, filling</i> . | Shown in figure Location of gearbox on page 99 . |
| 4 | Required oil level: max. 5 mm below the oil plug hole. | |
| 5 | Add <i>oil</i> if required. | Art. no. is specified in Required equipment on page 99 . Further information about how to fill the oil may be found in the section Changing oil, gearbox axis 6 on page 126 . |
| 6 | Refit oil plug, filling. | Tightening torque: 20 Nm |

3.3.4 Inspecting, balancing device bearings and piston rod guide ring

Location of balancing device

The figure shows the location of the balancing device.



xx0500002495

| | |
|---|---|
| A | Balancing device |
| B | Piston rod |
| C | Guide ring (not visible in this figure) |

Required equipment

| Equipment | Art.no | Note |
|--|----------------|--|
| Grease | 3HAC042536-001 | Shell Gadus S2 |
| Locking liquid | - | Loctite 243 |
| Auxiliary shaft, upper | 3HAC5276-1 | |
| Auxiliary shaft, lower | 3HAC5275-1 | |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Continues on next page



3 Maintenance

3.3.4 Inspecting, balancing device bearings and piston rod guide ring

Continued




Inspecting, bearings

Use this procedure to inspect the bearings, balancing device.

| | Action | Note |
|---|--|--|
| 1 | Move axis 2 to calibration position. | |
| 2 |  <p>DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the safe-guarded space.</p> | |
| 3 | Remove locknuts (KM10), sealing rings and support washers. |  <p>xx0500002496</p> <ul style="list-style-type: none"> A Ear (adjustable needle bearing located inside) B Support washer C Lock nut KM10 (with sealing ring) D Piston rod E Guide ring (not visible in this view) F Inner ring |
| 4 | Fit the <i>auxiliary shafts</i> on upper and lower axes of balancing device. The shafts should be tightened to their bottom position. | Art. no. is specified in <i>Required equipment on page 101</i> . |

Continues on next page

3.3.4 Inspecting, balancing device bearings and piston rod guide ring Continued

| | Action | Note |
|----|--|--|
| 5 | Remove the protection hood from the M12 hole on top of the balancing device. |  <p>xx0600002687</p> <p>A Attachment (seen from above) B Protection hood</p> |
| 6 | Unload the bearings using a M12x50 screw, in the hole for the protective hood, at the cylinder top. | |
| 7 | Pull out the cylinder a little, in order to be able to inspect the <i>inner rings</i> without removing the balancing cylinder. | Shown in previous figure in this procedure. |
| 8 | Wipe the inner rings clean and check that there are no pressure marks or other similar deformations. |  Note It is quite normal for the bearing races to have a darker color than the surrounding material. |
| 9 | Inspect the <i>bearings, support washers and sealing rings</i> . | Shown in previous figure. |
| 10 | If any of the parts looks abnormal, replace. | Detailed in section Replacing the balancing device on page 231 . |
| 11 | Lubricate the shafts, if needed. | |
| 12 | Push the cylinder back in. | Make sure that the inner support washers and sealing rings get in the correct position. |
| 13 | Remove the auxiliary shafts. | |
| 14 | Remove the M12x50 screw. Put back the protection hood in the hole. |  Note Don't forget to remove the screw! If the screw isn't removed it may damage the balancing device, when the robot starts operating. |
| 15 | Apply <i>locking liquid</i> on the lock nuts (KM10) and refit them. | Tightening torque on the lock nuts: <ul style="list-style-type: none"> • 120 Nm |

Continues on next page




3 Maintenance

3.3.4 Inspecting, balancing device bearings and piston rod guide ring

Continued

Inspecting, piston rod guide ring


Use this procedure to inspect the piston rod guide ring for wear.

| | Action | Note |
|---|---|--|
| 1 | Move axis 2 to a position where the balancing device is in a horizontal position. | |
| 2 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the safeguarded space. | |
| 3 | Check the guide ring for wear. Replace if necessary. |  <p data-bbox="997 1312 1102 1330">xx0600002689</p> <p data-bbox="1031 1350 1185 1368">A Guide ring</p> <p data-bbox="1031 1384 1142 1402">B Circlip</p> |
| 4 |  Note If there is a risk of metallic contact between the piston rod and the end cover, the guide ring must be replaced! | |

3.3.5 Inspecting, cable harness

Location of cable harness, axes 1-6

The axes-1-6 cable harness is shown below.



xx0500002497

| | |
|---|-------------------------------|
| A | Cable harness robot, axes 1-6 |
| B | Connectors at base |
| C | Motor cables |
| D | Cable guide, axis 2 |
| E | Metal clamps |

Continues on next page

3 Maintenance

3.3.5 Inspecting, cable harness



Continued

Required equipment


Visual inspection, no tools are needed.

Inspecting cable harness, axes 1-6

Use this procedure to inspect cable harness of axes 1-6.

| | Action | Note |
|---|---|--|
| 1 |  <p>DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the safeguarded space.</p> | |
| 2 | Make an overall inspection of the cable harness in order to detect wear and damage. | |
| 3 | Check the <i>connectors at the base</i> . | Shown in figure Location of cable harness, axes 1-6 on page 105 |
| 4 | Check the <i>motor cables</i> . | Shown in figure Location of cable harness, axes 1-6 on page 105 . |
| 5 | If the robot is equipped with a fork lift device, check that the velcro strap that holds the motor cable is properly attached to the adapter. |  <p>xx0600002691</p> <p>Velcro strap</p> |
| 6 | Check the <i>cable guide axis 2</i> . Replace if damaged. | Shown in figure Location of cable harness, axes 1-6 on page 105 . |
| 7 | Check the <i>metal clamps</i> on the lower arm. | Shown in figure Location of cable harness, axes 1-6 on page 105 |

Continues on next page

| | Action | Note |
|----|---|--|
| 8 | Check the metal clamps holding the cable harness inside the upper arm, as shown in figure to the right. |  <p data-bbox="1015 640 1118 658">xx0500002498</p> <p data-bbox="1082 674 1437 703">A: Metal clamp inside upper arm</p> |
| 9 | Check the metal clamp holding the motor cable on axis 6. | Shown in figure Location of cable harness, axes 1-6 on page 105 . |
| 10 | Replace the cable harness if wear or damage is detected! | Detailed in section: Replacing cable harness, lower end (axes 1-3) on page 146 . Replacing the cable harness, upper end (incl. axis 6) on page 154 . |


3 Maintenance

3.3.6 Inspecting the information labels

3.3.6 Inspecting the information labels

Location of labels


These figures show the location of the information labels to be inspected. The symbols are described in section [Safety symbols on manipulator labels on page 23](#).



xx0500002499

| | |
|---|---|
| A | Warning label concerning high temperature (located on motor cover) (4 pcs) |
| B | Warning label, symbol of flash (located on motor cover) (4 pcs) |
| D | Warning label concerning brake release |
| G | Warning label |
| J | Warning label |
| K | Warning label concerning extended working range (option) |
| - | Information labels at gearboxes and at robot base, specifying which oil is used in gearboxes. |

Continues on next page




xx0500002500

| | |
|---|---|
| C | Instruction label |
| E | Instruction label concerning lifting the robot |
| F | Warning label concerning risk of tipping |
| H | Warning label concerning stored energy |
| L | Information label at base, Kyodo Yushi TMO 150 in gearboxes |

Required tools and equipment

Visual inspection, no tools are required.

Inspecting, labels

| | Action | Note |
|---|---|---|
| 1 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the safeguarded space. | |
| 2 | Inspect the labels, located as shown in the figures. | |
| 3 | Replace any missing or damaged labels. | Article numbers for the labels and plate set is specified in Spare part lists on page 349 . |

3 Maintenance

3.3.7 Inspecting the axis-1 mechanical stop pin

3.3.7 Inspecting the axis-1 mechanical stop pin



WARNING

Mechanical stop pin can not be fitted onto robot if option 810-1 *Electronic Position Switch* is used.




WARNING

Mechanical stop pin can not be fitted onto robot if the option 561-1 *Extended working range* is used for axis 1.

Location of mechanical stop pin

The axis-1 mechanical stop is located as shown in the figure.



xx0600002695


| | |
|---|---------------------|
| A | Mechanical stop pin |
| B | Fixed stop |

Required equipment


Visual inspection, no tools are required.

Inspecting, mechanical stop pin

Use this procedure to inspect the axis-1 mechanical stop pin.

| Action | Note |
|--|------|
| 1  DANGER Turn off all: <ul style="list-style-type: none">• electric power supply• hydraulic pressure supply• air pressure supply to the robot, before entering the safeguarded space. | |

Continues on next page

| | Action | Note |
|---|--|------|
| 2 | <p>Inspect the axis-1 mechanical stop pin. If the mechanical stop pin is bent or damaged, it must be replaced.</p> <p> Note</p> <p>The expected life of gearboxes can be reduced after collision with the mechanical stop.</p> | |
| 3 | <p>Make sure the mechanical stop pin can move in both directions.</p> | |


3 Maintenance

3.3.8 Inspecting the additional mechanical stops

3.3.8 Inspecting the additional mechanical stops

Location of mechanical stops

This figure shows the location of the additional mechanical stops on axis 1. (The figure shows IRB 7600 but the location on axis 1 is the same on IRB 660.)



xx0300000049


| | |
|---|----------------------------|
| A | Additional mechanical stop |
| B | Stop pin |

Required equipment

| Equipment etc. | Article number | Note |
|------------------|----------------|--|
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |

Inspecting, mechanical stops

Use this procedure to inspect the additional mechanical stops.

| Action | Note |
|---|------|
| <p>1</p> <p> DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> | |

Continues on next page

| | Action | Note |
|---|---|---|
| 2 | Make sure no additional stops are damaged. | Shown in figure Location of mechanical stops on page 112 . |
| 3 | Make sure the stops are properly attached. Correct tightening torque, additional mechanical stops: <ul style="list-style-type: none">• Axis 1 = 120 Nm. | |
| 4 | If any damage is detected, the mechanical stops must be replaced. Correct attachment screws: <ul style="list-style-type: none">• Axis 1: M16 x 35, quality 12.9. | Article number is specified in Required equipment on page 112 . |


3 Maintenance

3.3.9 Inspection, dampers

3.3.9 Inspection, dampers

Location of dampers

This figure shows the location of dampers.



xx0500002501

| | |
|---|---|
| A | Damper, lower arm, upper (2 pcs) |
| B | Damper, lower arm, lower (1 pc) |
| C | Damper, axis 2 (2 pcs) |
| - | Damper, axis 3 (2 pcs). Not visible in this view. |


Continues on next page

Required equipment

| Equipment | Art.no. | Note |
|-------------------------|---|----------------------------|
| Damper lower arm, upper | See Spare part lists on page 349 . | To be replaced if damaged. |
| Damper lower arm, lower | See Spare part lists on page 349 . | To be replaced if damaged. |
| Damper axis 2, 3 | See Inspection, dampers on page 114 . | To be replaced if damaged. |

Inspecting, dampers

Use this procedure to inspect the dampers.

| | Action | Note |
|---|---|--|
| 1 |  <p>DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the safeguarded space.</p> | |
| 2 | Check all <i>dampers</i> for damage, cracks or existing impressions larger than 1 mm. | Shown in figure Location of dampers on page 114 . |
| 3 | Check attachment screws for deformation. | |
| 4 | If any damage is detected, the <i>damper</i> must be replaced with a new one. | Art.no. is specified in Required equipment on page 115 . |


3 Maintenance

3.3.10 Inspecting the signal lamp (option)

3.3.10 Inspecting the signal lamp (option)

Location of signal lamp

The signal lamp is located as shown in this figure.



xx0500002466

| | |
|---|---------------------------------|
| A | Signal lamp |
| B | Cable straps, outdoor |
| C | Cable |
| D | Connection point to cable gland |

Required tools and equipment


| Equipment | Article number | Note |
|------------------|--|--|
| Signal lamp kit | See Spare part lists on page 349 . | To be replaced if damage is detected. |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |

Inspecting, signal lamp

Use this procedure to inspect the function of the signal lamp.

| | Action | Note |
|---|---|------|
| 1 | Inspect that signal lamp is lit when motors are put in operation ("MOTORS ON"). | |

Continues on next page

| | Action | Note |
|---|---|---|
| 2 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the safeguarded space. | |
| 3 | If the lamp is not lit, trace the fault by: <ul style="list-style-type: none"> • inspecting whether the signal lamp is broken. If so, replace it. • inspecting cable connections. • measuring the voltage in the connectors of motor axis 6 (=24V). • inspecting the cabling. Replace the cabling if a fault is detected. | Article number is specified in Required tools and equipment on page 116 . |

3 Maintenance

3.4.1 Type of lubrication in gearboxes

3.4 Replacement/changing activities

3.4.1 Type of lubrication in gearboxes

Introduction


This section describes where to find information about the type of lubrication, article number and the amount of lubrication in the specific gearbox. It also describes the equipment needed when working with lubrication.

Type and amount of oil in gearboxes

Information about the type of lubrication, article number as well as the amount in the specific gearbox can be found in *Technical reference manual - Lubrication in gearboxes* available for registered users on myABB Business Portal, www.abb.com/myABB.

Location of gearboxes

The figure shows the location of the gearboxes.



xx0500002467

| | |
|---|-----------------|
| A | Gearbox, axis 1 |
| B | Gearbox, axis 2 |
| C | Gearbox, axis 3 |
| D | Gearbox, axis 6 |

Equipment


| Equipment | Note |
|---|--|
| Oil dispenser | Includes pump with outlet pipe. Use the suggested dispenser or a similar one: <ul style="list-style-type: none">Orion OriCan article number 22590 (pneumatic) |
| Nipple for quick connect fitting, with o-ring | |

3.4.2 Changing oil, axis-1 gearbox

Location of oil plugs

The axis-1 gearbox is located between the frame and base. See oil plugs in the following figure.


The oil is drained through a hose, which is located at the rear of the robot base.



xx0500002479

| | |
|---|----------------------|
| A | Oil plug, inspection |
| B | Gearbox axis 1 |
| C | Oil plug, filling |
| D | Motor, axis 1 |
| E | Drain hose |

Required equipment

| Equipment, etc. | Art. no. | Amount | Note |
|-----------------------|---|---|--|
| Lubricating oil | See <i>Type and amount of oil in gearboxes on page 118.</i> | See <i>Type and amount of oil in gearboxes on page 118.</i> |  Note Do not mix with other oils! |
| Oil collecting vessel | - | | Capacity: 8,000 ml. |

Continues on next page

3 Maintenance

3.4.2 Changing oil, axis-1 gearbox

Continued




| Equipment, etc. | Art. no. | Amount | Note |
|------------------------|----------------|--------|--|
| Oil exchange equipment | 3HAC021745-001 | | Content is defined in section Special tools on page 345 . |
| Standard toolkit | - | | Content is defined in section Standard tools on page 344 . |

Draining oil, axis-1 gearbox



Use this procedure to drain the oil in gearbox axis 1.

When using oil exchange equipment, follow the instructions enclosed with the kit.

Art. no. for the kit is specified in [Required equipment on page 119](#).



| | Action | Note |
|---|---|---|
| 1 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the safeguarded space. | |
| 2 |  WARNING Handling gearbox oil involves several safety risks, see Gearbox lubricants (oil or grease) on page 34 . | |
| 3 | Remove rear cover on the base by unscrewing its attachment screws. | |
| 4 | Pull out the draining hose from the rear of the base. |  <p>xx0200000237</p> <p>The hose is located beneath the base, seen from below. A Oil draining hose</p> |
| 5 | Place an oil vessel close to hose end. | Vessel capacity is specified in Required equipment on page 119 . |
| 6 | Remove <i>oil plug, filling</i> in order to drain oil quicker! | Shown in figure Location of oil plugs on page 119 . |

Continues on next page

| | Action | Note |
|---|---|---|
| 7 | <p>Open the hose end and drain the oil into a vessel.</p> <p> CAUTION</p> <p>Drain as much oil as possible.</p> | <p> Note</p> <p>Draining is time-consuming. Elapsed time depends on the temperature of the oil.</p> |
| 8 | <p>Close the oil drain hose, and put it back inside the base.</p> | |
| 9 | <p>Refit rear cover by securing it with its attachment screws.</p> | |

Filling oil, axis-1 gearbox

Use this procedure to fill gearbox axis 1 with oil.

| | Action | Note |
|---|---|---|
| 1 | <p> DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the safeguarded space.</p> | |
| 2 | <p> WARNING</p> <p>Handling gearbox oil involves several safety risks, see Gearbox lubricants (oil or grease) on page 34.</p> | |
| 3 | <p>Open the <i>oil plug, filling</i>.</p> | <p>Shown in figure Location of oil plugs on page 119.</p> |
| 4 | <p>Refill the gearbox with clean <i>lubricating oil</i>. The correct oil level is detailed in section Inspecting the oil level in axis-1 gearbox on page 94.</p> | <p>Where to find type of oil and total amount is detailed in Type and amount of oil in gearboxes on page 118.</p> |
| 5 | <p>Refit the oil plug, filling.</p> | <p>Tightening torque: 24 Nm.</p> |

3 Maintenance


3.4.3 Changing oil, gearbox axes 2 and 3

3.4.3 Changing oil, gearbox axes 2 and 3

Location of oil plugs

Gearboxes, axes 2 and 3, are located in lower arm rotational center, underneath motor attachment.

The figure shows the position of gearbox, axis 2.




xx0500002482

| | |
|---|---------------------------------------|
| A | Gearbox axis 2 |
| B | Oil plug, draining |
| C | Oil plug, filling |
| D | Ventilation hole plug, gearbox axis 2 |

Continues on next page


The figure shows position of gearbox, axis 3.



xx0500002483

| | |
|---|---------------------------------------|
| A | Gearbox, axis 3 |
| B | Oil plug, draining |
| C | Oil plug, filling |
| D | Ventilation hole plug, gearbox axis 3 |

Required equipment

| Equipment etc. | Art. no. | Amount | Note |
|------------------------|---|---|--|
| Lubricating oil | See <i>Type and amount of oil in gearboxes on page 118.</i> | See <i>Type and amount of oil in gearboxes on page 118.</i> |  Note Do not mix with other oils! |
| Oil collecting vessel | | | Capacity: 6,000 ml |
| Oil exchange equipment | 3HAC021745-001 | | Content is defined in section <i>Special tools on page 345.</i> |
| Standard toolkit | - | | Content is defined in section <i>Standard tools on page 344.</i> |

Continues on next page

3 Maintenance



3.4.3 Changing oil, gearbox axes 2 and 3

Continued

Draining, axes 2 and 3

Use this procedure to drain oil in gearbox axes 2 and 3.



When using oil change equipment, follow the instructions enclosed with kit.

| | Action | Note |
|---|---|---|
| 1 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the safeguarded space. | |
| 2 |  WARNING Handling gearbox oil involves several safety risks, see Gearbox lubricants (oil or grease) on page 34 . | |
| 3 | Remove the <i>ventilation hole plug</i> . | Shown in Location of oil plugs on page 122 . |
| 4 | Remove the <i>oil plug, draining</i> , and drain gearbox using a hose with a nipple and an oil collecting vessel. | Shown in Location of oil plugs on page 122 . Vessel capacity is specified in Required equipment on page 123 . Draining is time-consuming. Elapsed time varies depending on the temperature of the oil. |
| 5 | Refit the oil plug, draining. | Tightening torque: 24 Nm. |

Filling, axes 2 and 3

Use this procedure to fill gearboxes of axes 2 and 3 with oil.

When using oil change equipment, follow the instructions enclosed with kit.

| | Action | Note |
|---|---|------|
| 1 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the safeguarded space. | |
| 2 |  WARNING Handling gearbox oil involves several safety risks, see Gearbox lubricants (oil or grease) on page 34 . | |

Continues on next page

| | Action | Note |
|---|--|--|
| 3 | Remove the <i>oil plug, filling</i> . (<i>Ventilation hole plug</i> should also be removed.) | Shown in Location of oil plugs on page 122 . Tightening torque: 24 Nm. |
| 4 | Refill gearbox with <i>lubricating oil</i> . The <i>amount of oil</i> to be filled depends on the amount that was previously drained. | Art.no. and total amount are specified in Required equipment on page 123 . |
| 5 | Refit <i>oil plug, filling</i> and <i>ventilation hole plug</i> . | Shown in Location of oil plugs on page 122 . Tightening torque: 24 Nm. |


3 Maintenance

3.4.4 Changing oil, gearbox axis 6

3.4.4 Changing oil, gearbox axis 6

Location of oil plugs

Gearbox axis 6 is located in the center of the tilt house unit.



xx0500002484

| | |
|---|--------------------|
| A | Gearbox, axis 6 |
| B | Oil plug, filling |
| C | Oil plug, draining |

Required equipment

| Equipment, etc. | Art. no. | Amount | Note |
|------------------------|----------------|--------|--|
| Lubrication oil | 3HAC032140-001 | 250 ml | Kyodo Yushi TMO 150 Do not mix with other oil types! |
| Oil exchange equipment | 3HAC021745-001 | | |
| Oil collecting vessel | | | Vessel capacity: 400 ml. |
| Standard toolkit | | - | Content is defined in section Standard tools on page 344. |


Draining, oil

Use this procedure to drain oil from gearbox axis 6.

When using oil change equipment, follow the instructions enclosed with kit.

| | Action | Note |
|---|--|------|
| 1 | Put tilt house in a suitable position. | |


Continues on next page

| | Action | Note |
|---|---|---|
| 2 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the safeguarded space. | |
| 3 | Drain oil from gearbox into a vessel by removing <i>oil plug, draining</i> . Also remove <i>oil plug, filling</i> . | Shown in figure Location of oil plugs on page 126 . Vessel capacity is specified in Required equipment on page 126 . |
| 4 | Refit oil plugs, draining and filling. | Tightening torque: 20 Nm. |

Filling, oil

Use this procedure to fill gearbox axis 6 with oil.

When using oil change equipment, follow the instructions enclosed with kit.

| | Action | Note |
|---|---|---|
| 1 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the safeguarded space. | |
| 2 | Remove the <i>oil plug, filling</i> . | Shown in figure Location of oil plugs on page 126 . |
| 3 | Refill the gearbox with <i>lubricating oil</i> . Amount of oil to be refilled depends on the amount that was previously drained. Correct oil level is detailed in section Inspection, oil level axis-6 gearbox on page 100 . | Art. no. and the total amount are specified in Required equipment on page 126 . |
| 4 | Refit the oil plug. | Tightening torque: 20 Nm |

3 Maintenance

3.4.5 Replacing the SMB battery

3.4.5 Replacing the SMB battery



Note

The battery low alert (38213 **Battery charge low**) is displayed when the battery needs to be replaced. The recommendation to avoid an unsynchronized robot is to keep the power to the controller turned on until the battery is to be replaced. For a SMB board with 3-pole battery contact (RMU101 3HAC044168-001 or RMU102 3HAC043904-001), the lifetime of a new battery is typically 36 months. For a SMB board with 2-pole battery contact (DSQC), the typical lifetime of a new battery is 36 months if the robot is powered off 2 days/week or 18 months if the robot is powered off 16 h/day. The lifetime can be extended for longer production breaks with a battery shutdown service routine. See the operating manual for the robot controller for instructions.




WARNING

See [Hazards related to batteries on page 36](#).

Location of SMB battery

The SMB battery (SMB = serial measurement board) is located on the left hand side of the frame as shown in the figure.

Battery pack with a 2-pole battery contact (DSQC)




xx0500002486

| | |
|---|-------------------|
| A | SMB battery cover |
| B | SMB battery pack |
| C | Battery cable |

Continues on next page

Battery pack with a 3-pole battery contact (RMU)



xx1400002574

| | |
|---|--------------------|
| A | Battery pack RMU |
| B | Holder for battery |
| C | SMB cover |
| D | Battery cable |
| E | Battery holder |
| F | Guide pin (2 pcs) |
| G | SMB unit |

Required equipment



Note

There are two variants of SMB units and batteries. One with 2-pole battery contact (DSQC) and one with 3-pole battery contact (RMU). The variant with the 3-pole battery contact has longer lifetime for the battery.

It is important that the SMB unit uses the correct battery. Make sure to order the correct spare parts. Do not exchange battery contacts!

| Equipment, etc. | Spare part no. | Note |
|------------------|---|---|
| Battery unit | For spare part no. see: <ul style="list-style-type: none"> Spare part lists on page 349 | Battery includes protection circuits. Only replace with a specified spare part or an ABB-approved equivalent. |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |

Continues on next page

3 Maintenance




3.4.5 Replacing the SMB battery

Continued

| Equipment, etc. | Spare part no. | Note |
|-----------------|----------------|--|
| Circuit diagram | - | See chapter Circuit diagrams on page 351 . |

Removing, battery






Use this procedure to remove the SMB battery.

| | Action | Note |
|---|---|---|
| 1 | Move the robot to its calibration position. | This is done in order to facilitate updating of the revolution counter. |
| 2 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the safeguarded space. | |
| 3 |  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit please read the safety information in the section The unit is sensitive to ESD on page 49 | |
| 4 | Remove the <i>SMB battery cover</i> by unscrewing the attachment screws.  CAUTION Clean cover from metal residues before opening. Metal residues can cause shortage on the boards which can result in hazardous failures. | Shown in figure Location of SMB battery on page 128 . |
| 5 | Pull out the battery and disconnect the <i>battery cable</i> . | Shown in figure Location of SMB battery on page 128 . |
| 6 | Remove the <i>SMB battery</i> . Battery includes protection circuits. Only replace with a specified spare part or with an ABB- approved equivalent. | Shown in figure Location of SMB battery on page 128 . |

Continues on next page

Refitting, battery

Use this procedure to refit the SMB battery.

| | Action | Note |
|---|--|--|
| 1 |  <p>DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the safeguarded space.</p> | |
| 2 |  <p>ELECTROSTATIC DISCHARGE (ESD)</p> <p>The unit is sensitive to ESD. Before handling the unit please read the safety information in the section The unit is sensitive to ESD on page 49</p> | |
| 3 | <p>Reconnect the <i>battery cable</i> and install the battery pack into the SMB/battery recess.</p>  <p>Note</p> <p>RMU batteries are installed together with a battery holder to be properly secured inside the recess. See figure.</p> <p>Strap the battery cable to the holder.</p> | <p>Art. no. is specified in Required equipment on page 129.</p> <p>Shown in figure Location of SMB battery on page 128.</p>  <p>xx1300000307</p> <p>A Battery pack RMU B Battery holder C Battery cable D Strap</p> |
| 4 | <p>Secure the <i>SMB battery cover</i> with its attachment screws.</p> | <p>Shown in figure Location of SMB battery on page 128.</p> |
| 5 | <p>Update the revolution counters.</p> | <p>Detailed in chapter Calibration - section Updating revolution counters on IRC5 robots on page 306.</p> |
| 6 |  <p>DANGER</p> <p>Make sure all safety requirements are met when performing the first test run.</p> | |

3 Maintenance

3.5.1 Lubricating balancing device bearings and piston rod

3.5 Lubrication activities

3.5.1 Lubricating balancing device bearings and piston rod


Overview

This procedure details how to lubricate the balancing device's bearings and piston rod.

Location of bearings and piston rod

This figure shows the location of bearings and piston rod.

Note! Balancing device must be fitted on robot when lubricating bearings!



xx0500002489

| | |
|---|---------------------------------------|
| A | Ear (bearing located inside) |
| B | Support washer |
| C | Lock nut |
| D | Piston rod |
| E | Guide ring (not visible in this view) |

Continues on next page



3.5.1 Lubricating balancing device bearings and piston rod *Continued*

Required equipment

| Equipment | Art. no. | Note |
|--|----------------|---|
| Lubrication tool | 3HAC5222-2 | |
| Bearing grease | 3HAC042536-001 | Equivalent: <ul style="list-style-type: none"> • Shell Gadus S2 |
| Cleaning agent | - | Isopropanol |
| Piston rod grease | - | Choose any of following equivalents: <ul style="list-style-type: none"> • Shell: SRS Grease 4000 • Preem: Novatex Heavy EP 2 • Castrol: Entrenadfett • Statoil: Uniway 2X2N |
| Locking liquid | - | Loctite 243 |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Lubricating, bearings

Use this procedure to lubricate the balancing device bearings.

| | Action | Note |
|---|---|--|
| 1 | Move axis 2 to calibration position. | |
| 2 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the safeguarded space. | |
| 3 | Remove the locknut. | Be careful not to loose the support washer in the process. |
| 4 | Fit the lubricating tool. It should be tightened to the bottom, by hand only. | |
| 5 | Grease through nipple on the lubricating tool. | |
| 6 | Continue filling grease until clean grease exudes behind the inner sealing ring. Repeat this procedure at the other bearing! | |
| 7 | Remove the lubricating tool and clean the threads on the shaft ends of grease. | Also clean of old grease on the inner side! |
| 8 | Apply some grease to the support washers. | |
| 9 |  Note Apply locking liquid on the lock nuts (KM10). Do not apply locking liquid on the shafts! | Tightening torque on lock nuts: <ul style="list-style-type: none"> • 120 Nm |

Continues on next page

3 Maintenance


3.5.1 Lubricating balancing device bearings and piston rod

Continued

| | Action | Note |
|----|--|--|
| 10 | Check play between support washer and bearings at both bearings. | Minimum play: <ul style="list-style-type: none">• 0.1 mm |

Lubricating, piston rod

Use this procedure to lubricate the balancing device piston rod.

| | Action | Note |
|---|---|---|
| 1 | Position axis 2 so that the balancing device is horizontal and the piston rod is extended to the greatest extent possible. | |
| 2 |  DANGER Turn off all: <ul style="list-style-type: none">• electric power supply• hydraulic pressure supply• air pressure supply to the robot, before entering the safeguarded space. | |
| 3 | Clean piston rod with isopropanol before applying new grease. | |
| 4 | Apply new grease. | Type of grease is specified in Required equipment on page 133 . |

3.6 Cleaning activities

3.6.1 Cleaning the IRB 660



DANGER

Turn off all:

- electric power supply
- hydraulic pressure supply
- air pressure supply

to the robot, before entering the safeguarded space.

General

To secure high uptime it is important that the IRB 660 is cleaned regularly. The frequency of cleaning depends on the environment in which the product works. Different cleaning methods are allowed depending on the type of protection of the IRB 660.



Note

Always verify the protection type of the robot before cleaning.

Oil spills

Oil spills from gearboxes

Use the following procedure if any oil spills are detected that can be suspected to originate from a gearbox.

- 1 Inspect that the oil level in the suspected gearbox is according to the recommendations, see [Inspection activities on page 94](#).
- 2 Write down the oil level.
- 3 Inspect the oil level again after, for example, 6 months.
- 4 If the oil level is decreased then replace the gearbox.

Special cleaning considerations

This section specifies some special considerations when cleaning the robot.

- Always use cleaning equipment as specified. Any other cleaning equipment may shorten the life of the robot.
- Always check that all protective covers are fitted to the robot before cleaning.
- Never point the water jet at connectors, joints, sealings, or gaskets.
- Do not use compressed air to clean the robot.
- Never use solvents that are not approved by ABB to clean the robot.
- Do not spray from a distance closer than 0.4 m.
- Do not remove any covers or other protective devices before cleaning the robot.

Continues on next page

3 Maintenance

3.6.1 Cleaning the IRB 660

Continued

Cleaning methods

The following table defines what cleaning methods are allowed depending on the protection type.

| Protection type | Cleaning method | | | |
|-----------------|-----------------|-------------------------------------|--|------------------------------|
| | Vacuum cleaner | Wipe with cloth | Rinse with water | High pressure water or steam |
| Standard | Yes | Yes. With light cleaning detergent. | Yes. It is highly recommended that the water contains a rust-prevention solution and that the manipulator is dried afterwards. | No |

Cleaning with water and steam

Instructions for rinsing with water

ABB robots with protection types *Standard*, *Foundry Plus*, *Wash*, or *Foundry Prime* can be cleaned by rinsing with water (water cleaner).¹

The following list defines the prerequisites:

- Maximum water pressure at the nozzle: 700 kN/m² (7 bar)¹
- Fan jet nozzle should be used, min. 45° spread
- Minimum distance from nozzle to encapsulation: 0.4 meters
- Maximum flow: 20 liters/min¹

¹ Typical tap water pressure and flow

Cables

Movable cables need to be able to move freely:

- Remove waste material, such as sand, dust and chips, if it prevents cable movement.
- Clean the cables if they have a crusty surface, for example from dry release agents.

¹ See [Cleaning methods on page 136](#) for exceptions.

4 Repair

4.1 Introduction

Structure of this chapter

This chapter describes repair activities for the IRB 660. Each procedure contains the information required to perform the activity, for example spare parts numbers, required special tools, and materials.



WARNING

Repair activities not described in this chapter must only be carried out by ABB.

Report replaced units



Note

When replacing a part on the IRB 660, report to your local ABB the serial number, the article number, and the revision of both the replaced unit and the replacement unit.

This is particularly important for safety equipment to maintain the safety integrity of the installation.

Safety information

Make sure to read through the chapter [Safety on page 19](#) before commencing any service work.



Note

If the IRB 660 is connected to power, always make sure that the IRB 660 is connected to protective earth and a residual current device (RCD) before starting any repair work.

For more information see:

- *Product manual - OmniCore V250XT*
- *Product manual - IRC5*
- *Product manual - IRC5 Panel Mounted Controller*

4 Repair

4.2.1 Performing a leak-down test

4.2 General procedures

4.2.1 Performing a leak-down test


When to perform a leak-down test

After refitting any motor and gearbox, the integrity of all seals enclosing the gearbox oil must be tested. This is done in a leak-down test.

Required equipment

| Equipment, etc. | Article number | Note |
|----------------------|----------------|------|
| Leak-down tester | - | |
| Leak detection spray | - | |

Performing a leak-down test

| | Action | Note |
|---|---|--|
| 1 | Finish the refitting procedure of the motor or gear in question. | |
| 2 | Remove the upper oil plug on the gear and replace it with the leak-down tester. Regulators, which are included in the leak-down test, may be required. | |
| 3 | Use caution, apply compressed air and raise the pressure with the knob until the correct value is shown on the manometer.  CAUTION The pressure must under no circumstance be higher than 0.25 bar (20-25 kPa). Also during the time when the pressure is raised. | Correct value: 0.2-0.25 bar (20-25 kPa) |
| 4 | Disconnect the compressed air supply. | |
| 5 | Wait for approximately 8-10 minutes and make sure that no pressure loss occurs. | If the compressed air is significantly colder or warmer than the gearbox to be tested, a slight pressure increase or decrease may occur. This is quite normal. |
| 6 | If any pressure drop occurred, then localize the leak as described in step 7. If no pressure drop occurred, then remove the leak-down tester and refit the oil plug. The test is complete. | |
| 7 | Spray any suspected leak areas with the leak detection spray. Bubbles indicate a leak. | |
| 8 | When the leak has been localized, take the necessary measures to correct the leak. | |

4.2.2 Mounting instructions for bearings

General

This section describes how to mount and grease different types of bearings on the robot.

Equipment

| Equipment, etc. | Article number | Note |
|-----------------|----------------|--|
| Grease | 3HAC042536-001 | Shell Gadus S2 Used to grease the bearings, if not specified otherwise. |

Assembly of all bearings


Attend to the following instructions while mounting a bearing on the robot.

| | Action | Note |
|---|---|------|
| 1 | To avoid contamination, let a new bearing remain in its wrapping until it is time for fitting. | |
| 2 | Ensure that the parts included in the bearing fitting are free from burrs, grinding waste, and other contamination. Cast components must be free of foundry sand. | |
| 3 | Bearing rings, inner rings, and roller elements must not be subjected to direct impact. The roller elements must not be exposed to any stresses during the assembly work. | |

Assembly of tapered bearings

Follow the preceding instructions for the assembly of the bearings when mounting a tapered bearing on the robot.

In addition to those instructions, the following procedure must be carried out to enable the roller elements to adjust to the correct position against the race flange.

| | Action | Note |
|---|--|------|
| 1 | Tension the bearing gradually until the recommended pre-tension is achieved.  Note The roller elements must be rotated a specified number of turns before pre-tensioning is carried out and also rotated during the pre-tensioning sequence. | |
| 2 | Make sure the bearing is properly aligned as this will directly affect the durability of the bearing. | |

Greasing of bearings



Note

This instruction is not valid for solid oil bearings.

Continues on next page

4 Repair

4.2.2 Mounting instructions for bearings

Continued

The bearings must be greased after assembly according to the following instructions:

- The bearings must not be completely filled with grease. However, if space is available beside the bearing fitting, the bearing may be totally filled with grease when mounted, as excessive grease will be pressed out from the bearing when the robot is started.
- During operation, the bearing should be filled to 70-80% of the available volume.
- Ensure that grease is handled and stored properly to avoid contamination.

Grease the different types of bearings as following description:

- *Grooved ball bearings* must be filled with grease from both sides.
- *Tapered roller bearings* and axial needle bearings must be greased in the split condition.

4.2.3 Mounting instructions for sealings

General

This section describes how to mount different types of sealings.

Equipment

| Consumable | Article number | Note |
|------------|----------------|----------------|
| Grease | 3HAC042536-001 | Shell Gadus S2 |

Rotating sealings

The procedure below describes how to fit rotating sealings.



CAUTION

Please observe the following before commencing any assembly of sealings:

- Protect the sealing during transport and mounting, especially the main lip.
- Keep the sealing in its original wrappings or protect it well before actual mounting.
- The fitting of sealings and gears must be carried out on clean workbenches.
- Use a protective sleeve for the main lip during mounting, when sliding over threads, keyways or other sharp edges.


| Action | Note |
|--|--|
| 1 Check the sealing to ensure that: <ul style="list-style-type: none"> • The sealing is of the correct type. • There is no damage on the main lip. | |
| 2 Inspect the shaft surface before mounting. If scratches or damage are found, the shaft must be replaced since it may result in future leakage. Do not try to grind or polish the shaft surface to get rid of the defect. | |
| 3 Lubricate the sealing with grease just before fitting. (Not too early - there is a risk of dirt and foreign particles adhering to the sealing.) Fill 2/3 of the space between the dust lip and the main lip with grease. If the sealing is without dust lip, just lubricate the main lip with a thin layer of grease. | <p>Article number is specified in Equipment on page 141.</p> <p>xx2000000071</p> <p>A Main lip B Grease C Dust lip</p> |

Continues on next page

4 Repair

4.2.3 Mounting instructions for sealings

Continued

| | Action | Note |
|---|--|---|
| 4 | <p>Mount the sealing correctly with a mounting tool. Never hammer directly on the sealing as this may result in leakage.</p> |  <p>xx2000000072</p> <p>A Gap</p> |

Flange sealings and static sealings

The following procedure describes how to fit flange sealings and static sealings.

| | Action |
|---|--|
| 1 | <p>Check the flange surfaces. They must be even and free from pores. It is easy to check flatness using a gauge on the fastened joint (without sealing compound). If the flange surfaces are defective, the parts may not be used because leakage could occur.</p> |
| 2 | <p>Clean the surfaces properly in accordance with the recommendations of ABB.</p> |
| 3 | <p>Distribute the sealing compound evenly over the surface, preferably with a brush.</p> |
| 4 | <p>Tighten the screws evenly when fastening the flange joint.</p> |

O-rings

The following procedure describes how to fit o-rings.

| | Action | Note |
|---|---|---|
| 1 | <p>Ensure that the correct o-ring size is used.</p> | |
| 2 | <p>Check the o-ring for surface defects, burrs, shape accuracy, or deformation.</p> | <p>Defective o-rings, including damaged or deformed o-rings, may not be used.</p> |

Continues on next page

| | Action | Note |
|---|---|------|
| 3 | Check the o-ring grooves. The grooves must be geometrically correct and should be free of pores and contamination. | |
| 4 | Lubricate the o-ring with grease. | |
| 5 | Tighten the screws evenly while assembling. | |
| 6 | Check that the o-ring is not squashed outside the o-ring groove. | |

4 Repair

4.2.4 Cut the paint or surface on the robot before replacing parts

4.2.4 Cut the paint or surface on the robot before replacing parts


General

Follow the procedures in this section whenever breaking the paint of the robot during replacement of parts.

Required equipment

| Equipment | Spare parts | Note |
|--------------------------------------|----------------|----------------|
| Cleaning agent | | Ethanol |
| Knife | | |
| Lint free cloth | | |
| Touch up paint Standard/Foundry Plus | 3HAC067974-001 | Graphite White |
| Touch up paint Standard/Foundry Plus | 3HAC037052-001 | ABB Orange |

Removing

| Action | Description |
|--|--|
| 1 Cut the paint with a knife in the joint between the part that will be removed and the structure, to avoid that the paint cracks. |  xx0900000121 |
| 2 Carefully grind the paint edge that is left on the structure to a smooth surface. | |

4.2.5 The brake release buttons may be jammed after service work

4.2.5 The brake release buttons may be jammed after service work

Description

The brake release unit has push-buttons for the brake release of each axis motor. When service work is performed inside the SMB recess that includes removal and refitting of the brake release unit, the brake release buttons may be jammed after refitting.

**DANGER**

If the power is turned on while a brake release button is jammed in depressed position, the affected motor brake is released. This may cause serious personal injuries and damage to the robot.

Elimination

To eliminate the danger after service work has been performed inside the SMB recess, follow the procedure below.

| | Action |
|---|---|
| 1 | Make sure the power is turned off. |
| 2 | Remove the push-button guard, if necessary. |
| 3 | Verify that the push-buttons of the brake release unit are working by pressing them down, one by one. Make sure none of the buttons are jammed in the tube. |
| 4 | If a button gets jammed in the depressed position, the alignment of the brake release unit must be adjusted so that the buttons can move freely in their tubes. |

4 Repair

4.3.1 Replacing cable harness, lower end (axes 1-3)

4.3 Complete robot

4.3.1 Replacing cable harness, lower end (axes 1-3)


Overview

The cable harness 1-6 is undivided.

How to replace the cable harness is described in two steps - lower end (axes 1-3) and upper end (axis 6). This procedure describes how to replace the lower end of the cable harness. How to replace the upper end can be found in section [Replacing the cable harness, upper end \(incl. axis 6\) on page 154](#).

Location of cable harness - lower end (axes 1-3)

The cable harness, lower end (axes 1-3) is located throughout the base, frame and lower arm as shown in the figure.



xx0600002608


| | |
|---|--------------------------------|
| A | Cable harness, lower end |
| B | Cable harness, upper end |
| C | Connector R1.MP |
| D | Connector R1.SMB |
| E | Attachment point for earth lug |
| F | Cover plate |
| G | Rear cover plate |
| H | Cable gland, SMB |
| I | Cable guide, axis 2 |

Continues on next page

4.3.1 Replacing cable harness, lower end (axes 1-3)

Continued

| | |
|---|------------------------|
| J | Metal clamp, frame |
| K | Metal clamp, lower arm |
| L | Metal clamp, upper arm |
| M | Metal clamp, tilthouse |



xx070000070

| | |
|---|--------------------------------|
| A | Cable guide, axis 2 |
| B | Metal clamp |
| C | Connector at base |
| D | Cable guide, axis 1 |
| E | Cable harness, axes 1-6 |
| F | Cover plate |
| G | Rear cover plate |
| H | Attachment point for earth lug |


Continues on next page

4 Repair

4.3.1 Replacing cable harness, lower end (axes 1-3)

Continued

The motors axes 2-3 are located on either side of the robot as shown in the figure below.



xx0600002599

| | |
|---|--|
| A | Motor, axis 2 |
| B | Motor, axis 3 |
| C | Motor attachment screws and washers |
| D | Cable gland cover (located on the lower side of the motor) |
| E | Motor cover |

Required equipment



| Equipment, etc. | Art.no. | Note |
|--|---|--|
| Cable harness 1-6 | For spare part no. see: • Spare part lists on page 349 | |
| Gasket | 3HAC3537-1 | Motor, axes 1-3 Replace if damaged. |
| Standard toolkit | - | The content is defined in the section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | - | These procedures include references to the tools required. |
| Circuit diagram | - | See Circuit diagrams on page 351 . |

Removing the cable harness - lower end (axes 1-3)

Use this procedure to remove the cable harness, lower end (axes 1-3).

| | Action | Note |
|---|---|---|
| 1 | Move the robot to the calibration position. | This is done in order to facilitate updating of the revolution counter. |

Continues on next page




| | Action | Note |
|---|--|--|
| 2 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the robot working area. | |
| 3 | Remove the <i>rear cover plate</i> from the robot by removing its attachment screws. | Shown in Location of cable harness - lower end (axes 1-3) on page 146 . |
| 4 | Disconnect the <i>earth cable</i> . | Shown in Location of cable harness - lower end (axes 1-3) on page 146 . |
| 5 | Disconnect the connectors <i>R1.MP</i> and <i>R1.SMB</i> . | See the figure Location of cable harness - lower end (axes 1-3) on page 146 . |
| 6 | Unscrew the screws of the <i>cable guide axis 2</i> inside the lower arm and loosen the cable guide. |  <p>xx0600002698</p> <ul style="list-style-type: none"> • A: Cable guide ax 2 |
| 7 | Unscrew the screws in the <i>metal clamps</i> holding the cable harness in the frame and lower arm. | Shown in Location of cable harness - lower end (axes 1-3) on page 146 . |
| 8 | Unscrew the screws of the motor covers for axes 1, 2 and 3 and lift away the covers. This is done in order to reach the motor connectors. | |

Continues on next page

4 Repair

4.3.1 Replacing cable harness, lower end (axes 1-3)


Continued

| | Action | Note |
|----|---|---|
| 9 | Disconnect all connectors at motors for axes 1, 2 and 3. | See sections: <ul style="list-style-type: none"> • Replacing motor, axis 1 on page 246 • Replacing motors, axes 2 and 3 on page 253 |
| 10 | Open the SMB cover carefully. |  |
| 11 | Disconnect connector R1.G on the <i>battery cable</i> between the battery and the SMB unit.  Note This causes a necessary updating of the revolution counter after refitting! | |
| 12 | Disconnect connectors R2.SMB, R1.SMB1-3, R1.SMB6 from the SMB unit. | |
| 13 | Disconnect X8, X9 and X10 from the brake release unit. | |
| 14 | Remove the SMB cover and put somewhere safe. | |
| 15 | Unscrew the screws for the <i>cable gland SMB</i> from inside the SMB recess and lift the cable gland out. Perform this removal with care, in order not to damage any of the components inside the SMB recess. |  |

Continues on next page



4.3.1 Replacing cable harness, lower end (axes 1-3)

Continued

| | Action | Note |
|----|--|---|
| 16 | Gently pull the cable harness out from the base through the <i>cable guide</i> , axis 1 and frame. |  <p>xx0600002699</p> |
| 17 | Continue removing the cable harness in the upper arm. | See section Replacing the cable harness, upper end (incl. axis 6) on page 154 . |

Refitting, cable harness - lower end (axes 1-3)

Use this procedure to refit the cable harness, lower end (axes 1-3).



| | Action | Note |
|---|---|---|
| 1 | <p>Push the cable harness and connectors down through the cable guide axis 1 in the center of the frame.</p> <p> CAUTION</p> <p>Make sure the cables are not twisted with each other or with customer harness (if any)!</p> |  <p>xx1000001331</p> |

Continues on next page




4 Repair

4.3.1 Replacing cable harness, lower end (axes 1-3)

Continued

| | Action | Note |
|---|---|--|
| 2 | <p>Pull out the cables and connectors of the SMB unit through the frame and refit the <i>cable gland</i> with its <i>attachment screws</i> from inside the SMB recess.</p> <p>Perform this refitting with care, in order not to damage any of the components inside the SMB recess.</p> |  <p>xx1000001330</p> |
| 3 | <p>Reconnect connectors <i>R1.MP</i> and <i>R1.SMB</i> at the robot base.</p> | <p>Tightening torque for R1.SMB: 10 Nm.</p> <p>Attachment points are shown in the figure Location of cable harness - lower end (axes 1-3) on page 146.</p> |
| 4 | <p>Reconnect the <i>earth cable</i>.</p> |  <p>xx1000001314</p> |
| 5 | <p>Refit the <i>rear cover plate</i> to the robot base with its attachment screws.</p> | <p>Shown in Location of cable harness - lower end (axes 1-3) on page 146.</p> |
| 6 | <p>Reconnect all connectors at <i>motors axes 1, 2 and 3</i> and refit the motor covers.</p> | <p>See sections:</p> <ul style="list-style-type: none"> • Replacing motor, axis 1 on page 246 • Replacing motors, axes 2 and 3 on page 253 |
| 7 | <p>Reconnect connectors R2.SMB, R1.SMB1-3, R1.SMB6 of the SMB unit.</p> <p>Reconnect X8, X9 and X10 to the brake release unit.</p> <p>Reconnect R1.G.</p> | |

Continues on next page

| | Action | Note |
|----|---|--|
| 8 | Secure the <i>SMB</i> cover with its attachment screws. If cabling is used for 7th axis (option), refit the connector R2.FB7 to the SMB cover and tighten with 6 Nm. | |
| 9 |  WARNING Before continuing any service work, please observe the safety information in section The brake release buttons may be jammed after service work on page 145 . | |
| 10 | Push the cable harness up through the lower arm. | |
| 11 | Refit the <i>metal clamps</i> holding the cable harness in the frame and lower arm with its attachment screws. | Shown in Location of cable harness - lower end (axes 1-3) on page 146 . |
| 12 | Refit the <i>cable guide</i> , axis 2. |  xx1100000157 |
| 13 | Continue refitting the cable harness in the upper arm. | See section Replacing the cable harness, upper end (incl. axis 6) on page 154 . |
| 14 | Update the revolution counter! | See section Updating revolution counters on IRC5 robots on page 306 . |
| 15 |  DANGER Make sure all safety requirements are met when performing the first test run. | |

4 Repair

4.3.2 Replacing the cable harness, upper end (incl. axis 6)


4.3.2 Replacing the cable harness, upper end (incl. axis 6)

Overview

Replacement of the cable harness is detailed in two steps - lower end (axes 1-3) and upper end. The procedure below details replacement of the cable harness in the upper end (incl. axis 6). The procedure for replacing the lower end (axis 1-3) is detailed in section [Replacing cable harness, lower end \(axes 1-3\) on page 146](#).

Location of cable harness, upper end

The upper end of the cable harness is located as shown in the figure.



xx0600002608

| | |
|---|--------------------------------|
| A | Cable harness, lower end |
| B | Cable harness, upper end |
| C | Connector R1.MP |
| D | Connector R1.SMB |
| E | Attachment point for earth lug |
| F | Cover plate |
| G | Rear cover plate |
| H | Cable gland, SMB |
| I | Cable guide, axis 2 |
| J | Metal clamp, frame |
| K | Metal clamp, lower arm |
| L | Metal clamp, upper arm |


Continues on next page

4.3.2 Replacing the cable harness, upper end (incl. axis 6)

Continued

| | |
|---|------------------------|
| M | Metal clamp, tilthouse |
|---|------------------------|

The motor axis 6 is located as shown in the figure below.



xx0600002600

| | |
|---|-------------------------------|
| A | Motor, axis 6 |
| B | Attachment screws and washers |
| C | Cable gland cover |
| D | Motor cover |

Required equipment

| Equipment, etc | Art.no. | Note |
|--|---|--|
| Cable harness, 1-6 | For spare part no. see: • Spare part lists on page 349 | |
| Gasket | - | Motor, axis 6 |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |
| Circuit diagram | See chapter Circuit diagrams on page 351 . | |

Removing cable harness, upper end (incl. axis 6)

Use this procedure to remove the cable harness, upper arm (incl. axis 6).





| | Action | Note |
|---|---|---|
| 1 | Move the robot to the calibration position. | This is done in order to facilitate updating of the revolution counter. |

Continues on next page

4 Repair

4.3.2 Replacing the cable harness, upper end (incl. axis 6)



Continued

| | Action | Note |
|---|--|--|
| 2 | <p> DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> | |
| 3 | <p>If the complete cable harness is being replaced, start removal by removing the <i>cable harness, lower end</i>.</p> | <p>Detailed in section Replacing cable harness, lower end (axes 1-3) on page 146.</p> |
| 4 | <p>Remove the axis 6 motor cover by removing its attachment screws, in order to reach the connectors.</p> |  <p>xx1000001106</p> |
| | <p>Remove the <i>cable gland cover</i> at the cable exit by unscrewing its <i>attachment screw</i> on the inside.</p> <p> Note</p> <p>Make sure the gasket is not damaged!</p> |  <p>xx0600002694</p> <ul style="list-style-type: none"> • A: Screw securing the cable gland |
| 5 | <p>Disconnect connectors at axis 6 motor.</p> | |

Continues on next page

4.3.2 Replacing the cable harness, upper end (incl. axis 6)

Continued

| | Action | Note |
|---|--|--|
| 6 | Remove the metal clamp that holds the cable at the tilt house, by removing its nuts. |  <p>xx1000001336</p> |
| 7 | Carefully pull the cable harness out of motor axis 6. | |
| 8 | Remove the nuts (on the outside of the upper arm) that secure the cable harness metal clamps inside the upper arm (2 + 2 pcs). |  <p>xx1000001338</p> |
| 9 | Carefully pull out the cable harness from the upper and lower arm. | |

Continues on next page



4 Repair

4.3.2 Replacing the cable harness, upper end (incl. axis 6)






Continued

Refitting cable harness, upper end

Use this procedure to refit the cable harness, upper end.

| | Action | Note |
|---|---|--|
| 1 | Start by fitting the cable harness, lower end if it has been removed. | Detailed in section Replacing cable harness, lower end (axes 1-3) on page 146 |
| 2 | Push the cable harness through the upper arm tube. | |
| 3 | Refit the cable harness inside the upper arm by refitting the cable clamps with the nuts (2 + 2 pcs) from the outside of the upper arm. |  <p>xx1000001338</p> |
| 4 | Refit the <i>metal clamp</i> at the tilthouse with its nuts. |  <p>xx1000001336</p> |

Continues on next page

| | Action | Note |
|----|--|---|
| 5 | <p>Push the axis 6 motor cables carefully through the cable gland.</p> <p> Note</p> <p>Do not twist the cables!</p> | |
| 6 | Reconnect all connectors in motor axis 6. | |
| 7 | Check the <i>gasket</i> . If damaged, replace it. | |
| 8 | Refit the cable gland with its <i>attachment screw</i> . |  <p>xx0600002694</p> <ul style="list-style-type: none"> • A: Screw holding the cable gland <p>Make sure the gasket is not damaged! Replace if damaged.</p> |
| 9 | <p>Refit the <i>cover</i>, motor axis 6 with its <i>attachment screws</i> and <i>washers</i>. Make sure the cabling is placed correctly when refitting the cover and does not get jammed.</p> <p> Note</p> <p>Make sure the cover is tightly sealed!</p> |  <p>xx1000001106</p> |
| 10 | Update the revolution counter! | Detailed in section <i>Updating revolution counters on IRC5 robots on page 306</i> . |
| 11 | <p> DANGER</p> <p>Make sure all safety requirements are met when performing the first test run.</p> | |

4 Repair

4.3.3 Replacing the base, including axis 1 gearbox

4.3.3 Replacing the base, including axis 1 gearbox


Introduction

The term *complete arm system* used in this procedure is defined as the complete robot excluding:

- base
- gearbox axis 1

Location of the base

The location of the base, including gearbox axis 1, is shown in the figure. It also shows the complete arm system as defined above.



xx0600002612

| | |
|---|--------------------------------------|
| A | Parallel rod |
| B | Linkage |
| C | Complete upper arm (incl. tilthouse) |
| D | Balancing device |
| E | Frame |
| F | Gearbox, axis 1 |
| G | Base |
| H | Base attachment screws |

Continues on next page

Required equipment

| Equipment, etc. | Art. no. | Note |
|--|----------------|--|
| Guide pins M12 x 130 | 3HAC022637-001 | Used to guide the complete arm system when refitting. Always use the guide pins in pairs! Guide pins that are longer than 140 mm will not be possible to remove because the lack of space. |
| Lifting accessory | 3HAC15607-1 | Includes: <ul style="list-style-type: none"> user instructions, 3HAC15971-2 |
| Roundsling | | 1 pc: 1,5 m Lifting capacity 1,000 kg |
| Hoisting block | - | Used to adjust the length of the lifting chain. |
| Power supply | - | 24 VDC, max. 1.5 A For releasing the brakes. |
| Crank | - | Used to turn the gear when mating it to the frame. |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |
| Circuit diagram | - | See chapter Circuit diagrams on page 351 . |

Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.

| | Action | Note |
|---|--|------|
| 1 | Decide which calibration routine to use for calibrating the robot. <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |

Continues on next page

4 Repair



4.3.3 Replacing the base, including axis 1 gearbox

Continued

| Action | Note |
|--|--|
| <p>If the robot is to be calibrated with reference calibration:</p> <p>Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot.</p> <p>If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible.</p> | <p>Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values.</p> <p>Creating new values requires possibility to move the robot.</p> <p>Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i>.</p> |
| <p>If the robot is to be calibrated with fine calibration:</p> <p>Remove all external cable packages (DressPack) and tools from the robot.</p> | |



Removing the complete arm system

Use this procedure to remove the complete arm system.

| Action | Note |
|--------|--|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. |
| 2 | <p>Move the robot to the transport position.</p>  <p>xx0500002275</p> |
| 3 | <p> DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> |
| 4 | Run an overhead crane to a position above the robot. |

Continues on next page

4.3.3 Replacing the base, including axis 1 gearbox
Continued





| | Action | Note |
|----|--|--|
| 5 | Remove the <i>block for calibration</i> and the <i>axis 1 calibration plate</i> . |  <p>xx0600002734</p> <p>A Block for calibration B Calibration plate axis 1</p> |
| 6 | Drain the axis 1 gearbox. | See Changing oil, axis-1 gearbox on page 119 . |
| 7 | Loosen the cable connectors from the base and pull up the cabling from the base, through the hole in the center of the frame. | See Replacing cable harness, lower end (axes 1-3) on page 146 . |
| 8 | Remove the axis 1 motor. | See Replacing motor, axis 1 on page 246 . |
| 9 |  CAUTION The robot arm system weighs 245 kg. All lifting accessories used must be sized accordingly! | |
| 10 | Fit the lifting accessories and adjust it as described in the enclosed user instructions. | Make sure the lift is done completely level. This is detailed in section Lifting robot with lifting accessory (recommended lifting method) on page 58 . |

Continues on next page

4 Repair


4.3.3 Replacing the base, including axis 1 gearbox

Continued

| Action | Note |
|---|--|
| <p>11 Unfasten the arm system from the base by unscrewing the attachment screws.</p> |  <p>xx0600003070</p> <p>A Serrated lock washer B Axis 1 gearbox C Attachment screws M12x80</p> |
| <p>12 Fit two <i>guide pins</i> in the holes. This will facilitate the removal of the complete arm system and prevent damage on the gearbox.</p> | <p>Article number is specified in Required equipment on page 161.</p> |
| <p>13 Lift the <i>complete arm system</i> carefully and secure it in a safe area.</p> <p> Note</p> <p>Continue lifting even if the arm system turns out to be unbalanced despite earlier adjustments! The risk of damaging the interface is bigger if the load is lowered unbalanced!</p> <p> CAUTION</p> <p>Always move the robot at very low speed, making sure it does not tip!</p> | <p> Note</p> <p>Make sure all hooks and attachments stay in the correct position while lifting the arm system and that the lifting accessory does not wear against sharp edges.</p> |
| <p>14 If needed, continue to remove the axis 1 gearbox from the base.</p> | <p>See Replacing the axis 1 gearbox on page 271.</p> |







Refitting the complete arm system

Use this procedure to refit the complete arm system.

| Action | Note |
|--|--|
| <p>1  DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> | |
| <p>2 Refit the axis 1 gearbox, if it has been removed.</p> | <p>See Replacing the axis 1 gearbox on page 271.</p> |

Continues on next page

4.3.3 Replacing the base, including axis 1 gearbox
Continued





| | Action | Note |
|---|--|--|
| 3 | <p> CAUTION</p> <p>The robot arm system weighs 245 kg. All lifting accessories used must be sized accordingly!</p> | |
| 4 | <p>Fit the <i>lifting accessories</i> and adjust it as described in the enclosed user instructions. Also fit a <i>hoisting block</i> to the front chain, used to adjust the balance of the arm system in order to lift it completely level!</p> | <p>Article number is specified in Required equipment on page 161. Make sure the lift is done completely level! How to adjust the lift is described in the enclosed instruction to the lifting accessory! Follow the instructions before lifting! This is detailed in section Lifting robot with lifting accessory (recommended lifting method) on page 58.</p> |
| 5 | <p>Lift the complete arm system and move it at very low speed to the mounting site, making sure it does not tip!</p> <p> Note</p> <p>The refitting must be made completely level! Make sure the roundslings are adjusted prior to refitting the arm system.</p> | <p> Note</p> <p>Make sure all hooks and attachments stay in the correct position while lifting the arm system and that the lifting accessory does not wear against sharp edges.</p> |
| 6 | <p>Fit two <i>guide pins</i> in opposite holes in the frame.</p> <p> Tip</p> <p>In order to make refitting easier it is recommended to use two guide pins of different lengths. Notice that longer guide pins than 140 mm will not be possible to remove after refitting because of lack of space.</p> |  <p>xx0600002632</p> <p>The figure above shows the frame, view from below.</p> <ul style="list-style-type: none"> A: Attachment holes for the guide pins, M12 <p>Dimension is specified in Required equipment on page 161.</p> <p> Note</p> <p>Always use guide pins in pairs.</p> |

Continues on next page

4 Repair



4.3.3 Replacing the base, including axis 1 gearbox

Continued

| | Action | Note |
|----|--|--|
| 7 | Look through the empty mounting hole of the axis 1 motor to assist in aligning the assembly during refitting of the complete arm system. | |
| 8 | <p>Lower the complete arm system with guidance from the guide pins previously fitted to the axis 1 gearbox.</p> <p> Note</p> <p>The refitting must be made completely level! Make sure the roundslings are adjusted prior to refitting the arm system.</p> | <p> CAUTION</p> <p>This is a complex task to be performed with utmost care in order to avoid injury or damage!</p> <p>Use a crank to turn the gearbox in order to find the right position for the holes.</p> |
| 9 | <p>Place the <i>serrated lock washers</i> on the attachment screws.</p> <p> Note</p> <p>Check that the <i>serrated lock washers</i> are turned the correct way. See figure!</p> | <p>Reused screws can be used providing they are lubricated as described in Screw joints on page 340.</p>  <p>xx0600003070</p> <p>Parts:</p> <ul style="list-style-type: none"> A Serrated lock washer (24 pcs) B Axis 1 gearbox C Attachment screws M12x110 quality 12.9 gleitmo (24 pcs) |
| 10 | Fit 22 of the 24 attachment screws before the arm system is completely lowered. This is done in order to be able to attach all screws into the threads correctly. | |
| 11 | Replace the guide pins with the remaining attachment screws and secure the complete arm system to the base with its attachment screws and washers. | |
| 12 | Lower the arm system completely. | |
| 13 | Secure the complete arm system with its attachment screws. | Tightening torque: <ul style="list-style-type: none"> • 115 Nm. |
| 14 | Refit the cable harness in the base and the frame. | See Replacing cable harness, lower end (axes 1-3) on page 146 . |
| 15 | Refit the axis 1 motor. | See Replacing motor, axis 1 on page 246 . |

Continues on next page

4.3.3 Replacing the base, including axis 1 gearbox
Continued

| | Action | Note |
|----|---|--|
| 16 | Refit the <i>block for calibration</i> and the <i>axis 1 calibration plate</i> . |  <p data-bbox="991 904 1094 920">xx0600002734</p> <p data-bbox="1023 943 1315 1003">A Block for calibration B Calibration plate axis 1</p> |
| 17 | Perform a leak-down test of the axis 1 gearbox. | See Performing a leak-down test on page 138 . |
| 18 | Refill the axis 1 gearbox with lubricating oil. | See Changing oil, axis-1 gearbox on page 119 . |
| 19 | Recalibrate the robot. | Axis Calibration is described in Calibrating with Axis Calibration method on page 312 . General calibration information is included in section Calibration on page 301 . |
| 20 |  <p data-bbox="580 1361 687 1391">DANGER</p> <p data-bbox="491 1420 963 1473">Make sure all safety requirements are met when performing the first test run.</p> | |

4 Repair


4.4.1 Replacing the turning disk

4.4 Upper and lower arm

4.4.1 Replacing the turning disk

Location of turning disk

The turning disk is located in the front of the wrist housing as shown in the figure below.



xx0600002627

| | |
|---|--|
| A | Turning disk |
| B | Attachment screws (6 pcs) turning disk |
| C | Tilthouse unit |
| D | Gearbox, axis 6 |
| E | Attachment screws, axis 6 |

Required equipment


| Equipment, etc. | Art. no. | Note |
|-------------------------|---|--|
| Turning disk | For spare part no. see: Spare part lists on page 349. | O-rings are not included! |
| O-ring Wrist, type 1 | 3HAB3772-65 (1pc) 21520431-20 (6 pcs) | For robot v. IRB 660 180/3.15, 250/3.15 Must be replaced when replacing the turning disk! |
| Grease | 3HAC042536-001 | Shell Gadus S2 Used to lubricate the o-rings. |
| Flange sealant | 3HAC034903-001 | Loctite 574 |

Continues on next page

| Equipment, etc. | Art. no. | Note |
|--|----------|--|
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Removing, turning disk

Use this procedure to remove the turning disk.

| | Action | Note |
|---|--|--|
| 1 | Run the robot to a position where the tilthouse is best positioned for the turning disk to be replaced. | |
| 2 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the robot working area. | |
| 3 | Remove any equipment fitted to the turning disk. | |
| 4 | Drain the axis 6 gearbox. | See section <ul style="list-style-type: none"> • Changing oil, gearbox axis 6 on page 126 |
| 5 | Remove the <i>attachment screws</i> that secure the turning disk. | Shown in the figure Location of turning disk on page 168 . |
| 6 | Remove the <i>turning disk</i> . | |
| 7 | <i>Foundry Plus:</i> Remove old flange sealant residues and other contamination from the contact surfaces. | |

Continues on next page



4 Repair

4.4.1 Replacing the turning disk


Continued

Refitting, turning disk

Use this procedure to refit the turning disk.

| | Action | Note |
|---|--|--|
| 1 | Lubricate the <i>o-ring</i> of the turning disk with <i>grease</i> and fit it to the turning disk. Also fit the six <i>o-rings</i> , when refitting the attachment screws. | <p>Art. no. is specified in Required equipment on page 168.</p>  <p>xx0200000218</p> <ul style="list-style-type: none"> A: Sealing surface, o-ring |
| 2 | Foundry Plus: Apply Loctite 574 flange sealant on the contact surface. |  <p>xx1400000995</p> |
| 3 | Secure the turning disk with its <i>attachment screws</i> . | <p>6 pcs M14 x 25, 12.9 quality. Tightening torque: 175 Nm Reused screws may be used, providing they are lubricated as detailed in section Screw joints on page 340 before fitting.</p> |
| 4 | Perform a <i>leak-down test</i> of the gearbox axis 6. | Detailed in the section Performing a leak-down test on page 138 . |
| 5 | Refill the axis 6 gearbox with oil. | <p>See section</p> <ul style="list-style-type: none"> Changing oil, gearbox axis 6 on page 126 |
| 6 | Refit any equipment removed during disassembly to the turning disk. | |

Continues on next page

| | Action | Note |
|---|--|------|
| 7 |  DANGER Make sure all safety requirements are met when performing the first test run. | |


4 Repair

4.4.2 Replacement of tilthouse unit

4.4.2 Replacement of tilthouse unit

Location of tilt house

The tilthouse unit is located as shown in the figure below.




xx0600002616

| | |
|---|-------------------|
| A | Tilthouse unit |
| B | Upper arm |
| C | Upper rod |
| D | Screw M6x10 |
| E | Washer 6.4x12x1.6 |
| F | Ballplug |
| G | Protection cap |

Continues on next page

Location of axes 2 and 3 sides of the robot

The figure below shows the location of the axes 2 and 3 sides of the robot. See markings on the lower arm (axis 2) and the parallel arm (axis 3).




xx0600002743

| | |
|---|--------------------------|
| A | Axis 2 side of the robot |
| B | Axis 3 side of the robot |

Cut away view of the assembly of the tilthouse unit

The figure below shows a cut away view of how the tilthouse unit is fitted to the upper arm. The letters in the figure are being referred to in the step by step procedures below.



xx0600002742

Continues on next page

4 Repair

4.4.2 Replacement of tilthouse unit

Continued

| | |
|---|---|
| A | Axis 2 side |
| B | Axis 3 side |
| C | VK cover, VK 19 x 6, 2 pcs |
| D | VK cover, VK 68 x 8, 2 pcs |
| E | Screw M6 x 10 Steel 8.8-A2F + Washers, 4 + 4 pcs (for filling bearing grease) |
| F | Retaining ring fore bores, 2 pcs |
| G | Rust protection, Dinitrol 490 |
| H | Upper arm |
| I | Tilthouse |
| J | Bearing, 2 pcs (on the outside of the tilthouse) |
| K | Bearing, 2 pcs (on the inside of the tilthouse) |
| L | Ring |
| M | Shaft, 2 pcs |
| N | Radial seal with dustlip, 2 pcs |
| O | Lock nut, KM7 2 pcs |
| P | Screw M6x16 + washer (for locking the shafts), 2 + 2 pcs |


Required equipment

| Equipment, etc. | Art.no. | Note |
|--|----------------|---|
| Press tool, premounting bearing | 3HAC023075-001 | |
| Press tool, mounting axis 6 | 3HAC077982-001 | Hydraulic pressing accessory. User instructions are enclosed with the tool. |
| KM7 socket | 6369901-438 | |
| Shims | | Width = 3 mm |
| Grease | 3HAC042536-001 | Shell Gadus S2 |
| Rust protection | | Dinitrol 490 |
| Locking liquid | | Loctite 243 |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |
| Circuit diagram | - | See chapter Circuit diagrams on page 351 . |

Continues on next page

Press tool premounting bearing

The press tool for premounting the bearing race, bearing complete, radial seal with dustlip and ring in the tilthouse, is assembled with the parts shown in the figure below.



xx0600002750

▣

Note! The parts cannot be ordered separately, but are included when ordering the complete tool. The article numbers are given only for identification.

| | |
|---|----------------------------------|
| A | Hydraulic cylinder, 3HAC 11731-1 |
| B | Mounting washer, 3HAC 023075-004 |
| C | Bushing, 3HAC 023075-006 |
| D | Screw M6x25, 2 pcs (MC6S) |
| E | Threaded washer, 3HAC 5507-1 |
| F | Press washer, 3HAC 023075-002 |
| G | Threaded bar, M16 L = 300 mm |

Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.

| | Action | Note |
|---|---|------|
| 1 | <p>Decide which calibration routine to use for calibrating the robot.</p> <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |

Continues on next page

4 Repair

4.4.2 Replacement of tilthouse unit




Continued

| Action | Note |
|---|--|
| <p>If the robot is to be calibrated with reference calibration: Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot.</p> <p>If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible.</p> | <p>Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values.</p> <p>Creating new values requires possibility to move the robot.</p> <p>Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i>.</p> |
| <p>If the robot is to be calibrated with fine calibration: Remove all external cable packages (DressPack) and tools from the robot.</p> | |





Removal, tilthouse

This procedure describes how to remove the tilthouse unit.

The item letters within parentheses refer to the figure [Cut away view of the assembly of the tilthouse unit on page 173](#).

| | Action | Note |
|---|--|---|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. | |
| 2 | Move the robot to a position where the tilthouse rests on a workbench, pallets or similar. | |
| 3 | <p> DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> | |
| 4 | <p>Secure the <i>tilthouse</i> with a roundsling in an overhead crane.</p> <p>This is done in order to prevent the tilthouse from falling down when the upper link is removed.</p> <p> DANGER</p> <p>If not secured the tilthouse will fall down when the upper link is removed. See figure!</p> |  <p>xx1000001067</p> |

Continues on next page




| | Action | Note |
|---|---|---|
| 5 | <p>Disassemble the <i>upper link</i> from the tilt house unit.</p> <p> Note</p> <p>It is not needed to remove the upper link from the link.</p> | <p>Detailed in section Replacement of linkage - upper rod on page 196</p>  <p>xx1000001065</p> <p>Part: Upper link</p> |
| 6 | <p>Disconnect <i>motor cables</i> from motor axis 6. Place the motor cables in a way that it will not be damaged.</p> | <p>Detailed in section Replacing the cable harness, upper end (incl. axis 6) on page 154</p> |
| 7 | <p>Remove one of the <i>M6 screws</i> and <i>washer</i> at the cover for filling grease.</p> |  <p>xx0600002735</p> <ul style="list-style-type: none"> • A: Screw M6, grease filling hole |
| 8 | <p>Be careful not to damage the ball plug!</p> <p> Note</p> <p>Do not remove the ball plug!</p> | <p>Shown in the figure Location of tilt house on page 172.</p> |
| 9 | <p>Remove one shaft at a time by following the steps below.</p> | |

Continues on next page




4 Repair

4.4.2 Replacement of tilthouse unit

Continued

| | Action | Note |
|----|--|---|
| 10 | <p>Use compressed air in the M6 hole for filling grease, in order to remove the VK cover.</p> <p> CAUTION</p> <p>Only a very low air pressure is needed!</p> | <p>Put a hand with some paper over the VK cover in order to catch it.</p>  <p>xx1000001072</p> <p>Parts:</p> <ul style="list-style-type: none">M6 screw in hole for filling greaseVK cover |
| 11 | Remove the screw that locks the shaft. |  <p>xx0600002703</p> <ul style="list-style-type: none">A: Screw M6x16B: ShaftC: Upper arm |

Continues on next page



| | Action | Note |
|----|--|--|
| 12 | Remove the <i>small VK cover</i> from the inside with the help of a punch. |  <p>xx1000001073</p> |
| 13 | Remove the <i>lock nut</i> . |  <p>xx1000001074</p> |
| 14 | <p>Apply the press tool, mounting axis 6 in the following way:</p> <ul style="list-style-type: none"> • Push the threaded bar M16 through the holes in the shafts. • Apply the washer and the nut on the right side of the right shaft. • Put the distance ring on the bar on the left side of the shaft • Apply the hydraulic pump on the bar • Secure the hydraulic pump with a nut. <p>Remove the <i>shaft</i> with the <i>press tool</i>, mounting axis 6.</p> <p> Note</p> <p>A longer threaded bar M16 is needed when removing the shaft than the one specified when fitting.</p> | <p>Art.no. is specified in Required equipment on page 174.</p> |

Continues on next page


4 Repair

4.4.2 Replacement of tilthouse unit

Continued

| | Action | Note |
|----|---|--|
| 15 | Press out the <i>shaft</i> . |  <p data-bbox="997 801 1101 824">xx1000001075</p> <p data-bbox="1029 840 1125 869">A Shaft</p> |
| 16 | Remove the <i>press tool, mounting axis 6 and the shaft</i> . |  <p data-bbox="997 1368 1101 1391">xx1000001076</p> |
| 17 | Check that the tilthouse is secured in a overhead crane or similar before proceeding with the next shaft. | |
| 18 | Remove the other shaft in the same way. | Follow steps above. |

Continues on next page

| | Action | Note |
|----|--|---|
| 19 | Lift the tilthouse to a safe place. | Check that bearings are kept clean, if being refitted.  xx1000001077 |
| 20 | Force away the sealing ring (N) with a screwdriver or similar. | The sealing must be replaced with a new one when refitting. |
| 21 | If needed change the bearings. | |

Premounting tilthouse bearings and other parts, axis 2 side

The procedure below details how to fit the bearings and other parts in the tilthouse on the axis 2 side, before fitting the tilthouse to the upper arm.

This work is best done on a workbench or similar.

| | Action | Note |
|---|--|---|
| 1 | Lift the tilthouse to a workbench (or similar) with a roundsling in an overhead crane. | |
| 2 | Apply some <i>grease</i> in the hole for the <i>bearings</i> (J) and (K). | Art.no. is specified in Required equipment on page 174 . Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . |
| 3 | Fit two <i>retaining rings for bores</i> (F). | Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . |
| 4 | Fit the outer race of the <i>bearing</i> (J) facing the outside of the tilthouse. Use a plastic hammer or similar. | Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . |
| 5 | Thread the <i>radial seal with dustlip</i> (N) and the <i>inner bearing complete</i> (K) on the <i>presswasher</i> (F) of the <i>pressing tool, premounting bearings</i> . | Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . Shown in the figure Press tool premounting bearing on page 175 . Art.no. is specified in Required equipment on page 174 . |

Continues on next page

4 Repair

4.4.2 Replacement of tilthouse unit

Continued

| | Action | Note |
|---|---|--|
| 6 | Thread the race of the outer <i>bearing</i> (J) on the <i>bushing</i> (C) of the <i>pressing tool</i> , <i>premounting bearings</i> . | Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . Shown in the figure Press tool pre-mounting bearing on page 175 . Art.no. is specified in Required equipment on page 174 . |
| 7 | Fit the pressing tool and press the parts together. | |

Premounting tilthouse bearings and other parts, axis 3 side

The procedure below details how to fit the bearings and other parts in the tilthouse on the axis 3 side, before fitting the tilthouse to the upper arm.

This work is best done on a workbench or similar.

| | Action | Note |
|---|--|--|
| 1 | Apply some <i>grease</i> in the hole for the <i>bearings</i> (J) and (K). | Art.no. is specified in Required equipment on page 174 . Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . |
| 2 | Fit the outer race of the <i>bearing</i> (J) facing the outside of the tilthouse. Use a plastic hammer or similar. | Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . |
| 3 | Thread the <i>radial seal with dustlip</i> (N), the <i>inner bearing complete</i> (K) and the <i>ring</i> (L) on the <i>press washer</i> (F) of the <i>pressing tool</i> , <i>premounting bearings</i> . | Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . Shown in the figure Press tool pre-mounting bearing on page 175 . Art.no. specified in Required equipment on page 174 . |
| 4 | Thread the race of the outer <i>bearing</i> (J) on the <i>bushing</i> (C) of the <i>pressing tool</i> , <i>premounting bearings</i> . | Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . Shown in the figure Press tool pre-mounting bearing on page 175 . Art.no. is specified in Required equipment on page 174 . |
| 5 | Fit the pressing tool and press the parts together. | |



Refitting, tilt house

The procedure below details how to refit the tilthouse unit.

Before starting this procedure, prepare the tilthouse as detailed in the procedures [Premounting tilthouse bearings and other parts, axis 2 side on page 181](#) and [Premounting tilthouse bearings and other parts, axis 3 side on page 182](#).

| | Action | Note |
|---|--|------|
| 1 | Secure the tilthouse with a roundsling in an overhead crane and lift it to its mounting position on the upper arm. | |

Continues on next page



| | Action | Note |
|---|---|---|
| 2 | Apply <i>Dinitrol 490</i> (G) on the surfaces where the tilthouse faces the upper arm for rust protection. | Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . |
| 3 | Apply some <i>grease</i> in the holes for the <i>shafts</i> (M) in the upper arm. | Art. no. is specified in Required equipment on page 174 . Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . |
| 4 | <i>Note!</i> Fit the axis 2 side first. | Shown in the figure Location of axes 2 and 3 sides of the robot on page 173 . |
| 5 | Push the axis 2 <i>shaft</i> (M) into its hole, from the inside. | Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173 . |
| 6 | <p>Thread the race of the <i>bearing</i> (J) facing the outside of the tilthouse, on the <i>press housing</i> (C) of the <i>press tool</i>, mounting axis 6 and fit it on the <i>shaft</i> (M).</p>  <p>xx0900000813</p> <p>Go to the user instructions enclosed with the press tool.</p> <p> DANGER</p> <p>Handling the tool incorrectly will cause serious injury.</p> <p>Read and follow enclosed user instructions for the tool.</p> <p>The power for brake release is only applied for 180 seconds after activation.</p> | <p>Shown in the figure Cut away view of the assembly of the tilthouse unit on page 173.</p> <p>Art. no. is specified in Required equipment on page 174.</p> |
| 7 | Apply locking liquid on the lock nut, KM7 axis 2 side and fit it with the flat surface facing inside. | Loctite 243. Tightening torque: 90 Nm |
| 8 | Apply locking liquid on the lock nut, KM7 axis 3 side and fit it with the flat surface facing inside. | Loctite 243. Tightening torque: 90 Nm |

Continues on next page


4 Repair

4.4.2 Replacement of tilthouse unit

Continued

| | Action | Note |
|----|---|---|
| 9 | Apply locking liquid in the holes for the screws locking the shafts and fit screws and washers on both sides, locking the shafts. |  <p>xx0600002703</p> <ul style="list-style-type: none"> • A: Screw M6x16 • B: Shaft • C: Upper arm |
| 10 | Fit the inner VK cover (C) on both axes. | Shown in the figure <i>Cut away view of the assembly of the tilthouse unit on page 173.</i> |
| 11 | Fit the outer VK cover (D) on both axes. | Shown in the figure <i>Cut away view of the assembly of the tilthouse unit on page 173.</i> |
| 12 | Fill bearings with grease. | Specified in <i>Required equipment on page 174.</i> |
| 13 | Refit the motor cable, axis 6. | Detailed in section <i>Replacing the cable harness, upper end (incl. axis 6) on page 154</i> |
| 14 | Refit the M6 screw and washer at the cover for filling grease. |  <p>xx0600002735</p> <ul style="list-style-type: none"> • A: Screw M6, grease filling hole |

Continues on next page

| | Action | Note |
|----|--|---|
| 15 | Refit the upper rod. | Detailed in section Replacement of linkage - upper rod on page 196 |
| 16 | Recalibrate the robot. | Axis Calibration is described in Calibrating with Axis Calibration method on page 312 . General calibration information is included in section Calibration on page 301 . |
| 17 |  DANGER Make sure all safety requirements are met when performing the first test run. | |


4 Repair

4.4.3 Replacement of upper arm

4.4.3 Replacement of upper arm

Location of upper arm

The upper arm is located as shown below.




xx0600002609

| | |
|---|------------------|
| A | Upper arm |
| B | Motor axis 6 |
| C | Balancing device |
| D | Lower arm |
| E | Parallel rod |
| F | Linkage |

Continues on next page

View of the assembly of the upper arm components

Shown below is a cut away view of how the upper arm is fitted to the lower arm (seen from above). The letters are being referred to in the following step by step procedures.



xx0600002692

| | |
|---|-----------------------------------|
| A | Shaft, axis 2 |
| B | Shaft, axis 3 |
| C | Set screw, cup point (M10 x 20) |
| D | Lubricant paste (Molycote 1000) |
| E | Sealing ring (V-ring) |
| F | Sealing ring |
| G | Taper roller bearing |
| H | O-ring |
| I | Sealing ring |
| J | Sealing assembly |
| K | Lock nut (KM12) |
| L | O-ring (Di = 54.2 mm, t = 5.7 mm) |

Continues on next page

4 Repair

4.4.3 Replacement of upper arm

Continued

Required equipment

| Equipment, etc. | Art.no. | Note |
|--|--|--|
| Upper arm, axis 4 | For spare part part number, see Spare part lists on page 349 . | |
| Support ring | For spare part part number, see Spare part lists on page 349 . | 2 pcs Install on a new upper arm. |
| Adapter | 3HAC071308-001 | Used on the axis-3 shaft. |
| Grease filling tool | - | |
| Rust preventive | 3HAC034903-001 | Mercasol 3110 Waxcoat |
| Press tool, support ring | 3HAC072616-001 | Used to press in the support rings in the upper arm housing. |
| Pressing tool, upper arm | 3HAC023084-001 | Used on the bearings. |
| KM12 socket | 3HAC023739-001 | |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |
| Circuit diagram | - | See chapter Circuit diagrams on page 351 . |

Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.



| | Action | Note |
|---|--|--|
| 1 | <p>Decide which calibration routine to use for calibrating the robot.</p> <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |
| | <p>If the robot is to be calibrated with reference calibration:</p> <p>Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot.</p> <p>If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible.</p> | <p>Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values.</p> <p>Creating new values requires possibility to move the robot.</p> <p>Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i>.</p> |

Continues on next page

| Action | Note |
|---|------|
| <p>If the robot is to be calibrated with fine calibration:</p> <p>Remove all external cable packages (DressPack) and tools from the robot.</p> | |

Removal, upper arm

The procedure below details how to remove the upper arm.


| | Action | Note |
|----|--|--|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. | |
| 2 | Remove all equipment fitted to the turning disk. | |
| 3 | Move the upper arm to a horizontal position. | |
| 4 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the robot working area. | |
| 5 | Secure the <i>upper arm</i> with roundslings in an overhead crane. | |
| 6 | Remove the <i>cable harness</i> in the upper arm. | Detailed in section |
| 7 |  CAUTION The complete upper arm with weights 170 kg (without any additional equipment fitted). Use a suitable lifting accessory to avoid injury to personnel! | |
| 8 | Raise the lifting equipment to take the weight of the upper arm. | |
| 9 | Remove the <i>balancing device</i> . | Detailed in section Replacing the balancing device on page 231 |
| 10 | Remove the <i>linkage</i> . | Detailed in section Replacement of linkage - upper rod on page 196 Detailed in section Replacing the linkage - lower rod on page 200 Detailed in section Replacement of linkage - link on page 204 |
| 11 | Remove the <i>parallel rod</i> . | Detailed in section Replacing the parallel rod on page 211 |

Continues on next page

4 Repair

4.4.3 Replacement of upper arm




Continued

| | Action | Note |
|----|---|--|
| 12 | Remove the shaft, axis 3 (B): 1 Remove the <i>lock nut</i> (K). 2 Remove the <i>set screw</i> (C) holding the <i>shaft</i> . 3 Put the <i>adapter</i> on the <i>shaft</i> . 4 Remove the shaft. | Shown in the figure View of the assembly of the upper arm components on page 187 . Perform the removal with care. Threads can otherwise be damaged! Art.no. is specified in Required equipment on page 188 |
| 13 | Then remove the <i>shaft, axis 2</i> (A) in the same order: 1 Remove the <i>lock nut</i> (K) 2 Remove the <i>set screw</i> (C) holding the shaft 3 Remove the <i>shaft axis 2</i> . | Shown in the figure View of the assembly of the upper arm components on page 187 .  Note The adapter is not needed on this shaft! |
| 14 | Put the <i>shafts</i> in a clean and safe place. | |
| 15 | Remove the <i>upper arm</i> . | |

Continues on next page

Preparations before refitting, upper arm

The procedure below details the preparations which must be done before refitting the upper arm.





| | Action | Note |
|---|--|--|
| 1 | <p>Prepare the shafts:</p> <ul style="list-style-type: none"> • Put the <i>shafts</i> (A & B) on a workbench and fit the <i>sealing rings</i> (E). • Lubricate the sealing rings with grease. • Apply some grease on the <i>shafts</i>. <p> Note</p> <p>Don't apply grease on the threads and cones of the shafts!</p> <ul style="list-style-type: none"> • Apply <i>lubricant paste</i> (D) on the threads and cones of the <i>shafts</i>. Molycote 1000. • <i>Foundry Plus</i>: Apply rust preventive on the surfaces on the shaft, according to illustration. <p> Note</p> <p>Apply rust preventive to the shafts on both sides of the robot.</p>  <p>xx1400001124</p> | <p>Shown in the figure View of the assembly of the upper arm components on page 187.</p> |
| 2 | <p>Prepare the bearings:</p> <p>Fill the <i>bearings</i> (G) with bearing grease.</p> <p>Use grease filling tool.</p> | <p>Art. no. is specified Required equipment on page 188</p> <p>Shown in the figure View of the assembly of the upper arm components on page 187.</p> |

Continues on next page

4 Repair


4.4.3 Replacement of upper arm

Continued



| | Action | Note |
|---|---|---|
| 3 | <p>Install two support rings to the upper arm:</p> <ol style="list-style-type: none"> 1 Fit a support ring to the press tool and lubricate with grease for easier assembly. 2 Press in the support ring to the upper arm housing by screwing on the press tool assembly. Tighten with 120 Nm. 3 Remove the press tool. The support ring is now fitted to the upper arm housing. 4 Repeat the procedure on the other side. <p> CAUTION</p> <p>If the support ring is mounted askew, there is a risk of play between the shaft and the upper arm. Make sure the support rings are aligned correctly (level) inside the upper arm housing.</p> | <p>Art. no. is specified Required equipment on page 188</p>  <p>xx1900001713</p>  <p>xx1900001714</p>  <p>xx1900001205</p> |

Refitting, upper arm

The procedure below details how to refit the upper arm.

| | Action | Note |
|---|--|------|
| 1 | <p>Secure the <i>upper arm</i> with roundslings in an overhead crane.</p> | |
| 2 | <p> CAUTION</p> <p>The complete upper arm with weighs 170 kg (without any additional equipment fitted). Use a suitable lifting accessory to avoid injury to personnel!</p> | |

Continues on next page


| | Action | Note |
|---|---|--|
| 3 | Lift the <i>upper arm</i> with an overhead crane and move it to its mounting position. Make sure that the <i>upper arm</i> is placed in a horizontal position. | |
| 4 |  Note Refit the axis 3 side first! | |
| 5 | Refit the axis-3 shaft: <ol style="list-style-type: none"> 1 Carefully refit the <i>shaft, axis 3 (B)</i> by hand only. Do not use force since the threads can be damaged if fitting is not done in the correct way. 2 Put the <i>adapter</i> on the <i>shaft</i> and fit it. Secure the shaft. Tightening torque: 800 Nm. 3 Refit the <i>sealing ring (F)</i> on the <i>shaft</i>. 4 Refit the <i>bearing (G)</i> on the <i>shaft</i> with the pressing tool, upper arm. 5 Fit an <i>o-ring (H)</i> on the <i>sealing ring (I)</i> and fit it on the <i>shaft</i>.  Note The o-ring shall be faced against the <i>bearing</i> . <ol style="list-style-type: none"> 6 Fit the <i>o-ring (L)</i> on the <i>sealing assembly (J)</i> and refit the <i>sealing assembly</i> on the <i>shaft</i>. 7 Apply locking liquid (Loctite 243) on the <i>lock nut (K)</i> and refit it using a <i>KM12 socket</i>. Tightening torque 90 Nm. | Shown in the figure View of the assembly of the upper arm components on page 187 . Art. no. is specified Required equipment on page 188 Loctite 243. |

Continues on next page


4 Repair

4.4.3 Replacement of upper arm

Continued

| | Action | Note |
|----|--|---|
| 6 | <p>Refit the axis-2 shaft:</p> <ol style="list-style-type: none"> 1 Carefully refit the <i>shaft, axis 2 (A)</i> by hand only. Do not use force since the threads can be damaged if fitting is not done in the correct way. 2 Secure the shaft. Tightening torque: 800 Nm. 3 Refit the <i>sealing ring (F)</i> on the <i>shaft</i>. 4 Refit the <i>bearing (G)</i> on the <i>shaft</i> with the pressing tool, upper arm. 5 Fit an <i>o-ring (H)</i> on the <i>sealing ring (I)</i> and fit it on the <i>shaft</i>. <p> Note</p> <p>The o-ring shall be faced against the <i>bearing</i>.</p> <ol style="list-style-type: none"> 6 Fit the <i>o-ring (L)</i> on the <i>sealing assembly (J)</i> and refit the <i>sealing assembly</i> on the <i>shaft</i>. 7 Apply locking liquid (Loctite 243) on the <i>lock nut (K)</i> and refit it using a <i>KM12 socket</i> in three steps: <ol style="list-style-type: none"> a Fit the <i>lock nut</i> with a tightening torque of 300 Nm. b Unscrew the <i>lock nut</i>. c Fit the <i>lock nut</i> once again. This time with a tightening torque of 90 Nm. | <p>Shown in the figure View of the assembly of the upper arm components on page 187. Art. no. is specified Required equipment on page 188 Loctite 243.</p> |
| 7 | <p>Apply locking liquid in the holes for the <i>set screws (C)</i> and fit the screws.</p> | <p>Shown in the figure View of the assembly of the upper arm components on page 187 Loctite 243. Tightening torque: 35 Nm.</p> |
| 8 | <p>Wipe residual grease from the <i>shafts</i>.</p> | |
| 9 | <p>Refit the parallel rod.</p> | <p>Detailed in section Replacing the parallel rod on page 211</p> |
| 10 | <p>Refit the <i>cable harness, upper end</i>.</p> | <p>Detailed in section</p> |
| 11 | <p>Refit the <i>linkage</i>.</p> | <p>Detailed in section Replacement of linkage - upper rod on page 196 Detailed in section Replacing the linkage - lower rod on page 200 Detailed in section Replacement of linkage - link on page 204</p> |
| 12 | <p>Refit the <i>balancing device</i>.</p> | <p>Detailed in section Replacing the balancing device on page 231</p> |
| 13 | <p>Recalibrate the robot.</p> | <p>Axis Calibration is described in Calibrating with Axis Calibration method on page 312. General calibration information is included in section Calibration on page 301.</p> |

Continues on next page

| | Action | Note |
|----|--|------|
| 14 |  DANGER Make sure all safety requirements are met when performing the first test run. | |

4 Repair

4.4.4 Replacement of linkage - upper rod


4.4.4 Replacement of linkage - upper rod

Overview

The link system consists of three basic parts - upper rod, lower rod and link. These procedures describes how to remove and refit the upper rod.

Location of upper rod

The upper rod is located as shown in the figure below.



xx0600002592

| | |
|---|-----------|
| A | Lower rod |
| B | Upper rod |
| C | Link |

Required equipment



| Equipment | Spare part no. | Art no. | Note |
|----------------|----------------|----------------|---|
| Upper rod | 3HAC023744-003 | | White RAL 9003 |
| Needle bearing | 3HAC3311-1 | | Replace if damaged. |
| Bearing grease | | 3HAC042536-001 | Shell Gadus S2 Used to lubricate the bearings. |
| Locking liquid | | 3HAB7116-1 | Loctite 243 |

Continues on next page

| Equipment | Spare part no. | Art no. | Note |
|--|----------------|---------|--|
| Standard toolkit | | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | | These procedures include references to the tools required. |

Removal, upper rod

The procedure below details how to remove the upper rod of the linkage.




| | Action | Note |
|---|--|---|
| 1 | Put the robot in a position where it is possible to reach all parts that shall be removed. | Check especially that it is possible to remove the lock nut at the link. |
| 2 | Let the <i>tilthouse</i> rest on a workbench, on some pallets or similar. This is done in order to prevent the tilthouse from falling downwards when the upper rod is removed. |  <p style="text-align: right; font-size: small;">xx1000001132</p> |
| 3 |  <p>DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> | |

Continues on next page

4 Repair


4.4.4 Replacement of linkage - upper rod

Continued



| | Action | Note |
|---|---|---|
| 4 | Remove the <i>lock nuts</i> and <i>support washers</i> holding the upper rod at each end. |  <p>xx1000001080</p> |
| 5 | Remove the upper rod as shown in the figure.  Note The support washers on the inside of the rod can stick to the grease of the bearings when the rod is being removed. Remove them from the link arm! |  <p>xx1000001081</p> |
| 6 | Remove the <i>support washers</i> and the <i>sealing rings</i> . | |
| 7 | Remove residual grease. | |

Refitting, upper rod

The procedure below details how to refit the upper rod of the linkage.

| | Action | Note |
|---|---|--|
| 1 | If needed, replace the <i>bearings</i> in the rod.  Note The bearings are sensitive for pushes. Make sure they are not damaged! | Spare part no. is specified in <i>Required equipment on page 196</i> . |

Continues on next page

| | Action | Note |
|----|---|--|
| 2 | Lubricate the bearings properly with <i>bearing grease</i> . | Specified in Required equipment on page 196 . |
| 3 | Refit the <i>sealing rings</i> on the shaft ends of the link and tilthouse. | |
| 4 | Refit the <i>support washers</i> on the shaft ends. | |
| 5 | Lubricate the shaft ends lightly with grease. | |
| 6 | Refit the upper rod to its place on the shafts. | Check that the rod is pushed in completely. |
| 7 | Refit the <i>support washers</i> on the outside of the upper rod on the shaft ends. |  <p data-bbox="991 1167 1094 1182">xx1000001080</p> <p data-bbox="1059 1205 1318 1263">Lock nut (2 pcs) Support washer (2 pcs)</p> |
| 8 | Apply <i>locking liquid</i> on the threads for the lock nuts. | |
| 9 | Refit the <i>lock nuts</i> on the link and tilthouse, using <i>locking liquid</i> . | Tightening torque: 120 Nm. |
| 10 |  <p data-bbox="580 1458 687 1480">DANGER</p> <p data-bbox="491 1514 959 1570">Make sure all safety requirements are met when performing the first test run.</p> | |

4 Repair

4.4.5 Replacing the linkage - lower rod

4.4.5 Replacing the linkage - lower rod

Overview


The linkage consists of three basic parts - upper rod, lower rod and link. The procedures below details how to remove and refit the lower rod.

How to replace the upper rod and link, see:

- [Replacement of linkage - upper rod on page 196.](#)
- [Replacement of linkage - link on page 204](#)

Location of lower rod

The lower rod is located as shown in the figure below.



xx0600002592

| | |
|---|-----------|
| A | Lower rod |
| B | Upper rod |
| C | Link |

Required equipment



| Equipment | Art no. | Note |
|-----------|--|------|
| Lower rod | For spare part no. see: <ul style="list-style-type: none">• Spare part lists on page 349 | |

Continues on next page

| Equipment | Art no. | Note |
|--|--|--|
| Needle bearing | For spare part no. see: <ul style="list-style-type: none"> Spare part lists on page 349 | Replace if damaged. |
| Bearing grease | 3HAC042536-001 | Shell Gadus S2 |
| Locking liquid | 3HAB7116-1 | Loctite 243 |
| KM10 socket | - | Standard |
| Standard toolkit | | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Removal, lower rod

Use this procedure to remove the lower rod of the linkage.




| Action | Note |
|--|---|
| <p>1</p>  <p>DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> | |
| <p>2</p> <p>If the upper rod is removed, secure the link with a roundsling in a crane. Use the hole in the middle of the link.</p> |  <p>xx1000001252</p> <p>This is done in order to prevent the link from moving if both the upper rod and lower rod are removed.</p> |

Continues on next page

4 Repair



4.4.5 Replacing the linkage - lower rod

Continued




| | Action | Note |
|---|--|------|
| 3 | <p>Remove the <i>lock nuts</i> and <i>support washers</i> that hold the lower rod at each end.</p> <p> Note</p> <p>The support washers can stick to the grease and can easily be forgotten and lost when removing the lock nuts.</p> | |
| 4 | <p> CAUTION</p> <p>The link weighs . All lifting accessories used must be sized accordingly!</p> | |
| 5 | <p>Remove the lower rod by lifting it straight out.</p> <p> Note</p> <p>The support washers on the inside of the rod can stick to the grease of the bearings when the rod is being removed. Remove them from the rod!</p> | |
| 6 | Remove the inner <i>support washers</i> and the <i>sealing/spacer rings</i> . | |
| 7 | Remove residual grease. | |

Refitting, lower rod

Use this procedure to refit the lower rod of the linkage.

| | Action | Note |
|---|---|---|
| 1 | <p>If needed, replace the <i>bearings</i>.</p> <p> Note</p> <p>The bearings are sensitive for pushes. Make sure they are not damaged!</p> | Spare part no. is specified in Required equipment on page 200 . |
| 2 | Lubricate the bearings properly with <i>bearing grease</i> . | Specified in Required equipment on page 200 . |
| 3 | Refit the <i>sealing/spacer rings</i> to the shaft ends on the link and frame. | |
| 4 | Refit the <i>support washers</i> on the sealing/spacer rings. | <p>Replace if damaged.</p> <p> Tip</p> <p>Putting some grease on the support washers will keep them in position.</p> |
| 5 | Check that the bearings in the lower rod are fitted correctly, that is in the center of the hole. (The same distance from bearing to the edge of the lower rod on both sides.) | |

Continues on next page

| | Action | Note |
|----|--|---|
| 6 |  CAUTION The link weighs . All lifting accessories used must be sized accordingly! | |
| 7 | Place the lower rod on the shaft ends of the link and frame.  Note Check that the lower rod is pushed completely in. | |
| 8 | Refit the support washers on the outside of the lower rod, on the link and frame shafts. | |
| 9 | Apply <i>locking liquid</i> on the threads of the lock nuts. | Specified in Required equipment on page 200 . |
| 10 | Refit the lock nuts on the shaft ends. Use a KM10 socket. | Tightening torque: 120 Nm. |
| 11 |  DANGER Make sure all safety requirements are met when performing the first test run. | |

4 Repair

4.4.6 Replacement of linkage - link

4.4.6 Replacement of linkage - link

Overview


The linkage consists of three basic parts - upper rod, lower rod and link. The procedures below details how to remove and refit the link.

How to replace the upper rod and lower rod, see:

- [Replacement of linkage - upper rod on page 196.](#)
- [Replacing the linkage - lower rod on page 200.](#)

Location of link

The link is located as shown in the figure.



xx0600002592

| | |
|---|-----------|
| A | Lower rod |
| B | Upper rod |
| C | Link |

Cut away view of the assembly of the link

The figure shows a cut view of how the link is fitted.

Continues on next page

Required equipment

| Equipment, etc. | Art. no. | Note |
|--|--|--|
| Link | For spare part no. see: <ul style="list-style-type: none"> Spare part lists on page 349 | |
| Auxiliary shaft | 3HAC023081-004 | Used for bearings. |
| Pressing tool, link | 3HAC023081-001 | Used to press the link on the shaft |
| Pressing tool, link | 3HAC077981-001 | Hydraulic pressing accessory used to press the outer rings of the bearings in the link. User instructions are enclosed with the tool. |
| Lubrication tool | 3HAC5222-2 | |
| Sealing compound | 3HAC073510-001 | Trans7 |
| Locking liquid | 3HAB7116-1 | Loctite 243 |
| Grease | 3HAC042536-001 | Shell Gadus S2 |
| Standard toolkit | | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.

| | Action | Note |
|---|---|--|
| 1 | Decide which calibration routine to use for calibrating the robot. <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |
| | If the robot is to be calibrated with reference calibration: Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot. If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible. | Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values. Creating new values requires possibility to move the robot. Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i> . |
| | If the robot is to be calibrated with fine calibration: Remove all external cable packages (DressPack) and tools from the robot. | |

Continues on next page



4 Repair

4.4.6 Replacement of linkage - link




Continued

Removal, link

Use this procedure to remove the link of the linkage.

| | Action | Note |
|---|--|---|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. | |
| 2 |  DANGER Turn off all: <ul style="list-style-type: none">• electric power supply• hydraulic pressure supply• air pressure supply to the robot, before entering the robot working area. | |
| 3 | Secure the link with a roundsling in a crane. Use the hole in the middle of the link. This is done to prevent the link from moving when the upper rod and lower rod are removed. |  xx1000001265 |
| 4 | Remove the upper rod and lower rod. | Detailed in section Replacement of linkage - upper rod on page 196 Detailed in section Replacing the linkage - lower rod on page 200 |
| 5 | Fit the auxiliary shaft on the shaft. | Art.no. is specified in Required equipment on page 205 |

Continues on next page



| | Action | Note |
|---|---|---|
| 6 | <p>Remove <i>screw and washer</i> in the hole for filling grease.</p> |  <p>xx1000001266</p> |
| 7 | <p>Use compressed air to remove the <i>VK cover</i>. Blow with a very low air pressure into the hole for filling grease.</p> <p> CAUTION</p> <p>Only a very low air pressure is needed!</p> |  <p>xx1000001267</p> <p>Put one hand with some paper on top of the <i>VK cover</i> in order to catch it when released.</p> |

Continues on next page

4 Repair

4.4.6 Replacement of linkage - link



Continued

| | Action | Note |
|----|--|--|
| 8 | Remove the <i>lock nut (KM8)</i> . |  <p>xx1000001268</p> |
| 9 |  CAUTION The link weighs approximately . All lifting accessories used must be sized accordingly! | |
| 10 | Put the end of the link facing the upper rod, downwards in order to find room to knock on it from the inside as close to its center as possible. | Normally a not too hard knock is needed to loosen the link. Note! Loosen the roundsling some before knocking! Otherwise the link may be locked by the lifting power. |
| 11 | Use a pair of levers, to bend the link loose. | |
| 12 | Remove the link. | |
| 13 | Remove the <i>support ring with the radial seal</i> . | |
| 14 | Wipe off residual grease. | |
| 15 | If needed, replace the bearings and radial seal. | |

Fitting outer races of the bearing and sealing in the link


| | Action | Note |
|---|------------------------------|------|
| 1 | Put the link on a workbench. | |

Continues on next page

| | Action | Note |
|---|---|---|
| 2 | <p>Fit the new <i>outer races</i> using the mounting tool.</p>  <p>xx0900000813</p> <p>Go to the user instructions enclosed with the press tool.</p> <p> DANGER</p> <p>Handling the tool incorrectly will cause serious injury.</p> <p>Read and follow enclosed user instructions for the tool.</p> <p>The power for brake release is only applied for 180 seconds after activation.</p> | <p>Art.no. is specified in Required equipment on page 205</p> |

Refitting, link

Use this procedure to refit the link of the linkage.




| | Action | Note |
|---|--|---|
| 1 | <p> CAUTION</p> <p>The link weighs . All lifting accessories used must be sized accordingly!</p> | |
| 2 | <p>Secure the link with a roundsling in an overhead crane and lift it to the mounting position.</p> | |
| 3 | <p>Fit the <i>auxiliary shaft</i> on the shaft.</p> | <p>Art.no. is specified in Required equipment on page 205</p> |
| 4 | <p>Apply sealing compound on the support ring.</p> | <p>Sealing compound: 3HAC073510-001 (Trans7).</p> |
| 5 | <p>Fit the support ring, with the radial seal fitted, on the shaft.</p> | <p>Replace the radial seal if needed!</p> |
| 6 | <p>Lubricate and place the bearings and link on the shaft, in the following order:</p> <ul style="list-style-type: none"> • bearing • link • bearing | |
| 7 | <p>Apply the <i>pressing tool</i> and secure the link.</p> | <p>Art.no. is specified in Required equipment on page 205</p> |
| 8 | <p>Apply <i>locking liquid</i> on the lock nut.</p> | <p>Loctite 243</p> |

Continues on next page

4 Repair

4.4.6 Replacement of linkage - link


Continued

| | Action | Note |
|----|---|---|
| 9 | Secure the lock nut in these three steps: <ol style="list-style-type: none"> 1 Tighten with a torque of 300 Nm. 2 Unscrew the lock nut. 3 Tighten the lock nut finally with a tightening torque of 90 Nm.  Note The recommended order of tightening the lock nut is important to follow to avoid future problems with the shaft. | |
| 10 | Refit the VK cover. | |
| 11 | Fill the link with <i>grease</i> . Use lubrication tool. | Art.no. is specified in Required equipment on page 205  xx1000001266 |
| 12 | Refit the screw and washer in the hole for filling grease. | |
| 13 | Refit the upper rod to the link. | Detailed in section Replacement of linkage - upper rod on page 196 |
| 14 | Refit the upper rod to the link. | Detailed in section Replacing the linkage - lower rod on page 200 |
| 15 | Recalibrate the robot! | Axis Calibration is described in Calibrating with Axis Calibration method on page 312 . General calibration information is included in section Calibration on page 301 . |
| 16 |  DANGER Make sure all safety requirements are met when performing the first test run. | |

4.4.7 Replacing the parallel rod

Location of parallel rod

The parallel rod is located as shown in the figure.



xx0600002610

| | |
|---|--------------|
| A | Parallel rod |
|---|--------------|

Required equipment

| Equipment, etc. | Art.no. | Note |
|--------------------------|--|---|
| Parallel rod | For spare part no. see: • Spare part lists on page 349. | |
| Mounting/Demounting tool | 3HAC5021-1 | |
| Locking liquid | 3HAB7116-1 | Loctite 243 |
| Rust preventive | 3HAC034903-001 | Mercasol 3110 Waxcoat |
| Protection plug | 3HAC4836-2 | F21 28x22, 4x12x9 |
| Standard toolkit | - | Content is defined in section Standard tools on page 344. |

Continues on next page

4 Repair




4.4.7 Replacing the parallel rod

Continued



| Equipment, etc. | Art.no. | Note |
|--|---------|--|
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Removing, parallel rod

Use this procedure to remove the parallel rod. The procedure is the same in both ends of the parallel rod.

| | Action | Note |
|---|--|--|
| 1 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the robot working area. | |
| 2 |  CAUTION Secure the upper arm with a roundsling in an overhead crane or similar, in order to avoid accidents. | |
| 3 | <i>Foundry Plus:</i> Remove the protection plugs | |
| 4 | Remove the upper <i>lock screw</i> and <i>washer</i> , that secure the parallel rod in position. |  <p>xx0600002741</p> <ul style="list-style-type: none"> • A: Lock screw M6x16 |

Continues on next page

| | Action | Note |
|----|---|--|
| 5 | Remove the upper <i>shaft</i> (A) and <i>cover washer</i> (B), using the <i>fitting/removing tool</i> . | <p>Art. no. is specified in Required equipment on page 211.</p>  <p>xx0700000065</p> <p>Parts:</p> <ul style="list-style-type: none"> A Shaft B Cover washer C Parallel rod D Sealed spherical bearing E Bearing grease F Thrust washer |
| 6 | Remove the <i>thrust washer</i> (F). | See figure above! |
| 7 | <p> CAUTION</p> <p>The parallel rod weighs . All lifting accessories used must be sized accordingly!</p> | |
| 8 | Move the <i>parallel rod</i> backwards from its upper connection point and let it rest against the frame and base. | See figure above and Location of parallel rod on page 211! |
| 9 | Secure the parallel rod with a roundsling in an overhead crane or similar. | |
| 10 | <p>Remove the lower end of the parallel rod in the same way as the upper end:</p> <ol style="list-style-type: none"> 1 Remove the lower <i>lock screw</i> and <i>washer</i>. 2 Remove the lower <i>shaft</i> (A) and <i>cover washer</i> (B). 3 Remove the <i>thrust washer</i> (F). | See figure above! |
| 11 | Remove the parallel rod from the robot. | |
| 12 | Replace the <i>bearings</i> (D), if necessary. | See figure above! |

Continues on next page





4 Repair

4.4.7 Replacing the parallel rod



Continued

Refitting, parallel rod

Use this procedure to refit the parallel rod. The procedure is the same in both ends of the parallel rod.

| | Action | Note |
|---|--|--|
| 1 | Start by refitting the lower end. | |
| 2 | Verify that the bearings are in correct position in the parallel rod. | |
| 3 | <p> CAUTION</p> <p>The parallel rod weighs . All lifting accessories used must be sized accordingly!</p> | |
| 4 | Lift the parallel rod to the mounting position of the lower end, and let it rest on the the frame and base. | |
| 5 | <p><i>Foundry Plus:</i> Apply rust preventive on the highlighted areas.</p> <p> Note</p> <p>Rust preventive should be applied in both ends of the parallel rod.</p> |  <p>xx1400001126</p> |
| 6 | Put the <i>thrust washer</i> (F) on the axis 2 side of the <i>parallel rod</i> (C). |  <p>xx0700000065</p> <p>Parts:</p> <ul style="list-style-type: none"> A Shaft B Cover washer C Parallel rod D Sealed spherical bearing E Bearing grease F Thrust washer |
| 7 | Put the <i>cover washer</i> (B) on the axis 3 side of the parallel rod. | See figure above! |

Continues on next page

| | Action | Note |
|----|---|---|
| 8 | Refit the <i>shaft</i> (A) by pressing it through the parallel bar with the <i>fitting/removing tool</i> . | Art. no. is specified in <i>Required equipment on page 211</i> . See figure above! |
| 9 | Apply <i>locking liquid</i> in the hole of the lock screw. | Loctite 243 |
| 10 | Refit the <i>lock screw</i> and plain washer. |  <p data-bbox="991 898 1094 913">xx0600002741</p> <ul data-bbox="1023 936 1294 958" style="list-style-type: none"> • A: Lock screw M6x16 |
| 11 | Lift the parallel rod up into position for fitting the upper end. | |
| 12 | Refit the upper end of the parallel rod in the same way as the lower end. | |
| 13 | <i>Foundry Plus:</i> Refit the protection plugs. | |
| 14 |  <p data-bbox="592 1234 699 1256">DANGER</p> <p data-bbox="499 1290 979 1346">Make sure all safety requirements are met when performing the first test run.</p> | |


4 Repair

4.4.8 Replacing the complete lower arm

4.4.8 Replacing the complete lower arm

Location of lower arm

The complete lower arm is located as shown in the figure below.



xx0600002611

| | |
|---|--------------|
| A | Lower arm |
| B | Parallel arm |

Required equipment

| Equipment, etc. | Art.no. | Note |
|----------------------------------|--|---|
| Lower arm | For spare part no. see: • Spare part lists on page 349. | |
| Sealing, axes 2/3 | | Always change the sealing. |
| Guide sleeves | 3HAC14446-1 | Used to keep the axes 2/3 sealing in place during refitting of lower arm. |
| Crank | 3HAC023132-001 | |
| Lock screw | - | M16x90 |
| Lifting tool, lower arm complete | 3HAC8446-1 | |

Continues on next page

| Equipment, etc. | Art.no. | Note |
|--|---------|--|
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |
| Circuit diagram | | See chapter Circuit diagrams on page 351 . |

Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.

| | Action | Note |
|---|--|--|
| 1 | <p>Decide which calibration routine to use for calibrating the robot.</p> <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |
| | <p>If the robot is to be calibrated with reference calibration:</p> <p>Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot.</p> <p>If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible.</p> | <p>Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values.</p> <p>Creating new values requires possibility to move the robot.</p> <p>Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i>.</p> |
| | <p>If the robot is to be calibrated with fine calibration:</p> <p>Remove all external cable packages (DressPack) and tools from the robot.</p> | |

Removal, lower arm

The procedure below details how to remove the lower arm.





| | Action | Note |
|---|--|------|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. | |

Continues on next page

4 Repair






4.4.8 Replacing the complete lower arm

Continued

| | Action | Note |
|----|--|---|
| 2 | <p> DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> | |
| 3 | <p>Secure the lower arm with a <i>lock screw</i> in the hole as shown in the figure to the right.</p> <p> CAUTION</p> <p>Tighten by hand!</p> |  <p>xx1000001101</p> |
| 4 | Remove the linkage. | <p>See Replacement of linkage - upper rod on page 196</p> <p>See Replacing the linkage - lower rod on page 200</p> <p>See Replacement of linkage - link on page 204</p> |
| 5 | Remove the balancing device. | See Replacing the balancing device on page 231 |
| 6 | Remove the parallel rod. | Also see |
| 7 | <p>Remove the cable harness in the upper and lower arm.</p> <p>Secure the cable harness in a way that it is protected from oil spill and damage.</p> | Also see |
| 8 | Remove the complete upper arm. | See Replacement of upper arm on page 186 . |
| 9 | Remove the axes 2 and 3 motors. | See Replacing motors, axes 2 and 3 on page 253 . |
| 10 | Remove the axes 2 and 3 gearboxes. | Also see |
| 11 | <p> CAUTION</p> <p>The robot lower arm weighs 65 kg.</p> <p>All lifting accessories used must be sized accordingly!</p> | |

Continues on next page

4.4.8 Replacing the complete lower arm Continued





| | Action | Note |
|----|---|---|
| 12 | Secure the complete lower arm system (including the parallel arm) with a <i>lifting tool</i> , <i>lower arm complete</i> in an overhead crane or similar. | Specified in <i>Required equipment on page 216</i> . |
| 13 | Remove the <i>lock screw</i> that secures the lower arm system. |  <p>xx1000001101</p> |
| 14 | Remove all M12 and M16 screws that hold the lower arm, on both sides.  Note The axis 3 side has no M16 screws! | |
| 15 |  DANGER Secure the parallel arm to the lower arm before lifting the lower arm system. If not secured, the parallel arm can fall down and cause a serious accident! |  <p>xx1000001359</p> |
| 16 |  CAUTION The parallel arm system weighs 118 kg. All lifting accessories used must be sized accordingly! | |

Continues on next page

4 Repair

4.4.8 Replacing the complete lower arm




Continued

| | Action | Note |
|----|--|---|
| 17 | Move the parallel arm and secure it to the lower arm as shown in the figure, to prevent it from falling down. |  <p>xx1000001357</p> |
| 18 | The space between the gearboxes is cramped. Push together the lower and parallel arm together with help of an iron bar or similar before removing them. |  Note If the parts are not pushed together, it will be difficult to remove the complete lower arm. |
| 19 |  CAUTION The robot lower arm weighs 65 kg. All lifting accessories used must be sized accordingly! | |
| 20 | Remove the complete lower arm (including the parallel arm). |  <p>xx1000001358</p> |
| 21 | How to replace the parallel arm is detailed in section Replacement of parallel arm on page 224 . | |

Continues on next page

Refitting, lower arm

Use this procedure to refit the lower arm system.




| | Action | Note |
|---|--|--|
| 1 | Fit the parallel arm to the lower arm. | See Replacement of parallel arm on page 224 . |
| 2 |  CAUTION The robot lower arm weighs 65 kg. All lifting accessories used must be sized accordingly! | |
| 3 | Fit a <i>lifting tool, lower arm complete</i> , to the lower arm system and lift it up.  DANGER Secure the parallel arm to the lower arm before lifting the lower arm system. If not secured, the parallel arm can fall down and cause a serious accident! | Specified in Required equipment on page 216 . |
| 4 | Fit two <i>guide sleeves</i> for the axes 2/3 sealings to the lower arm and put the sealings on them. See figure. | Art. no. is specified in Required equipment on page 216 .  xx1000001368 |

Continues on next page

4 Repair




4.4.8 Replacing the complete lower arm

Continued

| | Action | Note |
|----|--|---|
| 5 | <p>Put the lower arm in its mounting position. If the hole pattern needs to be adjusted, use a <i>crank</i> to move the gears in order to find the correct hole pattern.</p> | <p>Art. no. is specified in Required equipment on page 216.</p>  <p>xx1000001370</p> |
| 6 | <p> Note Refit the axis 2 side first!</p> | |
| 7 | <p>Verify that the sealings are still in place.</p> | |
| 8 | <p>Refit all screws (both M12 and M16) and washers, that are possible to fit at this stage, on the axis 2 side.</p> | <p>Tightening torque M16: 300 Nm Tightening torque M12: 120 Nm</p> |
| 9 | <p>Push the parallel arm against the axis 3 side with the help of an iron bar or similar.</p> | |
| 10 | <p>Refit all screws and washers, that are possible to fit, on the axis 3 side.</p> <p> Note The axis 3 side has no M16 screws!</p> | <p>Tightening torque M12: 120 Nm</p> |
| 11 | <p>Remove the guide sleeves and secure two screws more.</p> | |
| 12 | <p>Change the position of the lower arm in order to reach the remaining attachment holes, and fit the remaining screws.</p> | |

Continues on next page

4.4.8 Replacing the complete lower arm
Continued

| | Action | Note |
|----|--|---|
| 13 | Secure the lower arm by fitting a <i>lock screw</i> .  CAUTION Tighten by hand! | Dimension is specified in Required equipment on page 216 .  xx1000001101 |
| 14 | Refit the axes 2 and 3 gearboxes. | See Replacing the gearbox, axes 2-3 on page 282 . |
| 15 | Refit the axes 2 and 3 motors. | See Replacing motors, axes 2 and 3 on page 253 . |
| 16 | Refit the complete upper arm. | See Replacement of upper arm on page 186 . |
| 17 | Refit the cable harness. | Also see |
| 18 | Refit the parallel rod. | See Replacing the parallel rod on page 211 |
| 19 | Refit the balancing device. | Also see |
| 20 | Refit the linkage. | See Replacement of linkage - upper rod on page 196 See Replacing the linkage - lower rod on page 200 See Replacement of linkage - link on page 204 |
| 21 | Remove the lock screw. | |
| 22 | Recalibrate the robot. | Axis Calibration is described in Calibrating with Axis Calibration method on page 312 . General calibration information is included in section Calibration on page 301 . |
| 23 |  DANGER Make sure all safety requirements are met when performing the first test run. | |


4 Repair

4.4.9 Replacement of parallel arm

4.4.9 Replacement of parallel arm

Location of parallel arm

The parallel arm is located as shown in the figure below.



xx0600002611

| | |
|---|--------------|
| A | Lower arm |
| B | Parallel arm |

Required equipment

| Equipment, etc. | Art.no. | Note |
|-----------------|---|--|
| Parallel arm | For spare part no. see: <ul style="list-style-type: none">Spare part lists on page 349. | |
| VK cover | | |
| VK cover | | |
| Bearing grease | 3HAC042536-001 | Shell Gadus S2 |
| Rust preventive | 3HAC034903-001 | Mercasol 3110 Waxcoat |
| Press equipment | 3HAC076749-001 | For replacing the bearings on parallel arm. User instructions are enclosed with the tool. |

Continues on next page

| Equipment, etc. | Art.no. | Note |
|--|----------------|--|
| Lifting accessory, parallel arm | 3HAC023098-001 | |
| Lifting accessory, lower arm complete | 3HAC8446-1 | |
| Level | - | |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.

| | Action | Note |
|---|--|--|
| 1 | <p>Decide which calibration routine to use for calibrating the robot.</p> <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |
| | <p>If the robot is to be calibrated with reference calibration:</p> <p>Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot.</p> <p>If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible.</p> | <p>Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values.</p> <p>Creating new values requires possibility to move the robot.</p> <p>Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i>.</p> |
| | <p>If the robot is to be calibrated with fine calibration:</p> <p>Remove all external cable packages (DressPack) and tools from the robot.</p> | |

Removal, parallel arm

Use this procedure to remove the parallel arm.





| | Action | Note |
|---|--|------|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. | |

Continues on next page




4 Repair

4.4.9 Replacement of parallel arm

Continued

| | Action | Note |
|---|--|---|
| 2 | <p> DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> | |
| 3 | Remove the complete lower arm. | See Replacing the complete lower arm on page 216 . |
| 4 | <p>Put the complete lower arm on a workbench as shown in the figure.</p> <p> Tip</p> <p>Removal of the parallel arm is best performed on a workbench.</p> |  <p>xx1000001024</p> |
| 5 | Remove the two VK covers. |  <p>xx1000001371</p> |

Continues on next page




| | Action | Note |
|---|---|---|
| 6 | Fit the <i>lifting accessory, parallel arm</i> on the parallel arm. Lift the parallel arm to the position shown in the figure. | <p>Art. no. is specified in Required equipment on page 224.</p>  <p>xx1000001375</p> |
| 7 | Disassemble the parallel arm from the lower arm by using the <i>pressing tool, lower arm</i> . | <p>Art. no. is specified in Required equipment on page 224.</p> |
| 8 | <p> CAUTION</p> <p>The parallel arm system weighs 118 kg. All lifting accessories used must be sized accordingly!</p> | |
| 9 | Remove the parallel arm. |  <p>xx1000001018</p> |

Continues on next page

4 Repair


4.4.9 Replacement of parallel arm

Continued






| | Action | Note |
|----|--|---|
| 10 | <p>If needed, replace bearings, using the <i>press equipment, parallel arm</i>, according to user instructions enclosed with the equipment.</p>  <p>xx0900000813</p> <p>Go to the user instructions enclosed with the press tool.</p> <p> DANGER</p> <p>Handling the tool incorrectly will cause serious injury.</p> <p>Read and follow enclosed user instructions for the tool.</p> <p>The power for brake release is only applied for 180 seconds after activation.</p> |  <p>xx1100000218</p> |

Refitting, parallel arm

Use this procedure to refit the parallel arm.

| | Action | Note |
|---|--|---|
| 1 | Refitting of the parallel arm is best performed on a workbench. | |
| 2 | Check that the assembly and the condition of the <i>bearing</i> is good. | |
| 3 | Apply some <i>grease</i> on the shafts on the parallel arm. | Specified in <i>Required equipment on page 224</i> |
| 4 | Refit a <i>spacing sleeve</i> on each shaft. |  <p>xx1000001376</p> |

Continues on next page





| | Action | Note |
|----|---|--|
| 5 | <p>Refit a bearing on each shaft with <i>pressing tool, lower arm</i>.</p>  <p>xx0900000813</p> <p>Go to the user instructions enclosed with the press tool.</p> <p> DANGER</p> <p>Handling the tool incorrectly will cause serious injury. Read and follow enclosed user instructions for the tool. The power for brake release is only applied for 180 seconds after activation.</p> | <p>Art. no. is specified in Required equipment on page 224</p>  <p>xx1000001377</p> |
| 6 | <p><i>Foundry Plus:</i> Apply rust preventive on the highlighted areas.</p> |  <p>xx1400001127</p> |
| 7 | <p>Refit the protection washer on the inner shaft.</p> | |
| 8 | <p>Refit the lock ring on the inner shaft.</p> | |
| 9 | <p> CAUTION</p> <p>The parallel arm system weighs 118 kg. All lifting accessories used must be sized accordingly!</p> | |
| 10 | <p>Fit the <i>lifting accessory, parallel arm</i>.</p> | <p>Art. no. is specified in Required equipment on page 224.</p> |
| 11 | <p>Lift the parallel arm onto the workbench where the lower arm is placed.</p> | <p>Art. no. is specified in Required equipment on page 224</p> |
| 12 | <p>Adjust the lower arm in a way that both holes are parallel. Use a <i>level</i>.</p> | |

Continues on next page

4 Repair

4.4.9 Replacement of parallel arm

Continued


| | Action | Note |
|----|--|--|
| 13 | <p>Apply some <i>grease</i> in the holes in the lower arm (thick blue arrows).</p> <p> Note</p> <p>Do not put grease on the surfaces for the VK covers (thin red arrow)!</p> |  <p>xx1000001380</p> |
| 14 | Lift the parallel arm, lower it and put it in mounting position with the lower arm. |  <p>xx1000001379</p> |
| 15 | Carefully press the parallel arm onto the lower arm using the <i>pressing tool, lower arm</i> . | Art. no. is specified in Required equipment on page 224 . |
| 16 | Fit the big and small VK cover. | |
| 17 | Refit the complete lower arm. | Detailed in section Replacing the complete lower arm on page 216 . |
| 18 | Recalibrate the robot. | <p>Axis Calibration is described in Calibrating with Axis Calibration method on page 312.</p> <p>General calibration information is included in section Calibration on page 301.</p> |
| 19 | <p> DANGER</p> <p>Make sure all safety requirements are met when performing the first test run.</p> | |

4.5 Frame and base

4.5.1 Replacing the balancing device

Location, balancing device

The balancing device is located as shown in the figure.



xx0600002604

| | |
|---|--|
| A | Balancing device |
| B | Hole to neutralize the spring force. (M12) |
| C | Hole on lifting ear |
| D | Hole for lock screw |

Required equipment

| Equipment, etc. | Art.no. | Note |
|------------------|---|------|
| Balancing device | For spare part number, see Spare part lists on page 349 . | |

Continues on next page

4 Repair



4.5.1 Replacing the balancing device

Continued



| Equipment, etc. | Art.no. | Note |
|------------------------|------------|---|
| Auxiliary shaft | 3HAC5281-1 | For fitting the inner rings of the bearings |
| Auxiliary shaft, long | 3HAC5275-1 | |
| Auxiliary shaft, short | 3HAC5276-1 | |
| Lock screw | - | M16 x 90 For securing the lower arm. |
| Screw | | 2 pcs, M12 x 50 For neutralizing the spring force of the balancing cylinder. |
| Lubrication tool | 3HAC5222-2 | |
| Lifting accessories | - | |
| Locking liquid | 3HAB7116-1 | Loctite 243 |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Ball bearing puller | - | |

Removing, balancing device

Use this procedure to remove the balancing device.

| | Action | Note |
|---|--|--|
| 1 | Move the robot to a position close enough to its calibration position, to allow the lock screw to be inserted into the hole for the lock screw. | The balancing device must be placed in a 90° angle from the floor, in order to be lifted in the most secure way. See the figure in Location, balancing device on page 231 . |
| 2 | Lock the lower arm by inserting the <i>lock screw</i> into the <i>hole</i> .  CAUTION Tighten by hand! |  xx1000001101 |

Continues on next page






| | Action | Note |
|---|--|--|
| 3 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the robot working area. | |
| 4 | Remove the <i>protection hood</i> in the upper end of the balancing device. | |
| 5 | Insert two <i>screws, M12x50</i> in the holes to neutralize the spring force. Screw in the screws until they have proper contact with the cylinder inside. The length of the cylinder is now locked and the balancing device is unloaded. It should now be possible to easily rotate the balancing device. | |
| 6 | Attach a <i>lifting accessories</i> to the balancing device. Use the <i>hole</i> in the lifting ear. |  <p data-bbox="1023 1563 1134 1585">xx1000001112</p> |

Continues on next page



4 Repair

4.5.1 Replacing the balancing device

Continued

| | Action | Note |
|----|---|--|
| 7 | <p>Remove the upper and lower <i>lock nuts</i> and <i>support washers</i> (2+2 pcs).</p> <p> Note</p> <p>Make sure that the shaft between the upper and lower arm does not rotate when unscrewing the lock nuts! The lock nut is locked with Loctite 243.</p> |  <p>xx1000001113</p> |
| 8 | <p>Fit the <i>auxiliary shafts</i> on the upper and lower pivot shaft.</p> <p>Fit the short auxiliary shaft on the upper shaft and the longer on the lower shaft.</p> | <p>Art.no. is specified in Required equipment on page 231</p> |
| 9 | <p>Stretch the <i>roundsling</i>.</p> | |
| 10 | <p>Apply a <i>ball bearing puller</i> behind the lower ear of the balancing device.</p> <p> Note</p> <p>The ball bearing puller must be applied around the <i>spacer ring</i>. See figure!</p> |  <p>xx1000001115</p> |
| 11 | <p> CAUTION</p> <p>The balancing device weighs 70 kg. All lifting accessories used must be sized accordingly!</p> | |

Continues on next page

| | Action | Note |
|----|---|---|
| 12 | With the help of the ball bearing puller carefully remove the <i>balancing device</i> from its upper and lower attachments. |  <p data-bbox="1024 869 1134 891">xx1000001114</p> |
| 13 | Remove the balancing device and put it in a safe place. | |
| 14 | Remove the inner rings of the bearings. | |
| 15 | Remove upper and lower <i>spacer rings</i> and <i>support washers</i> (2+2 pcs). |  <p data-bbox="1024 1529 1134 1552">xx1000001116</p> |
| 16 | Remove residual grease. | |

Refitting, balancing device

use this procedure to refit the balancing device.




| | Action | Note |
|---|--|------|
| 1 | Check the bearings. Replace if needed. | |

Continues on next page



4 Repair

4.5.1 Replacing the balancing device

Continued

| | Action | Note |
|---|---|--|
| 2 | Refit the inner <i>sealing rings</i> and <i>support washers</i> in both ends. |  xx1000001116 |
| 3 | Refit the inner ring of the bearings on the upper and lower pivot shaft with the auxiliary shaft. | |
| 4 | Fit the auxiliary shafts on the upper and lower shafts. Fit the short auxiliary shaft on the upper shaft and the longer on the lower shaft. | Art.no. is specified in section Required equipment on page 231 |
| 5 |  CAUTION The balancing device weighs 70 kg. All lifting accessories used must be sized accordingly! | |
| 6 | Attach lifting accessory to the balancing device and lift it on to the auxiliary shafts. |  xx1000001112 |

Continues on next page




| | Action | Note |
|----|---|--|
| 7 | <p>Adjust the length between the upper and lower bearings by means of the M12 screws, used to neutralize the spring force.</p> <p>This length should preferably be 0.5 mm too short than 0.1 mm too long. If the distance is too long the bearings may be damaged when erecting the balancing device.</p> |  <p>xx1000001111</p> |
| 8 | <p>Carefully refit the balancing device on the upper and lower shafts.</p> |  <p>xx1000001271</p> |
| 9 | <p>Fit the <i>lubricating tool</i>.</p> <p>The tool should be tightened to the bottom position by hand power only.</p> | <p>Art. no. is specified in section Required equipment on page 231.</p> |
| 10 | <p>Fill the bearings with grease through the nipple. Continue until grease excudes behind the inner sealing.</p> | |
| 11 | <p>Remove the lubricating tool and wipe off protruding grease.</p> | |
| 12 | <p>Remove the auxiliary shafts.</p> | |
| 13 | <p>Apply <i>locking liquid</i> on the threads of the lock nuts.</p> | <p>Specified in section Required equipment on page 231.</p> |

Continues on next page

4 Repair

4.5.1 Replacing the balancing device


Continued

| | Action | Note |
|----|---|---|
| 14 | Refit the lock nuts and support washers. | <p>Tightening torque: 120 Nm</p>  <p>xx1000001113</p> |
| 15 | Check play (min. 0.1 mm) between support washers and bearing seat at both bearings. | |
| 16 | Remove the M12x50 screws from the balancing device to restore the springforce. | |
| 17 | Remove the <i>lock screw</i> . |  <p>xx1000001101</p> |
| 18 |  <p>DANGER</p> <p>Make sure all safety requirements are met when performing the first test run.</p> | |

4.5.2 Replacing the SMB unit

Location of SMB unit

The SMB unit (SMB = serial measurement board) is located on the left hand side of the frame as shown in the figure.



xx0600002621

| | |
|---|--------------------|
| A | SMB cover |
| B | SMB unit |
| C | Battery cable |
| D | SMB battery |
| E | SMB battery, cover |

Required equipment



Note

There are different variants of SMB units and batteries. The variant with the 3-pole battery contact has longer lifetime for the battery.

It is important that the SMB unit uses the correct battery. Make sure to order the correct spare parts. Do not replace the battery contact!

| Equipment, etc. | Article number | Note |
|------------------|---|---|
| SMB unit | For spare part number, see: Spare part lists on page 349. | |
| Battery pack | For spare part number, see: Spare part lists on page 349. | |
| Standard toolkit | - | Content is defined in section Standard tools on page 344. |

Continues on next page

4 Repair





4.5.2 Replacing the SMB unit

Continued

| Equipment, etc. | Article number | Note |
|-----------------|----------------|--|
| Circuit diagram | - | See chapter Circuit diagrams on page 351 . |

Removing, SMB unit





Use this procedure to remove the SMB unit.

| | Action | Note |
|---|--|---|
| 1 | Move the robot to the calibration position. | |
| 2 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the robot working area. | |
| 3 |  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 49 . | |
| 4 | Remove the SMB cover by unscrewing its attachment screws.  CAUTION Clean cover from metal residues before opening. Metal residues can cause shortage on the boards which can result in hazardous failures. | Shown in the figure Location of SMB unit on page 239 . |
| 5 | Use caution and remove the connectors X8, X9 and X10 from the brake release board, if need of more space. | |
| 6 | Remove the nuts and washers from the guide pins that secure the board. | Shown in the figure Location of SMB unit on page 239 . |
| 7 | Use caution and disconnect the connectors from the SMB unit when pulling the board out. | Connectors R1.SMB1-3, R1.SMB4-6 and R2.SMB |
| 8 | Disconnect the battery cable by pressing down the upper lip of the R2.G connector to release the lock while pulling the connector upwards. |  xx1700000993 |

Continues on next page

Refitting, SMB unit

Use this procedure to refit the SMB unit.

| | Action | Note |
|----|--|--|
| 1 |  <p>DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> | |
| 2 |  <p>ELECTROSTATIC DISCHARGE (ESD)</p> <p>The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 49.</p> | |
| 3 | <p>Connect the <i>battery cable</i> to the SMB unit. Make sure the lock on the battery cable connector R2.G snaps into place during refitting.</p> | <p>Shown in the figure Location of SMB unit on page 239.</p> |
| 4 | <p>Connect all connectors to the SMB board: R1.SMB1-3, R1.SMB6 and R2.SMB</p> | <p>Art. no. is specified in Required equipment on page 239.</p> <p>Shown in the figure Location of SMB unit on page 239.</p> |
| 5 | <p>Fit the <i>SMB unit</i> onto the <i>guide pins</i>.</p> | |
| 6 | <p>Secure the SMB unit to the pins with the nuts and washers.</p> | |
| 7 | <p>If disconnected, reconnect the connectors X8, X9 and X10 to the brake release board. Be careful not to damage the sockets or pins. Make sure the connector and its locking arms are snapped down properly.</p> |  <p>xx1700000978</p> |
| 8 | <p>Secure the <i>SMB cover</i> with its attachment screws. If cabling is used for 7th axis (option), refit the 7th axis connector to the SMB cover and tighten with 6 Nm.</p> | <p>Shown in the figure Location of SMB unit on page 239.</p> |
| 9 | <p>Update the revolution counters.</p> | <p>See Updating revolution counters on IRC5 robots on page 306.</p> |
| 10 |  <p>DANGER</p> <p>Make sure all safety requirements are met when performing the first test run.</p> | |


4 Repair

4.5.3 Replacing the brake release board

4.5.3 Replacing the brake release board

Location of brake release board

The brake release unit is located together with the SMB unit on the left hand side of the frame, right next to the gearbox, axis 2, as shown in figure below.



xx0600002621

| | |
|---|--------------------|
| A | SMB cover |
| B | SMB unit |
| C | Battery cable |
| D | SMB battery |
| E | SMB battery, cover |




Required equipment

| Equipment, etc. | Article number | Note |
|--|----------------|--|
| Brake release board | 3HAC065020-001 | DSQC1050 |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Continues on next page

Removing, brake release board

Use this procedure to remove the brake release board.


| | Action | Note |
|---|---|--|
| 1 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply to the robot • hydraulic pressure supply to the robot • air pressure supply to the robot Before entering the robot working area. | |
| 2 |  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 49 . | |
| 3 | Remove the push button guard from the SMB cover. | Shown in the figure Location of brake release board on page 242 . The guard must be removed to ensure a correct refitting of the brake release board. |
| 4 | Open the SMB cover by unscrewing the attachment screws. Let the battery stay connected, to avoid the need of synchronization of the robot!  CAUTION Clean cover from metal residues before opening. Metal residues can cause shortage on the boards which can result in hazardous failures. | Shown in the figure Location of brake release board on page 242 . |
| 5 | Take a picture or make notes of how the robot cabling is positioned in regard to the brake release board. | |
| 6 | Remove the complete brake release board (including brake release board and bracket) from the SMB recess, by removing its two attachment screws. | |

Continues on next page

4 Repair




4.5.3 Replacing the brake release board

Continued



| | Action | Note |
|---|---|--|
| 7 | Disconnect the connectors X8, X9 and X10 from the brake release board. |  <p data-bbox="968 546 1075 562">xx1700000978</p> <p data-bbox="968 584 1382 658">Location of the brake release unit is shown in the figure Location of brake release board on page 242.</p> |
| 8 | Remove the brake release board from the bracket by removing the four attachment screws. | |

Refitting, brake release board

Use this procedure to refit the brake release board.

| | Action | Note |
|---|--|--|
| 1 |  <p data-bbox="555 981 963 1010">ELECTROSTATIC DISCHARGE (ESD)</p> <p data-bbox="464 1043 963 1122">The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 49.</p> | |
| 2 | <p data-bbox="464 1160 963 1211">Connect the connectors X8, X9 and X10 to the brake release board.</p> <p data-bbox="464 1223 963 1308">Be careful not to damage the sockets or pins. Make sure the connector and its locking arms are snapped down properly.</p> |  <p data-bbox="968 1391 1075 1406">xx1700000978</p> |
| 3 | <p data-bbox="464 1444 963 1496">Fasten the <i>brake release board</i> on the bracket with the attachment screws.</p> <p data-bbox="464 1507 963 1599">Make sure the board is positioned as straight as possible on the bracket! The push buttons can otherwise get jammed when the SMB cover is refitted.</p> | <p data-bbox="968 1444 1362 1473">Maximum tightening torque: 5 Nm.</p> <p data-bbox="968 1485 1394 1532">Shown in the figure Location of brake release board on page 242.</p> <p data-bbox="968 1547 1404 1592">Art. no. is specified in Required equipment on page 242.</p> |
| 4 | <p data-bbox="464 1624 963 1697">Refit the complete brake release board (including brake release board and bracket) to the SMB recess with the two attachment screws.</p> | |
| 5 | <p data-bbox="464 1720 963 1794">Verify that the robot cabling is positioned correctly, according to previously taken picture/notes.</p>  <p data-bbox="555 1839 676 1868">WARNING</p> <p data-bbox="464 1899 963 2002">Screened cables must not get in contact with the brake release board after installation. Eliminate all risks of contact between screened cables and the brake release board.</p> | |

Continues on next page

| | Action | Note |
|----|---|---|
| 6 | Refit the <i>SMB</i> cover with its attachment screws. | Shown in the figure Location of brake release board on page 242 . |
| 7 |  WARNING Before continuing any service work, follow the safety procedure in The brake release buttons may be jammed after service work on page 145 . | |
| 8 | Refit the <i>push button guard</i> to the <i>SMB</i> cover. | Shown in the figure Location of brake release board on page 242 . |
| 9 | Press the push buttons 1 to 6, one at a time, to make sure that the buttons are moving freely and do not stay in a locked position. | |
| 10 | If the battery has been disconnected the revolution counter must be updated. | Detailed in the Calibration chapter - section Updating revolution counters on IRC5 robots on page 306 . |
| 11 |  DANGER Make sure all safety requirements are met when performing the first test run. | |

4 Repair


4.6.1 Replacing motor, axis 1

4.6 Motors

4.6.1 Replacing motor, axis 1

Location of motor axis 1

The motor axis 1 is located on the left hand side of the robot as shown in the figure.



xx0600002598

| | |
|---|--|
| A | Motor axis 1 |
| B | Motor attachment screws and washers |
| C | Cable gland cover (located on the left hand side of the motor) |
| D | Motor cover |

Required equipment

| Equipment, etc | Art.no. | Note |
|----------------|--|--|
| Motor axis 1 | For spare part number, see: <ul style="list-style-type: none">Spare part lists on page 349 | Includes: <ul style="list-style-type: none">• motor• pinion• o-ring (The old o-ring must be replaced when replacing the motor) |
| Grease | 3HAC042536-001 | Shell Gadus S2 For lubricating the o-ring. |
| Bits extension | 3HAC12342-1 | Used to reach the attachment screws for the motor. |

Continues on next page

| Equipment, etc | Art.no. | Note |
|--|---------|--|
| Power supply | - | 24 VDC, max. 1,5 A For releasing the brakes. |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |
| Circuit diagram | | See chapter Circuit diagrams on page 351 . |

Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.

| | Action | Note |
|---|--|--|
| 1 | Decide which calibration routine to use for calibrating the robot. <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |
| | <p>If the robot is to be calibrated with reference calibration:</p> <p>Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot.</p> <p>If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible.</p> | <p>Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values.</p> <p>Creating new values requires possibility to move the robot.</p> <p>Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i>.</p> |
| | <p>If the robot is to be calibrated with fine calibration:</p> <p>Remove all external cable packages (DressPack) and tools from the robot.</p> | |

Removing motor axis 1

Use this procedure to remove motor axis 1.






| | Action | Note |
|---|--|------|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. | |

Continues on next page





4 Repair

4.6.1 Replacing motor, axis 1

Continued

| | Action | Note |
|---|--|--|
| 2 | <p> DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none">• electric power supply• hydraulic pressure supply• air pressure supply <p>to the robot, before entering the robot working area.</p> | |
| 3 | <p>Remove the <i>motor cover</i> to get access to the connectors on top of the motor.</p> |  <p>xx1000001092</p> |
| 4 | <p>Remove the <i>cable gland cover</i> at the cable exit of the motor.</p> <p> Note</p> <p>Make sure the gasket is undamaged! Replace if damaged.</p> |  <p>xx1000001094</p> |
| 5 | <p>Disconnect all connectors beneath the motor cover.</p> | |
| 6 | <p>In order to release the brake, connect the 24 VDC power supply.</p> | <p>Connect to connector R2.MP1</p> <ul style="list-style-type: none">• + : pin 2• - : pin 5 |
| 7 | <p>Remove the <i>attachment screws</i> of the motor. Use the bits extension.</p> |  <p>xx1000001090</p> |

Continues on next page

| | Action | Note |
|----|--|--|
| 8 | <p>If required, press the motor out of position by fitting two screws in the holes on the motor for pressing out the motor.</p> | <p>Always use removal screws and tools in pairs!</p>  <p>xx1000001207</p> |
| 9 | <p> CAUTION</p> <p>The motor weighs 29 kg. All lifting accessories used must be sized accordingly!</p> | |
| 10 | <p>Remove the motor by carefully lifting it straight up to get the pinion away from gear.</p> <p> CAUTION</p> <p>Be careful not to damage the pinion in the process!</p> |  <p>xx1000001021</p> |
| 11 | <p>Disconnect the brake release voltage.</p> | |
| 12 | <p>Check the pinion. If there is any damage, the pinion must be replaced.</p> | |

Continues on next page







4 Repair

4.6.1 Replacing motor, axis 1






Continued

Refitting motor axis 1

Use this procedure to refit motor axis 1.

| | Action | Note |
|---|---|---|
| 1 | <p>Make sure the <i>o-ring</i> on the <i>circumference</i> of the motor is seated properly. Lightly lubricate the o-ring with <i>grease</i>.</p> |  <p>xx1000001096</p> <p>Parts:</p> <ul style="list-style-type: none"> A Circumference of motor B O-ring <p> Note</p> <p>The o-ring must be replaced when replacing the motor.</p> |
| 2 | <p> CAUTION</p> <p>The motor weighs 29 kg. All lifting accessories used must be sized accordingly!</p> | |
| 3 | <p>In order to release the brake, connect the 24 VDC power supply.</p> | <p>Connect to connector R2.MP1</p> <ul style="list-style-type: none"> • + : pin 2 • - : pin 5 |
| 4 | <p>Gently lower the <i>motor</i> into the gear, making sure the <i>pinion</i> is properly mated to the gearbox of axis 1.</p> <p> Note</p> <p>Make sure the motor is turned the right way. See figure.</p> <p> Note</p> <p>Make sure the motor pinion does not get damaged!</p> |  <p>xx1000001269</p> |

Continues on next page


| | Action | Note |
|----|---|---|
| 5 | Secure the motor with its four <i>attachment screws</i> and plain washers. Use the bits extension. |  <p>xx1000001090</p> <p>Attachment screws:</p> <ul style="list-style-type: none"> • M10x40 quality 12.9 Gleitmo <p>Tightening torque:</p> <ul style="list-style-type: none"> • 50 Nm |
| 6 | Disconnect the brake release voltage. | |
| 7 | Reconnect all connectors beneath the motor cover. | |
| 8 | Refit the <i>cable gland cover</i> at the cable exit with its attachment screws.  Note Make sure the cover is tightly sealed! Replace gasket if damaged. |  <p>xx1000001094</p> |
| 9 | Refit the <i>motor cover</i> with its attachment screws.  Note Make sure the cover is tightly sealed! |  <p>xx1000001092</p> |
| 10 | Recalibrate the robot! | <p>Axis Calibration is described in Calibrating with Axis Calibration method on page 312.</p> <p>General calibration information is included in section Calibration on page 301.</p> |

Continues on next page

4 Repair

4.6.1 Replacing motor, axis 1

Continued


| | Action | Note |
|----|--|------|
| 11 |  DANGER Make sure all safety requirements are met when performing the first test run. | |

4.6.2 Replacing motors, axes 2 and 3

Location of motors, axes 2 and 3

The motors axes 2 and 3 are located on either side of the robot as shown in the figure.

The procedure is the same for both motors.



xx0600002599

| | |
|---|--|
| A | Motor, axis 2 |
| B | Motor, axis 3 |
| C | Motor attachment screws and washers |
| D | Cable gland cover (located on the lower side of the motor) |
| E | Motor cover |
| F | Hole for lock screw |

Required equipment

| Equipment, etc. | Art. no. | Note |
|-----------------------------------|--|---|
| Motor axes 2-3 | For spare part no. see: <ul style="list-style-type: none"> Spare part lists on page 349 chapter | Includes <ul style="list-style-type: none"> motor pinion o-ring (the o-ring must be replaced when the motor is replaced) |
| Grease | 3HAC042536-001 | Shell Gadus S2 For lubricating the o-ring. |
| Guide pins | 3HAC13120-2 | M10x150 For guiding the motor. Guide pins are to be used in pairs! |
| Lifting accessory, motor axes 2-3 | 3HAC15534-1 | |
| Lock screw | - | M16x90 For securing the lower arm. |
| Bits extension | 3HAC12342-1 | Used to reach the attachment screws for the motor. |

Continues on next page

4 Repair

4.6.2 Replacing motors, axes 2 and 3

Continued

| Equipment, etc. | Art. no. | Note |
|--|----------|--|
| Power supply | - | 24 VDC, 1.5 A For releasing the brakes. |
| Rotation tool | | Used to rotate the motor pinion when mating it to the gear, when brakes are released with 24 VDC power supply. |
| Standard toolkit | | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |
| Circuit diagram | | See chapter Circuit diagrams on page 351 . |

Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.

| | Action | Note |
|---|---|--|
| 1 | Decide which calibration routine to use for calibrating the robot. <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |
| | If the robot is to be calibrated with reference calibration: Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot. If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible. | Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values. Creating new values requires possibility to move the robot. Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i> . |
| | If the robot is to be calibrated with fine calibration: Remove all external cable packages (DressPack) and tools from the robot. | |




Removing motors axes 2 and 3

Use this procedure to remove motors axes 2 and 3.

The procedure is the same for both motors.

| | Action | Note |
|---|--|------|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. | |

Continues on next page




| | Action | Note |
|---|--|---|
| 2 | Run the robot to a position close enough to its calibration position, to allow the lock screw to be inserted into the <i>hole for lock screw</i> . |  <p>xx1000001101</p> |
| 3 | Lock the <i>lower arm</i> by inserting the <i>lock screw</i> into the hole of the frame. This is done in order to secure axis 2 from collapsing when the axis 2 motor is being removed.  CAUTION Tighten by hand! | See figure above. |
| 4 | Run axis 3 to the end position so that it rests against the mechanical stop. Release the brake of axis 3 in order to set the weight of axis 3 against the mechanical stop. This is done in order to secure axis 3 from collapsing when the axis 3 motor is being removed. | |
| 5 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the robot working area. | |
| 6 | Drain the oil from <i>gearbox</i> . | See section <ul style="list-style-type: none"> • Changing oil, gearbox axes 2 and 3 on page 122. |

Continues on next page



4 Repair

4.6.2 Replacing motors, axes 2 and 3

Continued

| | Action | Note |
|----|---|--|
| 7 | Remove the <i>motor cover</i> . |  xx1000001102 |
| 8 | Remove the <i>cable gland cover</i> at the cable exit.  Note Make sure the gasket is not damaged! Replace if damaged. |  xx1000001103 |
| 9 | Disconnect all connectors beneath the motor cover. | |
| 10 | In order to release the brake, connect the 24 VDC power supply. | Connect to connector R2.MP2 <ul style="list-style-type: none">• + : pin 2• -: pin 5 |

Continues on next page




| | Action | Note |
|----|---|--|
| 11 | <p>Unscrew <i>attachment screws</i> and <i>washers</i> of the motor. Use the <i>bits extension</i>.</p> |  <p>xx1000001104</p> |
| 12 | <p>Fit two <i>guide pins</i> in two of the motors attachment holes.</p> | <p>Art. no. is specified in Required equipment on page 253.</p>  <p>xx1000001131</p> |

Continues on next page

4 Repair

4.6.2 Replacing motors, axes 2 and 3

Continued

| | Action | Note |
|----|--|---|
| 13 | If required, press the motor out of position by fitting two <i>screws</i> in the remaining attachment holes of the motor, diagonal to each other. | <p>M12x70, fully threaded. Always use the removal screws and tools in pairs!</p>  <p>xx1000001184</p> |
| 14 | Remove the two screws and fit the <i>lifting tool</i> , <i>motor axes 2-3</i> to the motor. | Art. no. is specified in Required equipment on page 253 . |
| 15 | <p> CAUTION</p> <p>The motor weighs 32 kg. All lifting accessories used must be sized accordingly!</p> | |
| 16 | Pull out the <i>motor</i> on the guide pins to get the pinion away from the gear. Make sure the pinion does not get damaged! | <p>The figure shows IRB 760 but the principle is the same.</p>  <p>xx1000001105</p> |
| 17 | Remove the motor by gently lifting it straight out and place it on a secure surface. | |


Continues on next page

| | Action | Note |
|----|--|------|
| 18 | Disconnect the brake release voltage! | |
| 19 | Check the pinion. If there is any damage, the motor pinion must be replaced. | |

Refitting, motors axes 2 and 3

Use this procedure to refit motors axes 2 and 3.

The procedure is the same for both motors.





| | Action | Note |
|---|--|--|
| 1 | Make sure the <i>o-ring</i> on the <i>circumference</i> of the motor is seated properly. Lightly lubricate the o-ring with grease. |  <p>xx1000001096</p> <p>Parts:</p> <ul style="list-style-type: none"> A Circumference B O-ring |
| 2 | In order to release the brake, connect the 24 VDC power supply. | Connect to connector R2.MP1 <ul style="list-style-type: none"> • + : pin 2 • -: pin 5 |
| 3 | Fit the <i>lifting tool, motor axes 2-3</i> to the motor. | Art. no. is specified in Required equipment on page 253 . |

Continues on next page




4 Repair

4.6.2 Replacing motors, axes 2 and 3

Continued

| | Action | Note |
|---|--|---|
| 4 | Fit the two <i>guide pins</i> in the two lower motor attachment holes. | <p>Art. no. is specified in Required equipment on page 253.</p> <p>The figure shows IRB 760 but the principle is the same.</p>  <p>xx1000001131</p> |
| 5 | <p> CAUTION</p> <p>The motor weighs 32 kg. All lifting accessories used must be sized accordingly!</p> | |
| 6 | <p>Lift the <i>motor</i> and guide it on to the <i>guide pins</i>, as close to the correct position as possible without pushing the motor <i>pinion</i> into the gear.</p> <p> Note</p> <p>Make sure the motor is turned the right way, that is connections for the cables facing downwards.</p> | <p>The figure shows IRB 760 but the principle is the same.</p>  <p>xx1000001185</p> |
| 7 | Remove the lifting tool and allow the motor to rest on the guide pins. | |

Continues on next page






| | Action | Note |
|----|--|--|
| 8 | <p>Use the <i>rotation tool</i> in order to rotate the motor pinion when mating it to the gear (see figure). Fit the motor, making sure the motor pinion is properly mated to the gear of gearbox axis 2-3 and that it doesn't get damaged.</p> <p> Note</p> <p>The rotation tool is used beneath the motor cover, directly on the motor shaft as shown in figure above.</p> |  <p>xx0200000165</p> <p>Part: Rotation tool</p> |
| 9 | Remove the guide pins. | |
| 10 | <p>Secure the motor with its four <i>attachment screws</i> and <i>plain washers</i>. Use the <i>bits extension</i>.</p> <p>Reused screws can be used, providing they are lubricated as detailed in section Screw joints on page 340 before fitting.</p> |  <p>xx1000001104</p> <p>Attachment screws:</p> <ul style="list-style-type: none"> • M10 x 40 quality 12.9 Gleitmo <p>Tightening torque:</p> <ul style="list-style-type: none"> • 50 Nm |
| 11 | Disconnect the brake release voltage. | |
| 12 | Reconnect all connectors beneath the motor cover. | Connect in accordance with markings on connectors. |

Continues on next page


4 Repair

4.6.2 Replacing motors, axes 2 and 3

Continued

| | Action | Note |
|----|--|--|
| 13 | Refit the <i>cable gland cover</i> at the cable exit with its two attachment screws.  Note Use a new gasket! |  xx1000001103 |
| 14 | Refit the <i>motor cover</i> with its attachment screws and washers.  Note Make sure the cover is tightly sealed! |  xx1000001102 |
| 15 | Remove the <i>lock screw</i> from the <i>hole for lock screw</i> . |  xx1000001101 |
| 16 | Perform a leak-down test of the axis 2 or 3 gearbox. | See section Performing a leak-down test on page 138 . |
| 17 | Refill the gearbox with oil. | See section Changing oil, gearbox axes 2 and 3 on page 122 . |

Continues on next page

| | Action | Note |
|----|--|---|
| 18 | Recalibrate the robot! | Axis Calibration is described in Calibrating with Axis Calibration method on page 312 . General calibration information is included in section Calibration on page 301 . |
| 19 |  DANGER Make sure all safety requirements are met when performing the first test run. | |


4 Repair

4.6.3 Replacing motor, axis 6

4.6.3 Replacing motor, axis 6

Location of motor axis 6

Motor axis 6 is located in the center of the tilthouse as shown in the figure.



xx0600002600

| | |
|---|-------------------------------|
| A | Motor, axis 6 |
| B | Attachment screws and washers |
| C | Cable gland cover |
| D | Motor cover |

Required equipment

| Equipment, etc. | Art.no. | Note |
|--|--|---|
| Motor axis 6 | For spare part no. see: <ul style="list-style-type: none">Spare part lists on page 349 | Includes <ul style="list-style-type: none">motorpiniono-ring (the o-ring must be replaced when the motor is replaced) |
| Bits extension | 3HAC12342-1 | Used to reach attachment screws for motor. |
| Locking liquid | 3HAB7116-1 | Loctite 243 |
| Power supply | - | 24 VDC, 1.5 A For releasing the brakes. |
| Grease | 3HAC042536-001 | Shell Gadus S2 For lubricating the o-ring. |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Continues on next page

| Equipment, etc. | Art.no. | Note |
|-----------------|---------|--|
| Circuit diagram | | See chapter Circuit diagrams on page 351 . |


Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.

| | Action | Note |
|---|--|--|
| 1 | <p>Decide which calibration routine to use for calibrating the robot.</p> <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |
| | <p>If the robot is to be calibrated with reference calibration:</p> <p>Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot.</p> <p>If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible.</p> | <p>Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values.</p> <p>Creating new values requires possibility to move the robot.</p> <p>Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i>.</p> |
| | <p>If the robot is to be calibrated with fine calibration:</p> <p>Remove all external cable packages (DressPack) and tools from the robot.</p> | |

Removing, motor axis 6

Use this procedure to remove motor, axis 6.







| | Action | Information |
|---|--|-------------|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. | |
| 2 | <p>Run the robot to a position where it is easiest to remove the motor axis 6 when standing in front of the robot.</p> <p> Note</p> <p>The motor axis 6 can be replaced without draining the gear oil.</p> | |

Continues on next page




4 Repair

4.6.3 Replacing motor, axis 6

Continued

| | Action | Information |
|---|--|--|
| 3 | <p> DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> | |
| 4 | Remove <i>motor cover</i> . |  <p>xx1000001106</p> |
| 5 | <p>Remove the <i>cable gland cover</i> at the cable exit by unscrewing its <i>attachment screw (A)</i> on the inside.</p> <p> Note</p> <p>Make sure the gasket is not damaged!</p> |  <p>xx0600002694</p> |
| 6 | <p>Disconnect all connectors beneath the cover.</p> <p> Note</p> <p>The connection to the <i>UL lamp</i>, must also be disconnected, if the robot is equipped with one.</p> |  <p>xx0500002466</p> <p>A Signal lamp (UL lamp) B Cable straps, outdoor C Cable D Connection point to the cable gland</p> |

Continues on next page

| | Action | Information |
|----|---|--|
| 7 | In order to release the brake, connect the 24 VDC power supply. | Connect to connector R2.MP6 <ul style="list-style-type: none"> • + : pin 2 • -: pin 5 |
| 8 | Remove <i>attachment screws</i> and <i>washers</i> . Use the bits extension. |  <p style="text-align: right; font-size: small;">xx1000001012</p> |
| 9 | If required, press the motor out of position by fitting two screws in the motor attachment holes diagonal to each other | Always use the screws for removal in pairs! |
| 10 | Lift the motor carefully to get the <i>pinion</i> away from the gear.  Note Make sure the <i>pinion</i> does not get damaged! |  <p style="text-align: right; font-size: small;">xx1000001108</p> |
| 11 | Disconnect the brake release voltage. | |
| 12 | Remove the motor by gently lifting it straight up and place it on a secure surface. | |

Continues on next page





4 Repair

4.6.3 Replacing motor, axis 6



Continued

Refitting, motor axis 6

Use this procedure to refit motor axis 6.

| | Action | Information |
|---|---|---|
| 1 | <p>Make sure the <i>o-ring</i> on the <i>circumference</i> of the motor is seated properly. Lightly lubricate the o-ring with grease.</p> <p> Note</p> <p>The o-ring must be replaced when the motor is replaced.</p> |  <p>xx1000001109</p> <p>Parts:</p> <ul style="list-style-type: none"> • A: Pinion • B: O-ring • C: Circumference |
| 2 | <p>In order to release the brake, connect the 24 VDC power supply.</p> | <p>Connect to connector R2.MP6</p> <ul style="list-style-type: none"> • + : pin 2 • - : pin 5 |
| 3 | <p>Fit the two <i>guide pins</i> in two of the motor attachment holes.</p> | <p>Art. no. is specified in Required equipment on page 264.</p> |
| 4 | <p>Lift the motor carefully in place. Make sure the motor <i>pinion</i> is properly mated to the gearbox, axis 6.</p> <p> Note</p> <p>Make sure the motor is turned the correct way. See figure!</p> |  <p>xx1000001108</p> |
| 5 | <p>Remove the guide pins.</p> | |
| 6 | <p>Apply <i>locking liquid</i> (<i>Loctite 243</i>) on the attachment screws.</p> | |

Continues on next page





| | Action | Information |
|----|--|--|
| 7 | <p>Secure the motor with its four <i>attachment screws</i> and <i>washers</i>.</p> <p>Reused screws may be used, providing they are lubricated as detailed in section Screw joints on page 340 before fitting.</p> |  <p>xx1000001012</p> <p>Washers:</p> <ul style="list-style-type: none"> • 8.4x16x1.6 quality Steel-A2F <p>Attachment screws:</p> <ul style="list-style-type: none"> • M10 x 40 quality 8.8-A2F <p>Tightening torque:</p> <ul style="list-style-type: none"> • 50 Nm |
| 8 | <p>Disconnect the brake release voltage.</p> | |
| 9 | <p>Perform a leak-down test of the axis 6 gearbox.</p> | <p>See section Performing a leak-down test on page 138.</p> |
| 10 | <p>Reconnect all connectors in motor axis 6.</p> | <p>Connect in accordance with markings on connectors.</p> |
| 11 | <p>Refit the connections to the UL lamp, if the robot is equipped with one.</p> | |
| 12 | <p>Check the <i>gasket</i>. If damaged, replace it.</p> |  <p>xx1000001224</p> |

Continues on next page

4 Repair

4.6.3 Replacing motor, axis 6

Continued


| | Action | Information |
|----|---|---|
| 13 | Refit the cable gland with its attachment screw. |  <p>xx0600002694</p> <ul style="list-style-type: none"> • A: Screw holding the cable gland <p>Make sure the gasket is not damaged! Replace if damaged.</p> |
| 14 | Refit the cover, motor axis 6 with its <i>attachment screws</i> and <i>washers</i> .  Note Make sure the cover is tightly sealed! |  <p>xx1000001106</p> |
| 15 | Re-calibrate the robot! | Axis Calibration is described in Calibrating with Axis Calibration method on page 312 . General calibration information is included in section Calibration on page 301 . |
| 16 |  DANGER Make sure all safety requirements are met when performing the first test run. | |

4.7 Gearboxes

4.7.1 Replacing the axis 1 gearbox

Location of gearbox

The axis 1 gearbox is located between the frame and base as shown in the figure.



xx0600002631

| | |
|---|-----------------|
| A | Gearbox, axis 1 |
| B | Frame |
| C | Base |

Required equipment

| Equipment, etc. | Art. no. | Note |
|---------------------------|--|--|
| Gearbox | For spare part no. see: • Spare part lists on page 349. | Includes: • gearbox • all o-rings and sealing rings |
| O-ring | 3HAB3772-54 | Replace if damaged! |
| O-ring | 3HAB3772-55 | Replace if damaged! |
| Sealing ring | 3HAC11581-4 | Replace if damaged! |
| Grease | 3HAC042536-001 | Shell Gadus S2 For lubricating the o-ring. |
| Support, base and gear 1 | 3HAC15535-1 | |
| Lifting accessory, base | 3HAC15560-1 | |
| Lifting accessory (chain) | 3HAC15556-1 | |
| Guide pins | | 2 pcs, M16x150. Used for guiding the gearbox into place in the base. Always use guide pins in pairs! |

Continues on next page

4 Repair

4.7.1 Replacing the axis 1 gearbox

Continued

| Equipment, etc. | Art. no. | Note |
|--|----------------|---|
| Calibration tool box, Axis Calibration | 3HAC055412-001 | Delivered as a set of calibration tools. Required if Axis Calibration is the valid calibration method for the robot. |
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.




| | Action | Note |
|---|---|--|
| 1 | Decide which calibration routine to use for calibrating the robot. <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |
| | If the robot is to be calibrated with reference calibration: Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot. If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible. | Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values. Creating new values requires possibility to move the robot. Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i> . |
| | If the robot is to be calibrated with fine calibration: Remove all external cable packages (DressPack) and tools from the robot. | |

Removal, gearbox axis 1

Use this procedure to remove gearbox, axis 1.

| | Action | Note |
|---|--|------|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. | |

Continues on next page



| | Action | Note |
|---|--|--|
| 2 | Move the robot to its most stable position, shown in the figure to the right. |  <p>xx0500002275</p> |
| 3 |  <p>DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p>to the robot, before entering the robot working area.</p> | |
| 4 | Drain the axis 1 gearbox. | See Changing oil, axis-1 gearbox on page 119 . |
| 5 | Remove the complete arm system. | See Replacing the base, including axis 1 gearbox on page 160 . |
| 6 | Unfasten the robot base from the foundation by removing the base attachment screws. | |
| 7 | Attach the <i>lifting accessory, base and gear 1</i> and the <i>lifting tool (chain)</i> to the gearbox and base. |  <p>xx1000001395</p> <p>Specified in Required equipment on page 271.</p> |

Continues on next page

4 Repair




4.7.1 Replacing the axis 1 gearbox

Continued

| | Action | Note |
|----|--|---|
| 8 |  CAUTION The base and axis 1 gearbox weighs 130 kg + . All lifting accessories used must be sized accordingly! | |
| 9 | Lift the robot base including the axis 1 gearbox to allow the <i>base and gear 1 support</i> be fitted on each sides of the base. | Art. no. is specified in <i>Required equipment on page 271</i> . |
| 10 | Secure the support to the base and to the foundation. Make sure the base remains in a stable position before performing any work underneath the base! |  xx100000364 A Support base (4 pcs) |

Continues on next page

4.7.1 Replacing the axis 1 gearbox
Continued





| | Action | Note |
|----|--|--|
| 11 | <p>Remove the bottom plate from underneath the base in order to get access to the attachment screws.</p> <p>It may be necessary to also remove the rear connector plate.</p> |  <p>xx1000001385</p>  <p>xx0300000612</p> <ul style="list-style-type: none"> A Bottom plate B Rear connector plate C Attachment screw D Groove |
| 12 | <p>Unscrew the attachment screws and remove the washers.</p> |  <p>xx0200000227</p> <p>A view from below:</p> <ul style="list-style-type: none"> • A: Oil drain hose • B: Attachment screws, gearbox axis 1, 18 pcs • C: Washers, 3 pcs |

Continues on next page

4 Repair

4.7.1 Replacing the axis 1 gearbox



Continued

| | Action | Note |
|----|---|--|
| 13 | Remove the cable guide in the center of gearbox 1 by unscrewing its attachment screws. |  xx1000001387 |
| 14 |  CAUTION The gearbox weighs . All lifting accessories used must be sized accordingly! | |
| 15 | Lift the gearbox away with the already mounted lifting tools. | |
| 16 | Turn the gearbox, and remove the protection pipe by unscrewing two attachment screws.  Note Move the protective pipe over to the new gearbox. |  xx1400000786 |

Continues on next page

Refitting, gearbox axis 1

Use this procedure to refit gearbox, axis 1.




| | Action | Note |
|---|--|--|
| 1 | Fit the <i>support, base and gear 1</i> to the base. | <p>Mounting of the support, base and gear 1 is detailed in section Removal, gearbox axis 1 on page 272.</p>  <p>xx1000000364</p> <p>A Support base (4 pcs)</p> |
| 2 | Make sure the two <i>o-rings</i> on the circumference of the gearbox are seated properly in their respective groove. Lubricate them with <i>grease</i> . | <p>Art no. is specified in Required equipment on page 271.</p>  <p>xx0200000055</p> <ul style="list-style-type: none"> • A: Guide pin • C: O-ring 3HAB 3772-54 • D: O-ring 3HAB 3772-55 • E: Sealing ring 3HAC 11581-4 |

Continues on next page

4 Repair


4.7.1 Replacing the axis 1 gearbox

Continued

| | Action | Note |
|---|---|---|
| 3 | Make sure the small o-ring around the oil hole is fitted properly! |  xx1000001392 |
| 4 | Attach the <i>lifting accessory, base and gear 1</i> and the <i>lifting tool (chain)</i> to the gearbox. | Specified in Required equipment on page 271 .  xx1000001395 |
| 5 | Fit two <i>guide pins</i> in two of the attachment holes in the gearbox, parallel to each other. | Specified in Required equipment on page 271 . |
| 6 |  CAUTION The gearbox weighs . All lifting accessories used must be sized accordingly! | |

Continues on next page

4.7.1 Replacing the axis 1 gearbox
Continued



| | Action | Note |
|---|---|--|
| 7 | <p>Lift the gearbox. Make sure the guide pin in the bottom face of the gearbox is properly aligned with the base.</p> |  <p>xx1000001389</p> <p>xx1000001391</p> |
| 8 | <p>Lift gearbox axis 1 onto the guide pins and lower it carefully to its mounting position.</p> | <p>Always use guide pins in pairs!</p> |

Continues on next page






4 Repair

4.7.1 Replacing the axis 1 gearbox

Continued

| | Action | Note |
|----|--|--|
| 9 | Secure the gearbox with its <i>attachment screws</i> and washers. | <p>18 pcs, M16 x 70, 12.9 quality UN-BRAKO.</p> <p>Tightening torque: 300 Nm</p> <p>Reused screws may be used, providing they are lubricated as detailed in section Screw joints on page 340 before fitting.</p>  <p>xx0200000227</p> <p>A view from below:</p> <ul style="list-style-type: none">• A: Oil drain hose• B: Attachment screws, gearbox axis 1, 18 pcs• C: Washers, 3 pcs |
| 10 | Refit the cable guide in the center of gearbox 1 with its attachment screws. |  <p>xx1000001393</p> |

Continues on next page

| | Action | Note |
|----|---|--|
| 11 | <p>Refit the bottom plate underneath the robot base by pushing it into the groove and fitting the attachment screw.</p> <p>If removed, also refit the rear connector plate.</p> <p> Note</p> <p>Direct the bends on the bottom plate downwards!</p> | <p>1 screw: M6 x 8.</p>  <p>xx0300000612</p> <ul style="list-style-type: none"> • A: Bottom plate • B: Rear connector plate • C: Attachment screw • D: Groove |
| 12 | <p> CAUTION</p> <p>The base and axis 1 gearbox weighs 130 kg + .</p> <p>All lifting accessories used must be sized accordingly!</p> | |
| 13 | Lift the robot base and gearbox 1 and remove the base and gear support. | |
| 14 | Secure the base to the mounting site. | See Orienting and securing the robot on page 68 . |
| 15 | <p>Refit the complete arm system.</p> <p> CAUTION</p> <p>This is a complex task to be performed with utmost care in order to avoid injury or damage!</p> | See Replacing the base, including axis 1 gearbox on page 160 . |
| 16 | Perform a leak-down test. | See section Performing a leak-down test on page 138 . |
| 17 | Refill the gearbox with oil. | See Changing oil, axis-1 gearbox on page 119 . |
| 18 | Recalibrate the robot. | <p>Axis Calibration is described in Calibrating with Axis Calibration method on page 312.</p> <p>General calibration information is included in section Calibration on page 301.</p> |
| 19 | <p> DANGER</p> <p>Make sure all safety requirements are met when performing the first test run.</p> | |


4 Repair

4.7.2 Replacing the gearbox, axes 2- 3

4.7.2 Replacing the gearbox, axes 2- 3

Location of gearbox, axes 2-3

The axis-2 and axis-3 gearboxes are located on either side of the frame as shown in the figure.



| | |
|---|-----------------|
| A | Gearbox, axis 1 |
| B | Gearbox, axis 2 |
| C | Gearbox, axis 3 |
| D | Gearbox, axis 6 |

Required equipment

| Equipment, etc. | Art.no | Note |
|-------------------|---|---|
| Gearbox, axes 2-3 | For spare part no. see: <ul style="list-style-type: none">• Spare part lists on page 349. | |
| Sealing axes 2-3 | 3HAC022379-001 | Always replace. |
| O-ring | 3HAB3772-127 | Replace if damaged. |
| Lock screw M16x55 | - | Use to lock the lower arm. |
| Screw M12x50 | - | 2 pcs. Use to unload the balancing device. |
| Screw M12x100 | - | 2 pcs, must have full thread. Use to press the gearbox free from the frame. |
| Guide pins M12 | - | Use guide pins in pairs. |
| Lifting accessory | - | Roundsliding and a rotating lifting point. Lifting capacity: 100 kg. Used to lift the gearbox. |
| Guide sleeves | 3HAC14628-1/2 | Use to keep the sealing in place. |
| Grease | | Use to lubricate surfaces on the gearbox for easier assembly. |

Continues on next page

| Equipment, etc. | Art.no | Note |
|--|----------------|--|
| Bearing grease | 3HAC042536-001 | Shell Gadus S2 Option Foundry Plus |
| Rust preventive | 3HAC034903-001 | Mercasol 3110 Waxcoat |
| Standard toolkit | | Content is defined in section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.

| | Action | Note |
|---|--|--|
| 1 | Decide which calibration routine to use for calibrating the robot. <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |
| | <p>If the robot is to be calibrated with reference calibration:</p> <p>Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot.</p> <p>If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible.</p> | <p>Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values.</p> <p>Creating new values requires possibility to move the robot.</p> <p>Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i>.</p> |
| | <p>If the robot is to be calibrated with fine calibration:</p> <p>Remove all external cable packages (DressPack) and tools from the robot.</p> | |

Removal, axis-2 / axis-3 gearbox

Use this procedure to remove the axis-2 or axis-3 gearbox.



Note

Do not replace both gearboxes at the same time, unless the complete arm system is already removed!



| | Action | Note |
|---|--|------|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. | |

Continues on next page





4 Repair

4.7.2 Replacing the gearbox, axes 2- 3

Continued

| | Action | Note |
|---|--|--|
| 2 | <p>When removing axis 2 gearbox: Run the axis 2 to -42° and all other axes to 0° (calibration position).</p> <p>When removing axis 3 gearbox: Run the axis 2 to -40°, axis 3 to $+15^{\circ}$ and all other axes to 0°.</p> | |
| 3 | <p>When removing axis 2 gearbox: Remove all screws in the lower screw area on the inside of the lower arm (7 pcs M12, 2 pcs M16). See figure.</p> <p>When removing axis 3 gearbox: Remove all screws in the upper front screw area and three screws in the upper back area.</p> | <p>Axis 2:</p>  <p>xx110000623</p> <p>Axis 3:</p>  <p>xx110000624</p> |
| 4 | Run axis 2 to 0° . | |

Continues on next page




| | Action | Note |
|----|--|--|
| 5 | <p>Fit the <i>lock screw</i> in the lower arm to secure axis 2.</p> <p> CAUTION</p> <p>Tighten by hand!</p> |  <p>xx1000001101</p> |
| 6 | Secure the weight of the upper arm with roundslings in an overhead crane. | |
| 7 | Raise the lifting equipment to take the weight of the upper arm. | |
| 8 | Release the brakes of axis 2 to rest the weight of the axis against the lock screw. | |
| 9 | Release the brakes of axis 3 to rest the weight of the axis by the roundslings and overhead crane. | |
| 10 | <p>Remove the two plastic screws in the upper end of the balancing device.</p> <p> Note</p> <p>Keep the plastic screws. They will be refitted later.</p> |  <p>xx1000001111</p> |

Continues on next page





4 Repair

4.7.2 Replacing the gearbox, axes 2- 3

Continued

| | Action | Note |
|----|--|---|
| 11 | Insert two <i>screws, M12x50</i> in the holes to neutralize the spring force. Screw in the screws until they have proper contact with the cylinder inside. The length of the cylinder is now locked and the balancing device is unloaded. It should now be possible to easily rotate the balancing device. | See the previous figure! |
| 12 |  DANGER Turn off all: <ul style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply to the robot, before entering the robot working area. | |
| 13 | Drain the gearbox. | Detailed in section Draining, axes 2 and 3 on page 124.  Note Time-consuming activity! |
| 14 | Remove the motor cables of axis-2 or axis-3 motor, depending on which gearbox is being removed. Protect the cables from getting damaged and from oil spill. | |
| 15 | Remove one gearbox at a time! | |
| 16 | Remove the axis-2 or axis-3 motor, depending on which gearbox is being removed. | Detailed in section Replacing motors, axes 2 and 3 on page 253 |
| 17 | Remove all remaining <i>attachment screws</i> that secure the gearbox to the lower arm system. Axis 2: M16 and M12. Axis 3: M12. |  xx1000001405 |

Continues on next page




| | Action | Note |
|----|--|---|
| 18 | Remove the gearbox cover by removing its attachment screws. |  <p>xx1200000628</p> |
| 19 | Remove two opposite screws of the attachment screws that hold the gearbox and replace them with two guide pins. |  Note Always use guide pins in pairs! |
| 20 | Remove the remaining attachment screws. | |
| 21 | Fit the <i>lifting accessory</i> to the gearbox. | Art. no. is specified in Required equipment on page 282 . |
| 22 |  CAUTION The gearbox weighs 69 kg. All lifting accessories used must be sized accordingly! | |
| 23 | If required, apply two <i>screws, M12x100</i> to the holes in the gearbox, in order to press it free. (The screws need to have a full thread.) | |
| 24 |  CAUTION When the gearbox comes free from the frame and comes off the guide pins it will tilt and there is a risk of damage to the gearbox surfaces! Be aware of this and remove the gearbox carefully! | |

Continues on next page

4 Repair

4.7.2 Replacing the gearbox, axes 2- 3



Continued

| | Action | Note |
|----|---|--|
| 25 | Remove the gearbox axis 2-3 using an overhead crane or similar, with guidance from the fitted guide pins. |  <p>xx120000629</p> |
| 26 | Remove the sealing from the lower arm and clean it.  Note The sealing can hang onto the gearbox, sticking to the oil. |  <p>xx120000630</p> |

Continues on next page

Refitting, axis-2 / axis-3 gearbox

Use this procedure to refit the axes-2 or axis-3 gearbox.





| | Action | Note |
|---|--|--|
| 1 | <p>Make sure that the o-ring is fitted to the gearbox. Lightly lubricate it with <i>grease</i>.</p> |  <p>xx1000001404</p> <p>Specified in Required equipment on page 282.</p> |
| 2 | <p>Fit two <i>guide pins</i> in the frame. Use two of the attachment holes for the screws that hold the gearbox.</p> | |
| 3 | <p> CAUTION</p> <p>The gearbox weighs 69 kg! All lifting equipment used must be sized accordingly!</p> | |
| 4 | <p>Fit the <i>lifting accessory</i> to the gearbox and lift it with an overhead crane.</p> | <p>Specified in Required equipment on page 282.</p> |

Continues on next page




4 Repair

4.7.2 Replacing the gearbox, axes 2- 3

Continued

| | Action | Note |
|---|--|--|
| 5 | <p>Fit a new <i>sealing</i> to the gearbox and secure it to the gearbox by using two <i>guide sleeves</i>.</p> <p>When refitting axis 2 gearbox: Insert the guide sleeves in the two middle holes of the upper screw areas.</p> <p>When refitting axis 3 gearbox: Insert one guide sleeve in the middle screw hole in the upper back area and one guide sleeve in the middle screw hole in the the lower area.</p> | <p>Art. no. is specified in Required equipment on page 282.</p> <p>Axis 2:</p>  <p>xx1100000621</p> <p>Axis 3:</p>  <p>xx1100000622</p> |
| 6 | <p>Foundry Plus: Apply bearing grease on the highlighted areas on both sides of the sealing.</p> <p> Note</p> <p>Do not apply grease closer than 20 mm from the edge of the holes in the sealing.</p> |  <p>xx1400000993</p> |

Continues on next page




| | Action | Note |
|----|--|---|
| | <p><i>Foundry Plus:</i> Apply rust preventive on the highlighted area.</p> |  <p>xx1400001132</p> |
| 7 | <p>Lubricate necessary surfaces of the gearbox with <i>grease</i> in order to make it easier to insert the gearbox into the frame.</p> | <p>Specified in <i>Required equipment on page 282</i>.</p> |
| 8 | <p>Put the gearbox onto the guide pins and slide it carefully into place in the frame.</p> <p> Note Check that the sealing is in place during the procedure.</p> |  <p>xx1000001406</p> |
| 9 | <p>Use a crank to move the gears in order to find the holes for the attachment screws.</p> | |
| 10 | <p>Secure the gearbox to the lower arm with the <i>attachment screws</i> and <i>washers</i> in two of the screw areas (the third is not reachable at this point). Do not remove the guide sleeves yet.</p> | <p>Axis 2 M12x60 quality 12.9 Gleitmo (6+6 pcs) • Tightening torque: 120 Nm. M16x90 quality 12.9 Gleitmo (2+2 pcs) • Tightening torque: 300 Nm. Axis 3 M12x60 quality 12.9 Gleitmo • Tightening torque: 120 Nm.</p> |
| 11 | <p>Remove the two guide sleeves and replace them with the two remaining M12 screws.</p> | <p>M12x60 quality 12.9 Gleitmo (1+1 pc) • Tightening torque: 120 Nm.</p> |
| 12 | <p>Secure the gearbox to the frame.</p> | <p>M12, quality 8.8-A2F Tightening torque: 120 Nm.</p> |

Continues on next page



4 Repair

4.7.2 Replacing the gearbox, axes 2- 3

Continued

| | Action | Note |
|----|--|---|
| 13 | Clean the gearbox of residual grease. | |
| 14 | Apply locking liquid in the attachment holes for the gearbox cover. | Loctite 243. |
| 15 | Fit the <i>o-ring</i> in the cover. |  <p data-bbox="948 1070 1054 1093">xx1000001407</p> |
| 16 | Refit the cover with its attachment screws and washers.  Note Fit the cover so that the arrow on the cover points upwards! | M8x35 quality 8.8-A2F (12 pcs) Tightening torque: 24 Nm  <p data-bbox="948 1839 1054 1861">xx1000001408</p> |
| 17 | Refit the <i>motors axes 2-3</i> . | See Replacing motors, axes 2 and 3 on page 253 |
| 18 | Perform a leakdown test. | See Performing a leak-down test on page 138 . |

Continues on next page

| | Action | Note |
|----|---|---|
| 19 | Refill the gearbox axes 2-3 with oil. | See Filling, axes 2 and 3 on page 124 |
| 20 | Remove the screws that unload the balancing device and put back the plastic screws. |  <p>xx1000001111</p> |
| 21 | Remove the lock screw from the lower arm. | |
| 22 | Run the axes 2 and 3 to a position where the remaining screws in the lower arm can be fitted. | <p>Axis 2</p> <ul style="list-style-type: none"> • M12x60 quality 12.9 Gleitmo (6 pcs) • Tightening torque: 120 Nm. <p>M16x90 quality 12.9 Gleitmo (2 pcs)</p> <ul style="list-style-type: none"> • Tightening torque: 300 Nm. <p>Axis 3</p> <ul style="list-style-type: none"> • M12x60 quality 12.9 Gleitmo • Tightening torque: 120 Nm. |
| 23 | Recalibrate the robot. | <p>Axis Calibration is described in Calibrating with Axis Calibration method on page 312.</p> <p>General calibration information is included in section Calibration on page 301.</p> |
| 24 |  <p>DANGER</p> <p>Make sure all safety requirements are met when performing the first test run.</p> | |


4 Repair

4.7.3 Replacing gearbox axis 6

4.7.3 Replacing gearbox axis 6

Location of gearbox axis 6

The axis 6 gearbox is located in the center of the wrist as shown in the figure.



xx0600002627

| | |
|---|---|
| A | Turning disk |
| B | Attachment screws (6 pcs) turning disk |
| C | Tilthouse unit |
| D | Gearbox, axis 6 |
| E | Attachment screws and washers, gearbox axis 6 |

Required equipment

| Equipment | Art. no. | Note |
|------------------------------------|---|--|
| Gearbox axis 6 | For spare part no. see: <ul style="list-style-type: none">Spare part lists on page 349. | Includes o-ring |
| Turning disk | For spare part no. see: <ul style="list-style-type: none">Spare part lists on page 349. | |
| Washers | 3HAA1001-172 | Not included in gearbox. Replace only if damaged! |
| O-ring (type 2) 164.7x3.53 | 3HAB3772-57 | Must be replaced when reassembling gearbox. |
| O-ring (type 2) 150.0x2.0 | 3HAB3772-64 | Must be replaced when reassembling gearbox. |
| O-ring (type 2) 12 pcs 13.1x1.6 | 3HAB3772-61 | Must be replaced when reassembling gearbox. |
| Grease | 3HAC042536-001 | Shell Gadus S2 Used to lubricate the o-ring |

Continues on next page

| Equipment | Art. no. | Note |
|--|----------|--|
| Guide pins | - | Always use guide pins in pairs! |
| Standard toolkit | | The content is defined in the section Standard tools on page 344 . |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |

Deciding calibration routine

Decide which calibration routine to be used, based on the information in the table. Depending on which routine is chosen, action might be required prior to beginning the repair work of the robot, see the table.

| | Action | Note |
|---|--|--|
| 1 | Decide which calibration routine to use for calibrating the robot. <ul style="list-style-type: none"> Reference calibration. External cable packages (DressPack) and tools can stay fitted on the robot. Fine calibration. All external cable packages (DressPack) and tools must be removed from the robot. | |
| | <p>If the robot is to be calibrated with reference calibration:</p> <p>Find previous reference values for the axis or create new reference values. These values are to be used after the repair procedure is completed, for calibration of the robot.</p> <p>If no previous reference values exist, and no new reference values can be created, then reference calibration is not possible.</p> | <p>Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values.</p> <p>Creating new values requires possibility to move the robot.</p> <p>Read more about reference calibration for Axis Calibration in <i>Product manual - IRB 4600</i>.</p> |
| | <p>If the robot is to be calibrated with fine calibration:</p> <p>Remove all external cable packages (DressPack) and tools from the robot.</p> | |

Removing gearbox axis 6

Use this procedure to remove gearbox axis 6.



| | Action | Note |
|---|--|------|
| 1 | Decide which calibration routine to use, and take actions accordingly prior to beginning the repair procedure. | |
| 2 | Jog the robot to a position where the tilt-house unit is placed in an appropriate service position. | |

Continues on next page


4 Repair

4.7.3 Replacing gearbox axis 6

Continued


| | Action | Note |
|---|--|---|
| 3 | <p> DANGER</p> <p>Turn off all:</p> <ul style="list-style-type: none">• electric power supply• hydraulic pressure supply• air pressure supply <p>to the robot, before entering the robot working area.</p> | |
| 4 | Drain the <i>oil</i> from the gearbox. | See section <ul style="list-style-type: none">• Changing oil, gearbox axis 6 on page 126 |
| 5 | Remove the <i>turning disk</i> . | See section <ul style="list-style-type: none">• Replacing the turning disk on page 168 |
| 6 | Remove the gearbox by unscrewing the <i>attachment screws</i> and <i>washers</i> that secure it. | |
| 7 | If required apply two M8 screws in the holes shown in the figure, and press out the gearbox. |  <p>xx0200000220</p> <p>A: M8 holes for pressing out the gearbox</p> |

Continues on next page

| | Action | Note |
|---|---|--|
| 8 | Remove <i>gearbox axis 6</i> carefully without damaging pinion or gear. |  <p data-bbox="986 864 1091 882">xx1000001412</p> |
| 9 | Check the pinion. A damaged pinion must be replaced! | |

Refitting gearbox axis 6

Use this procedure to refit gearbox axis 6.



| | Action | Note |
|---|--|------|
| 1 |  <p data-bbox="592 1189 699 1218">DANGER</p> <p data-bbox="501 1249 632 1279">Turn off all:</p> <ul data-bbox="536 1285 863 1379" style="list-style-type: none"> • electric power supply • hydraulic pressure supply • air pressure supply <p data-bbox="501 1386 922 1438">to the robot, before entering the robot working area.</p> | |

Continues on next page


4 Repair

4.7.3 Replacing gearbox axis 6

Continued

| | Action | Note |
|---|---|---|
| 2 | <p>Make sure the <i>o-ring</i> is undamaged and fitted to the gearbox. If the o-ring is damaged, replace! Lubricate the o-ring with grease.</p> | <p>For art. no. see: Required equipment on page 294.</p>  <p>xx0200000221</p> |
| 3 | <p>Release the brakes of the axis 6 motor manually.</p> | <p>See section</p> <ul style="list-style-type: none"> • Manually releasing the brakes on page 60 |
| 4 | <p>Check that the <i>pinion</i> is undamaged on the axis 6 motor.</p> | |
| 5 | <p>Carefully insert the <i>axis 6 gearbox</i> into the tilthouse, using guide pins. Make sure the gears of the gearbox mate with the pinion of the axis 6 motor.</p> <p> CAUTION</p> <p>Do not damage pinion or gears in the process!</p> | |
| 6 | <p>Secure the gearbox with its <i>attachment screws</i> and <i>washers</i>. Reused screws may be used, providing they are lubricated as detailed in section Screw joints on page 340 before fitting.</p> | <p>8 pcs or 18 pcs (depending on wrist version): M8 x 40, 12.9 quality Gleitmo, Tightening torque: 30 Nm.</p> |
| 7 | <p>Refit the <i>turning disk</i>.</p> | <p>See section</p> <ul style="list-style-type: none"> • Replacing the turning disk on page 168 |
| 8 | <p>Perform a <i>leak-down test</i>.</p> | <p>See section</p> <ul style="list-style-type: none"> • See section Performing a leak-down test on page 138. |
| 9 | <p>Refill the gearbox with <i>oil</i>.</p> | <p>See section</p> <ul style="list-style-type: none"> • Changing oil, gearbox axis 6 on page 126 |

Continues on next page

| | Action | Note |
|----|--|--|
| 10 | Re-calibrate the robot. | Axis Calibration is described in Calibrating with Axis Calibration method on page 312 . General calibration information is included in section Calibration on page 301 . |
| 11 |  DANGER Make sure all safety requirements are met when performing the first test run. | |

This page is intentionally left blank

5 Calibration

5.1 Introduction to calibration

5.1.1 Introduction and calibration terminology

Calibration information

This chapter includes general information about the recommended calibration methods and also the detailed procedures for updating the revolution counters, checking the calibration position etc.

Detailed instructions of how to perform Axis Calibration are given on the FlexPendant during the calibration procedure. To prepare calibration with Axis Calibration method, see [Calibrating with Axis Calibration method on page 312](#).

Calibration terminology

| Term | Definition |
|---------------------------|---|
| Calibration method | A collective term for several methods that might be available for calibrating the ABB robot. Each method contains calibration routines. |
| Synchronization position | Known position of the complete robot where the angle of each axis can be checked against visual synchronization marks. |
| Calibration position | Known position of the complete robot that is used for calibration of the robot. |
| Standard calibration | A generic term for all calibration methods that aim to move the robot to calibration position. |
| Fine calibration | A calibration routine that generates a new zero position of the robot. |
| Reference calibration | <p>A calibration routine that in the first step generates a reference to current zero position of the robot. The same calibration routine can later on be used to recalibrate the robot back to the same position as when the reference was stored.</p> <p>This routine is more flexible compared to fine calibration and is used when tools and process equipment are installed.</p> <p>Requires that a reference is created before being used for recalibrating the robot.</p> <p>Requires that the robot is dressed with the same tools and process equipment during calibration as during creation of the reference values.</p> |
| Update revolution counter | A calibration routine to make a rough calibration of each manipulator axis. |
| Synchronization mark | Visual marks on the robot axes. When marks are aligned, the robot is in synchronization position. |

5 Calibration

5.1.2 Calibration methods

5.1.2 Calibration methods

Overview

This section specifies the different types of calibration and the calibration methods that are supplied by ABB.

Types of calibration

| Type of calibration | Description | Calibration method |
|----------------------|--|--------------------|
| Standard calibration | The calibrated robot is positioned at calibration position. Standard calibration data is found on the SMB (serial measurement board) or EIB in the robot. For robots with RobotWare 5.04 or older, the calibration data is delivered in a file, <code>calib.cfg</code> , supplied with the robot at delivery. The file identifies the correct resolver/motor position corresponding to the robot home position. | Axis Calibration |

Brief description of calibration methods

Axis Calibration method

Axis Calibration is a standard calibration method for calibration of IRB 660. It is the recommended method in order to achieve proper performance.

The following routines are available for the Axis Calibration method:

- Fine calibration
- Update revolution counters
- Reference calibration

The calibration equipment for Axis Calibration is delivered as a toolkit.

An introduction to the calibration method is given in this manual, see [Calibrating with Axis Calibration method on page 312](#).

The actual instructions of how to perform the calibration procedure and what to do at each step is given on the FlexPendant. You will be guided through the calibration procedure, step by step.

References

Article numbers for the calibration tools are listed in the section [Special tools on page 345](#).

5.1.3 When to calibrate

When to calibrate

The system must be calibrated if any of the following situations occur.

The resolver values are changed

If resolver values are changed, the robot must be re-calibrated using the calibration methods supplied by ABB. Calibrate the robot carefully with standard calibration, according to information in this manual.

The resolver values will change when parts affecting the calibration position are replaced on the robot, for example motors or parts of the transmission.

The revolution counter memory is lost

If the revolution counter memory is lost, the counters must be updated. See [Updating revolution counters on page 306](#). This will occur when:

- The battery is discharged
- A resolver error occurs
- The signal between a resolver and measurement board is interrupted
- A robot axis is moved with the control system disconnected

The revolution counters must also be updated after the robot and controller are connected at the first installation.

The robot is rebuilt

If the robot is rebuilt, for example, after a crash or when the reachability of a robot is changed, it needs to be re-calibrated for new resolver values.

5 Calibration

5.2.1 Synchronization marks and synchronization position for axes


5.2 Synchronization marks and axis movement directions

5.2.1 Synchronization marks and synchronization position for axes

Introduction

This section shows the position of the synchronization marks and the synchronization position for each axis.

Synchronization marks, IRB 660



xx0500002487

| | |
|---|--|
| A | Synchronization plate, axis 1 |
| B | Synchronization tab on robot |
| C | Synchronization mark, axis 2 |
| D | Synchronization mark, axis 3 |
| E | Synchronization plate and mark, axis 6 |

Synchronization marks at axes 2 and 3

The synchronization marks at axes 2, 3 and 6, shown in the figure above, consist of two single marks that should be positioned opposite to one another when the robot is standing in its synchronization position. One of the marks is more narrow than the other and should be positioned within the limits of the wider mark.

5.2.2 Calibration movement directions for all axes


Overview

When calibrating, the axis must consistently be run towards the calibration position in the same direction in order to avoid position errors caused by backlash in gears and so on. Positive directions are shown in the graphic below.

Calibration service routines will handle the calibration movements automatically and these might be different from the positive directions shown below.

Manual movement directions, 4 axes

Note! The graphic shows an IRB 260. The positive direction is the same for all 4-axis robots



xx0500001927

5 Calibration

5.3.1 Updating revolution counters on IRC5 robots

5.3 Updating revolution counters

5.3.1 Updating revolution counters on IRC5 robots

Introduction

This section describes how to do a rough calibration of each manipulator axis by updating the revolution counter for each axis, using the FlexPendant.

Step 1 - Manually running the manipulator to the synchronization position

Use this procedure to manually run the manipulator to the synchronization position.

| | Action | Note |
|---|--|---|
| 1 | Select axis-by-axis motion mode. | |
| 2 | Jog the manipulator to align the synchronization marks. | See Synchronization marks and synchronization position for axes on page 304 . |
| 3 | When all axes are positioned, update the revolution counter. | Step 2 - Updating the revolution counter with the FlexPendant on page 307 . |

Correct calibration position of axis 4 and 6

When jogging the manipulator to synchronization position, it is extremely important to make sure that axes 4 and 6 of the following mentioned manipulators are positioned correctly. The axes can be calibrated at the wrong turn, resulting in an incorrect manipulator calibration.

Make sure the axes are positioned according to the correct calibration values, not only according to the synchronization marks. The correct values are found on a label, located either on the lower arm, underneath the flange plate on the base or on the frame.

At delivery the manipulator is in the correct position. Do NOT rotate axis 4 or 6 at power up before the revolution counters are updated.

If one of the following mentioned axes are rotated one or more turns from its calibration position before updating the revolution counter, the correct calibration position will be lost due to non-integer gear ratio. This affects the following manipulators:



| Manipulator variant | Axis 4 | Axis 6 |
|---------------------|--------|--------|
| IRB 660 | - | No |

If the synchronization marks seem to be wrong (even if the motor calibration data is correct), try to rotate the axis one turn, update the revolution counter and check the synchronization marks again (try both directions, if needed).

Continues on next page

Step 2 - Updating the revolution counter with the FlexPendant

Use this procedure to update the revolution counter with the FlexPendant (IRC5).

| Action | |
|--------|---|
| 1 | <p>On the ABB menu, tap Calibration.</p>  <p>xx150000942</p> |
| 2 | <p>All mechanical units connected to the system are shown with their calibration status. Tap the mechanical unit in question.</p>  <p>xx150000943</p> |

Continues on next page


5 Calibration

5.3.1 Updating revolution counters on IRC5 robots

Continued

Action

3 This step is valid for RobotWare 6.02 and later.
Calibration method used at factory for each axis is shown, as well as calibration method used during last field calibration.
Tap **Manual Method (Advanced)**.



Manual sbb_robcal_Bui.. (IN-L-BTGIS..) Motors On Stopped (Speed 100%)

Calibration - ROB_1

ROB_1: Calibrated


Calibration Method Overview

| Axis | Factory Method Used | Latest Method Used |
|--------|---------------------|--------------------|
| rob1_1 | Axis Calibration | Axis Calibration |
| rob1_2 | Axis Calibration | Manual |
| rob1_3 | Axis Calibration | Manual |
| rob1_4 | Axis Calibration | Axis Calibration |
| rob1_5 | Axis Calibration | Axis Calibration |
| rob1_6 | Axis Calibration | Manual |

Manual Method (Advanced) Run Calibration Method Close

xx1500000944

4 A screen is displayed, tap **Rev. Counters**.



Manual MySystem (RSTEST4) Motors On Stopped (2 of 2) (Speed 100%)

Calibration - ROB_1

Update Revolution Counters...

Rev. Counters

Calib. Parameters


SMB Memory

Base Frame

Close

en0400000771

Continues on next page

| | Action |
|---|---|
| 5 | <p>Tap Update Revolution Counters...</p> <p>A dialog box is displayed, warning that updating the revolution counters may change programmed robot positions:</p> <ul style="list-style-type: none"> • Tap Yes to update the revolution counters. • Tap No to cancel updating the revolution counters. <p>Tapping Yes displays the axis selection window.</p> |
| 6 | <p>Select the axis to have its revolution counter updated by:</p> <ul style="list-style-type: none"> • Ticking in the box to the left • Tapping Select all to update all axes. <p>Then tap Update.</p> |
| 7 | <p>A dialog box is displayed, warning that the updating operation cannot be undone:</p> <ul style="list-style-type: none"> • Tap Update to proceed with updating the revolution counters. • Tap Cancel to cancel updating the revolution counters. <p>Tapping Update updates the selected revolution counters and removes the tick from the list of axes.</p> |
| 8 | <p> CAUTION</p> <p>If a revolution counter is incorrectly updated, it will cause incorrect manipulator positioning, which in turn may cause damage or injury!</p> <p>Check the synchronization position very carefully after each update. See Checking the synchronization position on page 326.</p> |

5 Calibration

5.3.2 Updating revolution counters on OmniCore robots

5.3.2 Updating revolution counters on OmniCore robots

Introduction

This section describes how to do a rough calibration of each manipulator axis by updating the revolution counter for each axis, using the FlexPendant.



Step 1 - Manually running the manipulator to the synchronization position

Use this procedure to manually run the manipulator to the synchronization position.


| | Action | Note |
|---|--|---|
| 1 | Select axis-by-axis motion mode. | |
| 2 | Jog the manipulator to align the synchronization marks. | See Synchronization marks and synchronization position for axes on page 304 . |
| 3 | When all axes are positioned, update the revolution counter. | Step 2 - Updating the revolution counter with the FlexPendant on page 310 . |

Step 2 - Updating the revolution counter with the FlexPendant

Use this procedure to update the revolution counter with the FlexPendant (OmniCore).

| | Action |
|---|---|
| 1 | On the start screen, tap Calibrate . |
| 2 | Select Calibration from the menu. The Mechanical Units page displays a list of available mechanical units.  Note This step is required only if you are not already in the Mechanical Unit page when you open Calibrate .  Note The Mechanical Unit page is displayed only if there are more than one mechanical unit available. Otherwise, the calibration summary page for the available mechanical unit is displayed. |
| 3 | Select the mechanical unit for which revolution counter need to be updated. |
| 4 | The calibration summary page for the selected mechanical unit is displayed. Calibration method used at factory for each axis is shown, as well as calibration method used during last field calibration. |
| 5 | Tap Calibration Methods on the right pane. The calibration options are displayed. |
| 6 | Tap Revolution Counters . |
| 7 | In the Selection column select the axes for which revolution counters need to be updated. |
| 8 | Tap Update . A dialog box is displayed, warning that the updating operation cannot be undone: <ul style="list-style-type: none">• Tap Update to proceed with updating the revolution counters.• Tap Cancel to cancel updating the revolution counters. Tapping Update and a confirmation window is displayed. |

Continues on next page

| Action | |
|--------|--|
| 9 | Tap OK. The revolution counter for the selected axes is updated. |
| 10 |  CAUTION If a revolution counter is incorrectly updated, it will cause incorrect manipulator positioning, which in turn may cause damage or injury! Check the synchronization position very carefully after each update. See Checking the synchronization position on page 326 . |

5 Calibration

5.4.1 Description of Axis Calibration

5.4 Calibrating with Axis Calibration method

5.4.1 Description of Axis Calibration

Instructions for Axis Calibration procedure given on the FlexPendant

The actual instructions of how to perform the calibration procedure and what to do at each step is given on the FlexPendant. You will be guided through the calibration procedure, step by step.

This manual contains a brief description of the method, additional information to the information given on the FlexPendant, article number for the tools and images of where to fit the calibration tools on the robot.

Overview of the Axis Calibration procedure

The Axis Calibration procedure applies to all axes, and is performed on one axis at the time. The robot axes are both manually and automatically moved into position, as instructed on the FlexPendant.

A fixed calibration pin/bushing is installed on each robot axis at delivery.

The Axis Calibration procedure described roughly:

- 1 A removable calibration tool is inserted by the operator into a calibration bushing on the axis chosen for calibration, according to instructions on the FlexPendant.



WARNING

Calibrating the robot with Axis Calibration requires special calibration tools from ABB. Using other pins in the calibration bushings may cause severe damage to the robot and/or personnel.



WARNING

The calibration tool must be fully inserted into the calibration bushing, until the steel spring ring snaps into place.

- 2 During the calibration procedure, RobotWare moves the robot axis chosen for calibration so that the calibration tools get into contact. RobotWare records values of the axis position and repeats the coming-in-contact procedure several times to get an exact value of the axis position.



WARNING

Risk of pinching! The contact force for large robots can be up to 150 kg. Keep a safe distance to the robot.

- 3 The axis position is stored in RobotWare with an active choice from the operator.

Continues on next page

Routines in the calibration procedure

The following routines are available in the Axis Calibration procedure, given at the beginning of the procedure on the FlexPendant.

Fine calibration routine

Choose this routine to calibrate the robot when there are no tools, process cabling or equipment fitted to the robot.

Reference calibration routine

Choose this routine to create reference values and to calibrate the robot when the robot is dressed with tools, process cabling or other equipment.



Note

When calibrating the robot with the reference calibration routine, the robot must be dressed with the same tools, process cabling and any other equipment as when the reference values were created.

If calibrating the robot with reference calibration there must be reference values created before repair is made to the robot, if values are not already available. Creating new values requires possibility to move the robot. The reference values contain positions of all axes, torque of axes and technical data about the tool installed. A benefit with reference calibration is that the current state of the robot is stored and not the state when the robot left the ABB factory. The reference value will be named according to tool name, date etc.

Follow the instructions given in the reference calibration routine on the FlexPendant to create reference values.

When reference calibration is performed, the robot is restored to the status given by the reference values.

Update revolution counters

Choose this routine to make a rough calibration of each manipulator axis by updating the revolution counter for each axis, using the FlexPendant.

Validation

In the mentioned routines, it is also possible to validate the calibration data.

Position of robot axes

The robot axes should be positioned close to 0 degrees before commencing the calibration program. The axis chosen for calibration is then automatically run by the calibration program to its exact calibration position during the calibration procedure.

It is possible to position some of the other axes in positions different from 0 degrees. Information about which axes are allowed to be jogged is given on the FlexPendant.

Continues on next page

5 Calibration

5.4.1 Description of Axis Calibration

Continued

These axes are marked with **Unrestricted** in the FlexPendant window. Also the following table shows the dependencies between the axes.

Requirements for axis positioning during calibration

| Required position of axis | Axis to calibrate | | | | | |
|---------------------------|-------------------|--------|--------|--------|--------|--------|
| | Axis 1 | Axis 2 | Axis 3 | Axis 4 | Axis 5 | Axis 6 |
| Axis 1 | - | * | * | | | * |
| Axis 2 | 0 | - | 0 | | | * |
| Axis 3 | 0 | 0 | - | | | * |
| Axis 6 | * | * | * | | | - |

| | |
|---|--|
| - | Axis to be calibrated |
| * | Unrestricted. Axis is allowed to be jogged to other position than 0 degrees. |
| 0 | Axis must be put in position 0 degrees. |

System containing SafeMove

SafeMove will lose its synchronization to the controller if a new calibration is done. New calibration values have to be downloaded to SafeMove, and a new SafeMove calibration has to be done. Make sure that the user rights admit to change the safety settings and to synchronize SafeMove.

For robots with EPS, the same applies as for SafeMove.

5.4.2 Calibration tools for Axis Calibration

Calibration tool set

The calibration tools used for Axis Calibration are designed to meet requirements for calibration performance, durability and safety in case of accidental damage. The calibration tool will eventually break from fatigue after longer period of use and then needs to be replaced. There is no risk for bad calibrations as long as the calibration tool is in one piece.



WARNING

Calibrating the robot with Axis Calibration requires special calibration tools from ABB. Using other pins in the calibration bushings may cause severe damage to the robot and/or personnel.

| Equipment, etc. | Article number | Note |
|--|----------------|--|
| Calibration tool box, Axis Calibration | 3HAC055412-001 | Delivered as a set of calibration tools. Required if Axis Calibration is the valid calibration method for the robot. |

Examining the calibration tool


Check prior to usage

Before using the calibration tool, make sure that the tube insert, the plastic protection and the steel spring ring are present.



WARNING

If any part is missing or damaged, the tool must be replaced immediately.



xx1500001914

| | |
|---|--------------------|
| A | Tube insert |
| B | Plastic protection |
| C | Steel spring ring |

Continues on next page

5 Calibration


5.4.2 Calibration tools for Axis Calibration

Continued

Periodic check of the calibration tool

If including the calibration tool in a local periodic check system, the following measures should be checked.

- Outer diameter within $\varnothing 12g4$ mm, $\varnothing 8g4$ mm or $\varnothing 6g5$ mm (depending on calibration tool size).
- Straightness within 0.005 mm.



xx150000951

| | |
|---|----------------|
| A | Outer diameter |
|---|----------------|

Identifying the calibrating tools

It is possible to make the calibration tool identifiable with, for example, an RFID chip. The procedure of how to install an RFID chip is described below.



Note

The tool identifier is NOT delivered from ABB, it is a customized solution.

| | Action | Note |
|---|---|------|
| 1 | <p>It is possible to use any RFID solution, with the correct dimensions. ABB has verified function on some suppliers fulfilling the requirements of NFC compatible devices (13.56 Mhz) according to ISO 14443 or ISO 15693.</p> <div style="margin-top: 10px;"> <p>Note</p> <p>The maximum dimensions on the RFID chip must not exceed $\varnothing 7.9$ mm x 8.0 mm, $\varnothing 5.9$ mm x 8.0 mm or $\varnothing 3.9$ mm x 8.0 mm (depending on calibration tool size).</p> </div> | |
| 2 | <p>There is a cavity on one end of the calibration tool in which the RFID chip can be installed.</p> <p>Install the RFID chip according to supplier instructions.</p> <p>Install the chip in flush with the tool end.</p> | |


5.4.3 Installation locations for the calibration tools

Location of fixed calibration items

This section shows how the robot is equipped with items for installation of calibration tools for Axis Calibration (fixed calibration pins and/or bushings). Installed calibration tools are not shown.

A fixed calibration pin and a bushing for the movable calibration tool are located on each axis as follows.

If there is not enough space on an axis to install a fixed calibration pin, the axis is equipped with two bushings instead, for installation of two calibration tools when calibration is carried out. This is shown in the figure.



xx160000699

The fixed calibration pin for axis 1 is installed on a removable tower. The tower will need to be removed if electronic position switches are fitted to the robot. Keep the tower in a safe location for future recalibration needs and mark it with robot serial number to ensure that the correct one is refitted.

Continues on next page

5 Calibration

5.4.3 Installation locations for the calibration tools

Continued

Spare parts

When calibration is not being performed, a protective cover and an o-ring should always be installed on the fixed calibration pin as well as a protective plug, included a sealing, in the bushing. Replace damaged parts with new.

| Spare part | Article number | Note |
|-------------------------------|----------------|---|
| Protection cover and plug set | 3HAC056806-001 | Contains replacement calibration pin covers and protective plugs for the bushing. |

5.4.4 Axis Calibration - Running the calibration procedure

Required tools

The calibration tools used for Axis Calibration are designed to meet requirements for calibration performance, durability and safety in case of accidental damage.



WARNING

Calibrating the robot with Axis Calibration requires special calibration tools from ABB. Using other pins in the calibration holes may cause severe damage to the robot and/or personnel.

| Equipment, etc. | Article number | Note |
|--|----------------|--|
| Calibration tool box, Axis Calibration | 3HAC055412-001 | Delivered as a set of calibration tools. Required if Axis Calibration is the valid calibration method for the robot. |

Required consumables

| Consumable | Article number | Note |
|-------------|----------------|------|
| Clean cloth | - | |

Spare parts

| Spare part | Article number | Note |
|-------------------------------|----------------|---|
| Protection cover and plug set | 3HAC056806-001 | Contains replacement calibration pin covers and protective plugs for the bushing. |

Overview of the calibration procedure on the FlexPendant

The actual instructions of how to perform the calibration procedure and what to do at each step is given on the FlexPendant. You will be guided through the calibration procedure, step by step.

Use the following list to learn about the calibration procedure before running the RobotWare program on the FlexPendant. It gives you a brief overview of the calibration procedure.

After the calibration method has been started on the FlexPendant, the following sequence will be run.

- 1 Choose calibration routine. The routines are described in [Routines in the calibration procedure on page 313](#).
- 2 Choose which axis/axes to calibrate.
- 3 The robot moves to synchronization position.
- 4 Validate the synchronization marks.
- 5 The robot moves to preparation position.
- 6 Remove the protective cover from the fixed pin and the protection plug from the bushing, if any, and install the calibration tool.

Continues on next page

5 Calibration

5.4.4 Axis Calibration - Running the calibration procedure



Continued

- 7 The robot performs a measurement sequence by rotating the axis back and forth.
- 8 Remove the calibration tool and reinstall the protective cover on the fixed pin and the protection plug in the bushing, if any.
- 9 The robot moves to verify that the calibration tool is removed.
- 10 Choose whether to save the calibration data or not.

Calibration of the robot is not finished until the calibration data is saved, as last step of the calibration procedure.


Preparation prior to calibration

The calibration procedure is described in the FlexPendant while conducting it.

| | Action | Note |
|---|--|--------------------|
| 1 |  DANGER While conducting the calibration, the robot needs to be connected to power. Make sure that the robot's working area is empty, as the robot can make unpredictable movements. | |
| 2 | Wipe the calibration tool clean.  Note The calibration method is exact. Dust, dirt or color flakes will affect the calibration value. | Use a clean cloth. |

Starting the calibration procedure

Use this procedure to start the Axis Calibration routine on the FlexPendant.

| | Action | Note |
|---|--|--|
| 1 | Tap the calibration icon and enter the calibration main page. | |
| 2 | All mechanical units connected to the system are shown with their calibration status. Tap the mechanical unit in question.  Note For RobotWare 7, the mechanical unit page is displayed only if there is more than one mechanical unit available. | |
| 3 | The calibration method used at ABB factory for each axis is shown, as well as calibration method used for the robot during last field calibration. | The FlexPendant will give all information needed to proceed with Axis Calibration. |
| 4 | Valid for RobotWare 6 Tap Call Calibration Method . The software will automatically call for the procedure for the valid calibration method. If not, tap Call Routine and then tap Axis calibration . | |

Continues on next page

5.4.4 Axis Calibration - Running the calibration procedure

Continued

| | Action | Note |
|---|---|---|
| 5 | Valid for RobotWare 7 Tap Calibration Methods on the right pane and then tap Calibration . The software will automatically call for the procedure for the valid calibration method. | |
| 6 | Follow the instructions given on the FlexPendant. | A brief overview of the sequence that will be run on the FlexPendant is given in Overview of the calibration procedure on the FlexPendant on page 319 . |

Restarting an interrupted calibration procedure

If the Axis Calibration procedure is interrupted before the calibration is finished, the RobotWare program needs to be started again. Use this procedure to take required action.

| Situation | Action |
|--|---|
| The three-position enabling device on the FlexPendant has been released during robot movement. | Press and hold the three-position enabling device and press Play . |
| The RobotWare program is terminated with PP to Main . | Remove the calibration tool, if it is installed, and restart the calibration procedure from the beginning. See Starting the calibration procedure . If the calibration tool is in contact the robot axis needs to be jogged in order to release the calibration tool. Jogging the axis in wrong direction will cause the calibration tool to break. Directions of axis movement is shown in Calibration movement directions for all axes on page 305 |

Axis Calibration with SafeMove option

To be able to run Axis Calibration, SafeMove needs to be unsynchronized. The Axis Calibration routine recognizes if the robot is equipped with SafeMove and will force SafeMove to unsynchronize automatically.

However, SafeMove may generate other warning messages anytime during the Axis Calibration routine. When a warning message is displayed, tap **Acknowledge** to confirm the unsynchronized state and continue Axis Calibration procedure.



CAUTION

SafeMove must be synchronized after the calibration is completed.



Continues on next page

5 Calibration

5.4.4 Axis Calibration - Running the calibration procedure

Continued

After calibration

| | Action | Note |
|---|---|--|
| 1 | Check the o-ring on the fixed calibration pin. Replace if damaged or missing. | |
| 2 | Reinstall the protective cover on the fixed calibration pin on each axis, directly after the axis has been calibrated. Replace the cover with new spare part, if missing or damaged. |  <p data-bbox="1027 725 1139 745">xx1600002102</p> <p data-bbox="1027 763 1366 817">Protection cover and plug set: 3HAC056806-001.</p> |
| 3 | Reinstall the protective plug and sealing in the bushing on each axis, directly after the axis has been calibrated. Ensure that the sealing is not damaged. Replace the plug and the sealing with new spare part, if missing or damaged. |  <p data-bbox="1027 1164 1139 1184">xx1500000952</p> <p data-bbox="1027 1202 1366 1256">Protection cover and plug set: 3HAC056806-001.</p> |

5.4.5 Reference calibration

Brief introduction to Reference Calibration

Reference calibration is a faster method compared to Fine calibration, as it refers to a previously made calibration.

- 1 Create a backup of the current robot system.
- 2 Check that the active calibration offset values corresponds to the values on the silver label (on the lower arm or the base).
- 3 Jog the manipulator so that all axes are in zero position (ex use `MoveAbsJ` instruction). Check that all axis scales are aligned with calibration marks.
- 4 If the scales differ from calibration marks it might depend on wrong turns of the revolution counters. Make a marker line on the corresponding axis to be able to validate the result of the calibration. If more than one motor revolutions are wrong, the calibration will fail.
- 5 Use a verification position. This is especially recommended if all axes were not aligned with the synchronization marks (step 3). Reuse an existing position that is suitable and accurate so it can be used to validate the repair. Use a position where a deviation in axis calibration gives a big deviation in positioning. Note! Check the position after each repair in one axis.
- 6 Use Reference calibration to save reference values for all axes that is to be replaced. Make sure that the values are saved in RobotStudio or FTP program. The files are located in "Active system folder name/HOME/RefCalibFiles".
- 7 Perform the repair.
- 8 Make sure that the tooling and process equipment are the same as when creating the reference. Use Reference calibration to update the system with new calibration offset value for the repaired axis.
- 9 Check the position against the verification position (step 5).
- 10 Proceed with the repair of the next axis, if necessary, and repeat (step 8-9) for every axis.
- 11 (For system containing SafeMove or EPS) Download new calibration values to SafeMove. Use Visual SafeMove in RobotStudio.(For system containing SafeMove) Download new calibration values to SafeMove. Use Visual SafeMove in RobotStudio.
- 12 (For system containing SafeMove or EPS) Synchronize SafeMove to activate SafeMove.(For system containing SafeMove) Synchronize SafeMove to activate SafeMove.
- 13 Perform test run.
- 14 Update the label for resolver values with new calibration values.

Manual tuning of calibration offset

Manual tuning of calibration offset is normally not needed, but can be useful in some situations. The requirement to do manual tuning is that there is a known accurate position, that worked accurately before the repair (step 5, see [Brief introduction to Reference Calibration on page 323](#)).

Continues on next page

5 Calibration

5.4.5 Reference calibration

Continued

Example "Adjust axis 4":

- 1 Create a backup.
- 2 Run the manipulator to the verification position. (The manipulator position is now deviating from the verification position.)
- 3 Read and note current axis 4 value in degrees (example: 96.3 degrees).
- 4 Manually jog, only axis 4, so that the manipulator is correctly positioned to the verification position.
- 5 Read and note current axis 4 value in degrees (example: 94.2 degrees).
- 6 Move the manipulator to its calibration position.
- 7 Calculate the angle difference (ie $96.3 - 94.2 = 2.1$ degrees).
- 8 Manually jog axis 4 the calculated angle difference (-2.1). NOTE! The direction +/- shall be the same direction as the direction used when axis 4 was manually jogged to coincide with the verification process. In the example -2.1 degrees.
- 9 Make a new manual fine calibration of axis 4 with axis in -2.1 degrees position.
- 10 Check again against the verification position.
- 11 Repeat the manual tuning if needed.
- 12 Create a new reference if the intention is to use the reference in the future.

5.5 Verifying the calibration

Introduction

Always verify the results after calibrating *any* robot axis to verify that all calibration positions are correct.

Verifying the calibration

Use this procedure to verify the calibration result.

| | Action | Note |
|---|--|---|
| 1 | Run the calibration home position program twice. Do not change the position of the robot axes after running the program! | See Checking the synchronization position on page 326 . |
| 2 | Adjust the <i>synchronization marks</i> when the calibration is done, if necessary. | This is detailed in section Synchronization marks and synchronization position for axes on page 304 . |
| 3 | Write down the values on a new label and stick it on top of the calibration label. The label is located on the lower arm. | |

5 Calibration

5.6 Checking the synchronization position

5.6 Checking the synchronization position

Introduction

Check the synchronization position of the robot before beginning any programming of the robot system. This may be done:

- Using a `MoveAbsJ` instruction with argument zero on all axes.
- Using the **Jogging** window on the FlexPendant. Using the **Jog** window on the FlexPendant.

Using a `MoveAbsJ` instruction

Use this procedure to create a program that runs all the robot axes to their synchronization position.

| | Action | Note |
|---|--|--|
| 1 | On ABB menu tap Program editor . | |
| 2 | Create a new program. | |
| 3 | Use MoveAbsJ in the Motion&Proc menu. | |
| 4 | Create the following program: <pre>MoveAbsJ [[0,0,0,0,0,0], [9E9,9E9,9E9,9E9,9E9,9E9]] \NoEOffs, v1000, fine, tool0</pre> | |
| 5 | Run the program in manual mode. | |
| 6 | Check that the synchronization marks for the axes align correctly. If they do not, update the revolution counters. | See Synchronization marks and synchronization position for axes on page 304 and Updating revolution counters on page 306 . |

Using the jogging window

Use this procedure to jog the robot to the synchronization position of all axes.

| | Action | Note |
|---|---|--|
| 1 | On the ABB menu, tap Jogging . | |
| 2 | Tap Motion mode to select group of axes to jog. | |
| 3 | Tap to select the axis to jog, axis 1, 2, or 3. | |
| 4 | Manually run the robots axes to a position where the axis position value read on the FlexPendant, is equal to zero. | |
| 5 | Check that the synchronization marks for the axes align correctly. If they do not, update the revolution counters. | See Synchronization marks and synchronization position for axes on page 304 and Updating revolution counters on page 306 . |

Continues on next page

Using a MoveAbsJ instruction

Use this procedure to create a program that runs all the robot axes to their synchronization position.

| | Action | Note |
|---|---|--|
| 1 | Tap Code . | |
| 2 | Create a new program. | |
| 3 | Use MoveAbsJ in the Add Instruction menu. | |
| 4 | Create the following program: <pre>MoveAbsJ [[0,0,0,0,0,0], [9E9,9E9,9E9,9E9,9E9,9E9]] \NoEOfs, v1000, fine, tool0</pre> | |
| 5 | Run the program in manual mode. | |
| 6 | Check that the synchronization marks for the axes align correctly. If they do not, update the revolution counters. | See Synchronization marks and synchronization position for axes on page 304 and Updating revolution counters on page 306 . |

Using the jogging window

Use this procedure to jog the robot to the synchronization position of all axes.

| | Action | Note |
|---|--|--|
| 1 | Tap Jog . | |
| 2 | From the Mechanical unit list select a mechanical unit. | |
| 3 | From the Motion mode section, select an axis-set that need to be jogged. For example, to jog axis 2, select the axis set Axis 1-3 . | |
| 4 | Follow the screen instruction on joystick movements to understand the direction of the axis that you want to move and move the joystick. | |
| 5 | Manually run the robots axes to a position where the axis position value read on the FlexPendant, is equal to zero. | |
| 6 | Check that the synchronization marks for the axes align correctly. If they do not, update the revolution counters. | See Synchronization marks and synchronization position for axes on page 304 and Updating revolution counters on page 306 . |

This page is intentionally left blank

6 Decommissioning

6.1 Introduction to decommissioning

Introduction

This section contains information to consider when taking a product, robot or controller, out of operation.

It deals with how to handle potentially dangerous components and potentially hazardous materials.



Note

The decommissioning process shall be preceded by a risk assessment.

Disposal of materials used in the robot

All used grease/oils and dead batteries **must** be disposed of in accordance with the current legislation of the country in which the robot and the control unit are installed.

If the robot or the control unit is partially or completely disposed of, the various parts **must** be grouped together according to their nature (which is all iron together and all plastic together), and disposed of accordingly. These parts **must** also be disposed of in accordance with the current legislation of the country in which the robot and control unit are installed.

See also [Environmental information on page 330](#).

Transportation

Prepare the robot or parts before transport, this to avoid hazards.

6 Decommissioning

6.2 Environmental information


6.2 Environmental information

Introduction

ABB robots contain components in different materials. During decommissioning, all materials should be dismantled, recycled, or reused responsibly, according to the relevant laws and industrial standards. Robots or parts that can be reused or upcycled helps to reduce the usage of natural resources.

Symbol

The following symbol indicates that the product must not be disposed of as common garbage. Handle each product according to local regulations for the respective content (see table below).



xx1800000058

Materials used in the product

The table specifies some of the materials in the product and their respective use throughout the product.

Dispose components properly according to local regulations to prevent health or environmental hazards.

| Material | Example application |
|------------------------|---|
| Aluminium | Covers, synchronization brackets |
| Batteries, Lithium | Serial measurement board |
| Cast iron/nodular iron | Base, lower arm, upper arm |
| Copper | Cables, motors |
| Neodymium | Brakes, motors |
| Oil, grease | Gearboxes |
| Plastic/rubber | Cables, connectors, drive belts, and so on. |
| Steel | Gears, screws, base frame, and so on. |

Continues on next page

Oil and grease

Where possible, arrange for oil and grease to be recycled. Dispose of via an authorized person/contractor in accordance with local regulations. Do not dispose of oil and grease near lakes, ponds, ditches, down drains, or onto soil. Incineration must be carried out under controlled conditions in accordance with local regulations.

Also note that:

- Spills can form a film on water surfaces causing damage to organisms. Oxygen transfer could also be impaired.
- Spillage can penetrate the soil causing ground water contamination.

6 Decommissioning

6.3 Scrapping of robot

6.3 Scrapping of robot



Note

The decommissioning process shall be preceded by a risk assessment.

Important when scrapping the robot



DANGER

The risk assessment should consider hazards arising in the decommissioning, such as, but not limited to:

- Always remove all batteries. If a battery is exposed to heat, for example from a blow torch, it will explode.
- Always remove all oil/grease in gearboxes. If exposed to heat, for example from a blow torch, the oil/grease will catch fire.
- When motors are removed from the robot, the robot will collapse if it is not properly supported before the motor is removed.
- A used robot does not have the same performance as on delivery. Springs, brakes, bearings, and other parts might be worn or broken.

6.4 Decommissioning of balancing device

General

There is much energy stored in the balancing device. Therefore a special procedure is required to dismantle it. The coil springs inside the balancing device exert a potentially lethal force unless dismantled properly.

The device must be dismantled by a decommissioning company.

Required equipment

| Equipment | Art. no. | Note |
|--|----------|--|
| Standard toolkit | - | Content is defined in section Standard tools on page 344 . |
| Protective clothing that also covers face and hands | - | Must protect against spatter of sparks and flames. |
| Cutting torch with a long shaft | - | For opening housing and cutting coils. The long shaft is a safety requirement. |
| Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below. | | These procedures include references to the tools required. |



DANGER

Do not under any circumstances, deal with the balancing device in any other way than that detailed in the product documentation! For example, attempting to open the balancing device is potentially lethal!

Action on field, decommissioning

The procedure below details the actions to perform on field, when the balancing device is to be decommissioned.

| | Action | Note |
|---|---|---|
| 1 | Remove the balancing device from the robot. | Detailed in section Replacing the balancing device on page 231 . |
| 2 | Send the device to a decommissioning company. | Make sure the decommissioning company is well informed about the stored energy built up by high tensioned compression springs and that the device contains some grease and plastic. The following procedure contains useful information about decommissioning. |

Continues on next page





6 Decommissioning

6.4 Decommissioning of balancing device


Continued

Decommissioning at decommissioning company, balancing device

The instruction below details how to decommission the balancing device. Contact ABB Robotics for further consultation.

| | Action | Note |
|---|---|---|
| 1 |  <p>DANGER</p> <p>There is stored energy built up by high tensioned compression springs inside the balancing device! When a coil is cut the released tension creates a spatter of sparks and flames.</p> <p>The working area must be free of flammable materials. Position the balancing device so that the spatter will be directed away from personnel.</p> | |
| 2 | <p>Clamp the device at the working location. Place the device at ground level so that the hole and spring coils are cut from a more safe distance.</p> | |
| 3 |  <p>WARNING</p> <p>There is some grease and a plastic layer inside the balancing device. When opening a hole in the device, the cutting torch will cause the plastic and the grease to start to burn.</p> <p>Wear protective clothing! Make sure that the working area is well ventilated!</p> | |
| 4 |  <p>DANGER</p> <p>The hole must be cut as specified in the figure. Pieces can be ejected from the cylinder at high speed if the hole is cut larger than specified!</p> | |
| 5 | <p>Cut a hole in the housing as shown in the figure.</p> | <p>Use a cutting torch with a long shaft.</p>  <p>xx110000096</p> <p>* Minimum measure, in millimeters. ** Maximum measure, in millimeters.</p> |

Continues on next page

| | Action | Note |
|---|---|--|
| 6 |  <p>DANGER</p> <p>There is stored energy built up by high tensioned compression springs inside the balancing device! When a coil is cut the released tension creates a spatter of sparks and flames.</p> <p>The working area must be free of flammable materials. Position the balancing device so that the spatter will be directed away from personnel.</p> | |
| 7 | Cut at least eight coils of the spring inside the housing. | Use a cutting torch with a long shaft. |
| 8 | <p>Double-check the number of coils cut and make sure all the tension in the spring is removed.</p> <p>Cut more coils if there is still tension in the spring.</p> | |

This page is intentionally left blank

7 Reference information

7.1 Introduction

General

This chapter includes general information, complementing the more specific information in the different procedures in the manual.

7 Reference information

7.2 Applicable standards

7.2 Applicable standards

General

The product is compliant with ISO 10218-1:2011, *Robots for industrial environments - Safety requirements - Part 1 Robots*, and applicable parts in the normative references, as referred to from ISO 10218-1:2011. In case of deviation from ISO 10218-1:2011, these are listed in the declaration of incorporation. The declaration of incorporation is part of the delivery.

Robot standards

| Standard | Description |
|----------|--|
| ISO 9283 | Manipulating industrial robots – Performance criteria and related test methods |
| ISO 9787 | Robots and robotic devices – Coordinate systems and motion nomenclatures |
| ISO 9946 | Manipulating industrial robots – Presentation of characteristics |

Other standards used in design

| Standard | Description |
|------------------|---|
| IEC 60204 | Safety of machinery - Electrical equipment of machines - Part 1: General requirements, normative reference from ISO 10218-1 |
| IEC 61000-6-2 | Electromagnetic compatibility (EMC) – Part 6-2: Generic standards – Immunity standard for industrial environments |
| IEC 61000-6-4 | Electromagnetic compatibility (EMC) – Part 6-4: Generic standards – Emission standard for industrial environments |
| ISO 13849-1:2006 | Safety of machinery - Safety related parts of control systems - Part 1: General principles for design, normative reference from ISO 10218-1 |

Region specific standards and regulations

| Standard | Description |
|------------------|---|
| ANSI/RIA R15.06 | Safety requirements for industrial robots and robot systems |
| ANSI/UL 1740 | Safety standard for robots and robotic equipment |
| CAN/CSA Z 434-03 | Industrial robots and robot Systems - General safety requirements |
| EN ISO 10218-1 | Robots and robotic devices — Safety requirements for industrial robots — Part 1: Robots |

7.3 Unit conversion

Converter table

Use the following table to convert units used in this manual.

| Quantity | Units | | |
|----------|-------|--------------|----------|
| Length | 1 m | 3.28 ft. | 39.37 in |
| Weight | 1 kg | 2.21 lb. | |
| Weight | 1 g | 0.035 ounces | |
| Pressure | 1 bar | 100 kPa | 14.5 psi |
| Force | 1 N | 0.225 lbf | |
| Moment | 1 Nm | 0.738 lbf-ft | |
| Volume | 1 L | 0.264 US gal | |

7 Reference information

7.4 Screw joints

7.4 Screw joints

General

This section describes how to tighten the various types of screw joints on ABB robots.

The instructions and torque values are valid for screw joints comprised of metallic materials and do *not* apply to soft or brittle materials.

UNBRAKO screws

UNBRAKO is a special type of screw recommended by ABB for certain screw joints. It features special surface treatment (Gleitmo as described below) and is extremely resistant to fatigue.

Whenever used, this is specified in the instructions, and in such cases, *no other type of replacement screw* is allowed. Using other types of screws will void any warranty and may potentially cause serious damage or injury.

Gleitmo treated screws

Gleitmo is a special surface treatment to reduce the friction when tightening the screw joint. It is recommended by ABB for M6-M20 screw joints. Screws treated with Gleitmo may be reused 3-4 times before the coating disappears. After this the screw must be discarded and replaced with a new one.

When handling screws treated with Gleitmo, protective gloves of nitrile rubber type should be used.

Generally, screws are lubricated with *Gleitmo 603* mixed with *Geomet 500* or *Geomet 702* in proportion 1:3. *Geomet* thickness varies according to screw dimensions, refer to the following.

| Dimension | Lubricant | Geomet thickness |
|-----------------------------------|---------------------------------|------------------|
| M6-M20 (any length except M20x60) | <i>Gleitmo 603 + Geomet 500</i> | 3-5 µm |
| M6-M20 (any length except M20x60) | <i>Gleitmo 603 + Geomet 720</i> | 3-5 µm |
| M20x60 | <i>Gleitmo 603 + Geomet 500</i> | 8-12 µm |
| M20x60 | <i>Gleitmo 603 + Geomet 720</i> | 6-10 µm |

Screws lubricated in other ways

Screws lubricated with Molykote 1000 or Molykote P1900 should *only* be used when specified in the repair, maintenance or installation procedure descriptions.

In such cases, proceed as follows:

- 1 Apply lubricant to the screw thread.
- 2 Apply lubricant between the plain washer and screw head.
- 3 Screw dimensions of M8 or larger must be tightened with a torque wrench. Screw dimensions of M6 or smaller may be tightened without a torque wrench *if* this is done by trained and qualified personnel.

Continues on next page

| Lubricant | Article number |
|---|----------------|
| Molykote 1000 (molybdenum disulphide grease) | 3HAC042472-001 |
| Molykote P1900 (molybdenum disulphide grease) | 3HAC070875-001 |

Tightening torque

Before tightening any screw, note the following:

- Determine whether a **standard** tightening torque or **special** torque is to be applied. The **standard torques** are specified in the following tables. Any **special torques** are specified in the repair, maintenance or installation procedure descriptions. **Any special torque specified overrides the standard torque!**
- Use the *correct tightening torque* for each type of screw joint.
- Only use *correctly calibrated* torque keys.
- *Always tighten the joint by hand*, and never use pneumatic tools.
- Use the *correct tightening technique*, that is *do not* jerk. Tighten the screw in a slow, flowing motion.
- Maximum allowed total deviation from the specified value is **10%!**

Tightening torque for oil-lubricated screws with slotted or cross-recess head screws

The following table specifies the recommended standard tightening torque for *oil-lubricated screws with slotted or cross-recess head screws*.



Note

A special torque specified in the repair, maintenance or installation procedure overrides the standard torque.

Tightening torque for oil-lubricated screws with allen head screws

The following table specifies the recommended standard tightening torque for *oil-lubricated screws with allen head screws*.



Note

A special torque specified in the repair, maintenance or installation procedure overrides the standard torque.

| Dimension | Tightening torque (Nm) Class 8.8, oil-lubricated | Tightening torque (Nm) Class 10.9, oil-lubricated | Tightening torque (Nm) Class 12.9, oil-lubricated |
|-----------|---|--|--|
| M5 | 6 | - | - |
| M6 | 10 | - | - |
| M8 | 24 | 34 | 40 |
| M10 | 47 | 67 | 80 |
| M12 | 82 | 115 | 140 |
| M16 | 200 | 290 | 340 |
| M20 | 400 | 560 | 670 |

Continues on next page

7 Reference information

7.4 Screw joints

Continued

| Dimension | Tightening torque (Nm) Class 8.8, oil-lubricated | Tightening torque (Nm) Class 10.9, oil-lubricated | Tightening torque (Nm) Class 12.9, oil-lubricated |
|-----------|---|--|--|
| M24 | 680 | 960 | 1150 |

Tightening torque for lubricated screws (Molykote, Gleitmo or equivalent) with allen head screws
The following table specifies the recommended standard tightening torque for *screws lubricated with Molykote 1000, Gleitmo 603 or equivalent with allen head screws.*



Note

A special torque specified in the repair, maintenance or installation procedure overrides the standard torque.

| Dimension | Tightening torque (Nm) Class 10.9, lubricated ⁱ | Tightening torque (Nm) Class 12.9, lubricated ⁱ |
|-----------|---|---|
| M5 | | 8 |
| M6 | | 14 |
| M8 | 28 | 35 |
| M10 | 55 | 70 |
| M12 | 96 | 120 |
| M16 | 235 | 300 |
| M20 | 460 | 550 |
| M24 | 790 | 950 |

ⁱ Lubricated with Molykote 1000, Gleitmo 603 or equivalent

7.5 Weight specifications


Definition

In installation, repair, and maintenance procedures, weights of the components handled are sometimes specified. All components exceeding 22 kg (50 lbs) are highlighted in this way.

To avoid injury, ABB recommends the use of a lifting accessory when handling components with a weight exceeding 22 kg. A wide range of lifting accessories and devices are available for each manipulator model.

Example

Following is an example of a weight specification in a procedure:

| | Action | Note |
|--|--|------|
| |  CAUTION The arm weighs 25 kg. All lifting accessories used must be sized accordingly. | |

7 Reference information

7.6 Standard tools

7.6 Standard tools

General

All service (repairs, maintenance, and installation) procedures contains lists of tools required to perform the specified activity.

All special tools required are listed directly in the procedures while all the tools that are considered standard are gathered in the standard toolkit and defined in the following table.

This way, the tools required are the sum of the standard toolkit and any tools listed in the instruction.

Contents, standard toolkit

| Qty | Tool | Rem. |
|-----|--|--------------------------|
| 1 | Ring-open-end spanner 8-19 mm | |
| 1 | Socket head cap 5-17 mm | |
| 1 | Torx socket no: 20-60 | |
| 1 | Box spanner set | |
| 1 | Torque wrench 10-100 Nm | |
| 1 | Torque wrench 75-800 Nm | |
| 1 | Ratchet head for torque wrench 1/2 | |
| 2 | Hexagon-headed screw M10x100 | |
| 1 | Hex bit socket head cap no. 14 socket 40 mm L=100 mm | |
| 1 | Hex bit socket head cap no. 14 socket 40 mm L=20 mm | To be shortened to 12 mm |
| 1 | Hex bit socket head cap no. 6 socket 40 mm L=145 mm | |
| 1 | Hex bit socket head cap no. 6 socket 40mm bit L=220 mm | |

7.7 Special tools

General

All service instructions contain lists of tools required to perform the specified activity. The required tools are a sum of standard tools, defined in the section [Standard tools on page 344](#), and of special tools, listed directly in the instructions and also gathered in this section.

Calibration equipment, Axis Calibration

The following table specifies the calibration equipment needed when calibrating the robot with the Axis Calibration method.

| Description | Art. no. | Note |
|--|----------------|--|
| Calibration tool box, Axis Calibration | 3HAC055412-001 | Delivered as a set of calibration tools. Required if Axis Calibration is the valid calibration method for the robot. |

Oil exchange equipment

The following table specifies the recommended equipment for oil exchange.

| Description | Art. no. | Note |
|------------------------|----------------|---|
| Oil exchange equipment | 3HAC021745-001 | Includes: <ul style="list-style-type: none"> • Vacuum pump with regulator, hose and coupling • Couplings and adapters • Pump (manual) with hose and coupling • Graduated measuring glass • Oil gun • User instructions. |

Basic tools

The following table specifies the tools in the basic toolkit that are used for the current robot model. This toolkit is necessary primarily when removing and refitting the motors.

The tools are also listed directly in the instructions.

| Description | Qty | Art. no. |
|---|-----|------------------------------|
| Guide pins M10 x 100 | 2 | 3HAC15521-1 |
| Guide pins M10 x 150 | 2 | 3HAC15521-2 |
| Lifting tool, motor ax 1 | 1 | 3HAC14459-1 |
| Lifting tool, motor ax 2, 3 | 1 | 3HAC15534-1 |
| Removal tool, motor M12x | | Fits motors axes 1, 2 and 3. |
| Rotation tool | 1 | 3HAC17105-1 |
| Bits extension | 1 | 3HAC12342-1 |
| Standard toolkit (content described in section Standard tools on page 344) | 1 | - |

Continues on next page

7 Reference information

7.7 Special tools

Continued

Lifting tools

The following table specifies the lifting tools required during several of the service procedures. The tools may be ordered separately and are also specified directly in concerned instructions in the *Product manual, procedures*.

| Description | Qty | Article no. |
|---|-----|----------------|
| Lifting tool, tilt house | | 3HAC023154-001 |
| Lifting tool, motor | | 3HAC15534-1 |
| Lifting tool, frame | | 3HAC023308-001 |
| Lifting tool, complete robot | | 3HAC15607-1 |
| Lifting tool, parallel arm | | 3HAC023098-001 |
| Lifting tool, turning device gearbox ax.1 | | 3HAC14406-1 |
| Lifting tool, base | | 3HAC14868-1 |

Special tools

The following table specifies the special tools required during several of the service procedures. The tools may be ordered separately and are also specified directly in concerned instructions.

| Description | Qty | Article no. |
|--------------------------------------|-----|----------------|
| Lower arm fixture | | 3HAC7035-1 |
| Pressing, link | | 3HAC023081-001 |
| Pressing, outer ring on link | | 3HAC077981-001 |
| KM7 socket | | 6369901-438 |
| KM8 socket | | Standard |
| KM10 socket | | Standard |
| KM12 socket extended | | 3HAC023739-001 |
| Pinion crank | | 3HAC023132-001 |
| Press tool, support ring | | 3HAC072616-001 |
| Pressing, lower arm/balancing weight | | 3HAC076749-001 |
| Pressing, upper arm | | 3HAC023084-001 |
| Pressing, tie rod | | 3HAC5021-1 |
| Pressing, tilt house | | 3HAC077982-001 |
| Pressing, outer ring, tilt house | | 3HAC023075-001 |
| Auxiliary shaft, long | | 3HAC5275-1 |
| Auxiliary shaft, short | | 3HAC5276-1 |
| Support shaft/bearing race | | 3HAC5281-1 |
| Axis 1 pinion | | 3HAC022436-001 |
| Tool for lubrication | | 3HAC5222-2 |
| Adapter for shaft axis 3 | | 3HAC071308-001 |
| Guide sleeves | | 3HAC14446-1 |

7.8 Lifting accessories and lifting instructions

General

Many repair and maintenance activities require different pieces of lifting accessories, which are specified in each procedure.

The use of each piece of lifting accessories is *not* detailed in the activity procedure, but in the instruction delivered with each piece of lifting accessories.

The instructions delivered with the lifting accessories should be stored for later reference.

This page is intentionally left blank

8 Spare part lists

8.1 Spare part lists and illustrations

Location

Spare parts and exploded views are not included in the manual but delivered as a separate document for registered users on myABB Business Portal, www.abb.com/myABB.



Tip

All documents can be found via myABB Business Portal, www.abb.com/myABB.

This page is intentionally left blank

9 Circuit diagrams

9.1 Circuit diagrams

Overview

The circuit diagrams are not included in this manual, but are available for registered users on myABB Business Portal, www.abb.com/myABB.

See the article numbers in the tables below.

Controllers

| Product | Article numbers for circuit diagrams |
|--|--------------------------------------|
| <i>Circuit diagram - OmniCore V250XT</i> | <i>3HAC074000-008</i> |
| <i>Circuit diagram - IRC5</i> | <i>3HAC024480-011</i> |
| <i>Circuit diagram - IRC5 Panel Mounted Controller</i> | <i>3HAC026871-020</i> |
| <i>Circuit diagram - Euromap 67, design 14</i> | <i>3HAC024120-005</i> |
| <i>Circuit diagram - Spot welding cabinet</i> | <i>3HAC057185-001</i> |

Manipulators

| Product | Article numbers for circuit diagrams |
|--|--------------------------------------|
| <i>Circuit diagram - IRB 120</i> | <i>3HAC031408-003</i> |
| <i>Circuit diagram - IRB 140 type C</i> | <i>3HAC6816-3</i> |
| <i>Circuit diagram - IRB 260</i> | <i>3HAC025611-001</i> |
| <i>Circuit diagram - IRB 360</i> | <i>3HAC028647-009</i> |
| <i>Circuit diagram - IRB 390</i> | <i>3HAC060545-009</i> |
| <i>Circuit diagram - IRB 460</i> | <i>3HAC036446-005</i> |
| <i>Circuit diagram - IRB 660</i> | <i>3HAC025691-001</i> |
| <i>Circuit diagram - IRB 760</i> | <i>3HAC025691-001</i> |
| <i>Circuit diagram - IRB 1200</i> | <i>3HAC046307-003</i> |
| <i>Circuit diagram - IRB 1410</i> | <i>3HAC2800-3</i> |
| <i>Circuit diagram - IRB 1600/1660</i> | <i>3HAC021351-003</i> |
| <i>Circuit diagram - IRB 1520</i> | <i>3HAC039498-007</i> |
| <i>Circuit diagram - IRB 2400</i> | <i>3HAC6670-3</i> |
| <i>Circuit diagram - IRB 2600</i> | <i>3HAC029570-007</i> |
| <i>Circuit diagram - IRB 4400/4450S</i> | <i>3HAC9821-1</i> |
| <i>Circuit diagram - IRB 4600</i> | <i>3HAC029038-003</i> |
| <i>Circuit diagram - IRB 6620</i> | <i>3HAC025090-001</i> |
| <i>Circuit diagram - IRB 6620 / IRB 6620LX</i> | <i>3HAC025090-001</i> |
| <i>Circuit diagram - IRB 6640</i> | <i>3HAC025744-001</i> |

Continues on next page

9 Circuit diagrams

9.1 Circuit diagrams

Continued

| Product | Article numbers for circuit diagrams |
|--|---|
| <i>Circuit diagram - IRB 6650S</i> | <i>3HAC13347-1 3HAC025744-001</i> |
| <i>Circuit diagram - IRB 6660</i> | <i>3HAC025744-001 3HAC029940-001</i> |
| <i>Circuit diagram - IRB 6700 / IRB 6790</i> | <i>3HAC043446-005</i> |
| <i>Circuit diagram - IRB 7600</i> | <i>3HAC13347-1 3HAC025744-001</i> |
| <i>Circuit diagram - IRB 14000</i> | <i>3HAC050778-003</i> |
| <i>Circuit diagram - IRB 910SC</i> | <i>3HAC056159-002</i> |

Index

A

- additional mechanical stop location, 112
- allergenic material, 30
- aluminum
 - disposal, 330
- ambient humidity
 - operation, 44
 - storage, 44
- ambient temperature
 - operation, 44
 - storage, 44
- assembly instructions, 41
- assessment of hazards and risks, 30
- Axis Calibration, 312
 - calibration tool
 - article number, 315, 319
 - examining, 315
 - installation position, 317
 - overview of method, 312
 - procedure on FlexPendant, 319
 - protective cover and protection plug, 317, 319

B

- balancing device
 - inspecting bearing, 101
 - inspecting piston rod guide ring, 101
 - lubricating bearing, 132
 - lubricating piston rod, 132
- base plate
 - guide pins, 63
 - securing, 63
- batteries
 - disposal, 330
- battery
 - replacing, 128, 239
- battery pack
 - replacing, interval, 92
- battery shutdown
 - service routine, 128, 239
- bearing, balancing device, 101
- bearing, balancing device, 132
- brake release, 60
- brake release board, replacement, 242
- brakes
 - testing function, 38
- buttons for brake release, 60

C

- cabinet lock, 31
- cable harness attachments, 105
- cabling, robot, 83
- cabling between robot and controller, 83
- calibrating
 - robot, 312
 - roughly, 306, 310
- calibrating robot, 312
- calibration
 - rough, 306, 310
 - standard type, 302
 - verification, 325
 - when to calibrate, 303
- calibration manuals, 302
- calibration marks, 304
- calibration position

- jogging to, 326–327
 - scales, 304
 - calibration scales, 304
 - carbon dioxide extinguisher, 31
 - cast iron
 - disposal, 330
 - changing oil
 - axis 1, 119
 - axis 2, 122
 - axis 3, 122
 - axis 6, 126
 - cleaning, 135
 - climbing on robot, 34
 - Cold environments, 82
 - connecting the robot and controller, cabling, 83
 - copper
 - disposal, 330

D

- damage to additional mechanical stop, 112
- damage to mechanical stop, 110
- dampers, 114
- dimensions
 - frame, 72
 - turning disk, 73
 - upper arm, 71
- direction of axes, 305

E

- environmental information, 330
- EPS, 77
- equipment on robot, 71
- ESD
 - damage elimination, 49
 - sensitive equipment, 49
- expected life, 93
- extended working range, 77
- extended working range, axis 1, 77
- extra equipment
 - frame, 72
 - robot, 71
 - turning disk, 73
 - upper arm, 71

F

- fire extinguishing, 31
- fitting equipment on robot, 71
- FlexPendant
 - jogging to calibration position, 326–327
 - MoveAbsJ instruction, 326–327
 - updating revolution counters, 307, 310
- fork lift, 50
- foundation
 - requirements, 44
- frame
 - dimensions, 72

G

- gearbox
 - oil change axis 1, 119
 - oil change axis 2, 122
 - oil change axis 3, 122
 - oil change axis 6, 126
- gearbox axis 1, replacement, 271
- gearboxes
 - location of, 118
- grease, 34

- disposal, 330
- guide pins, base plate, 63
- guide ring, piston rod, 101

H

- hanging
 - installed hanging, 30
- hazard levels, 21
- hazardous material, 330
- height
 - installed at a height, 30
- hot surfaces, 34
- HRA, 30
- humidity
 - operation, 44
 - storage, 44

I

- information labels location, 108
- inspecting
 - additional mechanical stop, 112
 - balancing device bearing, 101
 - balancing device piston rod guide ring, 101
 - cable harness, 105
 - information labels, 108
 - mechanical stop, 110
- inspecting oil levels
 - axes 2-3, 96
 - axis-1, 94
 - axis 6, 99
- inspection
 - dampers, 114
- installation
 - mechanical stop axis 1, 80
- installing equipment on robot, 71
- instructions for assembly, 41
- integrator responsibility, 30
- intervals for maintenance, 91

L

- labels
 - robot, 23
- leak-down test, 138
- lifting accessory, 343
- lifting accessory, robot, 58
- lifting robot
 - with fork lift, 50
 - with lifting accessory, 58
 - with roundslings, 55
- limitation of liability, 19
- linkage
 - replacing upper rod, 196
- Lithium
 - disposal, 330
- loads on foundation, 43
- lock and tag, 31
- lubricants, 34
- lubricating
 - balancing device bearing, 132
 - balancing device piston rod, 132
- lubrication
 - amount in gearboxes, 118
 - type of lubrication, 118

M

- maintenance schedule, 91
- manually releasing brakes, 60

- mechanical stop
 - axis 1, 80
- mechanical stop location, 110
- MoveAbsJ instruction, 326–327

N

- national regulations, 30
- negative directions, axes, 305
- neodymium
 - disposal, 330
- nodular iron
 - disposal, 330

O

- oil, 34
 - amount in gearboxes, 118
 - disposal, 330
 - type of oil, 118
- oil change
 - axis 1, 119
 - axis 2, 122
 - axis 3, 122
 - axis 6, 126
- oil level
 - gearbox axes 2-3, 96
 - gearbox axis-1, 94
 - gearbox axis 6, 99
- operating conditions, 44
- option
 - Extended working range, 77
- original spare parts, 19

P

- pedestal
 - installed on pedestal, 30
- personnel
 - requirements, 20
- piston rod, balancing device, 132
- piston rod guide ring inspecting, 101
- plastic
 - disposal, 330
- positive directions, axes, 305
- PPE, 20
- product standards, 338
- protection classes, 45
- protection type, 45
- protective equipment, 20
- protective wear, 20

R

- recycling, 330
- regional regulations, 30
- release brakes, 37
- replacement
 - brake release board, 242
 - gearbox axis 1, 271
 - turning disk, 168
- replacements, report, 137
- replacing
 - upper rod, linkage, 196
 - xx, 86
- report replacements, 137
- requirements on foundation, 44
- responsibility and validity, 19
- restricting
 - working range axis 1, 77, 80
- revolution counters

storing on FlexPendant, 307, 310
 updating, 306, 310

risk of burns, 34
 risk of tipping, 48

robot
 labels, 23
 protection class, 45
 protection types, 45
 symbols, 23

rubber
 disposal, 330

S

safety
 brake testing, 38
 ESD, 49
 fire extinguishing, 31
 release robot axes, 37
 signal lamp, 75
 signals, 21
 signals in manual, 21
 symbols, 21
 symbols on robot, 23
 test run, 88
 safety devices, 31
 safety equipment
 mechanical stop, 80
 signal lamp, 116
 safety hazard
 hydraulic system, 32
 pneumatic system, 32
 safety signals
 in manual, 21
 safety standards, 338
 scales on robot, 304
 schedule for maintenance, 91
 screw joints, 340
 securing
 base plate, 63
 securing, robot, 68
 securing the robot to foundation, attachment screws, 68
 shipping, 329
 signal lamp, 75
 signals
 safety, 21
 SMB
 replacing, 239
 SMB battery
 extension of lifetime, 128, 239
 replacing, 128, 239
 special tools, 345
 speed
 adjusting, 82
 stability, 48
 standards, 338
 ANSI, 338
 CAN, 338
 start of robot in cold environments, 82

steel
 disposal, 330
 storage conditions, 44
 symbols
 safety, 21
 synchronization position, 306, 310
 sync marks, 304
 system integrator requirements, 30

T

temperatures
 operation, 44
 storage, 44
 testing
 brakes, 38
 tools
 Axis Calibration, 345
 for service, 345
 oil exchange equipment, 345
 torques on foundation, 43
 transportation, 329
 troubleshooting
 oil spills, 135
 safety, 39
 turning disk dimensions, 73
 turning disk replacement, 168

U

upcycling, 330
 updating revolution counters, 306, 310
 upper arm
 dimensions, 71
 users
 requirements, 20

V

validity and responsibility, 19
 velocity
 adjusting, 82
 verifying calibration, 325

W

weight, 42
 base plate, 62, 67
 gearbox, 289
 robot, 54–55, 59, 163, 165, 202–203, 208–209, 213–214, 218–221, 227, 229, 234, 236, 249–250, 258, 260, 274, 276, 278, 281, 287
 working range, 46
 restricting axis 1, 80

X

xx
 replacing, 86

Z

zero position
 checking, 326



ABB AB

Robotics & Discrete Automation

S-721 68 VÄSTERÅS, Sweden

Telephone +46 (0) 21 344 400

ABB AS

Robotics & Discrete Automation

Nordlysvegen 7, N-4340 BRYNE, Norway

Box 265, N-4349 BRYNE, Norway

Telephone: +47 22 87 2000

ABB Engineering (Shanghai) Ltd.

Robotics & Discrete Automation

No. 4528 Kangxin Highway

PuDong New District

SHANGHAI 201319, China

Telephone: +86 21 6105 6666

ABB Inc.

Robotics & Discrete Automation

1250 Brown Road

Auburn Hills, MI 48326

USA

Telephone: +1 248 391 9000

abb.com/robotics