

ROBOTICS

Application manual

KEMPPI A7 MIG Welder 350/450



Trace back information:
Workspace Main version a483
Checked in 2022-11-16
Skribenta version 5.5.019

Application manual
KEMPPi A7 MIG Welder 350/450

RobotWare 6.14

Document ID: 3HAC086375-001

Revision: A

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damage to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2022 ABB. All rights reserved.
Specifications subject to change without notice.

Table of contents

Overview of this manual	7
1 Introduction to Kemppi A7 interface	9
2 Installation	11
2.1 Introduction	11
2.2 Hardware setup	12
2.3 A7 general robot settings	17
2.4 Software setup	18
3 Fieldbus configuration	21
3.1 Introduction	21
3.2 EtherNet/IP configuration	22
3.2.1 Installation	22
3.2.2 Kemppi A7 settings	23
3.2.3 Changing the IRC5 communication settings	25
3.2.4 Accessing the welder's service port from IRC5 controller	27
3.3 DeviceNet configuration	28
3.4 PROFINET configuration	30
4 Watchdog functionality	35
5 Kemppi Interface Modes	37
6 Weld Editor Interface	39
6.1 Introduction	39
6.2 Weld Editor in online control mode	42
6.3 Weld Editor in Memory Channel mode	48
6.4 Tuning of weld parameters	53
6.5 How to edit welddata using the partdata concept	54
7 System parameters	59
8 Seam Tracking with A7 MIG Welder 350/450	63
8.1 Introduction	63
8.2 Installation	64
8.3 Software installation	66
8.3.1 KEMPPPI A7 Tracking Feedback Signal	67
8.3.2 System parameters	69
8.4 Seam tracking	73
8.5 Tracking parameters	77
8.6 Best practice	78
8.7 Runtime widget	81
8.8 Weave and track data editor interface	82
9 The Kemppi A7 Logbook Viewer	85
10 Customize widgets	89
10.1 Production Screen widgets	89
10.2 Modifying the widgets on the FlexPendant	93
Index	95

This page is intentionally left blank

Overview of this manual

About this manual

This manual describes the options Kemppi A7 Interface and Weld Editor and contains instructions to configure it.



Note

It is the responsibility of the integrator to provide safety and user guides for the robot system.

This manual should be read before installing and commissioning of a Robotic Arc Welding system with a Kemppi A7 power source.

Prerequisites

The reader should have the required knowledge of:

- Mechanical installation work
- be familiar with the RAPID programming language
- be familiar with system parameters and how to configure them



Note

Before any work on or with the robot is performed, the safety information in the product manual for the controller and manipulator must be read.

References

References	Document ID
<i>Operating manual - IRC5 with FlexPendant</i>	3HAC050941-001
<i>Operating manual - RobotStudio</i>	3HAC032104-001
<i>Operating manual - Seam tracking with Weldguide III and MultiPass</i>	3HEA802921-001
<i>Technical reference manual - RAPID Instructions, Functions and Data types</i>	3HAC050917-001
<i>Technical reference manual - RAPID Overview</i>	3HAC050947-001
<i>Technical reference manual - System parameters</i>	3HAC050948-001
<i>Application manual - Arc and Arc Sensor</i>	3HAC050988-001
<i>Application manual - Controller software IRC5</i>	3HAC050798-001
<i>Application manual - MultiMove</i>	3HAC050961-001
<i>Application manual - Production Screen</i>	3HAC050964-001

Revisions

Revision	Description
A	Published with RobotWare 6.14.

This page is intentionally left blank

1 Introduction to Kemppi A7 interface

About Kemppi A7 MIG Welder interface

This manual describes the ABB Robotics IRC5 interface for:

- A7 MIG Welder 350/450

Requirements

The power source must meet the following requirements:

- A7 MIG Welder Robot Interface Firmware \geq 1.05.00.0
- A7 MIG Welder Firmware \geq 1.04.00.0 OR, if S/N, \geq 3018192 Firmware 2.01
- Fieldbus Interface for DeviceNet/ProfiNet or EtherNet/IP

Overview

The A7 MIG Welder power sources are based on top of the class inverter technology. They belong to the high-end system class of Kemppi products.

There is a wide range of processes for you to choose the one that suits your application:

- MIG, 1-MIG
- Pulse, Double Pulse
- Brazing
- Cladding
- WiseRoot+
- WiseThin+
- WiseFusion
- WisePenetration

The system can be configured to contain an optimal choice of just the right welding programs for the application. There are welding programs available for all the common filler wire and shielding gas combinations for mild steel, stainless steel and aluminum.



xx2200001851

This page is intentionally left blank

2 Installation

2.1 Introduction

Robot controller software

Robot prerequisites:

- IRC5 robot controller with main computer DSQC1000 or later
- RobotWare version 6.14 or later with the following options:
 - - [633-4] RobotWare Arc
 - - [637-1] Production Screen
- One of the following industrial networks:
 - - [709-1] DeviceNet Master/Slave
 - - [841-1] EtherNet/IP Scanner/Adapter
 - - [888-2] PROFINET Controller/Device
- The following option is recommended in order to use the *Partdata* concept within the welddata editor:
 - - [812-1] Production Manager

RobotStudio

RobotStudio software:

- RobotStudio version 2022 or later

Limitations

Currently only the first arc system is supported with this interface. If more than one welder is connected per robot, the arc sub-option *Standard I/O Welder* is required.

Tuning of weld speed and weld parameters is no longer supported by RobotWare Arc GUI.

Kemppi A7 add-in

The Kemppi A7 add-in consists of the following software components:

- Ready to weld interface to control a Kemppi A7 350/450 welder
- Logbook Viewer as RobotStudio add-in to download the logbook entries from any welder connected to a network
- Graphical weld data editor
- Graphical weave and track data editor
- Graphical application for manual functions such as
 - - Process blocking
 - - Wire feed (forward/backward)
 - - Purge gas
- Graphical widget displaying run-time data

2 Installation

2.2 Hardware setup

2.2 Hardware setup

Introduction

The ABB preferred connection to the welder is to connect the LAN port of the welder to LAN2 or WAN on the IRC5 controller. However, this is not mandatory but it is a convenient way to set up the system it gives access to the welder and the robot controller from RobotStudio.

This connection is only used with the RobotStudio add-in to download the logbook entries. Furthermore, it is possible to get access to the welders Web UI from RobotStudio by launching a web browser.

The I/O based communication to the welder which is needed to control the welder is done via a fieldbus interface and not through the LAN port on the welder.

A switch must be added if the system is a MultiMove system or if the LAN port is connected to a different network.


It is recommended that switches used in the I/O network support *Quality of Service* (QoS). I/O devices mark their packets with a priority value. The priority value is used in order to get better I/O data throughput and shorter delays on the network. Switches and routers are then able to differentiate the I/O devices critical from the other non-critical traffic. To do this, the switches and routers must support Quality of Service.

Continues on next page

Intended use of WAN and LAN ports

The WAN port is a public network interface to the controller, typically connected to the factory network with a public IP address provided by the network administrator.

The LAN ports are intended for connecting network-based process equipment to the controller, for example, industrial networks, cameras, and welding equipment. LAN 2 can only be used as a private network to the IRC5 controller.



Continues on next page


2 Installation

2.2 Hardware setup

Continued

Connecting to the IRC5 controller

Connect an Ethernet cable between the robot controller LAN2 port and the Kemppi A7 welder Ethernet port. The following illustration shows an overview of the computer unit.



xx130000608

X4	LAN2
X5	LAN3

Welder LAN port

The LAN port (service port) is located on the back of the robot interface unit on the welder. If connecting the welder to the IRC5 controller, make sure to use a static IP address and turn off DHCP.

Additional information of the robot interface unit can be found in the *Operator Manual* and the *Integration Guide* of the welder.

Continues on next page

LAN connection to the left, Fieldbus connection to the right.



xx2200001853

Continues on next page

2 Installation


2.2 Hardware setup

Continued

IP address of welder

The web user interface starts up automatically when the power is turned on. However, the network settings must be configured from the setup panel before access is possible to the Web UI from the computer connected to the web user interface server.

Go to the **Main menu > Robot > Network settings**, and configure the *DHCP enabled*, *IP address*, *Subnet mask*, and *Gateway* parameters to fit the network environment.



xx2200001854


To access the web interface, start a browser and enter the IP address.

Additional information can be found in the *Operator Manual* and the *Integration Guide* of the welder.

2.3 A7 general robot settings

A7 power source

The following settings need to be set in the A7 power source to work with the robot interface. The settings can be found using the web UI. Select **Welding System** and browse to **General Robot Settings**.



xx2200001855

2 Installation

2.4 Software setup


2.4 Software setup

Download Kemppi A7 package

In RobotStudio, download the Kemppi A7 Package from the **Add-Ins** tab (common tags: RobotWare-Addin) and install it.

Build the robot system


- 1 Start **Installation Manager** and build the robot system.
- 2 In the **Products** tab, add the **KemppiA7** product. No license is required for the package.



Added Product(s)		Name	Version	Publisher	Type	Status	Creation Date	Install Order
		RobotWare	6.14.00.00 RC2	ABB	RobotWare	Installed	25.08.2022	1
		Positioner	6.13.03.00	ABB	Addin	Installed	20.05.2022	2
		KemppiA7	1.00.0000 13.Internal	ABB	Addin	Installed	29.08.2022	3

xx2200001856

- 3 In the **Drive Modules** tab, select **RW Add-In loaded Welder** for each associated welding robot.




xx2200001857

- 4 For each welding robot, select the option **Install Power Supply** and select the fieldbus.

Continues on next page

- 5 If the system has the SmarTac option, select **Include SmarTac Config**. This will load configuration files to use the Kemppi touch sense function.



xx2200001858

- 6 If Seamtracking (TAST) is desired, select **Install SeamTracking Option**. This requires controller the option *Tracking Interface*.
- 7 If recording and replaying welding paths is desired, select **Install Multipass instructions**.
- 8 Apply the settings and download the system to the controller.

RobotWare functionality

The generic RAPID objects are described in *Technical reference manual - RAPID Instructions, Functions and Data types*. All documents are listed in [References on page 7](#).

trackdata

The data type `trackdata` and other arc-specific RAPID objects are described in *Application manual - Arc and Arc Sensor*.

This page is intentionally left blank

3 Fieldbus configuration

3.1 Introduction

Introduction

The Kemppi A7 Add-In package is delivered with pre-configured fieldbus configuration files for PROFINET , Ethernet/IP, and DeviceNet.



Note

All I/O signals are pre-configured as defined in the *A7 Integration Guide* based on *I/O table 15*. Additional information can be found in the *Operator Manual* and *Integration Guide* provided by Kemppi.

Default I/O board address

Fieldbus	Network	Default I/O board address
DeviceNet	N/A	Robot 1 -DN_Address 40 Robot 2 -DN_Address 41 Robot 3 -DN_Address 42 Robot 4 -DN_Address 43
EtherNet/IP	LAN2 (X4)	Robot 1 -IP_Address 192.168.125.60 Robot 2 -IP_Address 192.168.125.61 Robot 3 -IP_Address 192.168.125.62 Robot 4 -IP_Address 192.168.125.63
ProfiNet	LAN3 (X5)	Robot 1 -IP_Address 192.168.0.2 Robot 2 -IP_Address 192.168.0.3 Robot 3 -IP_Address 192.168.0.4 Robot 4 -IP_Address 192.168.0.5

3 Fieldbus configuration

3.2.1 Installation

3.2 EtherNet/IP configuration

3.2.1 Installation

Software prerequisites

Robot prerequisites:

- IRC5 robot controller with main computer DSQC1000 or later
 - RobotWare version 6.14 or higher with one of the following Arc sub-options (power source interface):
 - Standard I/O Welder
 - Kemppi A7 Product add-in
 - RobotStudio version 2022 or later
-

Hardware prerequisites

Required:

- 1 Ethernet cable

Optional:

- 1 Ethernet switch/hub
 - 2 Ethernet cables
-

Software installation

Download the Kemppi A7 Package and install it. Build the robot system. See [Software setup on page 18](#).

All parameters for the EtherNet/IP based communication will be automatically installed with the IP address mentioned earlier.

Make sure the Ethernet cable/switch is connected to LAN2.

3.2.2 Kemppi A7 settings

Changing the A7 network settings for web UI

Change the IP settings as described in section [IP address of welder on page 16](#), to be able to access the welder using the web UI.

Changing the A7 network settings for the IRC5 communication

Follow these steps to change the network settings for IRC5 communication:

- 1 Connect to the service port on the robot interface unit with the Ethernet cable connected to your PC (LAN connection to the left).



xx2200001853

- 2 From a web browser address bar, enter the defined IP address.
- 3 In the Kemppi web UI browser, browse to **Settings** and select **Fieldbus**. The configuration parameters can be modified here.

Continues on next page

3 Fieldbus configuration

3.2.2 Kemppi A7 settings

Continued

Fieldbus settings in web UI

FIELDBUS SETTINGS: ETHERNET/IP 2-PORT

IDENTIFICATION INFORMATION

ODVA VENDOR ID	1403
ODVA DEVICE TYPE	100
PRODUCT CODE	1
VERSION	0.0
SERIAL NUMBER	750176705
PRODUCT NAME	A7 MIG Welder

ADAPTER INFORMATION

MAC ADDRESS	00:30:11:2A:08:DC
-------------	-------------------

CONFIGURATION PARAMETERS

DHCP	<input checked="" type="radio"/> OFF	<input type="radio"/> ON					
IP ADDRESS	192	.	168	.	125	.	60
SUBNET MASK	255	.	255	.	255	.	0
GATEWAY	192	.	168	.	125	.	60


xx2200001859

3.2.3 Changing the IRC5 communication settings

IRC5 EtherNet/IP device


Use the following procedure to configure the communication between the IRC5 controller and the A7 welder.

- 1 In RobotStudio, double-click the system name.
- 2 In the **Controller** panel, expand **Configuration** and select **I/O System**.
- 3 In the **Configuration - I/O System** panel, select **EtherNet/IP Device** and select the Kemppi A7 power supply to be configured (*ioKemppiWld1*).



xx2200001860

- 4 In the **Instance Editor**, enter the IP address to use for the EtherNet/IP Device *ioKemppiWld1* (welder connected to robot 1) and click OK.



xx2200001861

IRC5 IP settings

Use the following procedure to configure the communication between the IRC5 controller and the Kemppi A7 welder.

- 1 In RobotStudio, double-click the system name.


Continues on next page

3 Fieldbus configuration

3.2.3 Changing the IRC5 communication settings


Continued

- 2 In the **Controller** panel, expand **Configuration** and select **Communication**.
- 3 In the **Configuration - Communication** panel, select **IP Setting**.



xx2200001862


- 4 In the **Instance Editor**, enter the IP address to use for the EtherNet/IP master and click **OK**.
- 5 Change **Interface** to **LAN3** (isolated network) and restart the controller



xx2200001863

3.2.4 Accessing the welder's service port from IRC5 controller

Use the following procedure to access the web UI from the IRC5 service port.



xx2200001864

- 1 Define the Kemppi network settings (192.168.125.165), see [Changing the A7 network settings for the IRC5 communication on page 23](#). This will set the service port of the power supply to the IRC5 private network.
- 2 Connect the X4 Lan 2 to an Ethernet switch, see [Hardware prerequisites on page 22](#).
- 3 Connect the Kemppi A7 Ethernet IP and service port to the Ethernet switch/hub.

3 Fieldbus configuration

3.3 DeviceNet configuration


3.3 DeviceNet configuration

Introduction

The DeviceNet network for IRC5 is running on a single channel PCI Express board in the IRC5 main computer. The DeviceNet board, DSQC1006, requires the main computer DSQC1000. With option *DeviceNet Master/Slave*, the IRC5 controller can act as a master, slave, or both, on the DeviceNet network.

Connections

The I/O network is connected to the DeviceNet PCI Express board, DSQC1006, on the main computer. The DeviceNet PCI Express board is a single channel board that can act both as a master and a slave simultaneously on the DeviceNet network. The following figure illustrates the location of the PCI Express board in the main computer unit.




xx1300001968

Continues on next page


Termination resistors

Each end of the DeviceNet network must be terminated with a 121 ohm resistor. The two terminating resistors should be as far apart as possible. The technical specification of the termination resistor is: 121 ohm, 1 %, 0.25 W metal film resistor. The termination resistor is placed in the cable connector. There is no internal termination on the DeviceNet PCI Express board.



xx0400000674

The following illustration shows an example of how to terminate the DeviceNet network.



xx1300000698

A	DeviceNet PCI Express board
B	Termination resistor
C	I/O device

3 Fieldbus configuration

3.4 PROFINET configuration

3.4 PROFINET configuration

Introduction

The PROFINET network is running on the IRC5 main computer and does not require any additional hardware. PROFINET as described in this manual requires the main computer DSQC1000.


Option *PROFINET Controller/Device* is required.

Default gateway

There are multiple default gateways in the system. Hence, it is possible to have two different default gateways in the system, one for the non-PROFINET traffic and one that only manages the PROFINET interface and its traffic. So, while using option *PROFINET Controller/Device*, the LAN3 port is used only for PROFINET traffic.

Connections

The I/O network can be connected to one of the the Ethernet ports WAN, LAN 2, or LAN 3 on the main computer. The following figure illustrates where the Ethernet port connectors, are placed on the main computer.




xx130000608

X4	LAN2
X5	LAN3

Continues on next page

The pre-defined configuration that is installed when selecting the PROFINET fieldbus for the welder assumes that LAN3 is used as an isolated network for the PROFINET communication.



xx2200001865

Connect the Ethernet Cable to LAN3 or to a switch connected to LAN3.

The PROFINET configuration is created with the I/O Engineering Tool in RobotStudio, and can be found in `HOME : /Arc/Kemppi_A7/PNET` along with the used GSDML file.

To change the IP address and station name, if needed, use the I/O Engineering Tool. It is recommended to use the tool in offline mode (not connected to a robot controller) to avoid a slotted device configuration which will not work with the predefined I/O.

Continues on next page

3 Fieldbus configuration

3.4 PROFINET configuration

Continued

Device properties

The following graphic shows the predefined configuration for PROFINET device *ioKemppiWld1*.

The screenshot displays the configuration software interface. The left pane shows a tree view of the configuration structure under 'Kemppi_A7_New.ioepj - Controller'. The right pane shows the 'Properties' window for the selected device 'ioKemppiWld1'.

Profinet Configuration	
StationName	iokemppiWld1
Reduction Ratio	2
Faulty Telegrams	24
Network	
IP Address	192 . 168 . 0 . 2
Subnet	255 . 255 . 255 . 0
Gateway	192 . 168 . 0 . 1
System	
Name	ioKemppiWld1
Information	
Input Size	16
Output Size	16
Startup Mode	Legacy
Vendor Name	Kemppi Oy
Device Family	A7 MIG Welder
Device Type	General
Product Name	RT Migration
Order Number	9774121PRN
Hardware Version	
Software Version	
Description	Kemppi A7 MIG Welder
Vendor Id	872
Device Id	1
GSD file	GSDML-V2.3-KEMPPPI-9774121PRN-20160826.xml

xx2200001866

Continues on next page

I/O slot configuration

The I/O device uses 16 byte output and 16 byte input. Each slot is configured to use 1 output byte and 1 input byte.

The screenshot displays the SIMATIC Manager configuration interface. The left pane shows the configuration tree for a controller named 'Kemppi_A7-350-450.ioepj - Controller:'. Under the 'PROFINET' section, there is a 'Controller' sub-section containing four I/O modules: 'ioKemppiW/d1', 'ioKemppiW/d2', 'ioKemppiW/d3', and 'ioKemppiW/d4'. The 'ioKemppiW/d1' module is expanded, showing 32 slots. Slots 00-16 are configured as 'Output 1 byte', and slots 17-32 are configured as 'Input 1 byte'. The right pane shows the 'Device Catalogue' with a search bar and a table of device properties.

Vendor	Family	Device	Order Number	Information
		Empty Module		
Kemppi Oy	Output 1 byte	Output 1 byte	9774121PRN	
Kemppi Oy	Output 1 word	Output 1 word	9774121PRN	
Kemppi Oy	Output 2 word	Output 2 word	9774121PRN	
Kemppi Oy	Output 4 word	Output 4 word	9774121PRN	
Kemppi Oy	Input 1 byte	Input 1 byte	9774121PRN	
Kemppi Oy	Input 1 word	Input 1 word	9774121PRN	
Kemppi Oy	Input 2 word	Input 2 word	9774121PRN	
Kemppi Oy	Input 4 word	Input 4 word	9774121PRN	

xx2200001867

Continues on next page

3 Fieldbus configuration

3.4 PROFINET configuration

Continued

Fieldbus settings A7 web

The PROFINET settings on the welder can be verified using the web UI, in **Settings > Fieldbus**. The fieldbus settings are based on the default configuration installed with the Kemppi A7 add-in.

FIELDBUS SETTINGS: PROFINET IO 2-PORT

IDENTIFICATION INFORMATION

DEVICE ID	1
PNO VENDOR ID	0x0368
STATION TYPE	A7 MIG Welder
DEVICE ORDER ID	9774121PRN2
SERIAL NUMBER	PSNK0176705
HARDWARE VERSION	1
VERSION	V.2.11.1

ADAPTER INFORMATION

PORT 1 MAC ADDRESS	00:30:11:13:B9:FC
PORT 2 MAC ADDRESS	00:30:11:13:B9:FD

CONFIGURATION PARAMETERS

DHCP	<input checked="" type="checkbox"/> OFF <input type="checkbox"/> ON
IP ADDRESS	192 . 168 . 0 . 2
SUBNET MASK	255 . 255 . 255 . 0
GATEWAY	192 . 168 . 0 . 1

xx2200001868

4 Watchdog functionality

Watchdog in IRC5

The Kemppi A7 interface has built in support for a watchdog functionality. The watchdog frequency is a fixed frequency of 0.5 Hz and cannot be changed in the robot controller. The functionality can be activated in the configuration (topic *Process*, PROC.cfg) in the type *Kemppi A7 Arc Equipment Properties* by setting *Enable Watchdog Output* to TRUE. In addition, the feature needs to be activated in the power source. See [Watchdog in A7 welder on page 35](#).

Name	Value	Information
Name	ARC1_KEMPP1_EQPR_A7_T_ROB1	
Use Equipment Standard IO	KEMPP1_A7_EQSTDIO_T_ROB1	
Use Kemppi A7 Equipment IO	KEMPP1_A7_EQIO_T_ROB1	
Mode	Memory Channel	
Ignition on	<input checked="" type="radio"/> TRUE <input type="radio"/> FALSE	
Heat on	<input checked="" type="radio"/> TRUE <input type="radio"/> FALSE	
Heat defined as time	<input type="radio"/> TRUE <input checked="" type="radio"/> FALSE	
Cool time on	<input checked="" type="radio"/> TRUE <input type="radio"/> FALSE	
Fill on	<input checked="" type="radio"/> TRUE <input type="radio"/> FALSE	
Arc Preset	0	
Ignition timeout	3	
Weld Off Timeout	10	
Override On	<input checked="" type="radio"/> TRUE <input type="radio"/> FALSE	
Autoinhibit On	<input checked="" type="radio"/> TRUE <input type="radio"/> FALSE	
Time to feed 15 mm wire	0,95	
Enable supervision on VC	<input checked="" type="radio"/> TRUE <input type="radio"/> FALSE	
Enable Watchdog Output	<input type="radio"/> TRUE <input checked="" type="radio"/> FALSE	

Value (string)
The changes will not take effect until the controller is restarted.


OK Cancel

xx2200001869

Watchdog in A7 welder

The watchdog can be enabled and disabled either on the front panel or using the web UI. The following screenshot shows the configuration done with the web UI.

The settings can be found in **Welding Settings > Welding System**.



xx2200001870

Continues on next page

4 Watchdog functionality

Continued

To use the watchdog with the fixed 0.5 Hz frequency generated by the A7 Interface, the timeout needs to be set higher than 2 seconds. Set it to 2.5 seconds.

Error 132

Error 132 is a communication error. This error typically indicates a communication problem on the fieldbus between the A7 welder and the robot controller.

5.2.5 Robot interface errors

Code	Description	Severity
131	FIELD BUS ERROR Failed to initialize the fieldbus card during start-up. The fieldbus module is missing, has been incorrectly connected, or is damaged.	Serious error
132	COMMUNICATION ERROR No connection to the robot. Fieldbus cable is broken or detached, or there is a robot failure or shutdown. Welding is interrupted when connection is lost.	Error
133	EMERGENCY STOP A user has pressed the emergency stop button. Welding is immediately interrupted.	Error

xx2200001871



Note

Error 132 can also be related to the watchdog. If communication to the robot controller is running, check the watchdog settings or switch it temporarily off to verify if error 132 disappears as no dedicated error message or error code is shown for a watchdog error.

5 Kemppi Interface Modes

Interface modes

Currently the Kemppi A7 welder interface has support for two modes, which will be customized by selecting the mode in the system parameters.



Note

A warm start is required if the mode is changed.

Interface mode	Description
Memory Channel	The welding parameters (except for pre flow, post flow, and purge time) are stored and set in the power supply using memory channels. The memory channel number is set in the Weld Data editor.
Online Control	The basic parameters such as the synergic line are configured in the memory channel but Wire feed speed, Fine tuning, and the dynamics can be set from the robot.

Setting the interface mode

The interface mode can be set in the **Configuration Editor** in RobotStudio or on the FlexPendant.


- 1 In the **Configuration Editor**, select the topic **Process**.
- 2 Select the type **Kemppi A7 Arc Equipment Properties**.
- 3 Select the robot and set the desired interface mode.
- 4 Restart the controller.

Continues on next page

5 Kemppe Interface Modes


Continued

The configuration editor on the FlexPendant



xx2200001872

The configuration editor in Robotstudio



xx2200001873

6 Weld Editor Interface

6.1 Introduction

Overview

The graphical user interface for the FlexPendant is called the *Weld Editor Interface*. The information is presented in widgets, which are small applications available when starting the application *Production Screen* on the FlexPendant. The Weld Editor Interface consists of tabs where the user can process and modify information such as:

- Ignition parameter
- Heat parameters
- Weld parameters
- End parameters

Unlike the regular data editor, it combines seam data and weld data for intuitive process setup and allows them to be modified at the same time. The Weld Data Editor also validates the data based on information from the welder. The data to edit can be selected either by moving the program pointer to a weld instruction or by using the last weld and seam data.

Widget screens

The default Kemppi A7 installation contains a weld status widget. It is placed on widget page 1. The widget displays the following useful information:

- Program pointer
- Seam name
- Current arc instruction data
For example, (1) p22, sm2, wdWeave11, wv1 (1 = Arc instruction sequence number).
- Current weld speed
- Current weld mode
- In **Memory Channel**, the channel number is shown
- In online control mode, the additional information such as wire feed speed, fine tuning, and dynamics are shown
- Process (currently active process)
- Process status, weld on/off, active weld error, real-time voltage and current

To switch between robots in a MultiMove setup, use the robot task selector in the upper right corner of the widget.

Continues on next page

6 Weld Editor Interface

6.1 Introduction

Continued

Memory Channel mode

Page 1

T_ROB1 Prog Pointer PART_1 SeamName Seam_1 T_ROB1

(2) *, seam1, weld1, weave1, track1

Memory Channel 1 Process 1-MIG

Weld Speed 7 [mm/s]

Process On Error

40,7 310 0,0

Volt Amp Gas

Setup Service Info Part A7 MIG R1 WvTr R1 1/2

Production Window Production Screen

xx2200001874

Online control mode

Page 1

T_ROB1 Prog Pointer PART_1 SeamName Seam_1 T_ROB1

"13:03:58 Started Kemppe Equip"

Memory Channel 1 Process 1-MIG

Weld Speed 7 [mm/s]

Wirefeed Speed 8 [m/min] Range < 0.5 - 25.0 >

FineTuning 0 [Volt] Range < -9.0 - + 9.0 >

Dynamics 0 [steps] Range < -9.0 - + 9.0 >

Process On Error

44,3 398 0,0

Volt Amp Gas

Setup Service Info Part A7 MIG R1 WvTr R1 1/2

Production Window Production Screen

xx2200001875

Continues on next page

Starting the Weld Editor Interface

- 1 On the FlexPendant, tap the **ABB** menu and then tap **Production Screen**.
- 2 Tap **A7 MIG R1** to start the Weld Editor widget.
- 3 Tap **Production Screen** to close the window and return to the previous window.

6 Weld Editor Interface

6.2 Weld Editor in online control mode

6.2 Weld Editor in online control mode

Ignition parameters

Tap the **Ignition** tab to view or modify the ignition phase parameters.



Note

Do not manipulate seam/welddata using the RAPID datatype editor. This can result in unwanted behavior and wrong welding parameters which can in worst case damage your welding equipment. Use the Weld mode editor.

The ignition phase parameters can only be modified in manual mode.



Tip

To copy the current weld phase mode settings, toggle **Use Weld Phase Mode** off, on, and then off again.

Manual
DE-L-7302296

Guard Stop
Stopped (Speed 100%)

Seam: seam1, Weld: weld1

<MainModule>TASK PERS seam1:=[0,0,[7,0,0,133.333,1.5,2,0,0,0],0,0,0,0,0,[0,0,0,0,0,0,...

Ignition	Heat	Weld	End
Purge Time	<input type="text" value="0"/> s	Ign Move Delay	<input type="text" value="0"/> s
Pre Flow	<input type="text" value="0"/> s		
		<input type="checkbox"/> Use Weld Phase Mode	
Memory Channel	<input type="button" value="<"/> <input type="text" value="7"/> <input type="button" value=">"/>		
Wirefeed Speed	<input type="button" value="<"/> <input type="text" value="8.00"/> <input type="button" value=">"/> Range <0,5 - 25,0> m/min		
Fine Tuning	<input type="button" value="<"/> <input type="text" value="1.5"/> <input type="button" value=">"/> Range <-9,0 - 9,0> Volt		
Dynamics	<input type="button" value="<"/> <input type="text" value="2"/> <input type="button" value=">"/> Range <-9 - 9>		

Production Window

Production Screen

ROB_1
1/3

xx2200001876

Button	Description
Refresh	Use the blue refresh button to return to the Weld Phase tab.
Confirm	Use the green check button to confirm any changes made.
Cancel	Use the red cancel button to cancel any changes made and return to the previous values.

Continues on next page

Parameter	Description
Ign Move Delay	The delay (in seconds) from the time the arc is considered stable at ignition until the heat phase is started.
Purge Time	The time (in seconds) it takes to fill the gas lines and the welding gun with protective gas, also called <i>gas purging</i> .
Pre-Flow Time	The time (in seconds) it takes to pre-flow the weld object with protective gas, also called <i>gas pre-flow</i> .
Use Weld Phase Mode	Not selected: Select weld parameters during ignition phase manually. Selected: Use the parameters from the Weld tab. This is the default mode.
Memory Channel	This represents the memory channel in the welder.
Wire Feed Speed	This is the wire feed speed.
Fine Tuning	This parameter represents the arc length when welding in synergic mode. The range is -9.0 to +9.0. -9 = shorter arc 0 = value from line +9 longer arc The actual value range in Volts is also shown as, Actual <x.x – y.y> [V] .
Dynamics	Control the arc behavior in short circuit. A lower value results in a softer arc and a higher value result in a rougher arc. The allowed value is -9 to +9.

Heat parameters

Tap the Heat tab to view or modify heat phase parameters.



Note

The heat phase parameters can only be modified in manual mode.



Tip

To copy the current weld phase mode settings, toggle **Use Weld Phase Mode** off, on, and then off again.

Continues on next page

6 Weld Editor Interface

6.2 Weld Editor in online control mode

Continued

xx2200001877

Button	Description
Refresh	Use the blue refresh button to return to the Weld Phase tab.
Confirm	Use the green check button to confirm any changes made.
Cancel	Use the red cancel button to cancel any changes made and return to the previous values.

Parameter	Description
Heat Dist / Heat as time	The distance during which the heat data is active at the start of the weld. If the parameter <i>Heat as time</i> is active, the distance will be replaced by time (in seconds).
Heat Speed	The welding speed during the heat phase at the start of the weld phase.
Use Weld Phase Mode	Not selected: Select weld parameters during ignition phase manually. Selected: Use the parameters from the Weld tab. This is the default mode.
Memory Channel	This represents the memory channel in the welder.
Wire Feed Speed	This is the wire feed speed.
Fine Tuning	This parameter represents the arc length when welding in synergic mode. The range is -9.0 to +9.0. -9 = shorter arc 0 = value from line +9 longer arc The actual value range in Volts is also shown as, Actual <x.x - y.y> [V] .
Dynamics	Control the arc behavior in short circuit. A lower value results in a softer arc and a higher value result in a rougher arc. The allowed value is -9 to +9.

Continues on next page

Weld parameters

Tap the Weld tab to view or modify weld phase parameters.

Note

The weld phase parameters can only be modified in manual mode.

Manual
DE-L-7302296

Guard Stop
Stopped (Speed 100%)

Seam: seam1, Weld: weld1

<MainModule>TASK PERS weld1:=[7,0,[1,0,0,133.333,1.5,0,0,0,0],[0,0,0,0,0,0,0,0]]

Ignition	Heat	Weld	End
<div style="font-size: 0.9em;"> <p>Weld Speed < <input style="width: 40px; text-align: center;" type="text" value="7"/> > mm/s</p> <p>Memory Channel < <input style="width: 40px; text-align: center;" type="text" value="1"/> > Unknown Process</p> <p>Wirefeed Speed < <input style="width: 40px; text-align: center;" type="text" value="8.00"/> > Range <0,5 - 25,0> m/min</p> <p>Fine Tuning < <input style="width: 40px; text-align: center;" type="text" value="2.0"/> > Range <-9,0 - 9,0> Volt</p> <p>Dynamics < <input style="width: 40px; text-align: center;" type="text" value="0"/> > Range <-9 - 9></p> </div>			

Production Window

Production Screen

ROB_1
1/3

xx2200001878

Button	Description
Refresh	Use the blue refresh button to return to the Weld Phase tab.
Confirm	Use the green check button to confirm any changes made.
Cancel	Use the red cancel button to cancel any changes made and return to the previous values.

Parameter	Description
Weld speed	The speed of the TCP of the welding torch during the weld instruction.
Memory Channel	This represents the memory channel in the welder.
Wire Feed Speed	This is the wire feed speed.
Fine Tuning	This parameter represents the arc length when welding in synergic mode. The range is -9.0 to +9.0. -9 = shorter arc 0 = value from line +9 longer arc The actual value range in Volts is also shown as, Actual <x.x - y.y> [V].
Dynamics	Control the arc behavior in short circuit. A lower value results in a softer arc and a higher value result in a rougher arc. The allowed value is -9 to +9.

Continues on next page

6 Weld Editor Interface

6.2 Weld Editor in online control mode

Continued

End parameters

Tap the **End** tab to view or modify end phase parameters.



Note

The end phase parameters can only be modified in manual mode.



Tip

To copy the current weld phase mode settings, toggle **Use Weld Phase Mode** off, on, and then off again.

xx2200001879

Button	Description
Refresh	Use the blue refresh button to return to the Weld Phase tab.
Confirm	Use the green check button to confirm any changes made.
Cancel	Use the red cancel button to cancel any changes made and return to the previous values.

Parameter	Description
Cool Time	The time (in seconds) during which the process is stopped, allowing the weld to cool before other end activities such as crater fill and burn back take place.
Fill Time	The crater-filling time (in seconds) at the end phase of the weld.
Post Flow	The time (in seconds) for purging with protective gas after the end of the process.

Continues on next page

Parameter	Description
Use Weld Phase Mode	Not selected: Select weld parameters during ignition phase manually. Selected: Use the parameters from the Weld tab. This is the default mode.
Memory Channel	This represents the memory channel in the welder.
Wire Feed Speed	This is the wire feed speed.
Fine Tuning	This parameter represents the arc length when welding in synergic mode. The range is -9.0 to +9.0. -9 = shorter arc 0 = value from line +9 longer arc The actual value range in Volts is also shown as, Actual <x.x – y.y> [V] .
Dynamics	Control the arc behavior in short circuit. A lower value results in a softer arc and a higher value result in a rougher arc. The allowed value is -9 to +9.

6 Weld Editor Interface

6.3 Weld Editor in Memory Channel mode

6.3 Weld Editor in Memory Channel mode

Ignition parameters

Tap the **Ignition** tab to view or modify the ignition phase parameters.



Note

Do not manipulate seam/welddata using the RAPID datatype editor. This can result in unwanted behavior and wrong welding parameters which can in worst case damage your welding equipment. Use the Weld mode editor.

The ignition phase parameters can only be modified in manual mode.



Tip

To copy the current weld phase mode settings, toggle **Use Weld Phase Mode** off, on, and then off again.

xx2200001880

Button	Description
Refresh	Use the blue refresh button to return to the Weld Phase tab.
Confirm	Use the green check button to confirm any changes made.
Cancel	Use the red cancel button to cancel any changes made and return to the previous values.

Continues on next page

Parameter	Description
Ign Move Delay	The delay (in seconds) from the time the arc is considered stable at ignition until the heat phase is started.
Purge Time	The time (in seconds) it takes to fill the gas lines and the welding gun with protective gas, also called <i>gas purging</i> .
Pre-Flow Time	The time (in seconds) it takes to pre-flow the weld object with protective gas, also called <i>gas pre-flow</i> .
Use Weld Phase Mode	Not selected: Select weld parameters during ignition phase manually. Selected: Use the parameters from the Weld tab. This is the default mode.
Memory Channel	The memory channel (schedule) that should be selected within the welder.

Heat parameters

Tap the Heat tab to view or modify heat phase parameters.



Note

The heat phase parameters can only be modified in manual mode.



Tip

To copy the current weld phase mode settings, toggle **Use Weld Phase Mode** off, on, and then off again.

Manual
DE-L-7302296

Guard Stop
Stopped (Speed 100%)

Seam: seam1, Weld: weld1

<MainModule>TASK PERS seam1:=[0,0,[7,0,0,133.333,3.2,2,0,0,0],0,0,7,0,0,[1,0,0,133.3...

Ignition	Heat	Weld	End
<div style="display: flex; justify-content: space-between;"> <div>Heat Dist <input style="width: 60px; text-align: center;" type="text" value="0"/> mm</div> </div> <div style="display: flex; justify-content: space-between; align-items: center;"> <div>Heat Speed <input style="width: 60px; text-align: center;" type="text" value="7.5"/> mm/s</div> <div><input type="checkbox"/> Use Weld Phase Mode</div> </div> <div style="display: flex; justify-content: space-between;"> <div>Memory Channel <input style="width: 60px; text-align: center;" type="text" value="1"/></div> </div>			

ROB_1

1/3

xx2200001881

Continues on next page

6 Weld Editor Interface

6.3 Weld Editor in Memory Channel mode


Continued

Button	Description
Refresh	Use the blue refresh button to return to the Weld Phase tab.
Confirm	Use the green check button to confirm any changes made.
Cancel	Use the red cancel button to cancel any changes made and return to the previous values.

Parameter	Description
Heat Dist / Heat as time	The distance during which the heat data is active at the start of the weld. If the parameter <i>Heat as time</i> is active, the distance will be replaced by time (in seconds).
Heat Speed	The welding speed during the heat phase at the start of the weld phase.
Use Weld Phase Mode	Not selected: Select weld parameters during ignition phase manually. Selected: Use the parameters from the Weld tab. This is the default mode.
Memory Channel	The memory channel (schedule) that should be selected within the welder.



Weld parameters

Tap the Weld tab to view or modify weld phase parameters.





Note

The weld phase parameters can only be modified in manual mode.

Manual
DE-L-7302296



Guard Stop
Stopped (Speed 100%)








Seam: seam1, Weld: weld1

<MainModule>TASK PERS weld1:=[7,0,[1,0,0,133.333,2,0,0,0,0],[0,0,0,0,0,0,0,0]]


Ignition	Heat	Weld	End
<div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> Weld Speed <div style="display: flex; align-items: center;"> < <div style="border: 1px solid black; padding: 2px 10px; text-align: center; margin: 0 5px;">7.5</div> > mm/s </div> </div> <div style="display: flex; justify-content: space-between;"> Memory Channel <div style="display: flex; align-items: center;"> < <div style="border: 1px solid black; padding: 2px 10px; text-align: center; margin: 0 5px;">1</div> > Unknown Process </div> </div>			

ROB_1
1/3



xx2200001882

Button	Description
Refresh	Use the blue refresh button to return to the Weld Phase tab.

Continues on next page

Button	Description
Confirm	Use the green check button to confirm any changes made.
Cancel	Use the red cancel button to cancel any changes made and return to the previous values.

Parameter	Description
Weld speed	The speed of the TCP of the welding torch during the weld instruction.
Memory Channel	The memory channel (schedule) that should be selected within the welder.

End parameters

Tap the End tab to view or modify end phase parameters.



Note

The end phase parameters can only be modified in manual mode.



Tip

To copy the current weld phase mode settings, toggle **Use Weld Phase Mode** off, on, and then off again.

Manual
DE-L-7302296

Guard Stop
Stopped (Speed 100%)

Seam: seam1, Weld: weld1

<MainModule>TASK PERS seam1:=[0,0,[7,0,0,133.333,3.2,2,0,0,0],0,0,7.5,0,0,[1,0,0,133...

Ignition	Heat	Weld	End
Cool Time	<input type="text" value="0"/> s	Post Flow	<input type="text" value="0"/> s
Fill Time	<input type="text" value="0.5"/> s		
		<input type="checkbox"/> Use Weld Phase Mode	
Memory Channel	<input type="text" value="1"/>		

Production Window

Production Screen

ROB_1

1/3

xx2200001883

Button	Description
Refresh	Use the blue refresh button to return to the Weld Phase tab.
Confirm	Use the green check button to confirm any changes made.

Continues on next page

6 Weld Editor Interface

6.3 Weld Editor in Memory Channel mode

Continued

Button	Description
Cancel	Use the red cancel button to cancel any changes made and return to the previous values.

Parameter	Description
Cool Time	The time (in seconds) during which the process is stopped, allowing the weld to cool before other end activities such as crater fill and burn back take place.
Fill Time	The crater-filling time (in seconds) at the end phase of the weld.
Post Flow	The time (in seconds) for purging with protective gas after the end of the process.
Use Weld Phase Mode	Not selected: Select weld parameters during ignition phase manually. Selected: Use the parameters from the Weld tab. This is the default mode.
Memory Channel	The memory channel (schedule) that should be selected within the welder.

6.4 Tuning of weld parameters

Introduction

Weld parameters marked with the arrows in the Weld Editor can be tuned, either offline (when not welding) or online (when welding).

When welding, these parameters can be tuned within the range with immediate response. Parameters in the **Weld** tab are easiest to tune.

Parameters that can be tuned in online control mode:

- Weld Speed
- Wirefeed Speed
- Fine Tuning
- Dynamics

Parameters that can be tuned in Memory Channel mode:

- Weld Speed

6 Weld Editor Interface

6.5 How to edit welddata using the partdata concept

6.5 How to edit welddata using the partdata concept

The partdata concept


The option *Production Manager* is needed to be able to use the partdata concept. Even though Production Manager is not configured to control the robot cell, its partdata concept can be used to edit welddata.

Additional information on how to use Production Manager and its part data can be found in *Application manual Production Manager*.

The optional argument `\SeamName` has to be used in the instruction `ArcLStart` to be able to show the seam in the editor.

Example

Here is an example how the welddata can be changed without the RAPID data editor or moving the program pointer around. The example consists of three parts which are configured in Production Manager.



xx2200001884

Continues on next page

RAPID example

```

10 TASK PERS partdata pd_Part_1=["Part_1","Discription of Part_1","",1,0,"",""];
11 TASK PERS partdata pd_Part_2=["Part_2","Discription of Part_2","",1,0,"",""];
12 TASK PERS partdata pd_Part_3=["Part_3","Discription of Part_3","",1,0,"",""];
13
14
15 PROC Part_1()
16   ActUnit STN1;
17   MoveJ p1,v1000,z10,tWeldGun\WObj:=wobjStn1;
18   ArclStart p2,v1000,sm1,wd1,fine,tWeldGun\WObj:=wobjStn1\SeamName:="Part_1_Pth_1_Weld_1";
19   Arcl p3,v100,sm1,wd1,z1,tWeldGun\WObj:=wobjStn1;
20   Arcl p4,v100,sm1,wd1,z1,tWeldGun\WObj:=wobjStn1;
21   Arcl p5,v100,sm1,wd1,z1,tWeldGun\WObj:=wobjStn1;
22   ArclEnd p6,v100,sm1,wd1,fine,tWeldGun\WObj:=wobjStn1;
23   MoveL p7,v1000,z10,tWeldGun\WObj:=wobjStn1;
24 ENDPROC
25
26
27
28 PROC Part_2()
29   ActUnit STN1;
30   MoveJ p1,v1000,z10,tWeldGun\WObj:=wobjStn1;
31   ArclStart p2,v1000,sm2,wd2,fine,tWeldGun\WObj:=wobjStn1\SeamName:="Part_2_Pth_1_Weld_1";
32   Arcl p3,v100,sm2,wd2,z1,tWeldGun\WObj:=wobjStn1;
33   Arcl p4,v100,sm2,wd2,z1,tWeldGun\WObj:=wobjStn1;
34   Arcl p5,v100,sm2,wd2,z1,tWeldGun\WObj:=wobjStn1;
35   ArclEnd p6,v100,sm2,wd2,fine,tWeldGun\WObj:=wobjStn1;
36   MoveL p7,v1000,z10,tWeldGun\WObj:=wobjStn1;
37 ENDPROC
38
39 PROC Part_3()
40   ActUnit STN1;
41   MoveJ p1,v1000,z10,tWeldGun\WObj:=wobjStn1;
42   ArclStart p2,v1000,sm3,wd3,fine,tWeldGun\WObj:=wobjStn1\SeamName:="Part_3_Pth_1_Weld_1";
43   Arcl p3,v100,sm3,wd3,z1,tWeldGun\WObj:=wobjStn1;
44   Arcl p4,v100,sm3,wd3,z1,tWeldGun\WObj:=wobjStn1;
45   Arcl p5,v100,sm3,wd3,z1,tWeldGun\WObj:=wobjStn1;
46   ArclEnd p6,v100,sm3,wd3,fine,tWeldGun\WObj:=wobjStn1;
47   MoveL p7,v1000,z10,tWeldGun\WObj:=wobjStn1;
48 ENDPROC

```

xx220001885


Continues on next page

6 Weld Editor Interface

6.5 How to edit welddata using the partdata concept

Continued


The welddata can now be selected from the Kemppi Production Screen application by selecting the partdata. Start the Kemppi A7 Application and press the partdata button (looking like a small chess board).



xx2200001886


Continues on next page

This will start the following screen and present all partdata found in the system.



xx2200001887

Click on the partdata to edit. In this example, **Part_2_Pth_1_Weld_1**. The used seamdata/welddata is shown in the header. In this example, **sm2/wd2**.



xx2200001888

Continues on next page

6 Weld Editor Interface

6.5 How to edit welddata using the partdata concept

Continued

Tap **Ok** to go back to the Weld Data editor. The editor automatically selects the used seam/welddata from the part. The header is now updated with **sm2/wd2**.

To update the editor with the value from the seam/welddata, tap the blue **Refresh** button.

7 System parameters

Overview

The Kemppi Equipment Class and settings are automatically activated after the controller is started with the Kemppi add-in.

This option has advanced support for a Kemppi A7 350/450 power source that includes support for two welding modes:

- Memory Channel
- Online control

Kemppi A7 Equipment Properties

Parameter	Data type	Description
Name	string	The name of the <i>Fronius Equipment Properties</i> .
Use Equipment Standard IO	string	The name of the <i>Equipment Standard IO</i> to use.
Use Fronius Equipment IO	string	The name of the <i>Equipment Standard IO</i> to use.
Mode	string	The mode of the welder. The following modes are available: <ul style="list-style-type: none"> • Memory Channel, this is default • Online Control
Ignition on	bool	Specifies if the ignition data specified in seamdata is to be used at the start of the weld phase. At the start it is often beneficial to define higher weld data values for a better ignition. If the ignition data parameter is changed, the contents of seamdata will also change. Default value: FALSE
Heat on	bool	When the arc is ignited, the seam will generally not have reached the correct temperature. Pre-heating can thus be used at the start of the weld to define higher weld data values. If the pre-heating parameter is changed, the contents of seamdata will also change. Default value: FALSE
Heat defined as time	bool	Specifies if the heat phase should use the seamdata parameters <code>heat_time</code> or <code>heat_distance</code> . TRUE means that <code>heat_time</code> is used and visible in the seamdata. FALSE means that <code>heat_distance</code> and <code>heat_speed</code> is used and visible in the seamdata. Default value: FALSE
Cool time on	bool	Enables masking of the <code>cool_time</code> component in seamdata. Default value: FALSE

Continues on next page

7 System parameters

Continued

Parameter	Data type	Description
Fill on	bool	Specifies whether a crater fill is to be used in the final phase. This means that the end crater that can form in the completed weld will be filled in with extra filler material. If the crater fill parameter is changed, the contents of seamdata will also change. Default value: FALSE
Arc Preset	num	Delays the power control signal with this time (seconds). This gives the analog reference signals and group output signals enough time to stabilize before the weld is started. Default value: 0
Ignition Timeout	num	The maximum time (in seconds) permitted for igniting the welding arc. Default value: 3
Weld off timeout	num	The maximum time (in seconds) permitted for shutting off the welding arc. Default value: 10
Override On	bool	Specifies the visibility of the <code>org</code> value components in <code>welddata</code> . Default value: TRUE
Auto inhibition on	bool	If this flag is set, weld inhibition will be allowed in AUTO mode, otherwise not allowed. Default value: FALSE
Time to feed 15 mm wire	num	The time in seconds to feed 15 mm of wire. Default value: 0.95
Enable supervision in VC	bool	Enables signal supervision in the virtual controller. Default value: FALSE
Enable Watchdog Output	bool	Enable the watchdog functionality with a fixed frequency of 0.5 Hz (2 seconds). Default value: FALSE The watchdog feature must be enabled in the welder.
Allow tuning in Auto	bool	If this flag is set tuning of <code>welddata</code> is allowed in auto mode. Default value: FALSE
Block tuning in Manual	bool	If this flag is set, edit and tuning will be blocked in manual mode from the TPSi editor and from the Weave & Track data editor. Default value: FALSE
Enable Wire Retract	bool	If this flag is set, the wire will be retracted at the end and of weld and feed at start (the specified time in <i>Time to feed 15mm wire</i> . Default value: FALSE
Widget Screen	num	Specifies the start screen (widget) for Production Screen. (Not yet implemented.)
Service port IP	num	The IP address of the welder's service port. This is used in conjunction with the RobotStudio add-in.

Continues on next page

Parameter	Data type	Description
Arc Stable Filter Time Active	num	The active filter time on arc stable. Default value: 50 ms Minimum value: 0 ms Maximum value: 1000 ms
Arc Stable Filter Time passive	num	The passive filter time on arc stable. Default value: 50 ms Minimum value: 0 ms Maximum value: 1000 ms

Kempfi A7 Equipment IO

Parameter	Data type	Description
ArcEst Label	string	Label describing the error level of the signal. There are three available levels, MAJOR, MINOR, and INFO.
WaterOK DI	signalDI	Digital input signal for supervision of the water. A high signal means that the water is OK.
GasOK DI	signalDI	Digital input signal for supervision of the protective gas. A high signal means that the protective gas is OK.
Supervision Welder DO	signalDO	Digital output signal that indicates welder supervision.
Supervision Arc DO	signalDO	Digital output signal for indication of welding arc errors. A high signal means that an error has occurred.
Supervision Water DO	signalDO	Digital output signal for indication of cooling water errors. A high signal means that an error has occurred.
Supervision Gas DO	signalDO	Digital output signal for indication of protective gas errors. A high signal means that an error has occurred.
Supervision Wirestick DO	signalDO	Digital output signal for indication of wire feed errors. A high signal means that an error has occurred.

This page is intentionally left blank

8 Seam Tracking with A7 MIG Welder 350/450

8.1 Introduction

About KEMPPI A7 IRC5 seam tracking

This guide describes the ABB Robotics IRC5 interface for:

- KEMPPI A7 Seam Tracking with fieldbus interface

The power source must meet the requirements specified in section [About Kemppei A7 MIG Welder interface on page 9](#).

Overview

The A7 MIG Welder power sources are based on top of the class inverter technology. They belong to the high-end system class of Kemppei products.

There is a wide range of processes to choose from: MIG, 1-MIG, Pulse, Double Pulse, Brazing, Cladding, WiseRoot+, WiseThin+, WiseFusion, and WisePenetration.

The system can be configured to contain an optimal choice of just the right welding programs for the application. There are welding programs available for all the common filler wire and shielding gas combinations for mild steel, stainless steel, and aluminum.

General functionality

The KEMPPI Tracking function is a powerful software based Through Arc Seam Tracking (TAST) RobotWare option.

Through-Arc Seam Tracking (TAST) is used in arc welding for following a welding groove automatically by weaving the welding gun and measuring the arc length. The seam tracking provides precise welds in setups where the workpiece position within repetitive tasks varies, or when the route of the groove is complicated.

The arc length depends on the wire tip distance from the middle of the groove. Weaving the welding gun between the edges of the groove generates a signal that is directly proportional to the arc length. The generated signal is equivalent to the welding current.

The welding power source measures welding current as a contiguous value during welding. It filters the raw current value to generate a stable signal for the TAST. The TAST signal is valid for all MIG/MAG processes including Pulse MIG and Double Pulse MIG. The TAST signal is passed to the welding robot as a numeric value using the digital robot interface. Using the TAST requires use of certain I/O tables containing a field for the TAST value and the control signal.

The TAST signal is composed inside the power source using welding current and voltage. Value changes as stick-out length varies during welding and is used for real time correction of the weld location during welding.



Note

The TAST signal is updated approximately every 10 ms (100Hz).

8 Seam Tracking with A7 MIG Welder 350/450

8.2 Installation

8.2 Installation

Prerequisites for the robot controller

- IRC5 robot controller with main computer DSQC1000 or later
 - RobotWare version 6.14 or later with the following options:
 - RobotWare Arc
 - Production Screen
 - Tracking Interface
 - Add-in for Kemppi A7 welder
-

Kemppi firmware

The A7 Welder must meet the following Firmware versions for Seam Tracking:

- A7 MIG Welder Robot Interface Firmware $\geq 1.05.00.0$
 - A7 MIG Welder Firmware $\geq 1.04.00.0$ OR If S/N ≥ 3018192 Firmware 2.01
-

RobotStudio

- RobotStudio version 2022 or later
-

Kemppi Tracking Add-In supported functions

The Add-In supports the following tracking functions:

- Centerline tracking
(Corrections are applied for Y/Z)
 - Height tracking only
(Corrections are only applied to Z)
 - Y-tracking only
(Corrections are only applied to Y)
 - Inverted Centerline
(Corrections are applied for -Y/-Z on "outside corners")
 - Single side left
(Corrections are only applied for Y on the left side. Z is set to zero)
 - Single side right
(Corrections are only applied for Y on the right side. Z is set to zero)
 - Adaptive welding to adapt weave width and welding speed based on groove width measurement
-

Limitations

- The option *Weldguide MultiPass* and *Tracking Interface* cannot be used in the same robot task. Either *Tracking Interface* or *Weldguide Multipass* can be used. In a MultiMove environment, each task can have one of these options.
 - Limited support of track modes. Only the modes listed above are supported.
 - Only basic support for Single Side-tracking left/right.
-

Continues on next page

- Aluminum welding and KEMPPI A7 Seam tracking is not supported until further notice.
- In a MultiMove robot, up to two manipulators are supported.
Contact your local ABB representative for more information if your robot has more than two manipulators.

Kemppi Tracking Add-In

The KEMPPI A7 Tracking option consists of the following software components:

- Ready to track Interface with a KEMPPI A7 welder
- Graphical Weave and Track data editor
- Graphical widget displaying run-time data
- MultiPass welding support
- Adaptive welding support (*ArcCalcX* instructions)

For more information on the MultiPass instructions, see *Operating manual - Seam tracking with Weldguide III and MultiPass*.

Installation of seam tracking function

No additional hardware is needed for the seam tracking function on the IRC5 controller. The Kemppi A7 seam tracking function is software based.

8 Seam Tracking with A7 MIG Welder 350/450

8.3 Software installation

8.3 Software installation

Software installation

See section [Software setup on page 18](#).

Continues on next page

8.3.1 KEMPPI A7 Tracking Feedback Signal

Feedback signal

The KEMPPI A7 power source provides a feedback signal (analog input) on the fieldbus that is used with the tracking option. If you have chosen the KEMPPI A7 welder add-in package as the welding interface, then the feedback signal is already pre-defined on the fieldbus and configured in the process parameters, ready to use.

If using the *Standard I/O Welder* interface with adapted fieldbus configuration (EIO mapping), then make sure to have the correct signal configuration (mapping) in the system. The feedback signal can have any name (follow your own naming convention). Connect the signal in the process configuration and re-start the controller.

EIO Mapping Seam Tracking Signal

Parameter	Default value (Old TAST)	Default value (New TAST)
Name	<i>aiWld1SeamTrack</i> (Can be any name)	<i>aiWld1SeamTrack</i> (Can be any name)
SignalType	AI	AI
Device	<i>ioKemppeiWld1</i> (your I/O unit)	<i>ioKemppeiWld1</i> (your I/O unit)
DeviceMap	72-87	72-87
EncType	Unsigned	Unsigned
MaxLog	6500	8191
MaxPys	10	10
MaxPhysLimit	10	10
MaxBitVal	6500	8191
MinLogValue	0	0
MinPys	0	0
MinPysLimit	0	0
MinBitVal	0	0

Default signal definition

```
-Name "aiWld1SeamTrack" -SignalType "AI" -Device "ioKemppeiWld1"
-DeviceMap "72-87" \
-Label "Kemppei A7 Seam tracking feedback" -EncType "UNSIGNED"
-MaxLog 8191 -MaxPhys 10 \
-MaxPhysLimit 10 -MaxBitVal 8191 -Category "Arc_1_R1" -Category
"Arc_1_R1"
```

Old definition based on A7 Firmware < 1.05.00.0

```
-Name "aiWld1SeamTrack" -SignalType "AI" -Device "ioKemppeiWld1"
-DeviceMap "72-87" \
-Label "Kemppei A7 Seam tracking feedback" -EncType "UNSIGNED"
-MaxLog 8191 -MaxPhys 10 \
```

Continues on next page

8 Seam Tracking with A7 MIG Welder 350/450

8.3.1 KEMPPI A7 Tracking Feedback Signal

Continued

```
-MaxPhysLimit 10 -MaxBitVal 6500 -Category "Arc_1_R1" -Category  
"Arc_1_R1"
```

8.3.2 System parameters

Overview

The KEMPPI A7 Seam Tracking function and settings are automatically activated after the controller is started with the KEMPPI A7 Tracking option. However, the system parameters for the tracking function can be modified using the FlexPendant or RobotStudio.

The parameters belong to the type *KEMPPI A7 Tracking Properties* in the topic *Process*.

For more information about system parameters, see *Technical reference manual - System parameters*.

Name	Value	Information
Name	ARC1_KEMPPI_TRACKING_T_ROB1	
Max Inc.Corr (mm)	0,5	
Weave Corr. Delay (Cycles)	1	
Ptrn Sync Threshold	95	
Stop Process DO (for tracking start error)		
Feedback Signal AI	aiWld1SeamTrack	
LogFile	Kemppi1TrackLog.txt	
LogFile Size	1000	
Number of Measurements	1	
Max correction warning	<input type="radio"/> TRUE <input checked="" type="radio"/> FALSE	
Sample on negative Edge	<input type="radio"/> TRUE <input checked="" type="radio"/> FALSE	
Correction Threshold (mm)	0,1	
Correction Threshold Y	0	
Correction Threshold Z	0	
Sample Time (ms)	24	
Simulator Used	<input type="radio"/> TRUE <input checked="" type="radio"/> FALSE	
TAST Function	Standard	

Value (string)
The changes will not take effect until the controller is restarted.

OK Cancel

xx2200001889

Continues on next page

8 Seam Tracking with A7 MIG Welder 350/450

8.3.2 System parameters

Continued

Type KEMPPi A7 Tracking Properties

Parameter	Data type	Description
Name	string	The name of the <i>KEMPPi A7 Tracking Equipment Properties</i> .
Max Incremental Correction	num	The maximum allowed incremental corrections per weave. A good value is 0.5 mm. The value can be increased, but depending on the robot type and weave frequency, the system might oscillate and result in bad tracking behavior. Default value: 0.5 mm Minimum value: 0 mm Maximum value: 2 mm
Weave Correction Delay	num	Number of weave cycles before correction values are applied to the path. Parameter can be used to skip a number of defined cycles if the welding process is unstable in the beginning. Default value: 1 Minimum value: 1 Maximum value: 15
Pattern Sync Threshold	num	The coordination position at the extents of the weaving pattern. It is specified as a percentage of the width on either side of the weaving center. When weaving is carried out beyond this point, a digital output signal is automatically set. Default value: 95% Minimum value: 0 Maximum value: 100
Stop Process DO	signaldo	Not yet implemented. Reserved for future use.
Feedback Signal AI	signalai	The name of the current feedback signal as configured on the fieldbus.
LogFile	string	The name for the tracklog log file. The logfile will be generated and stored in the HOME folder of the robot.
Logfile Size	num	The size of the tracklog ring buffer that is the number of sensor measurements that can be buffered during tracking Unit: measurements Default value: 1,000 Minimum value: 1,000 Maximum value: 10,000
Number of Measurements	num	The number of measurements taken at the extents of the weave pattern. A mean value is carried out and sent as a correction if more than 1 measurement is taken Default value: 1 Minimum value: 1 Maximum value: 5

Continues on next page

Parameter	Data type	Description
Max correction warning	bool	If this parameter is enabled, program execution is not interrupted, when the limit for maximum correction, specified in the track-data, is exceeded. Only a warning will be sent. Default value: FALSE
Sample on negative edge	bool	If set to TRUE, the current measurement is taken with the falling edge of the dwell bits. This can be used to compensate a delay for the current EIO signal used for tracking Default value: FALSE
Correction Threshold	num	The minimum calculated correction in mm that are needed before the corrections are sent to the controller. Unit: mm Default value: 0.1 Minimum value: 0 Maximum value: 2
Correction Threshold Y	num	This as a unit less parameter. It is the minimum feedback value that need to be exceeded before corrections in Y are applied to the controller. Can be used to filter some noise or other disturbances. A higher value will result in a less sensitive tracking system Default value: 50 Minimum value: 0 Maximum value: 500
Correction Threshold Z	num	This parameter is the minimum feedback value that need to be exceeded before corrections in Z are applied to the controller. Can be used to filter some noise or other disturbances. A higher value will result in a less sensitive tracking system Default value: 50 Minimum value: 0 Maximum value: 50
Sample Time	num	Sample time in milliseconds for the correction loop. The value is rounded to a multiple of 24. The minimum value allowed is 24 Unit: milliseconds Default value: 24 Minimum value: 24 Maximum value: 240
Simulator used	bool	Not yet implemented. Reserved for future use. Default value: FALSE

Continues on next page

8 Seam Tracking with A7 MIG Welder 350/450

8.3.2 System parameters

Continued

Parameter	Data type	Description
TAST Function	string	Select the TAST Firmware version. Standard will use the improved TAST functionality. It is not recommended to change this parameter to reverse to the old TAST functionality < Firmware 1.04.00.0 as this not supported. Default: Standard

8.4 Seam tracking

Introduction

A through-the-arc tracking system uses the arc as a sensor to adjust the robot path to the actual location of the part. Measuring the arc voltage and welding current, synchronized with the robot weave pattern, the stick-out length is calculated on both sides and in the middle of the weld. The stick-out length in the middle and the difference between the sides are converted in to robot vertical and horizontal corrections.

It is necessary to understand that there are several tracking modes as well as understanding their relationship within the tracking process.

The tracking methods described below are controlled by the `trackdata` component `track_type`. See [trackdata on page 19](#).

Preparations



Note

Well-functioning seam tracking with an arc sensor requires that the welding process should be adjusted to be stable, so that the arc length can be significantly changed for seam tracking purposes without destabilizing the process. If there are drastic changes in the weld process (instability) the system will react in a drastic manner (that is, the torch dives into the part or the torch loses the seam and wanders all over the welding surface).

The following peripheral conditions prevent seam tracking with an arc sensor:

- Disturbances in the process that interfere too strongly with the length change signals
- De-adjustment of the process during welding (for example, ramps)
- Inappropriate settings for the welding process

Make sure the welding process is reliable before activating seam tracking.

Geometric weaving shall be used for tracking.

Torch to work tracking (height, Z direction)

In torch-to-work mode, the same contact tip to work length is maintained. The contact tip to work distance is specified as reference data stored in the `trackdata`. No weaving is required. Measurements are taken at a fixed frequency of 10 Hz.



xx1300000875

Continues on next page


8 Seam Tracking with A7 MIG Welder 350/450

8.4 Seam tracking

Continued

Centerline tracking


Centerline tracking is the most commonly used tracking method. For centerline tracking the height corrections are based on measurements taken in the zero crossing of the weave pattern (in the middle of the pattern), while Y corrections are based on measurement made on the sides of the weave pattern. The position of the weld can be adjusted side to side using the bias.



xx1300000876

Side tracking (Y-direction only)

In this track mode only Y corrections are calculated based on measurement made on the sides of the weave pattern. The position of the weld can be adjusted side to side using the bias.



xx2200001890

Inverted centerline tracking

For inverted centerline tracking, make sure to use v-shaped weaving and negative height. See data types `weavedata` and `trackdata` in *Application manual - Arc and Arc Sensor*.



xx2200001891


Single side tracking (left and right)

The difference between the centerline tracking method and the single side method is that when using the single side method, data from one side of the weave is used and compared with the reference value. No corrections are applied in the Z direction, only in Y direction.

Continues on next page

The reference value could also be used as a form of weld penetration level. A higher value for means shorter stick out and higher penetration. A higher penetration level makes the weld move further into the selected side. This method can be used when tracking a lap joint, where the arc might consume one of the sides of the groove.

The position of the weld can be adjusted to the side using the bias component in the data type `trackdata`.



xx130000877



Note

The interface only provides basic support for single side tracking. Since the TAST feature is fully software based and no external sensors are used only limited information on either the left or right side of the weaving pattern is available. Problems can occur in such way that the robot TCP moves over the edge of the top metal plate. Once the robot TCP is over the edge, max incremental correction is applied since no side is detected. The robot will stop once the max correction is reached.

If there is a problem or not depends on a lot of factors, the weave width for example. If the weave width is close to the edges, then there is a higher probability of getting problems.

Limits and problems seen with seam tracking

Various peripheral conditions make seam tracking difficult or even impossible.

Some of these conditions are:

- Change of welding wire material such as steel or stainless steel
- Change in wire size
- Extreme Changes to welding parameters such as travel speed, wire feed speed or weave frequency
- Weld position relative to the joint location
- Used shield Gas
- Wire stick-out and welding process (short arc, spray arc or pulsed arc)
- Change in weave parameters such as frequency or weave type/form
- Material surface condition

Continues on next page

8 Seam Tracking with A7 MIG Welder 350/450

8.4 Seam tracking

Continued

Recommendation

Here are some points to consider:

- Weave width should at least 3 times the welding wire size
- A fillet weld may have a max. enclosed angle of 90° and the leg length must be more than 5 mm
- Weaving frequency should not exceed 3 Hz
- Use *Touch sensing* prior welding to locate the start of the weld

8.5 Tracking parameters

Gain_Y: horizontal gain

The recommended starting value is 20. This gain is used to increase or decrease the response of the cross-seam (horizontal) tracking. The lower the number the slower the system will respond to a change of seam direction. This variable impacts the stability of weld bead center. If the weld bead center position is oscillating, (snake shape weld bead) decrease this parameter. If the center position is slow to respond to a change in the center position, increase this parameter.

Gain_Z: vertical gain

The recommended starting value is 30. This gain is used to increase or decrease the response of the torch height (vertical) tracking. The lower the number the slower the system will respond to changes to the work surface or geometry. This variable impacts the stability of torch height. If the torch position is oscillating (moving up and down constantly), decrease this parameter. If the torch position is slow to respond to a change in position, increase this parameter.

Track bias

The position of the weld can be adjusted side to side using the bias.

8 Seam Tracking with A7 MIG Welder 350/450

8.6 Best practice


8.6 Best practice

Installation & setup workflow

- 1 Install a system with the KEMPPPI A7 Seam Tracking add-in.
- 2 Configure the system to be able to weld.
- 3 Create a simple weld routine with weaving (for example, for a T-joint) and develop your `welddata`. Use the graphical editor to define weave data.
- 4 Perform a couple of welds to make sure you have a stable weld process.
- 5 At the optional argument `\Track` and define your `trackdata` (use the graphical editor). Use centerline tracking.
- 6 Check that the track system is set to 2.
- 7 Block tracking and enable Seam Track Reference value calculation in the widget (**Enable** button).
- 8 Weld your seam. At the end the widget will present the reference value for the height corrections, and you can update your trackdata by pressing **Update Data**.

Update seam tracking reference

As mentioned above a good way to update the seam tracking reference is to use the Runtime widget.



xx2200001892

Continues on next page

Example: Puls Process with 7.5 m/min Wire feed speed

For this simple example the following parameters have been used together with pulsed arc on an 8 mm T-Joint. 1.2 mm solid wire and shield gas with 18% CO₂ was used.

Weave parameter

Parameter	Value
Weave length	2.5 mm
Weave width	4 mm
Weave shape	Zig zag
Weave type	Geometric (0)
Frequency	2 Hz

Track parameter

Parameter	Value
Maximum correction	20 mm
Gain Y	20
Gain Z	30
Track Bias	0
Reference Value	836

Weld parameter

Parameter	Value
Weldspeed	5 mm/s
Wirefeed speed	7.5 m/min
Stick out	20 mm
Current Reference	233 Ampere
Sheet Size	8 mm

No Wise Function used.

Simple RAPID example

GRAPHIC



Continues on next page

8 Seam Tracking with A7 MIG Welder 350/450

8.6 Best practice Continued

Active tracking


The robtargets for the End position have been offset by approximately 20 mm to the left right and then welded with active tracking. The path has been corrected and is placed in the center of the groove.

Description	Position
<p>Start point in correct position and End point with an offset.</p> <p>The robot has done the corrections and got pushed into the joint following to joint to the end position. Corrections have been applied in Y/Z (centerline tracking).</p>	 <p>xx2200001893</p>
<p>The robot has done the corrections and got pushed into the joint following to joint to the end position. Corrections have been applied in Y/Z (centerline tracking).</p>	 <p>xx2200001894</p>

8.7 Runtime widget

Introduction

The tracking runtime widget can be used to get the reference value for the height corrections. In addition, it has useful information of the current applied corrections and the accumulated corrections as well as present `trackdata` values. The widget is shown on page 3 in the *Production Screen* application.



xx2200001895

The following data is presented in the runtime widget:

- Task selection to select the active welding robot.
- Currently applied corrections for Y and Z direction [mm].
- Feedback value from the welder taken on the left/right side of the weave pattern.
- Total corrections in seam coordinate system per weld [mm].
- Active trackdata of current weld with information about `trackdata` name, type (center line, Height, Y only), Z reference, gain y, gain z, and bias.
- SeamTrack Reference calculation. Tap **Enable** to start collecting data from the weld. Once the weld is finished, the SeamTrack Reference value will be green and the text will say **Complete**. If the **Update data** button is pressed, the current z ref value in the active `trackdata` will be updated. Tap **Enable** to disable the SeamTrack Reference calculations.


8 Seam Tracking with A7 MIG Welder 350/450

8.8 Weave and track data editor interface

8.8 Weave and track data editor interface

Overview







The tracking option provides a convenient way to edit `weavedata` and `trackdata` using a graphical interface (editor). The editor can be started from *Production Screen*. Tap `WvTrR1` to launch the editor for robot 1. Each welding robot has its own editor.



xx2200001896

Weave editor

The **Weave data editor** tab presents the current data where the program pointer is. Data can only be changed in manual mode. Manual mode is indicated with a green status bar.

		Manual DE-L-7302296	Guard Stop Stopped (Speed 100%)	
59 ArcLStart * sm2 wd2 \Weave:=wv1 \Track:=tr1 \SeamName:="Seam1";				
<mKempfi>PERS wv1:=[1,0,2.5,4,0,0,0,0,0,0,0,0,0,0]				
Weld		Weave		Analog Track
Shape	Zig-zag (1)	Type	Geometric (0)	
Length	< 2.5 > mm	Direction	0 deg	
Width	< 4 > mm	Tilt	0 deg	
Height	< 0 > mm	Orientation	0 deg	
Bias	< 0 > mm	Store Path	<input type="checkbox"/>	
Dwell Left	0 mm	Result Frequency 2 Hz 1.0.190616		
Dwell Center	0 mm			
Dwell Right	0 mm			
  				
Production Screen				ROB_1 1/3

xx2200001897

With the **Weave data editor**, it is possible to edit the current weave data. For more information and a description of the parameters, see *Application manual - Arc and Arc Sensor*.

Continues on next page

Track data editor

The Analog Track data editor tab presents the current data where the program pointer is. Data can only be changed in manual mode. Manual mode is indicated with a green status bar.

xx2200001898

With the help of the track data editor, it is possible to edit the current track data. The following parameters can be changed/set:

Parameter	Value
Type	Select the track type. The following types are supported: <ul style="list-style-type: none"> • Center line • Height Only (Torch to work) • Y-Corrections only • Inverted center line • Single Side R + L
Max correction	The maximum allowed path correction. If the TCP is offset more than <code>max_corr</code> by path corrections, a track error is reported and program execution is stopped (depending on the boolean flag, <code>MaxCorrWarning</code>).
Gain Y	The <code>gain_y</code> parameter defines how big of a correction is sent to the robot. The higher the number, the faster the system corrects. The range of this parameter is from 1 to 100. Initial starting values for this parameter depend on weave size. Start with 30 for most weave widths and 5 for very small weave widths.
Gain Z	The <code>gain_z</code> parameter defines how big of a correction is sent to the robot. The higher the number the faster the system corrects. The range of this parameter is from 1 to 100. Initial starting values for this parameter depend on weave size. Start with 30 for most weave widths and 5 for very small weave widths.

Continues on next page

8 Seam Tracking with A7 MIG Welder 350/450


8.8 Weave and track data editor interface

Continued

Parameter	Value
Track Bias	The bias parameter is used to move the TCP in the seam y direction to bias (offset) one side of the joint or the other. The range for this parameter is from -50 to +50 where +50 is the highest amount of bias achievable in the plus Y direction of the seam coordinates. Used in center line tracking only.
Store path	A checkbox to enable the <code>store_path</code> component in <code>trackdata</code> . Used for saving the path with <i>MultiPass</i> .


9 The Kemppi A7 Logbook Viewer

Introduction



xx220001899

The Logbook Viewer can be started from the Add-Ins tab in Robotstudio. Select Kemppi Logbook Viewer to start.



xx220001900

Supported languages

The Logbook Viewer has support for all languages currently supported by the A7 Welder. These are :

- English
- Finnish
- Chinese
- German
- Norwegian
- Danish
- Dutch
- French

Continues on next page






9 The Kemppi A7 Logbook Viewer

Continued


- Spanish
- Russian
- Portuguese (Brazil)
- Italian

The language will be automatically set to the same language that is active in the welder once the logbook entries are downloaded. If opening a file from the hard disk and no previous logbook entries have been downloaded, the viewer uses the current culture settings.

Buttons

Button	Description
	Start download of the specified number of entries.
	Open a browser dialog and load a previously saved logbook file.
	Save logbook entries to a file.
	Clear logbook files in current view (entries will only be deleted in RobotStudio, not in the welder).
	Start the Web UI.

Settings



xx2200001907

Setting	Description
IP Address	The IP address of the A7 welder. Enter a valid IP address. A ping is sent prior to downloading the logbook entries awaiting a response from the entered client IP.
User	A username is needed if user identification is active in the A7 welder.
PIN Code	A pin code for the selected user is needed if user identification is active in the A7 welder.

Continues on next page

Setting	Description
Start from entry number	Enter a number the download should start from. Leave it empty to start from the most recent logbook entry.
Entries to download	Number of logbook entries to download. Leave it empty to download all entries. Downloading all entries can take some time (up to several minutes) depending on the number of logbook entries available in the welder. A progress bar is shown as long as the download is active

This page is intentionally left blank


10 Customize widgets

10.1 Production Screen widgets

Introduction

The Kemppi A7 Package provides a set of widgets that can be used. The configuration is done with the template files located in the system's HOME folder.

\HOME\Arc\Kemppi_A7\WidgetConfig



xx2200001908


Copy the template file(s) into the following folder in the systems HOME directory and restart Production Screen.

Continues on next page

10 Customize widgets

10.1 Production Screen widgets

Continued



xx2200001909

The customizable widgets are placed on page 2.


For more information about how to use and setup *Production Screen*, see *Application manual - Production Screen*.

Simulate Process widget

The **Simulate Process** widget can be used in manual and automatic mode. It can be used to test the welding program. The power source simulates a real welding process by using the welding simulation signal.

- A programmed welding path can therefore be travelled without any welding taking place
- All signals are set, just like the real thing (with no timing interdependencies or actual values)
- Arc stable
- No arcs are ignited
- No wire electrode is fed
- The gas solenoid valve is not activated


Continues on next page



xx2200001910

ArcStatus widget

The **ArcStatus** widget has a status LED to indicate active welding process. Also, the widget shows the current seam name and segment.



xx2200001911

Continues on next page


10 Customize widgets

10.1 Production Screen widgets

Continued

Stop Process widget

The **Stop Process** widget can be used to stop the current welding process. This is mainly used for testing and should not be used in real production.



xx2200001912

10.2 Modifying the widgets on the FlexPendant


The widget area

The widget area is a 10x4 grid of cells. Each cell is 60x60 pixels. The smallest space a widget can occupy is one cell.

Widget area navigation

Tap the widget page indicators or the widget page navigation arrows to change widget page.

To access the widget location view, first enable widget move state, then tap and hold the widget. The widget can now be moved by tapping any cell in the widget area.



xx2200001913

Continues on next page

10 Customize widgets

10.2 Modifying the widgets on the FlexPendant

Continued



xx2200001914

The widget can also be moved to a different page. Tap and hold a widget to access the widget location view. Tap the desired page in the widget page indicator. Finally, tap any cell in the widget area.

Index

T
tracking methods, 73



ABB AB

Robotics & Discrete Automation

S-721 68 VÄSTERÅS, Sweden

Telephone +46 (0) 21 344 400

ABB AS

Robotics & Discrete Automation

Nordlysvegen 7, N-4340 BRYNE, Norway

Box 265, N-4349 BRYNE, Norway

Telephone: +47 22 87 2000

ABB Engineering (Shanghai) Ltd.

Robotics & Discrete Automation

No. 4528 Kangxin Highway

PuDong New District

SHANGHAI 201319, China

Telephone: +86 21 6105 6666

ABB Inc.

Robotics & Discrete Automation

1250 Brown Road

Auburn Hills, MI 48326

USA

Telephone: +1 248 391 9000

abb.com/robotics