

ROBOTICS

Application manual

Spot options



Trace back information:
Workspace 23A version a25
Checked in 2023-06-16
Skribenta version 5.5.019

Application manual

Spot options

RobotWare 6.15

Document ID: 3HAC050979-001

Revision: O

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damage to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2004-2023 ABB. All rights reserved.
Specifications subject to change without notice.

Table of contents

| | |
|---|------------|
| Overview of this manual | 9 |
| Product documentation | 13 |
| Safety | 15 |
| 1 Introduction to RobotWare Spot | 17 |
| 1.1 Spot option and features | 17 |
| 1.2 Principles of the Spot option | 20 |
| 1.3 Programming principles | 21 |
| 2 Installation | 23 |
| 2.1 Prerequisites | 23 |
| 2.2 Installation | 24 |
| 3 Configuration | 25 |
| 3.1 Spot process configuration | 25 |
| 3.1.1 The Spot System instance | 27 |
| 3.1.2 The Spot Error Handling instance | 30 |
| 3.1.3 The Spot Equipment instance | 32 |
| 3.1.4 The Spot Weld Equipment instance | 33 |
| 3.1.5 The Spot Gun Equipment instance | 39 |
| 3.1.6 The Spot Media Equipment instance | 46 |
| 3.1.7 The Spot SoftWare Equalizing instance | 48 |
| 3.1.8 The Spot GUI instance | 50 |
| 3.2 Spot I/O configuration | 51 |
| 3.2.1 Spot template I/O configuration for single gun system | 52 |
| 3.2.2 Spot template I/O configuration multiple guns system | 56 |
| 3.2.3 Spot template I/O configuration for MultiMove/MultiProcess systems | 60 |
| 3.3 Spot Weld timer configuration options | 64 |
| 3.3.1 782-1 Bosch DeviceNet AC and 782-7 Bosch DeviceNet MFDC | 64 |
| 3.3.2 782-11 Bosch PROFINET MFDC | 68 |
| 4 Programming | 73 |
| 4.1 Quick start for servo gun | 74 |
| 4.2 Spot weld instructions and data | 75 |
| 4.3 Testing spot weld instructions in simulated mode | 82 |
| 4.4 Gun control | 83 |
| 4.5 Manual actions | 84 |
| 4.6 Process sequence and error handling | 86 |
| 4.7 Weld process timing | 99 |
| 4.8 Process data access | 102 |
| 4.9 Miscellaneous information | 103 |
| 4.9.1 Jogging the robot after unintentional servo gun disconnection | 103 |
| 4.9.2 Tip dressing for servo guns | 104 |
| 4.9.3 Pneumatic spot welding gun and gripper | 105 |
| 4.10 Supervision task SW_SUP | 106 |
| 5 RAPID references | 107 |
| 5.1 Instructions | 107 |
| 5.1.1 SpotL/SpotJ - The basic spot welding instructions | 107 |
| 5.1.2 SpotML/SpotMJ - Spot welding with multiple guns | 113 |
| 5.1.3 SetForce - Close and Open a gun with desired force and time | 118 |
| 5.1.4 CalibL/CalibJ - Calibrate a servo gun during robot movement | 123 |
| 5.1.5 Calibrate - Calibrate a servo gun | 129 |
| 5.1.6 MeasureWearL - Measure current electrode wear and recalculate the TCP | 133 |
| 5.1.7 ReCalcTCP - Calculate current electrode wear and recalculate the TCP | 141 |

| | | |
|----------|---|------------|
| 5.1.8 | IndGunMove - Activates independent mode for a servo gun | 145 |
| 5.1.9 | IndGunMoveReset - Resets servo gun from independent mode | 147 |
| 5.1.10 | OpenHighLift/CloseHighLift - Control the position of a pneumatic gun | 148 |
| 5.1.11 | GunArmSearch - Used to search for a surface | 150 |
| 5.2 | Data types | 152 |
| 5.2.1 | gundata - Equipment specific weld data | 152 |
| 5.2.2 | spotdata - Spot weld data | 157 |
| 5.2.3 | forcedata - Spot gun force data | 161 |
| 5.2.4 | simdata - Simulation data | 164 |
| 5.2.5 | smeqdata - SoftMove Equalizing data | 167 |
| 5.2.6 | searchdata - Search data | 169 |
| 5.3 | Global instructions and functions | 171 |
| 5.3.1 | SwGetCurrTargetName - Get the current robtarget name | 171 |
| 5.3.2 | SwGetCurrSpotName - Get the current spotdata name | 172 |
| 5.3.3 | SwSetIntSpotData - Set the internal spotdata | 173 |
| 5.3.4 | SwSetIntForceData - Set the internal forcedata | 174 |
| 5.3.5 | SwSetIntGunData - Set the internal gundata | 175 |
| 5.3.6 | SwSetIntSimData - Set the internal simdata | 176 |
| 5.3.7 | SwGetCalibData - Get the latest total tip wear and position adjustment | 177 |
| 5.3.8 | SwGetFixTipData - Get the latest fixed tip wear and position adjustment | 178 |
| 5.3.9 | SwGetCurrThickness - Get the latest measured thickness for a spot instruction ... | 179 |
| 5.3.10 | SwGetCurrProclInfo - Get the latest process data for a spot instruction | 180 |
| 5.3.11 | SwDebugState - Activate and deactivate debug state | 181 |
| 5.3.12 | SGClose - Used to close a servo gun | 182 |
| 5.3.13 | SGOpen - Used to open a servo gun | 185 |
| 5.4 | System modules | 187 |
| 5.4.1 | SWUSER | 187 |
| 5.4.2 | SWUSRM | 193 |
| 6 | Software Equalizing | 197 |
| 6.1 | Introduction to Software Equalizing | 197 |
| 6.2 | Some basic definitions | 199 |
| 6.3 | Weld position Touch Up | 202 |
| 6.4 | Releasing of the fixed gun arm and gun opening | 204 |
| 6.5 | Gun arm deflection compensation | 206 |
| 6.6 | Tip wear compensation | 209 |
| 6.7 | Movable gun arm search mode | 215 |
| 6.8 | SoftMove Equalizing | 219 |
| 7 | Servo gun motion control | 229 |
| 7.1 | Servo gun introduction | 229 |
| 7.2 | Installation and service | 230 |
| 7.3 | General motion control for servo guns | 238 |
| 7.4 | Asynchronous movements with force control | 240 |
| 7.5 | Tip management | 242 |
| 7.6 | Stationary gun | 244 |
| 7.7 | Servo tool change | 245 |
| 8 | FlexPendant Interface | 249 |
| 8.1 | Application Overview | 249 |
| 8.2 | Main View | 250 |
| 8.3 | Manual Actions | 254 |
| 8.4 | Process Equipment | 255 |
| 8.5 | Simulation | 256 |
| 8.6 | Configuration | 257 |
| 8.7 | Customizing the UI | 259 |

| | | |
|-----------|---|------------|
| 9 | Bosch FlexPendant Interface | 261 |
| 9.1 | Application Overview | 261 |
| 9.2 | Pre Warning | 264 |
| 9.3 | Weld Fault | 265 |
| 9.4 | Last Weld | 266 |
| 9.5 | Weld Parameters | 267 |
| 9.6 | Communication and configuration | 278 |
| 10 | Customizing RobotWare-Spot | 279 |
| 10.1 | Introduction | 279 |
| 10.2 | Files to be changed during customizing | 280 |
| 10.3 | Customizing guides | 282 |
| 10.3.1 | How to remove not used signals from the process sequence | 282 |
| 10.3.2 | How to remove not used process hooks | 283 |
| 10.3.3 | How to change the number of guns equipment to be used | 284 |
| 10.3.4 | How to define max/min values for data components | 286 |
| 10.3.5 | How to change the Spot data types | 287 |
| 10.3.6 | How to add functionality in the process sequence | 288 |
| 10.3.7 | How to use spot data programmed in the weld timer | 290 |
| 10.3.8 | How to set the number of automatic rewelds after weld error | 292 |
| 10.3.9 | How to change the user modules names and file path | 293 |
| 10.3.10 | How to package and install the result from the customizing | 294 |
| 11 | SpotWare add-in | 295 |
| 11.1 | Distribution | 295 |
| 11.2 | Installation | 296 |
| | Index | 299 |

This page is intentionally left blank

Overview of this manual

About this manual

This manual describes the RobotWare option *Spot* and its configurations *Spot Pneumatic*, *Spot Servo*, and *Spot Servo Equalizing*.

Usage

This manual should be used during installation and configuration of the RobotWare option *Spot*.

Who should read this manual?

This manual is intended for:

- Commissioning personnel
- Service engineers
- Robot programmers
- Personnel responsible for installations and configurations of fieldbus hardware/software
- Personnel responsible for system configuration
- System integrators

Prerequisites

The reader should have the required knowledge of:

- IRC5 programming and usage
- System parameter configuration
- Mechanical installation work
- Electrical installation work
- System parameters and be used to editing these, either via RobotStudio or via cfg-files

References

| References | Document ID |
|--|----------------|
| <i>Operating manual - IRC5 with FlexPendant</i> | 3HAC050941-001 |
| <i>Operating manual - RobotStudio</i> | 3HAC032104-001 |
| <i>Product manual - IRC5</i> | 3HAC021313-001 |
| <i>Product specification - Controller IRC5 with FlexPendant</i> | 3HAC041344-001 |
| <i>Technical reference manual - System parameters</i> | 3HAC050948-001 |
| <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> | 3HAC050917-001 |
| <i>Technical reference manual - RAPID Overview</i> | 3HAC050947-001 |
| <i>Application manual - Additional axes and standalone controller</i> | 3HAC051016-001 |
| <i>Application manual - Servo Gun Setup</i> | 3HAC065014-001 |
| <i>Application manual - SoftMove</i> | 3HAC050977-001 |

Continues on next page

Continued

| References | Document ID |
|---|----------------|
| Application manual - RobotWare Add-Ins | 3HAC051193-001 |
| Application manual - DeviceNet Master/Slave | 3HAC050992-001 |
| Application manual - PROFINET Controller/Device | 3HAC065546-001 |

Revisions

| Revision | Description |
|----------|---|
| - | Released with RobotWare 6.0. |
| A | Released with RobotWare 6.01. |
| A | Released with RobotWare 6.01. <ul style="list-style-type: none"> Updated the path to the template files, see 782-11 Bosch PROFINET MFDC on page 68. |
| B | Released with RobotWare 6.02. <ul style="list-style-type: none"> Possibility to configure supervision task SW_SUP, Supervision task SW_SUP on page 106. Added possibility to use sensor search in MeasureWearL, see MeasureWearL - Measure current electrode wear and recalculate the TCP on page 133. Added possibility to perform a test weld in the CalibL and CalibJ instructions, see CalibL/CalibJ - Calibrate a servo gun during robot movement on page 123. Added possibility to use dual forces in the SetForce instruction, see SetForce - Close and Open a gun with desired force and time on page 118. Added support for Spot in a MultiProcess configuration on 2 robots. |
| C | Released with RobotWare 6.03. <ul style="list-style-type: none"> Changed template I/O naming for MultiGun and MultiMove configurations, see Spot I/O configuration on page 51. |
| D | Released with RobotWare 6.04. <ul style="list-style-type: none"> Changed template gun names in the SWUSER modules, see gundata - Equipment specific weld data on page 152. Improved information on how to define TCP, see How to define the TCP on page 199. Improved handling of independent gun mode in SetForce, see SetForce - Close and Open a gun with desired force and time on page 118. Improved gun force gravity compensation, see Servo gun force gravity compensation on page 233. General improvements. |
| E | Released with RobotWare 6.05. <ul style="list-style-type: none"> Added possibility to handle tip change and tip wear supervision errors in the MeasureWearL and ReCalcTCP instructions in the user defined error handling. Added supervision of force calibration status of used gun, and also a possibility to create a default force table in the ManualForceCalib and ManualServiceCalib service routines. |
| F | Released with RobotWare 6.06. <ul style="list-style-type: none"> Limitations regarding servo tool change has been updated. Water flow supervision information improved. Added possibility to configure gun deflection parameters via system parameters. |

Continues on next page

| Revision | Description |
|----------|--|
| G | Released with RobotWare 6.07. <ul style="list-style-type: none"> References to the new manual <i>Application manual - Servo Gun Setup</i>, that replace the old <i>Application manual - Servo Gun Tuning</i>. Added possibility to configure gun force unit, see The Spot System instance on page 27 Misc. information improvements. |
| H | Released with RobotWare 6.08. <ul style="list-style-type: none"> Improved information about automatic rewelding and valid program check, see The Spot Weld Equipment instance on page 33. |
| J | Released with RobotWare 6.09. <ul style="list-style-type: none"> Improved information about default handling of I/O signals. Limitation information updated for instructions SpotL/SpotJ and SpotML/SpotMJ in SpotL/SpotJ - The basic spot welding instructions on page 107 and SpotML/SpotMJ - Spot welding with multiple guns on page 113. Possibility to run some Spot functionality without robot, i.e. a stand alone controller setup. Force calibration, possibility to specify minimum gun force, see Servo gun force calibration on page 231. Increased max allowed tip change and tip wear supervision data. Spot option released as a stand alone add-in, accessible from Robot-Studio Add-Ins, see SpotWare add-in on page 295. |
| K | Released with RobotWare 6.11. <ul style="list-style-type: none"> Added information about how to use custom user modules, see How to change the user modules names and file path on page 293. Reference position is automatically checked in MeasureWearL, see Program execution on page 138. Added possibility to perform a single weld in touch up mode. Added missing information about the function SwGetCurrThickness see SwGetCurrThickness - Get the latest measured thickness for a spot instruction on page 179. |
| L | Released with RobotWare 6.12. <ul style="list-style-type: none"> Added information about how to setup and use gravity compensation from motion configuration, see gravity compensation parameters in The Spot Gun Equipment instance on page 39. Merged SpotWare Addin version 1.05. Misc. information improvements. Added information about the movable gun arm search (MGAS) functionality. |
| M | Released with RobotWare 6.13. <ul style="list-style-type: none"> Added new licensed additional sub option to enable access to process related data. 1585-1 Process data access. New instruction SwGetCurrProcInfo to get latest weld process information. Added possibility to add and use optional data 'part id' in spotdata. New instruction SwDebugState to activate and deactivate debug state. Merged SpotWare Addin versions up to release 1.08, see separate release notes regarding changes in the SpotWare addin Minor illustration updates. |
| N | Released with RobotWare 6.14. <ul style="list-style-type: none"> Updated limitation information regarding instruction IndGunMoveReset. |

Continues on next page

Overview of this manual

Continued

| Revision | Description |
|----------|--|
| O | <p>Released with RobotWare 6.15.</p> <ul style="list-style-type: none"><li data-bbox="592 338 1412 398">• Added description of the new servo gun specific instructions SGClose and SGOpen.<li data-bbox="592 398 1412 427">• Added new instruction GunArmSearch.<li data-bbox="592 427 1412 459">• Miscellaneous information improvements. |

Product documentation

Categories for user documentation from ABB Robotics

The user documentation from ABB Robotics is divided into a number of categories. This listing is based on the type of information in the documents, regardless of whether the products are standard or optional.



Tip

All documents can be found via myABB Business Portal, www.abb.com/myABB.

Product manuals

Manipulators, controllers, DressPack/SpotPack, and most other hardware is delivered with a **Product manual** that generally contains:

- Safety information.
 - Installation and commissioning (descriptions of mechanical installation or electrical connections).
 - Maintenance (descriptions of all required preventive maintenance procedures including intervals and expected life time of parts).
 - Repair (descriptions of all recommended repair procedures including spare parts).
 - Calibration.
 - Troubleshooting.
 - Decommissioning.
 - Reference information (safety standards, unit conversions, screw joints, lists of tools).
 - Spare parts list with corresponding figures (or references to separate spare parts lists).
 - References to circuit diagrams.
-

Technical reference manuals

The technical reference manuals describe reference information for robotics products, for example lubrication, the RAPID language, and system parameters.

Application manuals

Specific applications (for example software or hardware options) are described in **Application manuals**. An application manual can describe one or several applications.

An application manual generally contains information about:

- The purpose of the application (what it does and when it is useful).
- What is included (for example cables, I/O boards, RAPID instructions, system parameters, software).
- How to install included or required hardware.
- How to use the application.

Continues on next page

- Examples of how to use the application.

Operating manuals

The operating manuals describe hands-on handling of the products. The manuals are aimed at those having first-hand operational contact with the product, that is production cell operators, programmers, and troubleshooters.

Safety

Safety regulations

Before beginning mechanical and/or electrical installations, ensure you are familiar with the safety information in the product manuals for the robot.

The integrator of the robot system is responsible for the safety of the robot system.

This page is intentionally left blank

1 Introduction to RobotWare Spot

1.1 Spot option and features

The Spot option

The Spot option is a general and flexible software platform for creation of customized and easy to use function packages for different types of spot welding systems and process equipment.

The Spot option software provides dedicated spot welding instructions for fast and accurate positioning combined with gun manipulation, process start and supervision of the different gun equipment.

Communication with the external welding equipment is done with standard I/O interface.

The Spot option is general and can be extensively customized. It has a default "template" functionality after installation, that can easily be customized to fit the surrounding equipment(s) by changing I/O signals, configuration data, RAPID data, and RAPID routines from RobotStudio.

The Spot option software is also available as an RobotWare add-in, see [SpotWare add-in on page 295](#).

Continues on next page


1 Introduction to RobotWare Spot

1.1 Spot option and features

Continued

Overview of the Spot option

The Spot option software can be customized to handle different types of process equipment(s), and this picture below shows 2 basic schematic examples of different spot welding systems and the Spot option software.



Configuration variants

There are three different main **Spot** configurations variants supporting spot welding, two for servo guns and one for pneumatic guns.

- The **Spot Pneu** configuration provides support for sequential welding with one gun equipment. For this configuration it is also possible to select a multiple gun configuration when configuring the system, with support for welding with up to four pneumatic guns at the same time.
- The **Spot Servo** configuration provides support for sequential welding with one gun equipment. For this configuration it is also possible to select a multiple gun configuration when configuring the system, with support for welding with up to four servo guns at the same time.
- The **Spot Servo Equalizing** configuration has the same functionality as the basic **Spot Servo Equalizing** configuration, but can also be used for guns without mechanical equalizing systems.

Continues on next page

Features

The Spot option packages contains the following features:

- Fast and accurate positioning using the unique *QuickMove* and *TrueMove* concept.
- Gun pre-closing, gun closing will be synchronized with robot reaching the weld position to save cycle time.
- Software equalizing functions (if the Spot Servo Equalizing configuration is installed).
- Support for mechanical gun equalizing systems.
- Support functions for tip wear management.
- Constant or changeable gun force during welding for servo guns.
- Gravity compensation of gun force during welding.
- Calibration functions for servo guns.
- Detection of missing or improper plates for servo guns.
- Reverse execution with gun control.
- Manual actions for welding and gun control.
- Support for fast tool changing between up to 8 different servo guns. Note that this requires the option *630-1 Servo Tool Change*.
- Support for simultaneous welding with up to four guns at the same time (for MultiMove systems with 2 robots, up to two guns each for simultaneous welding).
- Several simulation possibilities for test purposes.
- Weld error recovery with automatic rewelding.
- Default "ready to use" functionality directly after installation if a SpotPack configuration is selected.
- Wide customizing possibilities, process data types, spotdata, gundata, such as weld counters and tip wear data, for each used gun.
- Built in error handling and possibility for customizable user-defined supervision and error recovery.
- A dedicated Spot operator interface on the FlexPendant.
- Integrated weld equipment fault management (for the options *782-x Bosch Weld timer*)
- Support for Spotwelding on two robots in a MultiMove system, and run semi coordinated using WaitSyncTask. Note that option *634-1 MultiProcess* is required for more than one robot in a MultiMove system.
- Possibility to run some Spot functionality without a robot selected, i.e. a stand alone controller system.
- Possibility for weld process data access. Note that option *1585-1 Process data access* is required.

1 Introduction to RobotWare Spot

1.2 Principles of the Spot option

1.2 Principles of the Spot option

Process tasks

The spot welding process will be controlled by separate internal hidden semi static tasks, which will run independently from the motion task.

The robot movements, the spot welding process and the continuous supervision will be handled in different independent tasks. This means that if for example the program execution and thus the robot movements is stopped, then the welding and supervision will continue until they come to a well defined process stop.

For example, the welding process will carry on and finish the weld and open the gun, although the program has been stopped during the weld phase.

The tasks running the spot weld processes are hidden and will not be visible on the FlexPendant or in RobotStudio. Only the motion task and the default supervision task are visible.

User routines and modules

At well defined places in the welding sequence, customizable user routines (hooks) will be executed. This offers the possibility to adapt the software to different preconditions and environments other than the default behaviour.

A number of customizable data types are also available to shape the behavior of the spot weld instructions.

1.3 Programming principles

Introduction

Both the robot movement and the control of the spot weld equipment are embedded in the basic spot weld instructions `SpotL` and `SpotJ`. These are used for sequential welding and are available in all spot welding options. If there is a need to weld with several guns simultaneously then the instructions `SpotML` or `SpotMJ` are available for that purpose. See [RAPID references on page 107](#).

- Each spot welding process is specified by:
 - `spotdata`: spot weld process data. See [spotdata - Spot weld data on page 157](#).
 - `gundata`: spot weld equipment data. See [gundata - Equipment specific weld data on page 152](#).
- The system module SWUSR: Process data and RAPID routines for data transfer between user code and kernel code. See [SWUSR on page 193](#).
- The system module SWUSER: RAPID routines for customization of the process behavior, for example, checking additional external equipment etc. See [SWUSER on page 187](#).
- System parameters: the I/O signal configuration and the manipulator configuration. See [Configuration on page 25](#) and [Installation and service on page 230](#).
- See *Operating manual - IRC5 with FlexPendant* and *Technical reference manual - System parameters*.

Spot instructions

Both the robot movement and the control of the spot weld equipment are embedded in the basic spot weld instructions `SpotL` and `SpotJ`. These are used for sequential welding and are available in all spot welding options. If welding with several guns simultaneously then `SpotML` or `SpotMJ` has to be used.

| Instruction | Used to |
|-------------------------|--|
| <code>SpotL</code> | Control the motion, gun closure/opening and the welding process. Move the TCP along a linear path and perform a spot welding at the end position. |
| <code>SpotJ</code> | Control the motion, gun closure/opening and the welding process. Move the TCP along a non-linear path and perform a spot welding at the end position. |
| <code>SpotML</code> | Control the motion, gun closure/opening and 1 - 4 welding processes. Move the TCP along a linear path and perform spot welding with 1 - 4 gun equipments at the end position. Only available in option <i>3417-2 Spot Welding Premium</i> or <i>3417-3 Spot Welding Premium Plus</i> . |
| <code>SpotMJ</code> | Control the motion, gun closure/opening and 1 - 4 welding processes. Move the TCP along a non-linear path and perform spot welding with 1 - 4 gun equipments at the end position. Only available in option <i>3417-2 Spot Welding Premium</i> or <i>3417-3 Spot Welding Premium Plus</i> . |
| <code>IndGunMove</code> | Set the servo gun in independent mode and thereafter move the gun to a specific independent position. |

Continues on next page

1 Introduction to RobotWare Spot

1.3 Programming principles

Continued

| Instruction | Used to |
|-----------------|--|
| IndGunMoveReset | Reset the independent mode for servo gun. |
| SetForce | Close the gun a predefined time then open the gun. |
| OpenHighLift | Open the pneumatic gun to the highlift position (large gap). |
| CloseHighLift | Close the pneumatic gun to the work stroke position (small gap). |
| CalibL | Calibrate the servo gun during linear movement to the programmed position. |
| CalibJ | Calibrate the servo gun during non-linear movement to the programmed position. |
| Calibrate | Calibrate the servo gun in current position without movement. |
| STTune | Tune motion parameters for the servo gun. |
| STTuneReset | Reset tuned motion parameters for the servo gun. |
| MeasureWearL | Measure the tip wear and recalculates the TCP. Only available if <i>Spot Servo Equalizing</i> is installed. |
| ReCalcTCP | Calculates the tip wear and recalculates the TCP. Only available if <i>Spot Servo Equalizing</i> is installed. |

Spot welding data types

| Data type | Used to define |
|-----------|---|
| spotdata | The spot welding process, weld program number, gun force etc. |
| gundata | The spot welding equipment, gun name, weld counters etc. |
| forcedata | The <i>SetForce</i> process, gun force etc. Normally used for tip dressing. |
| simdata | Simulation modes, controller simulation, weld equipment simulation etc. |

2 Installation

2.1 Prerequisites

RobotWare options

Spot Welding requires the following RobotWare options:

- *635-6 Spot Welding*
- *625-1 Discrete Application Platform*

Depending on specific application needs, the following options may also be needed:

- *1583-1 Movable gun arm search*
- *1585-1 Process data access*
- *782-11 Bosch PROFINET MFDC*
- *832-1 Bosch Weld Timer Interface*
- *635-6 Servo Tool Change*
- *885-1 SoftMove*
- *604-2 MultiMove Independent*
- *634-1 MultiProcess*

The Spot product

The Spot Welding option software is a part of the RobotWare distribution. It is also distributed as a separate RobotWare add-in, this allows for independent release cycles not dependent on the RobotWare releases.


2 Installation

2.2 Installation

2.2 Installation

Selecting the Spot option

A valid license for RobotWare option 635-6 Spot Welding is required for the RobotWare Spot option.




xx190000880

- Select 635-6 Spot Welding in the Drive Modules tab.

Selecting Spot configuration

One of the Application Spot Welding configurations should be selected.



SpotApplicat

- Select desired spot configuration in the Application Spot Welding tree in the Applications tab.

Updating system

Apply the changes in the Confirmation tab and restart the system.

- Click **Apply** to update the system with the Spot Welding option.

Spot Add-in installation

Spot Welding is also distributed as a RobotWare add-in and can be added as an additional product in Installation Manager, see [SpotWare add-in on page 295](#).

3 Configuration

3.1 Spot process configuration

Introduction

This chapter describes the process configuration for the Spot options.

The parameters used for the Spot options are configured in the system parameters, in the **Process** domain.

From the ABB menu on the FlexPendant:

- 1 Tap **Control Panel**.
- 2 Tap **Configuration**.
- 3 Tap **Topics** and select **Process**.

The Spot application can be configured for several equipment setups, but the default setup is for a basic Spot configuration with one gun equipment.

Not used equipment's can also be removed if not needed, or shared in between several equipment instances in the Spot Equipment.



Note

Configuration setup will depend on the selected default equipment template variant.

Spot process configuration

The system parameters for SpotWare are divided in the following instances.

- Spot System
- Spot Error Handling
- Spot Equipment
- Spot Weld Equipment
- Spot Gun Equipment
- Spot Media Equipment
- Spot Equalizing
- Spot GUI

Configuration instances

| Configuration instances | Definitions |
|-------------------------|---|
| Spot System | Configuration of global Spot system specific parameters. |
| Spot Error Handling | Configuration of global Spot error handling parameters. |
| Spot Equipment | Defines the number of used Spot welding equipment's, up to 10 different equipment's are possible. |
| Spot Weld Equipment | Configuration of the Spot welding equipment's, parameters, signals needed in the process. |

Continues on next page

3 Configuration

3.1 Spot process configuration

Continued

| Configuration instances | Definitions |
|-------------------------|---|
| Spot Gun Equipment | Configuration of the Spot gun equipment's, parameters, signals needed in the process. |
| Spot Media Equipment | Configuration of the Spot media equipment's, parameters, signals needed in the process. |
| Spot Equalizing | Configuration of global Software Equalizing specific parameters. |
| Spot GUI | Configuration of the Spot user interface. |

Configuration files



Note

Configuration files and backups shall not be loaded into systems running an older RobotWare version than in which they were created.

Configuration files and backups are not guaranteed to be compatible between major releases of RobotWare and may need to be migrated after a RobotWare upgrade.

Continues on next page

3.1.1 The Spot System instance

Description

The *Spot System* contains parameters for global system settings.

Parameters

The following parameters are used to define the system settings in Spot.



Note

Settings are dependent on actual spot configuration.





| Parameter | Default value | Data type | Note |
|-------------------------|---------------|-----------|---|
| Name | spot_system | string | The name of the system. |
| Gun force unit type | N | string | <p>The used gun force unit type. (Newtons [N], Decanewtons [daN] or Pounds Force [lbf]).</p> Note Default value is Newton, the configured value is used as a string to present the actual gun force values shown on the FlexPendant. No automatic recalculations of any force values will be done if this parameter is changed, it is up to the user to specify correct force unit type and corresponding force values. Force calibration is required if values are changed. See Servo gun force calibration on page 231 . |
| Min gun force | 1000 N | num | <p>The minimum allowed gun force used for welding. (1-2000).</p> <p>This value will be set to 20% of the entered max gun force when performing a force calibration of the gun.</p> Note This value will be checked before weld in order to prevent too low forces. |
| Min force time | 1 s | num | The minimum allowed gun force time in <i>SetForce</i> . (0-2 s) |
| Max force time | 10 s | num | The maximum allowed gun force time in <i>SetForce</i> . (0-15 s) |
| Max simulation time | 10 s | num | The maximum allowed simulation time if simulated weld mode. (0-15 s) |
| Max plate thickness | 40 mm | num | The maximum allowed plate thickness in the system. (0-100 mm) |
| Max plate tolerance | 1 mm | num | The maximum allowed plate tolerance in the system. (0-10 mm) |
| Min allowed tool weight | 10 kg | num | The minimum allowed tool weight when running spot instructions. (0.5-800 kg) |

Continues on next page


3 Configuration

3.1.1 The Spot System instance

Continued

| Parameter | Default value | Data type | Note |
|--|----------------|-----------|--|
| No. of force calibration measurements | 2 | num | The number of force calibration measurements in the <i>ManualForceCalib</i> service routine. (2-10) |
| Sensor thickness for force calibration | 10 mm | num | The thickness of the force sensor used when performing a force calibration with the <i>ManualForceCalib</i> service routine. (0-50 mm) |
| Squeeze time for force calibration | 2 s | num | The squeeze time when when performing a force calibration with the <i>ManualForceCalib</i> service routine. (1-10 s) |
| Process data log activated | Yes | bool | <p>At system startup a log file will be created. The log file will be updated in each spot instruction and also if any error during the process occur.</p> <p>It contains various information related to the process, e.g target id, spot id, gun force, process ok/not ok etc.</p> <p>Location: HOME:/Spot/Logs/SwProcLog.csv.</p> <p>If this parameter is set to No the logging to local file will be deactivated.</p> <p> Note</p> <p>No log file will be created if the sub option 1585-1 Process data access is omitted when building a spot system.</p> <p> Note</p> <p>The content of this log file may be changed and/or expanded in later software releases.</p> |
| Process data log file size | 1 MB | num | <p>Size of the process data log in HOME:/Spot/Logs/SwProcLog.csv.</p> <p>Possible values are: 0.5MB: 1MB: 2MB: 4MB</p> <p> Note</p> <p>When the log file size exceeds the specified value a new log file will be created and the original log file will be renamed to SwProcLog_old.csv.</p> <p>When the new log file exceeds the limit the SwProcLog_old.csv will be permanently deleted and a new backup file will be created.</p> |
| Use Spot Equipment1 - 10 | spotequipment1 | string | The name of the used spot equipment(s) used in the system. Max number of spot equipment's are 10. |
| Motion task user module name | SWUS-RM.SYS | string | <p>The name of the user module running in the motion task only.</p> <p> Note</p> <p>If the user module names are to be changed from the default name this data needs to be changed accordingly.</p> |

Continues on next page

| Parameter | Default value | Data type | Note |
|-----------------------------|---------------|-----------|---|
| All task user module name | SWUSER.SYS | string | <p>The name of the user module running in all tasks.</p> <p> Note</p> <p>If the user module names are to be changed from the default name this data needs to be changed accordingly.</p> |
| Spot user modules file path | HOME:/Spot | string | <p>The location and file path of the spot user modules. Used when saving user data from the calibration and measurement routines, e.g CalibL, MeasureWearLetc.</p> <p>Default path HOME:/Spot.</p> |

3 Configuration

3.1.2 The Spot Error Handling instance




3.1.2 The Spot Error Handling instance

Description





The *Spot Error Handling* contains parameters for global error handling settings.

Parameters

The following parameters and signals are used to define the error handling in Spot.

| Parameter | Default value | Data type | Note |
|-----------------------------------|---------------------|-----------|---|
| Name | spot_error_handling | string | The name of the error handling instance. |
| Number of automatic rewelds | no reweld | num | Automatic reweld: Number of automatic tries to reweld after weld complete timeout before the weld error handling is activated. 0-3 are possible to configure. |
| User defined error handling | No | bool | User defined error handling. The error handling routine <code>SwErrorRecover</code> in <code>SWUSER</code> is called instead of the built in error handling if this parameter is set to Yes. |
| Show 'skip' button in auto mode | No | bool | Show 'Skip' button in automatic mode for weld error recovery, Yes/No.  Note This parameter has no function if User defined error handling is set to Yes. |
| Show 'skip' button in manual mode | Yes | bool | Show 'Skip' button in manual mode for weld error recovery, Yes/No.  Note This parameter has no function if User defined error handling is set to Yes. |
| Show 'ignore' button in auto mode | No | bool | Show 'Ignore' button in automatic mode for tip position error recovery mode, Yes/No.  Note This parameter has no function if User defined error handling is set to Yes. |

Continues on next page

| Parameter | Default value | Data type | Note |
|---|---------------|-----------|--|
| Show 'ignore' button in manual mode | Yes | bool | <p>Show 'Ignore' button in manual mode for tip position error recovery, Yes/No.</p> <p> Note</p> <p>This parameter has no function if User defined error handling is set to Yes.</p> |
| Break error dialogue with 'Skip' | skip_proc | signalDI | <p>Signal to acknowledge operator error dialogue with 'Skip' from an external source, e.g a PLC.</p> <p> Note</p> <p>This parameter has no function if User defined error handling is set to Yes.</p> |
| Break error dialogue with 'Retry' | reweld_proc | signalDI | <p>Signal to acknowledge operator error dialogue with 'Reweld/Retry' from an external source, e.g a PLC.</p> <p> Note</p> <p>This parameter has no function if User defined error handling is set to Yes.</p> |
| Break error dialogue with 'Skip' or 'Retry' | ext_override | signalDI | <p>Summary signal to break operator error dialogue, 'Skip' or 'Reweld/Retry'.</p> <p> Note</p> <p>This parameter has no function if User defined error handling is set to Yes.</p> |

3 Configuration

3.1.3 The Spot Equipment instance

3.1.3 The Spot Equipment instance

Description

The *Spot Equipment* defines the number of spot equipment's defined in the system. Max number of instances are 10.


Parameters

The following parameters and signals are used to define the equipment's in Spot.



Note

Settings will depend on the actual spot configuration.

| Parameter | Default value | Data type | Note |
|-----------------------|-----------------|-----------|--|
| Name | Spot Equipment1 | string | The name of the spot equipment instance. |
| Use Weld Equipment | weldtimer1 | string | Pointer to the used weld equipment. |
| Use Gun Equipment | servogun1 | string | Pointer to the used gun equipment. |
| Use Media Equipment | mediapanel1 | string | Pointer to the used media equipment. |
| Spot GUI equipment OK | diEquipmentOk | signal | Spot GUI equipment OK status signal. |
| Spot process running | doProcessRun | signal | Spot process running signal, set high during the spot process. |
| Spot process fault | doProcessFault | signal | Spot process fault signal, set high if any process fault occurs during process.  Note This signal will be reset if the PP is moved and current instruction is aborted. |



3.1.4 The Spot Weld Equipment instance

Description

The *Spot Weld Equipment* contains parameters for the connected weld equipment's. This instance can be multiplied or shared between several equipment's.

Parameters

The following parameters and signals are used to define the weld equipment's in Spot.

| Parameter | Default value | Data type | Note |
|----------------------------|----------------|-----------|--|
| Name | weldtimer1 | string | The name of the weld equipment instance. |
| Weld process start [DO] | doStartWeld | signaldo | Used to configure the weld start signal for the weld timer. This signal will be set when gun is closed with force and the robot is in position. This signal is mandatory.  Note The setting of this signal can be delayed via a system parameter if the servo gun needs some extra time for the force to be stabilized, Force Ready Delay, see System Parameters, Topic Motion and Type SG Process <i>Technical reference manual - System parameters</i> . |
| Weld process complete [DI] | diWeldComplete | signaldi | Used to configure the weld complete signal for the weld timer. Signal will be set by the weld timer when the current weld sequence is ready. This signal is mandatory. |
| Weld timeout | 2 s | num | The max time waiting for the weld process complete signal, after this time error handling is activated. (0-10 s)  Note If the auto reweld function is activated, the weld will be restarted automatically the specified times before the error handling is activated, see The Spot Error Handling instance on page 30 |

Continues on next page




3 Configuration

3.1.4 The Spot Weld Equipment instance

Continued

| Parameter | Default value | Data type | Note |
|--------------------------|-----------------|-----------|---|
| Enable current [DO] | doEnableCurrent | signaldo | <p>Used to configure the weld current enable signal. This signal is normally set during the process unless simulation in the weld timer or simulation in robot controller is activated. For more information about simulation modes see Simulation modes on page 90.</p> <p>If no signal name is specified here, there will be no function.</p> <p> Note</p> <p>Normally this signal is used in the weld timer to decide if the weld sequence should be run with or without current ("dry weld").</p> |
| Timer ready to weld [DI] | diTimerReady | signaldi | <p>Used to configure the weld timer ready signal. This signal will be set by the weld timer when it is ready to weld and no error is present.</p> <p>If no signal name is specified here, there will be no function.</p> |
| Timer ready timeout | 2 s | num | <p>The max time waiting for the weld timer ready signal, after this time error handling is activated. (0-5 s)</p> |
| Stop weld process [DI] | diWeldFault | signaldi | <p>Used to configure the stop weld process signal. This signal can be set by the weld timer if an error is detected in the weld equipment during the weld sequence. If set the current weld will be stopped and error handling will be activated.</p> <p>If no signal name is specified here, there will be no function.</p> |
| Weld program group [GO] | goWeldProgram | signalgo | <p>Used to configure the weld program group signal used by the weld timer. This signal will be set at the beginning of a spot instruction.</p> <p>Allowed values: 0 - to the configured size of the I/O group.</p> <p>Absolute max is the size of dnum, 4294967295 - 32bit.</p> <p>If no signal name is specified here, there will be no function.</p> |



Continues on next page

| Parameter | Default value | Data type | Note |
|-----------------------------|---------------|-----------|--|
| New program selection [DO] | doNewProgram | signado | <p>Used to configure the new weld program selection signal. This signal will be set just after the weld program group signal is set.</p> <p>If no signal name is specified here, there will be no function.</p> <p> Note</p> <p>Some weld timers requires a handshaking sequence regarding the weld program selection. This signal can be used to let the weld timer know that a "new" program has been selected at the weld program output group.</p> <p>Normally the weld timer responds with a "valid" program signal if the selected weld program is valid. If not error handling is activated.</p> |
| New program selection delay | 0 s | num | <p>Used to configure a delay before the new weld program selection signal is set after the weld program group is set. (0-0.5 s)</p> <p>Default value 0 s.</p> <p> Note</p> <p>A delay can be added here if timing issues are experienced with the connected weld timer regarding the handshaking sequence, e.g. if the new program selection signal is set too close to the weld program group.</p> <p> Note</p> <p>Adding a delay here will affect the cycle time negatively, check the device configuration settings first, production inhibit time, poll rate etc. See System Parameters, Topic I/O System and Type Device <i>Technical reference manual - System parameters</i>.</p> |



3 Configuration

3.1.4 The Spot Weld Equipment instance

Continued

| Parameter | Default value | Data type | Note |
|-----------------------------|---------------------|-----------|--|
| Weld program valid [DI] | diProgSelectValid | signalDI | <p>Used to configure the weld program valid signal. This signal will be set by the weld timer when a valid weld program is selected. It will be checked during the process before the weld is started.</p> <p>If no signal name is specified here, no check will be done.</p> <p> Note</p> <p>Some weld timers requires a hand-shaking sequence regarding the weld program selection. This signal can be used to let the robot know that the weld timer has validated the selected weld program output group, and that it is ready to weld.</p> <p> Note</p> <p>If automatic rewelding is activated the program valid signal will only be checked at the first try, not on the consequent retries.</p> <p>If the number of retries has been executed, a new check will be done when the operator selects "Reweld" and the reweld sequence is restarted from the beginning.</p> |
| Weld program valid timeout | 2 s | num | The max time waiting for the valid weld program signal, after this time the error handling is activated. (0-5 s) |
| Reset timer fault [DO] | doResetFault | signalDO | <p>Used to configure the reset weld timer fault signal. This signal can be used to reset weld timer faults before a reweld is done.</p> <p>If no signal name is specified here, there will be no function.</p> |
| Reset fault time | 2 s | num | The length of the reset fault signal pulse to reset the weld timer. (0-2 s) |
| Wait time after reset fault | 2 s | num | Wait time after the reset fault pulse before program execution continues. (0-2 s) |
| Weld contactor on [DO] | doWeldPower-Contact | signalDO | Used to configure the weld contactor signal. This signal will be set by a cross connection in the I/O configuration, as a result of the motor_on, doEnableCurrent and doProcess-Fault inverted. |

Continues on next page


| Parameter | Default value | Data type | Note |
|---------------------------------|------------------|-----------|---|
| Weld contactor on [DI] | diWeldContact | signalDI | Used to configure the weld contactor or activated signal. This signal is normally set by the weld contactor if a contactor is used. If not set before the weld, the error handling will be activated. If no signal name is specified here, there will be no function. |
| Gun force from timer [GI] | giGunForce | signalGI | Used to configure the gun force group signal. This signal can be used if external gun force data from the weld timer is required. If no signal name is specified here, there will be no function.  Note To activate the use of the weld timer input signals the corresponding parameter in spotdata must be set to -1, e.g. my_spot.tip_force := -1; |
| Force calculation factor | 40 | num | Gun force factor when using external force from the weld timer. (0-100) Example with 8 bit group input, 255 * 39.2 ~ 10000 N Max in weld timer. |
| Plate thickness from timer [GI] | giPlateThickness | signalGI | Used to configure the plate thickness group signal. This signal can be used if external plate thickness data from the weld timer is required. If no signal name is specified here, there will be no function.  Note To activate the use of the weld timer input signals the corresponding parameter in spotdata must be set to -1, e.g. my_spot.plate_thickness := -1; |
| Thickness calculation factor | 0.1 | num | Plate thickness factor when using external data from the weld timer. (0-100) Example with 8 bit group input, 255 * 0.1 = 25.5mm max thickness. |

Continues on next page

3 Configuration

3.1.4 The Spot Weld Equipment instance

Continued

| Parameter | Default value | Data type | Note |
|---------------------------------|------------------|-----------|---|
| Plate tolerance from timer [GI] | giPlateTolerance | signalgi | <p>Used to configure the plate tolerance group signal. This signal can be used if external plate tolerance data from the weld timer is required. If no signal name is specified here, there will be no function.</p> <p> Note</p> <p>To activate the use of the weld timer input signals the corresponding parameter in spotdata must be set to -1, e.g. my_spot.plate_tolerance := -1;</p> |
| Tolerance calculation factor | 0.1 | num | <p>Plate tolerance factor when using external data from the weld timer. (0-100)</p> <p>Example with 8 bit group input, $255 * 0.1 = 25.5$ max tolerance.</p> |
| Timer status [GI] | giTimerStatus | signalgi | <p>Used to configure the weld timer status group signal. This signal is used to check the timer status when a weld fault has occurred. If no signal name is specified here, there will be no function.</p> |
| Reset fault with reweld [DO] | | signaldo | <p>Used to configure the reset timer fault with reweld functionality. This signal can be used to enable a reweld in KSR mode in a Bosch weld timer when performing a reweld in adaptive weld mode. If used the normal start weld signal will be set to 1 during the reweld sequence, and this signal will reset the timer fault and perform the reweld. The normal reset fault signal will not be used. If no signal name is specified here, there will be no function.</p> |
| User defined gui signal1-10 | | string | <p>Used to configure user defined signals that should be visible in the Spot GUI process cabinet view. Not used in process.</p> |

3.1.5 The Spot Gun Equipment instance

Description

The *Spot Gun Equipment* contains parameters for the connected gun equipment's. This instance can be multiplied.

Parameters

The following parameters and signals are used to define the gun equipment's in Spot.



Note

Settings are dependent on actual spot configuration.



| Parameter | Default value | Data type | Note |
|----------------------------|---------------|-----------|---|
| Name | servogun1 | string | The name of the gun instance. |
| Selected gun type | Servo gun | string | Used to configure the gun type, possible values are Servo gun or Pneu gun. |
| Gun trafo over-temperature | diTrafoTempOk | signal | Used to configure the transformer temperature sensor signal connected to the gun. Signal will be checked during the spot process. If no signal name is specified here, no check will be done. |
| Max allowed gun force | 4000 N | num | <p>Servo gun specific data. Maximum allowed tip force for each gun. This value can be set from the <code>ManualForceCalib</code> service routine when performing a force calibration of the gun. (0-10000). See Available service routines on page 84.</p> <div data-bbox="1042 1368 1106 1431" data-label="Image"> </div> <h4>Note</h4> <p>Normally this parameter is supplied by the gun manufacturer. This parameter can also be configured via system parameters, see System Parameters, Topic Motion and Type SG Process <i>Technical reference manual - System parameters</i>. In this case this parameter has to be set to Deactivated = Not used.</p> |

Continues on next page



3 Configuration

3.1.5 The Spot Gun Equipment instance

Continued

| Parameter | Default value | Data type | Note |
|------------------------------|---------------|-----------|--|
| Gun force normal orientation | Deactivated | num | <p>Servo gun specific data.</p> <p>Reference gun force when moveable gun arm is working with gravity.</p> <p>This parameter can be set from the <code>ManualForceCalib</code> service routine.</p> <p>Example: Ordered gun force 4000N normal gun orientation, measured force 4000N.</p> <p>Deactivated (-1) = Not used.</p> <p> Note</p> <p>The max gun force will be used as reference for the two gun positions.</p> <p> Note</p> <p>The maximum gravitational force difference between normal and inverted orientation can also be configured via system parameters, see System Parameters, Topic Motion and Type SG Process <i>Technical reference manual - System parameters</i>. In this case this parameter has to be set to Value (0) = Motion parameter is used instead.</p> |

Continues on next page


| Parameter | Default value | Data type | Note |
|---|---------------|-----------|---|
| Gun force inverted orientation rotated 180° | Deactivated | num | <p>Servo gun specific data.</p> <p>Reference gun force in when moveable gun arm is working against gravity.</p> <p>This parameter can be set from the <code>ManualForceCalib</code> service routine.</p> <p>Example: Ordered gun force 4000N in inverted gun orientation, measured force 3500N.</p> <p>If these parameters are used the gun force will be compensated before weld depending on the current angle of the gun in the specific position.</p> <p>Deactivated, (-1) = Not used.</p> <p> Note</p> <p>The max gun force will be used as reference for the two gun positions.</p> <p> Note</p> <p>The maximum gravitational force difference between normal and inverted orientation can also be configured via system parameters, see System Parameters, Topic Motion and Type SG Process <i>Technical reference manual - System parameters</i>. In this case this parameter has to be set to Value (0) = Motion parameter is used instead.</p> |
| Use SoftWare equalizing | Yes | bool | <p>Software equalizing specific data.</p> <p>This data has to be set to Yes to activate the software equalizing functions release of the fixed gun arm and gun arm deflection compensation. Yes/No</p> |
| Tip change supervision value | 3 mm | num | <p>Software equalizing specific data.</p> <p>Tip change supervision value.</p> <p>Max allowed digression [mm] in positive and negative direction from stored reference values. Default value 3 mm.</p> <p>This data is used to supervise a missing tip or wrong size of the tip and is used in the <code>MeasureWearL</code> and <code>Calibrate/CalibL/J</code> instructions. (Max 40 mm)</p> |

Continues on next page

3 Configuration

3.1.5 The Spot Gun Equipment instance

Continued

| Parameter | Default value | Data type | Note |
|--------------------------------------|---------------|-----------|---|
| Tip wear supervision value | 0.2 mm | num | <p>Software equalizing specific data.</p> <p>Tip wear supervision value.</p> <p>Max allowed digression [mm] in positive and negative direction since last tip wear compensation. Default value 0.2 mm.</p> <p>This data is used to supervise the tip wear and is used in the <code>MeasureWearL</code>, <code>ReCalcTCP</code> and <code>Calibrate/CalibL/Jinstructions</code>. (Max 5 mm)</p> |
| Tip wear ratio, fixed vs total wear | Deactivated | num | <p>Software equalizing specific data.</p> <p>The expected ratio [%] between the tip wear for the fix tip related to the total tip wear. This value has to be set to a permitted value (between 0-100) if the calculation method (<code>ReCalcTCP</code>) is used for the tip wear compensation. The value can be set in predefined steps of 10%.</p> <p>Example: Fixed tip 60% of total wear Indicates that the wear of the fixed tip is 60% of the total tip wear, which leaves 40% for the moving tip, 60/40.</p> <p> Note</p> <p>If the measuring method is used, (<code>MeasureWearL</code>) this value has to be set to Deactivated.</p> |
| Opposite z-direction | No | bool | <p>Software equalizing specific data.</p> <p>Defined z-direction for the TCP, gives move direction for search and compensations movements.</p> <p>Yes/No.</p> <p>No = positive z-direction out from the fixed tip (Normal setting).</p> <p>Yes = positive z-direction into the fixed tip (Setting for stationary tools to achieve the same jogging behavior as with a robot held tool).</p> <p>This parameter also influences the direction of the gun arm deflection compensation.</p> <p>For more information, see How to define the TCP on page 199.</p> |
| <code>MeasureWearL</code> search I/O | | signalDI | <p>Software equalizing specific data.</p> <p>Used to configure an input signal that can be used instead of the reference plate for the search sequence in the <code>MeasureWearL</code> instruction.</p> <p>If this signal is specified the search will be done against a sensor signal instead of a fixed reference surface.</p> |

Continues on next page

| Parameter | Default value | Data type | Note |
|---|---------------|-----------|--|
| MeasureWearL TouchUp force override | Deactivated | num | Software equalizing specific data. Contact force (in N) during tip measurement in the MeasureWearL instruction, (typically between 50 - 150N). This parameter will override the global parameter in the Spot Equalizing instance if used. Deactivated = Not used. |
| Tip change fault | | signaldo | Software equalizing specific data. Used to configure the tip change fault signal. This signal will be set when a tip wear error is detected in the CalibL/J, MeasureWearL, RecalcTCP instructions. If no signal name is specified here, there will be no function. |
| Tip wear fault | | signaldo | Software equalizing specific data. Used to configure the tip wear fault signal. This signal will be set when a tip wear error is detected in the MeasureWearL and ReCalcTCP in- structions. If no signal name is specified here, there will be no function. |
| Gun equalizing | doEqualize | signaldo | Used to configure the gun equaliz- ing signal for the gun. This signal will be set a predefined time(Gun pre equalizing time) before the weld position, and it will be reset when opening the gun after weld. If no signal name is specified here, there will be no function. |
| Gun pre equaliz- ing time | 0 s | num | Time before gun is in weld position, when the equalizing signal is set for activation of a mechanical equaliz- ing system in the gun, if used. (0-0.5 s) |
| Gun opened | diGunOpen | signaldi | Pneumatic gun specific data. Used to configure the gun opened (work stroke position) sensor signal for a pneumatic gun. Signal will be checked during process. If no signal name is specified here, no check will be done during pro- cess. |
| Gun open timeout | 2 s | num | Pneumatic gun specific data. The max time[s] waiting for the gun open signal after a pneumatic gun has been opened, after this time the error handling is activated. (0-10 s) |

Continues on next page


3 Configuration

3.1.5 The Spot Gun Equipment instance

Continued

| Parameter | Default value | Data type | Note |
|----------------------|-----------------|-----------|---|
| Gun highlift open | diHighLiftOpen | signalDI | Pneumatic gun specific data. Used to configure the high lift open (max opening position) sensor signal for a pneumatic gun. Signal will be checked during the spot process. If no signal name is specified here, no check will be done during process. |
| Gun close | doCloseGun | signalDO | Pneumatic gun specific data. Used to configure the gun close signal for a pneumatic gun. This signal will be set a predefined time(Gun pre closing time) before the weld position, and reset when the weld is completed. If no signal name is specified here, there will be no function. |
| Gun pre closing time | 0.1 s | num | Pneumatic gun specific data. Time before gun is in weld position, when the asynchronous gun closure is started. For a pneumatic gun when the gun close signal is set. (0-0.5 s) This data is not used if Software Equalizing is active. In this case the preclosing is handled automatically during the movement from the release distance to the weld position. |
| Gun close timeout | 2 s | num | Pneumatic gun specific data. The max time waiting for gun open signal before closing a pneumatic gun, after this time the error handling is activated. (0-10 s) |
| Gun open highlift | doOpenHighLift | signalDO | Pneumatic gun specific data. Used to configure the open high lift (max opening position) signal for a pneumatic gun. Signal will be set during the spot process if the optional argument \OpenHighLift is selected in the spot instruction. If no signal name is specified here, there will be no function. |
| Gun close highlift | doCloseHighLift | signalDO | Pneumatic gun specific data. Used to configure the close high lift (work stroke position) signal for a pneumatic gun. Signal will be set during the spot process if the optional argument \CloseHighLift is selected in the spot instruction. If no signal name is specified here, there will be no function. |

Continues on next page

| Parameter | Default value | Data type | Note |
|-----------------------------|----------------|-----------|---|
| Gun pressure group | | signalgo | <p>Pneumatic gun specific data. Used to configure the gun pressure group signal for a pneumatic gun. Will be set to the value specified in the tip force parameter in spotdata. If no signal name is specified here, there will be no function.</p> <p> Note</p> <p>Normally the gun pressure is controlled from the weld timer, and in that case this signal is not used.</p> |
| Gun pressure OK | diPressureOk | signaldi | <p>Pneumatic gun specific data. Used to configure the gun pressure ok signal for a pneumatic gun. If no signal name is specified here, no check will be done during process.</p> |
| Gun pressure timeout | 2 s | num | <p>Pneumatic gun specific data. The max time waiting for gun pressure ok signal for a pneumatic gun, after this time the error handling is activated. (0-10 s)</p> |
| Force complete | force_complete | signaldi | <p>Pneumatic gun specific data. Used to configure a gun force complete signal that can be used in the <code>SetForce</code> instruction. If no signal name is specified here, there will be no function.</p> |
| User defined gui signal1-10 | | string | <p>Used to configure user defined signals that should be visible in the Spot GUI gun equipment view. Not used in process.</p> |

3 Configuration

3.1.6 The Spot Media Equipment instance


3.1.6 The Spot Media Equipment instance

Description



The *Spot Media Equipment* contains parameters for the connected media equipment's. This instance can be multiplied or shared between several equipment's or removed completely if not needed.

Parameters

The following parameters and signals are used to define the media equipment settings in Spot.

| Parameter | Default value | Data type | Note |
|------------------------------|----------------|-----------|--|
| Name | mediapanel1 | string | The name of the media panel instance. |
| Water flow sensor1 | diWaterFlow1Ok | signal | Used to configure the water flow sensor1 in the media panel. Signal will be checked during the spot process and from the supervision task if configured. If no signal name is specified here, no check will be done. |
| Water flow sensor2 | diWaterFlow2Ok | signal | Used to configure the water flow sensor2 in the media panel. Signal will be checked during the spot process and from the supervision task if configured. If no signal name is specified here, no check will be done. |
| Water sensor flow timeout | 2 s | num | Used to configure the water flow timeout. If no water flow is detected by the water flow sensors within the specified time an operator error dialog will take focus. (0-10 s) |
| Continuous water supervision | No = FALSE | bool | Used to configure the continuous water supervision in the <i>SW_SUP</i> task. If set to Yes, the <i>SW_SUP</i> task will supervise the water flow continuously if the system is in motors on state, if an error is detected the robot movement will stop.  Note Continuous water supervision will only be active if the water ok summary signal is defined. |
| Air flow sensor | diAirOk | signal | Used to configure the air flow signal in the media panel. Signal will be checked during the spot process. If no signal name is specified here, no check will be done. |

Continues on next page

| Parameter | Default value | Data type | Note |
|-----------------------------|---------------|-----------|--|
| Water flow start | doStartWater | signaldo | Used to configure the water start signal in the media panel. This signal will be reset when a flow error is detected. If a delay is configured the signal is reset after the time has passed. If no signal name is specified here, there will be no function. |
| Water turn off delay | 1 s | num | Used to configure a delay before the water start signal is reset, can be used as a filter to prevent air bubbles causing false alarms. (0-2 s) |
| Water saver activated | No | bool | Used to configure water saver function in the SW_SUP task. If set to Yes, water will only start and be supervised if the system is in cycle on state and executing a program. |
| Water OK | diWaterOk | signaldi | Used to configure the water ok summary signal. This signal will be checked during the process before the weld start, and continuously from the supervision task if configured. The spot process will wait for this signal the specified time in water sensor flow timeout. If no signal name is specified here, the water flow sensor signals will be checked independently.  Note Make sure that the corresponding cross connection is changed if only one of the water flow sensor signals are used, see Cross-connected signals on page 54 .  Note Continuous water supervision can not be used if this signal is undefined. |
| User defined gui signal1-10 | | string | Used to configure user defined signals that should be visible in the Spot GUI water and air unit view. Not used in process. |

3 Configuration

3.1.7 The Spot SoftWare Equalizing instance


3.1.7 The Spot SoftWare Equalizing instance

Description


The *Spot Equalizing* contains parameters for global software equalizing settings.

Parameters

The following parameters are used to define global software equalizing settings in Spot.

| Parameter | Default value | Data type | Note |
|------------------------------|-----------------|------------|---|
| Name | spot_equalizing | string | The name of the software equalizing instance. |
| MeasureWearL search speed | 5 mm/s | num | Search speed during tip measurement in the MeasureWearLinstruction, (between 1 - 5 mm/s) |
| MeasureWearL TouchUp force | 100 N | num | Contact force (in N) during tip measurement in the MeasureWearL instruction, (typically between 50 - 150N). -1 will deactivate this parameter and use the override parameter in the Spot Gun Equipment instance instead. |
| MeasureWearL movein distance | 10 mm | num | Maximal distance from programmed point to search for reference surface in the MeasureWearL instruction. |
| Max allowed release distance | 15 mm | num | Maximum allowed release distance. (0-20 mm) |
| Max allowed deflection value | 15 mm | num | Maximum allowed deflection distance. (0-20 mm) |
| Min allowed TouchUp step | 0.1 mm | num | Minimum allowed touch up step. (0-1 mm) |
| Max allowed TouchUp step | 10 mm | num | Maximum allowed touch up step. (1-15 mm) |
| SoftMove offset distance | 3 mm 3 mm | num num | Offset distance from the nominal plate position when SoftMove Equalizing should be activated (between 1 - 5 mm).  Note Too short distance may influence the performance on the equalizing functionality, the used distance should be larger than the expected tolerance deviation of the parts. |

Continues on next page

| Parameter | Default value | Data type | Note |
|-----------------------------------|---------------|-----------|--|
| SoftMove approach speed | 50 mm/s | num | <p>Search speed (v_{tcp}) into nominal position when using SoftMove Equalizing (between 20 - 200 mm/s).</p> <p> Note</p> <p>A too high speed will influence the "search" result negatively. Excessive force may deform the plate.</p> |
| SoftMove gun close speed | 200 mm/s | num | <p>Gun close speed (v_{leax}) to target position (plate thickness) when using SoftMove Equalizing (between 20 - 200 mm/s).</p> <p>This parameter can be used to change the gun closing speed if the moveable gun electrode tip is impacting the plates, for example if the location of the plates are higher than the nominal position.</p> |
| SoftMove force offset auto tuning | Yes | bool | <p>Enable or disable <code>force_offset</code> auto tuning.</p> |

3 Configuration

3.1.8 The Spot GUI instance

3.1.8 The Spot GUI instance

Description

The *Spot GUI* contains parameters for the Spot user interface.

Parameters

The following parameters are used to define the settings in the Spot UI.

| Parameter | Default value | Data type | Note |
|------------------------------------|---------------|-----------|---|
| Name | spot_gui | string | The name of the spot gui instance. |
| Show Spot GUI at startup | No | bool | Used to define if the spot gui should be started automatically at system startup, Yes/No. |
| Spot system type in Manual Actions | servo | string | Used to define the system type in the Manual Action view, pneumatic/servo/combined. |
| Show simdata in Process Data | No | bool | Used to define if the simdata should be visible in Process Data view. |
| Show forcedata in Process data | Yes | bool | Used to define if the forcedata should be visible in the Process Data view. |

3.2 Spot I/O configuration

Introduction

This chapter describes the different predefined template I/O configurations that are available for the Spot variants, and information about the use of the signals. The Spot package can be configured for different equipment setups. The default I/O configurations should be seen as default templates, and the physical connections and names can be changed freely and signals not in use can be connected to simulated devices or to no device.

The signals used are configured in the system parameters. From the ABB menu on the FlexPendant:

- 1 Tap **Control Panel**.
- 2 Tap **Configuration**.
- 3 Tap **Topics** and select **I/O**.

The signals used are configured in the system parameters.

The I/O configuration can be accessed from RobotStudio.



Note

The used signals names are also used in the process configuration. If the names are changed, the corresponding names in the process configuration must be changed also. For more information, see [Spot process configuration on page 25](#).

Continues on next page

3 Configuration

3.2.1 Spot template I/O configuration for single gun system

3.2.1 Spot template I/O configuration for single gun system

Introduction

If a basic configuration is selected when building a spot welding system, the system will be prepared with signals for one spot welding equipment on simulated I/O. It is then easy to adapt the configuration to the surrounding equipment, e.g. weld timer, media panel etc.

Default configuration

The I/O configuration is prepared for one weld equipment. A set of customized user modules are also installed if this configuration is selected.

The signals can be connected to any device type if needed, for example Profinet, EtherNetIP, and so on.



Note

Some of the signals are only used in a Spot Pneumatic configuration.

Predefined I/O devices

There are three predefined I/O devices:



- One Local device, named *SW_TIMER*, with signals for the weld timer.
- One Local device, named *SW_BOARD*, with signals for the media panel and the gun.
- One Local device, named *SW_SIM_BOARD* with some internal or normally not connected signals.

The devices are configured on the Local network by default.

Weld timer signals

| Name | Type | Information |
|-----------------|--------------|--|
| diWeldComplete | input | Weld complete signal from the weld timer. |
| diWeldFault | input | Fault signal from the weld timer. If this signal is activated during the weld process the weld error handling in Spot is started without waiting for weld time out. |
| diTimerReady | input | The timer is ready to weld. |
| doTimerOn | output | 24V safety signal cross connected to motors on, can be used to turn off the timer logic in motor off state. |
| doStartWeld | output | Start signal to the weld timer. |
| doEnableCurrent | output | Signal used for the weld simulation function (simtype = 2). See Simulation modes on page 82 . |
| doResetFault | output | Reset signal. Can be used to reset the welding controller after a weld error. The signal is pulsed with a user defined pulse length before manual or automatic rewelding. |
| goWeldProgram | output group | Selected weld program number in weld timer, see spotdata - Spot weld data on page 157 . Default size is 8 bits, 0 - 255, 256 different programs. The maximum group size can be configured up to 32 bits, see spotdata - Spot weld data on page 157 |

Continues on next page

| Name | Type | Information |
|-------------------|-------------|---|
| doNewProgram | output | <p>This signal can be used as handshaking to let the timer know a new program has been selected in the <i>goWeldProgram</i> group.</p> <p> Note</p> <p>For some timers this signal must be set after a new program number is set in <i>goWeldProgram</i> in order for the timer to set the corresponding inputs <i>giGunForce</i>, <i>giPlateThickness</i>, and <i>giPlateTolerance</i>.</p> |
| diProgSelectValid | input | <p>This signal can be used as handshaking to let spot know that a valid program has been read by the timer and to continue the execution and read the timer input groups, force, thickness, etc.</p> <p> Note</p> <p>Some timers has the possibility to check if a valid weld program selection has been done. Valid program = 1, Not valid = 0 This signal is used by spot. If not set, a program valid timeout will occur during execution.</p> |
| giGunForce | input group | Gun force from weld timer if <i>tip_force</i> in <i>spotdata</i> is -1. |
| giPlateThickness | input group | Plate thickness from weld timer if <i>plate_thickness</i> in <i>spotdata</i> is -1. |
| giPlateTolerance | input group | Plate tolerance from weld timer if <i>plate_tolerance</i> in <i>spotdata</i> is -1. |
| giTimerStatus | input group | Weld timer status code. |

Gun and media signals

| Name | Type | Information |
|----------------|-------|---|
| diGunOpen | input | Signal indicating that a pneumatic gun is opened. |
| diHighLiftOpen | input | Signal indicating that a pneumatic gun has reached the highlift position. |
| diPressureOk | input | Signal indicating that the right gun pressure is reached for a pneumatic gun. |
| diTrafoTempOk | input | Signal indicating that the temperature is too high. |
| diWaterFlow1Ok | input | Signal that can be used to indicate problems with the water supply in pipe 1. |
| diWaterFlow2Ok | input | Signal that can be used to indicate problems with the water supply in pipe 2. |
| diAirOk | input | Signal indicating low air pressure in the equalize cylinder. |
| diWeldContact | input | Signal indicating the state of the weld contactor. (0 = deactivated) |
| diEquipmentOk | input | Signal indicating the total gun status. A number of input signals from the gun is cross connected to this signal. |

Continues on next page


3 Configuration

3.2.1 Spot template I/O configuration for single gun system

Continued

| Name | Type | Information |
|--------------------|--------|---|
| doEqualize | output | Gun equalizing signal if mechanical equalizing system are used. |
| doCloseGun | output | Gun close signal for a pneumatic gun. |
| doOpenHighLift | output | Signal used to open a pneumatic gun to the highlift position. |
| doCloseHighLift | output | Signal used to close apneumatic gun from the highlift position. |
| doStartWater | output | Signal used to activate the water cooling system. This signal is set depending on status of several cross-connected signals. See Cross-connected signals on page 59 . |
| doWeldPowerContact | output | Signal used to pull the weld contactor. This signal is set depending on status of several cross-connected signals See Cross-connected signals on page 59 . |

Process status signals

| Name | Type | Information |
|----------------|--------|---|
| doProcessRun | output | Is set at motion start and is reset when the weld process is ready and motion is released. |
| doProcessFault | output | Is set when an error situation occurs and the process is interrupted.  Note The default configuration of the safe level for this signal is to keep the last value used. |


Other signals

| Name | Type | Information |
|----------------|-------|---|
| force_complete | input | Can be used to interrupt the <code>SetForce</code> instruction before the programmed force time is elapsed for a servo gun. |
| reweld_proc | input | Can be used to answer a weld error dialog on the FlexPendant with an input signal. The same as tapping Reweld . |
| skip_proc | input | Can be used to answer an error dialog on the FlexPendant with an input signal. The same as tapping Skip . Only in manual operating mode. |

Cross-connected signals

| Resultant | Activator(s) | Information |
|---------------------|--|--|
| doStartWater | motor_on AND doEnableCurrent AND doProcessFault (Inverted) | Water start signal, if any of the activators are not set the water start signal will be reset. |
| doWeldPower-Contact | motor_on AND doEnableCurrent AND doProcessFault (Inverted) | Weld contactor signal, if any of the activators are not set the weld contactor signal will be reset. |

Continues on next page

| Resultant | Activator(s) | Information |
|---------------|---|--|
| diEquipmentOk | diWaterFlow1Ok AND diWaterFlow2Ok AND diAirOk AND diTempOk AND diTimerReady | Equipment status signal, if any of the activators are not set the equipment ok signal will be re-set. |
| diWaterOk | diWaterFlow1Ok AND diWaterFlow2Ok | Water status signal, if any of the activators are not set the water ok signal will be reset.  Note This cross connection needs to be modified if one of the actor signals are removed from the process configuration, in order to get correct functionality. See The Spot Media Equipment instance on page 46 . |
| ext_override | skip_proc AND reweld_proc | Reset signal. Can be used to reset the operator error dialog on the FlexPendant when an error occurs. See Other signals on page 58 . |

Limitations

This configuration is only available for single robot Spot systems, not in MultiProcess systems with more than one Spot robot.

3 Configuration

3.2.2 Spot template I/O configuration multiple guns system

3.2.2 Spot template I/O configuration multiple guns system

Introduction

If a multiple gun configuration is selected when building a spot welding system, the system will be prepared with signals for four spot welding equipments on simulated I/O's. It is then easy to adapt the configuration to the surrounding equipment, e.g. weld timers, media panels etc.

Default configuration

The I/O configuration is prepared for four weld equipments. A set of customized user modules are also installed if this configuration is selected.

The signals can be connected to any device type if needed, for example Profinet, DeviceNet, and so on.



Note

Some of the signals are only used in a Spot Pneumatic configuration.



Note

Signal names for gun equipment 2 are the same as for gun 1 but with the ending G2, e.g. doStartWeldG2.

Predefined I/O devices

There are five predefined I/O devices if a multiple gun configuration is selected:



- One local device, named **SW_BOARD1**, with signals for gun equipment 1.
- One local device, named **SW_BOARD2** with signals for gun equipment 2.
- One local device, named **SW_BOARD3** with signals for gun equipment 3.
- One local device, named **SW_BOARD4** with signals for gun equipment 4.
- One local device, named **SW_SIM_BOARD** with some internal or normally not connected signals.

The devices are configured on a virtual network by default.

Weld timer signals for equipment 1

| Name | Type | Information |
|-----------------|--------|---|
| diWeldComplete | input | Weld complete signal from the weld timer. |
| diWeldFault | input | Fault signal from the weld timer. If this signal is activated during the weld process the weld error handling in Spot is started without waiting for weld time out. |
| diTimerReady | input | The timer is ready to weld. |
| doTimerOn | output | 24V safety signal cross connected to motors on, can be used to turn off the timer logic in motor off state. |
| doStartWeld | output | Start signal to the weld timer. |
| doEnableCurrent | output | Signal used for the weld simulation function (simtype = 2). See Simulation modes on page 82 . |

Continues on next page

| Name | Type | Information |
|-------------------|--------------|--|
| doResetFault | output | Reset signal. Can be used to reset the welding controller after a weld error. The signal is pulsed with a user defined pulse length before manual or automatic rewelding. |
| goWeldProgram | output group | Selected weld program number in weld timer, see spotdata - Spot weld data on page 157 . Default size is 8 bits, 0 - 255, 256 different programs. The maximum group size can be configured up to 32 bits, see spotdata - Spot weld data on page 157 |
| doNewProgram | output | This signal can be used as handshaking to let the timer know a new program has been selected in the <i>goWeldProgram</i> group.  Note For some timers this signal must be set after a new program number is set in <i>goWeldProgram</i> in order for the timer to set the corresponding inputs <i>giGunForce</i> , <i>giPlateThickness</i> , and <i>giPlateTolerance</i> . |
| diProgSelectValid | input | This signal can be used as handshaking to let spot know that a valid program has been read by the timer and to continue the execution and read the timer input groups, force, thickness, etc.  Note Some timers has the possibility to check if a valid weld program selection has been done. Valid program = 1, Not valid = 0 This signal is used by spot. If not set, a program valid timeout will occur during execution. |
| giGunForce | input group | Gun force from weld timer if <i>tip_force</i> in <i>spotdata</i> is -1. |
| giPlateThickness | input group | Plate thickness from weld timer if <i>plate_thickness</i> in <i>spotdata</i> is -1. |
| giPlateTolerance | input group | Plate tolerance from weld timer if <i>plate_tolerance</i> in <i>spotdata</i> is -1. |
| giTimerStatus | input group | Weld timer status code. |

Gun and media signals for equipment 1

| Name | Type | Information |
|----------------|-------|---|
| diGunOpen | input | Signal indicating that a pneumatic gun is opened. |
| diHighLiftOpen | input | Signal indicating that a pneumatic gun has reached the highlift position. |
| diPressureOk | input | Signal indicating that the right gun pressure is reached for a pneumatic gun. |
| diTrafoTempOk | input | Signal indicating that the temperature is too high. |
| diWaterFlow1Ok | input | Signal that can be used to indicate problems with the water supply in pipe 1. |
| diWaterFlow2Ok | input | Signal that can be used to indicate problems with the water supply in pipe 2. |

Continues on next page


3 Configuration

3.2.2 Spot template I/O configuration multiple guns system

Continued

| Name | Type | Information |
|--------------------|--------|---|
| diAirOk | input | Signal indicating low air pressure in the equalize cylinder. |
| diWeldContact | input | Signal indicating the state of the weld contactor. (0 = deactivated) |
| diEquipmentOk | input | Signal indicating the total gun status. A number of input signals from the gun is cross connected to this signal. |
| doEqualize | output | Gun equalizing signal if mechanical equalizing system are used. |
| doCloseGun | output | Gun close signal for a pneumatic gun. |
| doOpenHighLift | output | Signal used to open a pneumatic gun to the highlift position. |
| doCloseHighLift | output | Signal used to close apneumatic gun from the highlift position. |
| doStartWater | output | Signal used to activate the water cooling system. This signal is set depending on status of several cross-connected signals. See Cross-connected signals on page 59 . |
| doWeldPowerContact | output | Signal used to pull the weld contactor. This signal is set depending on status of several cross-connected signals See Cross-connected signals on page 59 . |

Process status signals for equipment 1

| Name | Type | Information |
|----------------|--------|--|
| doProcessRun | output | Is set at motion start and is reset when the weld process is ready and motion is released. |
| doProcessFault | output | Is set when an error situation occurs and the process is interrupted.  Note This signal will be reset if the PP is moved and current instruction is aborted. |

Other signals

| Name | Type | Information |
|----------------|-------|---|
| force_complete | input | Can be used to interrupt the <code>SetForce</code> instruction before the programmed force time is elapsed for a servo gun. |
| reweld_proc | input | Can be used to answer a weld error dialog on the FlexPendant with an input signal. The same as tapping Reweld . |
| skip_proc | input | Can be used to answer an error dialog on the FlexPendant with an input signal. The same as tapping Skip . Only in manual operating mode. |

Continues on next page

Cross-connected signals

| Resultant | Activator(s) | Information |
|---------------------|---|---|
| doStartWater | motor_on AND doEnableCurrent AND doProcessFault (Inverted) | Water start signal, if any of the activators are not set the water start signal will be reset. |
| doWeldPower-Contact | motor_on AND doEnableCurrent AND doProcessFault (Inverted) | Weld contactor signal, if any of the activators are not set the weld contactor signal will be reset. |
| diEquipmentOk | diWaterFlow1Ok AND diWaterFlow2Ok AND diAirOk AND diTempOk AND diTimerReady | Equipment status signal, if any of the activators are not set the equipment ok signal will be reset. |
| diWaterOk | diWaterFlow1Ok AND diWaterFlow2Ok | Water status signal, if any of the activators are not set the water ok signal will be reset. |
| ext_override | skip_proc AND reweld_proc | Reset signal. Can be used to reset the operator error dialog on the FlexPendant when an error occurs. See Other signals on page 58 . |

Limitations

This configuration alternative can not be used together with the option 634-1 MultiProcess, not in MultiMove systems with more than one Spot robot.

3 Configuration

3.2.3 Spot template I/O configuration for MultiMove/MultiProcess systems

3.2.3 Spot template I/O configuration for MultiMove/MultiProcess systems

Introduction

If a Spot MultiMove and MultiProcess configuration for more than one robot is selected when building a spot welding system, the system will be prepared with signals for two spot welding equipments on simulated I/O's, one equipment per robot. It is then easy to adapt the configuration to the surrounding equipment, e.g. weld timer, media panel etc.

Default configuration

The I/O configuration is prepared for two weld equipments. A set of customized user modules are also installed if this configuration is selected.

The signals can be connected to any device type if needed, for example Profinet, DeviceNet, and so on.



Note

Some of the signals are only used in a Spot Pneumatic configuration.



Note

Signal names for gun equipment 2 are the same as for gun 1 but with the ending G2, e.g. doStartWeldG2.

Predefined I/O devices

There are five predefined I/O devices if a MultiMove / MultiProcess configuration is selected:



- One local device, named *SW_TIMER1*, with signals for weld timer1 (Robot 1).
- One local device, named *SW_BOARD1*, with signals for media panel and gun1 (Robot 1).
- One local device, named *SW_TIMER2*, with signals for weld timer2 (Robot 2).
- One local device, named *SW_BOARD2*, with signals for media panel and gun2 (Robot 2).
- One local device, named *SW_SIM_BOARD* with some internal or normally not connected signals.

The devices are configured on a virtual network by default.

Weld timer signals

| Name | Type | Information |
|----------------|-------|---|
| diWeldComplete | input | Weld complete signal from the weld timer. |
| diWeldFault | input | Fault signal from the weld timer. If this signal is activated during the weld process the weld error handling in Spot is started without waiting for weld time out. |

Continues on next page

| Name | Type | Information |
|-------------------|--------------|--|
| diTimerReady | input | The timer is ready to weld. |
| doTimerOn | output | 24V safety signal cross connected to motors on, can be used to turn off the timer logic in motor off state. |
| doStartWeld | output | Start signal to the weld timer. |
| doEnableCurrent | output | Signal used enable simulated weld mode in a weld timer (simtype = 2). See Simulation modes on page 82 . |
| doResetFault | output | Reset signal. Can be used to reset the welding controller after a weld error. The signal is pulsed with a user defined pulse length before manual or automatic rewelding. |
| goWeldProgram | output group | Selected weld program number in weld timer, see spotdata - Spot weld data on page 157 . Default size is 8 bits, 0 - 255, 256 different programs. The maximum group size can be configured up to 32 bits, see spotdata - Spot weld data on page 157 . |
| doNewProgram | output | This signal can be used as handshaking to let the timer know a new program has been selected in the <i>goWeldProgram</i> group.  Note For some timers this signal must be set after a new program number is set in <i>goWeldProgram</i> in order for the timer to set the corresponding inputs <i>giGunForce</i> , <i>giPlateThickness</i> , and <i>giPlateTolerance</i> . |
| diProgSelectValid | input | This signal can be used as handshaking to let spot know that a valid program has been read by the timer and to continue the execution and read the timer input groups, force, thickness, etc.  Note Some timers has the possibility to check if a valid weld program selection has been done. Valid program = 1, Not valid = 0 This signal is used by spot. If not set, a program valid timeout will occur during execution. |
| giGunForce | input group | Gun force from weld timer if <i>tip_force</i> in <i>spotdata</i> is -1. |
| giPlateThickness | input group | Plate thickness from weld timer if <i>plate_thickness</i> in <i>spotdata</i> is -1. |
| giPlateTolerance | input group | Plate tolerance from weld timer if <i>plate_tolerance</i> in <i>spotdata</i> is -1. |
| giTimerStatus | input group | Weld timer status code. |

Gun and media signals

| Name | Type | Information |
|----------------|-------|---|
| diGunOpen | input | Signal indicating that the pneumatic gun is opened. |
| diHighLiftOpen | input | Signal indicating that the pneumatic gun has reached the highlift position. |

Continues on next page


3 Configuration

3.2.3 Spot template I/O configuration for MultiMove/MultiProcess systems

Continued

| Name | Type | Information |
|--------------------|--------|---|
| diPressureOk | input | Signal indicating that the right gun pressure is reached for a pneumatic gun. |
| diTrafoTempOk | input | Signal indicating that the temperature is too high. |
| diWaterFlow1Ok | input | Signal that can be used to indicate problems with the water supply in pipe 1. |
| diWaterFlow2Ok | input | Signal that can be used to indicate problems with the water supply in pipe 2. |
| diAirOk | input | Signal indicating low air pressure in the equalize cylinder. |
| diWeldContact | input | Signal indicating the state of the weld contactor. (0 = deactivated) |
| diEquipmentOk | input | Signal indicating the total gun status. A number of input signals from the gun is cross connected to this signal. |
| doEqualize | output | Gun equalizing signal. |
| doCloseGun | output | Gun close signal for a the pneumatic gun. |
| doOpenHighLift | output | Signal used to open the pneumatic gun to the highlift position. |
| doCloseHighLift | output | Signal used to close the pneumatic gun from the highlift position. |
| doStartWater | output | Signal used to activate the water cooling system. This signal is set depending on status of several cross-connected signals. See Cross-connected signals on page 59 . |
| doWeldPowerContact | output | Signal used to pull the weld contactor. This signal is set depending on status of several cross-connected signals See Cross-connected signals on page 59 . |

Process status signals

| Name | Type | Information |
|----------------|--------|--|
| doProcessRun | output | Is set at motion start and is reset when the weld process is ready and motion is released. |
| doProcessFault | output | Is set when an error situation occurs and the process is interrupted.  Note This signal will be reset if the PP is moved and current instruction is aborted. |

Other signals

| Name | Type | Information |
|----------------|-------|---|
| force_complete | input | Can be used to interrupt the <code>SetForce</code> instruction before the programmed force time is elapsed for a servo gun. |
| reweld_proc | input | Can be used to answer a weld error dialog on the FlexPendant with an input signal. The same as tapping Reweld . |

Continues on next page

| Name | Type | Information |
|-----------|-------|---|
| skip_proc | input | Can be used to answer an error dialog on the FlexPendant with an input signal. The same as tapping Skip . Only in manual operating mode. |

Cross-connected signals

| Resultant | Activator(s) | Information |
|---------------------|---|---|
| doStartWater | motor_on AND doEnableCurrent AND doProcessFault (Inverted) | Water start signal, if any of the activators are not set the water start signal will be reset. |
| doWeldPower-Contact | motor_on AND doEnableCurrent AND doProcessFault (Inverted) | Weld contactor signal, if any of the activators are not set the weld contactor signal will be reset. |
| diEquipmentOk | diWaterFlow1Ok AND diWaterFlow2Ok AND diAirOk AND diTempOk AND diTimerReady | Equipment status signal, if any of the activators are not set the equipment ok signal will be reset. |
| diWaterOk | diWaterFlow1Ok AND diWaterFlow2Ok | Water status signal, if any of the activators are not set the water ok signal will be reset. |
| ext_override | skip_proc AND reweld_proc | Reset signal. Can be used to reset the operator error dialog on the FlexPendant when an error occurs. See Other signals on page 58 . |

3 Configuration

3.3.1 782-1 Bosch DeviceNet AC and 782-7 Bosch DeviceNet MFDC

3.3 Spot Weld timer configuration options

3.3.1 782-1 Bosch DeviceNet AC and 782-7 Bosch DeviceNet MFDC

Introduction

If either of the additional spot weld timer options *782-1 Bosch DeviceNet AC* or *782-7 Bosch DeviceNet MFDC* are selected when building a spot welding system, the system will be prepared with signals for one spot welding equipment.

Default configuration

The default configuration is for one spot welding equipment. A set of customized user modules are also installed if this option is selected.



Note

Some of the signals are only used in a Spot Pneumatic configuration.



Note

This option requires the option *DeviceNet*, see *Application manual - DeviceNet Master/Slave*.

Predefined I/O devices




There are three pre-defined I/O devices configured by default:

- One DeviceNet device, named *SW_BOARD*, with signals for gun equipment, media panel etc. This device is configured on DeviceNet address 10 by default.
- One DeviceNet device, named *BOSCH_TIMER*, with signals for the weld timer. This device is configured on DeviceNet address 21 by default.
- One simulated device, named *SW_SIM_BOARD* with some internal or normally not connected signals.

Weld timer signals

| Name | Type | Information |
|-----------------|--------|---|
| diWeldComplete | input | Weld complete signal from the weld timer. |
| diWeldFault | input | Fault signal from the weld timer. If this signal is activated during the weld process the weld error handling in Spot is started without waiting for weld time out. |
| diTimerReady | input | The timer is ready to weld. |
| doTimerOn | output | 24V safety signal cross connected to motors on, used to turn off the timer logic in motor off state. |
| doStartWeld | output | Start signal to the weld timer. |
| doEnableCurrent | output | Signal used enable simulated weld mode in a weld timer (simtype = 2). See Simulation modes on page 82 . |

Continues on next page

| Name | Type | Information |
|-------------------|--------------|--|
| doResetFault | output | Reset signal. Can be used to reset the welding controller after a weld error. The signal is pulsed with a user defined pulse length before manual or automatic rewelding. |
| goWeldProgram | output group | Selected weld program number in weld timer, see spotdata - Spot weld data on page 157 . Default size is 8 bits, 0 - 255, 256 different programs. It is possible to use up to 20 bits for this timer. |
| doNewProgram | output | This signal is used as handshaking to let the timer know a new program has been selected by the robot.  Note This signal must be set after a new program number is set in <i>goWeldProgram</i> in order for the timer to set the corresponding inputs <i>giGunForce</i> , <i>giPlateThickness</i> , and <i>giPlateTolerance</i> . |
| diProgSelectValid | input | This signal is used as handshaking to let spot know that a valid program has been read by the timer and to continue the execution.  Note For this timer type the valid program selection is not implemented, but the signal is used by spot. If this signal is not set, a program valid timeout will occur during execution. Valid program = 1, Not valid = 0 |
| diProgComplete | input | Signal used to let the robot know that a new program has been selected. Will be set just after the <i>doNewProgram</i> has been set.  Note This signal will be set by the timer when a new program selection has been done, and it is cross-connected to the <i>diProgSelectValid</i> signal used to check if a valid weld program is selected. |
| giGunForce | input group | Gun force from weld timer if <i>tip_force</i> in <i>spotdata</i> is -1. |
| giPlateThickness | input group | Plate thickness from weld timer if <i>plate_thickness</i> in <i>spotdata</i> is -1. |
| giPlateTolerance | input group | Plate tolerance from weld timer if <i>plate_tolerance</i> in <i>spotdata</i> is -1. |
| giTimerStatus | input group | Weld timer status code. |

Gun and media signals

| Name | Type | Information |
|----------------|-------|---|
| diGunOpen | input | Signal indicating that a pneumatic gun is opened. |
| diHighLiftOpen | input | Signal indicating that a pneumatic gun has reached the highlift position. |

Continues on next page


3 Configuration

3.3.1 782-1 Bosch DeviceNet AC and 782-7 Bosch DeviceNet MFDC

Continued

| Name | Type | Information |
|--------------------|--------|---|
| diPressureOk | input | Signal indicating that the right gun pressure is reached for a pneumatic gun. |
| diTrafoTempOk | input | Signal indicating that the temperature is too high. |
| diWaterFlow1Ok | input | Signal that can be used to indicate problems with the water supply in pipe 1. |
| diWaterFlow2Ok | input | Signal that can be used to indicate problems with the water supply in pipe 2. |
| diAirOk | input | Signal indicating low air pressure in the equalize cylinder. |
| diWeldContact | input | Signal indicating the state of the weld contactor. (0 = deactivated) |
| diEquipmentOk | input | Signal indicating the total gun status. A number of input signals from the gun is cross connected to this signal. |
| doEqualize | output | Gun equalizing signal if mechanical equalizing system are used. |
| doCloseGun | output | Gun close signal for a pneumatic gun. |
| doOpenHighLift | output | Signal used to open a pneumatic gun to the highlift position. |
| doCloseHighLift | output | Signal used to close a pneumatic gun from the highlift position. |
| doStartWater | output | Signal used to activate the water cooling system. This signal is set depending on status of several cross-connected signals. See Cross-connected signals on page 59 . |
| doWeldPowerContact | output | Signal used to pull the weld contactor. This signal is set depending on status of several cross-connected signals See Cross-connected signals on page 59 . |

Process status signals

| Name | Type | Information |
|----------------|--------|--|
| doProcessRun | output | Is set at motion start and is reset when the weld process is ready and motion is released. |
| doProcessFault | output | Is set when an error situation occurs and the process is interrupted.  Note This signal will be reset if the PP is moved and current instruction is aborted. |

Other signals

| Name | Type | Information |
|----------------|-------|---|
| force_complete | input | Can be used to interrupt the <code>SetForce</code> instruction before the programmed force time is elapsed for a servo gun. |
| reweld_proc | input | Can be used to answer a weld error dialog on the FlexPendant with an input signal. The same as tapping Reweld . |

Continues on next page

| Name | Type | Information |
|-----------|-------|---|
| skip_proc | input | Can be used to answer an error dialog on the FlexPendant with an input signal. The same as tapping Skip . Only in manual operating mode. |

Cross-connected signals

| Resultant | Activator(s) | Information |
|---------------------|---|--|
| doStartWater | motor_on AND doEnableCurrent AND doProcessFault (Inverted) | Water start signal, if any of the activators are not set the water start signal will be reset. |
| doWeldPower-Contact | motor_on AND doEnableCurrent AND doProcessFault (Inverted) | Weld contactor signal, if any of the activators are not set the weld contactor signal will be reset. |
| diEquipmentOk | diWaterFlow1Ok AND diWaterFlow2Ok AND diAirOk AND diTempOk AND diTimerReady | Equipment status signal, if any of the activators are not set the equipment ok signal will be reset. |
| diWaterOk | diWaterFlow1Ok AND diWaterFlow2Ok | Water status signal, if any of the activators are not set the water ok signal will be reset. |
| ext_override | skip_proc AND reweld_proc | Reset signal. Can be used to reset the operator error dialog on the FlexPendant when an error occur. See Other signals on page 58 . |
| diProgSelectValid | diProgComplete | Valid program selection signal, signal used to check if a valid weld program is selected in the timer. |

Limitations

This configuration is only available for single robot Spot systems, not in MultiProcess systems with more than one Spot robot.

3 Configuration

3.3.2 782-11 Bosch PROFINET MFDC

3.3.2 782-11 Bosch PROFINET MFDC

Introduction

If the additional spot weld timer option *782-11 Bosch PROFINET MFDC* is selected when building a spot welding system, the system will be prepared with signals for one spot welding equipment.

Default configuration

The default configuration is for one spot welding equipment. A set of customized user modules are also installed if this option is selected.



Note

Some of the signals are only used in a Spot Pneumatic configuration.



Note

This option requires the option *PROFINET Master and Slave*, see *Application manual - PROFINET Controller/Device*.

Predefined PROFINET bus and I/O devices

The pre-installed PROFINET I/O bus *Profinet1* will be configured on address 192.168.5.1 by default if this option is selected, and the necessary network configuration file `IPPNETIO.xml` is copied to the home directory of the system.



Tip

The current KW-Software PROFINET Configurator project is available in the Spot option utility directory in the RobotWare installation. This can be use if there is a need to add new units or modify the configuration, see:

`...\RobotPackages\RobotWare_RPK_<version>\utility\Spot\BoschPnet\KWPnetProj.`

Navigate to the RobotWare installation folder from the RobotStudio **Add-Ins** tab, by right-clicking on the installed RobotWare version in the **Add-Ins** browser and selecting **Open Package Folder**.



For more information about PROFINET configuration, see *Application manual - PROFINET Controller/Device*.

There are two predefined PROFINET I/O devices and one virtual device configured by default:

- One PROFINET device, named *sw_board*, with signals for gun equipment, media panel etc. This device is configured on address *192.168.5.5* by default.
- One PROFINET device, named *bosch_timer*, with signals for the weld timer. This device is configured on address *192.168.5.7* by default.
- One simulated device, named *sw_sim_board* with some internal or normally not connected signals.

Continues on next page

Weld timer signals

| Name | Type | Information |
|-------------------|--------------|--|
| diWeldComplete | input | Weld complete signal from the weld timer. |
| diWeldFault | input | Fault signal from the weld timer. If this signal is activated during the weld process the weld error handling inside Spot is started without waiting for weld time out. |
| diTimerReady | input | The timer is ready to weld. |
| doTimerOn | output | 24V safety signal cross connected to motors on, used to turn off the timer logic in motor off state. |
| doStartWeld | output | Start signal to the weld timer. |
| doEnableCurrent | output | Signal used enable simulated weld mode in a weld timer (simtype = 2). See Simulation modes on page 82 . |
| doResetFault | output | Reset signal. Can be used to reset the welding controller after a weld error. The signal is pulsed with a user defined pulse length before manual or automatic rewelding. |
| goWeldProgram | output group | Selected weld program number in weld timer, see spot-data - Spot weld data on page 157 . Default size is 8 bits, 0 - 255, 256 different programs. It is possible to use up to 20 bits for this timer |
| doNewProgram | output | This signal can be used as handshaking to let the timer know a new program has been selected.  Note This timer requires this signal to be set after a new program number is set in <i>goWeldProgram</i> in order for the timer to set the corresponding inputs <i>giGunForce</i> , <i>giPlateThickness</i> , and <i>giPlateTolerance</i> . |
| diProgSelectValid | input | This signal can be used as handshaking to let spot know that a valid program has been read by the timer.  Note This timer has the possibility to check if a valid weld program selection has been done. Valid program = 1, Not valid = 0 This signal is used by spot. If not set, a program valid timeout will occur during execution. |
| giGunForce | input group | Gun force from weld timer if <i>tip_force</i> in <i>spotdata</i> is -1. |
| giPlateThickness | input group | Plate thickness from weld timer if <i>plate_thickness</i> in <i>spotdata</i> is -1. |
| giPlateTolerance | input group | Plate tolerance from weld timer if <i>plate_tolerance</i> in <i>spotdata</i> is -1. |
| giTimerStatus | input group | Weld timer status code. |

Gun and media signals

| Name | Type | Information |
|-----------|-------|---|
| diGunOpen | input | Signal indicating that a pneumatic gun is opened. |

Continues on next page


3 Configuration

3.3.2 782-11 Bosch PROFINET MFDC

Continued

| Name | Type | Information |
|--------------------|--------|---|
| diHighLiftOpen | input | Signal indicating that a pneumatic gun has reached the highlift position. |
| diPressureOk | input | Signal indicating that the right gun pressure is reached for a pneumatic gun. |
| diTrafoTempOk | input | Signal indicating that the temperature is too high. |
| diWaterFlow1Ok | input | Signal that can be used to indicate problems with the water supply in pipe 1. |
| diWaterFlow2Ok | input | Signal that can be used to indicate problems with the water supply in pipe 2. |
| diAirOk | input | Signal indicating low air pressure in the equalize cylinder. |
| diWeldContact | input | Signal indicating the state of the weld contactor. (0 = deactivated) |
| diEquipmentOk | input | Signal indicating the total gun status. A number of input signals from the gun is cross connected to this signal. |
| doEqualize | output | Gun equalizing signal if mechanical equalizing system are used. |
| doCloseGun | output | Gun close signal for a pneumatic gun. |
| doOpenHighLift | output | Signal used to open a pneumatic gun to the highlift position. |
| doCloseHighLift | output | Signal used to close a pneumatic gun from the highlift position. |
| doStartWater | output | Signal used to activate the water cooling system. This signal is set depending on status of several cross-connected signals. See Cross-connected signals on page 59 . |
| doWeldPowerContact | output | Signal used to pull the weld contactor. This signal is set depending on status of several cross-connected signals See Cross-connected signals on page 59 . |

Process status signals

| Name | Type | Information |
|----------------|--------|--|
| doProcessRun | output | Is set at motion start and is reset when the weld process is ready and motion is released. |
| doProcessFault | output | Is set when an error situation occurs and the process is interrupted.  Note This signal will be reset if the PP is moved and current instruction is aborted. |

Other signals

| Name | Type | Information |
|----------------|-------|---|
| force_complete | input | Can be used to interrupt the <code>SetForce</code> instruction before the programmed force time is elapsed for a servo gun. |

Continues on next page

| Name | Type | Information |
|-------------|-------|---|
| reweld_proc | input | Can be used to answer a weld error dialog on the FlexPendant with an input signal. The same as tapping Reweld . |
| skip_proc | input | Can be used to answer an error dialog on the FlexPendant with an input signal. The same as tapping Skip . Only in manual operating mode. |

Cross-connected signals

| Resultant | Activator(s) | Information |
|---------------------|---|--|
| doStartWater | motor_on AND doEnableCurrent AND doProcessFault (Inverted) | Water start signal, if any of the activators are not set the water start signal will be reset. |
| doWeldPower-Contact | motor_on AND doEnableCurrent AND doProcessFault (Inverted) | Weld contactor signal, if any of the activators are not set the weld contactor signal will be reset. |
| diEquipmentOk | diWaterFlow1Ok AND diWaterFlow2Ok AND diAirOk AND diTempOk AND diTimerReady | Equipment status signal, if any of the activators are not set the equipment ok signal will be reset. |
| diWaterOk | diWaterFlow1Ok AND diWaterFlow2Ok | Water status signal, if any of the activators are not set the water ok signal will be reset. |
| ext_override | skip_proc AND reweld_proc | Reset signal. Can be used to reset the operator error dialog on the FlexPendant when an error occur. See Other signals on page 58 . |

Limitations

This configuration is only available for single robot Spot systems, not in MultiProcess systems with more than one Spot robot.

This page is intentionally left blank

4 Programming

Introduction to programming

This chapter describes the basic functions and steps to take when creating, testing, and running spot weld programs with the Spot options.

It is assumed that a servo gun is installed and tuned at this stage. If not, see [Servo gun motion control on page 229](#), and *Application manual - Servo Gun Setup*.

Continues on next page

4 Programming

4.1 Quick start for servo gun

4.1 Quick start for servo gun

Install servo gun parameters

If the system is cold started, the servo gun parameters are probably not loaded. See [Install servo gun parameters on page 230](#).

Set the servo gun name

After the gun parameters are installed and the system is restarted, the `gundata` needs to be updated with the servo gun name (mechanical unit name) so the spot instructions will work correctly. See [Set the servo gun name on page 230](#).

Servo gun force calibration

To protect the gun from too high forces there is a RAPID service routine to calibrate the motor torque versus max tip force of the gun. See [Servo gun force calibration on page 231](#).

Servo gun initialization

Before running any spot instructions, the gun must be calibrated by performing a fine calibration or a revolution counter update. Apart from other kinds of additional axes, it is also required to run a RAPID service routine to find the contact position or zero position of the gun. See [Servo gun initialization calibration on page 234](#).

4.2 Spot weld instructions and data

Defining spot welding data


Before starting to program the instructions, define the spot welding data to be used. This data is divided into two types:

- `spotdata`; describes the spot welding process specific data for a specific spot (target). See [spotdata - Spot weld data on page 157](#).
- `gundata`; describes spot welding gun specific data, used mechanical unit, weld counters, tip wear data etc. The used **spot equipment** is specified by a gun index number (gun1 or G1). This index number points at the corresponding `gundata` array index in `curr_gundata` in SWUSER and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

Spot weld instructions for sequential welding

`SpotL` and `SpotJ` are the basic spot welding instructions. The instructions includes a movement to the weld position and performing the desired weld process. They contain basically the same type of information as a positioning instruction, and also arguments that serves as data for the spot welding process. These instructions are used for welding with one gun or several guns in sequence.

For further details, see [SpotL/SpotJ - The basic spot welding instructions on page 107](#).



en1200000250

Programming example for one servo gun

In this example a single servo gun (gun1) is used, held by the robot. Four spots are to be welded with two different `spotdata` used, `spot10` and `spot20`. The data is created in advance.

Continues on next page


4 Programming

4.2 Spot weld instructions and data

Continued

The gun index number used in the instruction (gun1) will use the servo gun *SGUN_1* specified in the corresponding *gundata* array index in *curr_gundata* located in the SWUSER module, and after weld update the weld counter in the same instance.

The targets p2 and p3 will be welded with weld program number 10 and the tip force 2000N. Thickness is set to 2mm and the supervision tolerance is set to 0.5mm. If the tolerance is exceeded the execution will be stopped with an operator dialog. The next two targets p4, p5 will be welded with weld program number 20 and the selected tip force is set to 3000N. The plate thickness 3mm, will not be supervised since the tolerance is set to 0.



xx1200000245

```
spot10                                curr_gundata{1}
  prog_num = 10                        gun_name = "SGUN_1"
  tip_force = 2500                     weld_counter = 112
  plate_thickness = 2                  max_nof_welds = 1000
  plate_tolerance = 0.5                curr_tip_wear = 5.2
  release_dist = 5                     max_tip_wear = 8
                                        curr_wear_fix = 3
                                        curr_wear_mov = 2.2

spot20
  prog_num = 20
  tip_force = 3000
  plate_thickness = 3
  plate_tolerance = 0
  release_dist = 5
```

RAPID code sequence:

```
MoveJ p1, v600, z50, toolGun1;
SpotL p2, vmax, gun1, spot10, toolGun1;
SpotL p3, vmax, gun1, spot10, toolGun1;
SpotL p4, vmax, gun1, spot20, toolGun1;
SpotL p5, vmax, gun1, spot20, toolGun1;
MoveL p6, v600, z50, toolGun1;
```


Programming example for one pneumatic gun

Same example as above but with parameters for a pneumatic gun.

Continues on next page

The targets p2 and p3 will be welded with weld program number 10 and the tip force output group is set to 2. The next two targets p4, p5 will be welded with weld program number 20 and the selected tip force output group is set to 3.

It is more common to control the the tip force from the weld timer, and in those cases the tip force parameter can be ignored or removed. See [How to change the Spot data types on page 287](#).



xx120000245

```

spot10                                curr_gundata{}
  prog_num = 10                        gun_name = "PNEU_G1"
  tip_force = 2                        weld_counter = 112
spot20                                  max_nof_welds = 1000
  prog_num = 20
  tip_force = 3

```

RAPID code sequence:

```

MoveJ p1, v600, z50, toolGun1;
SpotL p2, vmax, gun1, spot10, toolGun1;
SpotL p3, vmax, gun1, spot10, toolGun1;
SpotL p4, vmax, gun1, spot20, toolGun1;
SpotL p5, vmax, gun1, spot20, toolGun1;
MoveL p6, v600, z50, toolGun1;

```

Continues on next page

4 Programming

4.2 Spot weld instructions and data

Continued

Spot weld instructions for simultaneous welding with multiple guns


`SpotML` and `SpotMJ` has to be used if welding with several guns at the same time is desired. It is possible to use four guns simultaneously. The instruction includes a movement to the weld position and performing the desired weld processes. It contains basically the same type of information as a positioning instruction, and also arguments that serves as data for the different spot welding processes. See [SpotML/SpotMJ - Spot welding with multiple guns on page 113](#).



Note

It is not possible to use Software Equalizing mode for the `SpotML/SpotMJ` instructions.

For more information, see [Software Equalizing on page 197](#).



en1200000251

Programming example for two servo guns

In this example two different stationary guns are used, mounted close to each other. The robot is holding the work piece. Seven spots are to be welded with two different `spotdata` used, `spot10` and `spot20`.


The gun index numbers used in the instruction (G1) and (G2) will use the servo guns `SGUN_1` and `SGUN_2` specified in the corresponding `gundata` array indexes in `curr_gundata` located in the `SWUSER` module, and after weld update the weld counters in the same instances.

The target p2 will be welded with G1(`SGUN_1`) with weld program number 10 and the tip force 2000N. Thickness is set to 2mm and the supervision tolerance is set to 0.5mm. If the tolerance is exceeded the execution will be stopped with an operator dialog.

Continues on next page

The next targets p3 and p4 will also be welded with G1(SGUN_1), and also at the same time with G2(SGUN_2) with weld program number 20 and the selected tip force is set to 3000N. The plate thickness 3mm, will not be supervised since the tolerance is set to 0.

The target p5 will be welded with just G1(SGUN_1) also with weld program 20.



xx120000241

```

spot10                                curr_gundata{1}
  prog_num = 10                        gun_name = "SGUN_1"
  tip_force = 2000                     weld_counter = 112
  plate_thickness = 2                  max_nof_welds = 1000
  plate_tolerance = 0.5                curr_tip_wear = 5.2
                                       max_tip_wear = 8

spot20                                curr_gundata{2}
  prog_num = 20                        gun_name = "SGUN_2"
  tip_force = 3000                     weld_counter = 345
  plate_thickness = 3                  max_nof_welds = 1000
  plate_tolerance = 0                  curr_tip_wear = 3.4
                                       max_tip_wear = 11

```

RAPID code sequence:

```

MoveJ p1, v600, z50, toolGrip1\Wobj:= frame1;
SpotML p2, vmax\G1:=spot10,toolGrip1\Wobj:= frame1;
SpotML p3, vmax\G1:=spot20\G2:=spot20,toolGrip1\Wobj:= frame1;
SpotML p4, vmax\G1:=spot20\G2:=spot20,toolGrip1\Wobj:= frame1;
SpotML p5, vmax\G2:=spot20,toolGrip1\Wobj:= frame1;
MoveL p6, v600, z50, toolGrip1\Wobj:= frame1;

```

Programming example for two pneumatic guns

Same example as above but with parameters for pneumatic guns.

The target p2 will be welded with G1(PNEU_G1) with weld program number 10 and the tip force output group is set to 2.

The next targets p3 and p4 will also be welded with G1(PNEU_G1) but also at the same time with G2(PNEU_G2) with weld program number 20 and the selected tip force output group is set to 3.

The target p5 will be welded with only G2(PNEU_G2) also with weld program 20 and the tip force output group is set to 3.


Continues on next page

4 Programming

4.2 Spot weld instructions and data

Continued

It is more common to control the the tip force from the weld timer, and in those cases the tip force parameter can be ignore or removed. See [How to change the Spot data types on page 287](#).



xx120000241

```
spot10                                curr_gundata{1}
  prog_num = 10                        gun_name = "PNEU_G1"
  tip_force = 2                        weld_counter = 112
                                        max_nof_welds = 1000

spot20                                curr_gundata{2}
  prog_num = 20                        gun_name = "PNEU_G2"
  tip_force = 3                        weld_counter = 215
                                        max_nof_welds = 1000
```


RAPID code sequence:

```
MoveJ p1, v600, z50, toolGrip1\Wobj:= frame1;
SpotML p2, vmax\G1:=spot10,toolGrip1\Wobj:= frame1;
SpotML p3, vmax\G1:=spot10\G2:=spot20, toolGrip1\Wobj:= frame1;
SpotML p4, vmax\G1:=spot20\G2:=spot20, toolGrip1\Wobj:= frame1;
SpotML p5, vmax\G2:=spot20, toolGrip1\Wobj:= frame1;
MoveL p6, v600, z50, toolGrip1\Wobj:= frame1;
```

Programming spot welding instructions

- 1 Jog the robot to the desired destination position and jog also the gun axis to desired preclose tip position (Only for servo guns).
- 2 In the Editor, tap **Add instruction**, and then select **SpotWeld** from the list.
- 3 Select the instruction **SpotL** or **SpotJ**.
The instruction will be added directly to the program. The arguments are set in relation to the last programmed spot welding instruction.
- 4 Change the optional arguments if needed.
- 5 Jog the robot to another position and add more spot weld instructions the same way.


Continues on next page



en120000246

Edit current used spotdata

- 1 Select current spotdata in the instruction.
- 2 Tap **Debug**, and then tap **View Value**.
- 3 Change the value.
- 4 Tap **OK**.



en120000243

Changing to another spotdata

- 1 Select current spotdata in the instruction.
- 2 Tap **Edit**, and then tap **Change Selected**.
- 3 Select a spotdata from the list of available spotdata.
- 4 Tap **OK**.

4 Programming

4.3 Testing spot weld instructions in simulated mode

4.3 Testing spot weld instructions in simulated mode

Simulation modes

To prevent the spot welding process executing during programming and testing, it is possible to run the program in different simulation modes. For more information about simulation modes see [Simulation modes on page 90](#).



Tip

The fastest way to change the simulation mode is to use the Spot FlexPendant interface, see [Simulation on page 256](#).

4.4 Gun control

Preclosing of gun

The spot welding instructions have a built-in preclosing of the weld guns, that is when approaching the position the guns will start to close in advance to save time. For more information about gun control, see [Gun closing and pre closing time on page 87](#).

Mechanical gun equalizing

The spot welding instructions have a function for equalizing with mechanical equalizing systems in the gun, to minimize the impact on the plates during the welding. See [Gun equalizing on page 86](#).

Software equalizing

The spot welding instructions SpotL and SpotJ also has functions that make it possible to use spot welding guns **without** mechanical equalizing systems. These functions are available if the configuration *Spot Servo Equalizing* is selected. For more information, see [Software Equalizing on page 197](#).

4 Programming


4.5 Manual actions

4.5 Manual actions

Service routines

Some useful service routines are predefined to be used for manual actions during programming and test.

- From the Spot GUI application, select **RobotWare Spot** and **Manual Actions**.
- From the Program Editor, tap **Debug**, and then tap **Call Service Routine**.



en1200000242



Tip

It is also possible to access and run the service routines from the FlexPendant interface, see [Manual Actions on page 254](#)



Note


Some of the following routines are also possible to run without a robot selected, i.e. in a stand alone controller system.

Available service routines

The following service routines are available in the Spot Options:

| Service routine | Description |
|-------------------|---|
| ManualGunSearch | This routine will search the system for available servo guns and add their names to gun name in current gundata. |
| ManualGunControl | This routine will close or open the gun according to data in curr_forcedata. The gun equalize signal is also activated/deactivated. |
| ManualGunPosition | This routine will open or close the pneumatic gun to the large stroke or work stroke position. |

Continues on next page

| Service routine | Description |
|---------------------|---|
| ManualSpot | This routine will perform a weld in current position according to data in <code>curr_spotdata</code> . |
| ManualSetForce | This routine will perform a <code>SetForce</code> action according to data in <code>curr_forcedata</code> . The gun equalize signal is also activated/deactivated. |
| ManualCalib | <p>This routine will perform a calibration of the servo gun, 1 Tool Change, 2 Tip Change or 3 Tip Wear calibration.</p> <ul style="list-style-type: none"> Option 1. Tool Change calibration, used after changing tool if using more than one gun. Option 2: Tip Change calibration, used after worn tips has been replaced with new tips. Option 3: Tip Wear calibration, used after the tip has been dressed. <p>See Tip management on page 242.</p> |
| ManualForceCalib | <p>This routine will perform a force calibration of the servo gun. 2 - 10 forces and positions can be stored. See Servo gun force calibration on page 231.</p> <p>From this routine is also possible to setup the gravitational impact on the gun force. This function can be used if a servo gun loses force when the movable gun arm moves against gravity.</p> <p>For more information, see Servo gun force gravity compensation on page 233 and The Spot Gun Equipment instance on page 39.</p> |
| ManualServiceCalib | <p>This routine will perform a gun init calibration of the servo gun, find the zero position.</p> <ul style="list-style-type: none"> Option 1: Will synchronize the servo gun without jogging after the revolution counter has been updated. The servo gun will close slowly until it reaches the contact position. Option 2: Will synchronize the servo gun without jogging after the gun has been fine calibrated. The servo gun will move fast to a predefined pre-position. and then continue to close slowly until it reaches the contact position. <p>See Servo gun initialization calibration on page 234.</p> |
| ManualCheckMeas-Pos | <p>This routine can be used to verify if a robot position or gun orientation is suitable for a tip wear measurement with <code>MeasureWearL</code>. When this routine is run in the selected position, status information will be presented on the FlexPendant whether the position is suitable or not. The recommended touch up axis should be 4 to 6 and the touch up value should be in range between 0.25 and 1.</p> <p>This instruction is only available if the Spot Servo Equalizing option is installed.</p> <p> Note</p> <p>For some special configurations the <code>MeasureWearL</code> measuring method is less suitable, for example very large guns and/or when an acceptable touch up position is not possible to reach for some reason, e.g unsuitable robot axis configuration. Then the <code>ReCalcTcp</code> method should be used instead.</p> |

If several guns are used then a dialog will appear asking for the gun number of the gun to be handled.

4 Programming

4.6 Process sequence and error handling

4.6 Process sequence and error handling

Process sequence

This section describes the internal process sequence when a SpotL/J or a SpotML/MJ instruction is executed:

- 1 Data definition user routines are executed. (eg. DefineSpotData, DefineGunData)
- 2 The weld program number is set (goWeldProgram).
- 3 The new program selection signal is set (doNewProgram).
- 4 The robot and gun starts to move towards the programmed position.
- 5 The process will check and wait for the program valid signal from the weld controller (diProgSelectValid).
- 6 If valid program selection (diProgSelectValid), the process will read the weld controller groups if configured, (eg. giGunForce).
- 7 The new program selection signal is reset, if configured (doNewProgram).
- 8 User routine UpdateSpotData is executed.
- 9 User routine SwInitUserIO is executed.
- 10 User routine SwPrepare is executed.
- 11 User routine SwCloseGun is executed (for pneumatic guns).
- 12 The gun will start to close before the position is reached (unless argument \InPos is used), according to the predefined gun pre closing time.
- 13 The equalizing signal is set according to the predefined pre equalizing time. (eg. doEqualize).
- 14 User routine SwPreWeld is executed when the weld position is reached (Preweld supervision).
- 15 The plate thickness is checked. (Servo guns only). The requested gun force is established if OK.
- 16 The start signal to the weld controller is set (eg. doStartWeld).
- 17 The weld controller performs the weld, and can change the gun force during the weld sequence if configured (eg. new value on giGunForce).
- 18 When the weld complete signal from the weld controller is received, (eg. diWeldComplete) the start signal will be reset and the gun will start to open and the equalizing signal will be reset.
- 19 User routine SwOpenGun is executed (for pneumatic guns).
- 20 User routine SwPostWeld is executed.
- 21 The instruction is ready.

Gun equalizing

For pneumatic and servo guns without *Software Equalizing* activated the signal for the mechanical gun equalizing is activated at a defined time before the weld position. The signal is deactivated after the weld process before the next robot motion is released.

Continues on next page

The gun pre equalizing time, `Gun pre equalizing time`, is defined for each used gun in `Spot Gun Equipment` process data. See [The Spot Gun Equipment instance on page 39](#).

**Note**

The gun pre equalizing time in `Spot Gun Equipment` process data, `Gun pre equalizing time`, is not used when `SoftWare` equalizing is used. For more information see [Software Equalizing on page 197](#).

Gun closing and pre closing time

The spot welding instructions have a built-in preclosing of the weld guns, that is when approaching the position the guns will start to close in advance to save time. For servo guns the movement to the weld position starts with a synchronous phase which means that the servo gun axis is moved synchronized with the robot movement. The gun closing speed is automatically adapted so the contact position is reached at the same time as the robot reaches the programmed weld position. For more information about servo gun motion control, see [Servo gun motion control on page 229](#).

For pneumatic and servo guns without `Software Equalizing` activated the gun closure is activated at a defined time before the weld position. The gun pre closing time, `Gun pre closing time`, can be defined for each used gun in the `Spot Gun Equipment` process data. See [The Spot Gun Equipment instance on page 39](#).

**Note**

The data `Gun pre closing time` is not used if `Software Equalizing` is active, see [Software Equalizing on page 197](#).

**Note**

The pre closing can be disabled by using the `\InPos` argument in the instruction.

**Note**

If the pre closing time is set to high it can lead to a longer cycle time if close positions are programmed, because the gun movement will synchronize with the robot.

**Note**

If using gun open position less than 10mm for servo guns, there may be problems with sporadic "internal servo tool" errors. The reason for this is probably a too hard tuned or a very fast gun.

Continues on next page

4 Programming

4.6 Process sequence and error handling

Continued

Welding

Before weld the plate thickness is checked (Servo guns only). The weld start signal is set as soon as the internal supervisions and SwPreWeld is ready and the requested gun force is reached. After ordering weld, the system waits for weld complete from the weld equipment. If configured it is also possible to change the gun force before the weld complete is set. See [How to use spot data programmed in the weld timer on page 290](#).

For pneumatic guns the start signal is set as soon as the robot has reached the weld position and a number of supervisions have been acknowledged. The start signal is high during the entire welding period. It is reset either after weld complete or after a predefined time out time elapsed.

Gun opening

The gun starts to open to the programmed position after the weld process is finished. When the gun is opened enough and is ready then the movement is released and the robot movement is started. The gun is also opened to the programmed position after a weld error or in other error situations.

For pneumatic guns the gun opens to a small or large stroke after the welding has finished, depending on the parameter `\OpenHLift`. The opening is supervised in such a way that the gun open signal is expected.



Note

The gun opening gap must be large enough that the tips are free from the plates when welding.

So therefore, the software will compensate for the release distance that is used, and the plate thickness, as the opening position is the same as the tips closed with plates + release distance.

Example:

If the release distance is 10mm, the moving tip will open to 10mm even if you modify the position with the gun closed on the plate surface.

A simple recommendation is to have approximately the same distance from the plate to the movable electrode as the used release distance.

For more information about the SoftWare Equalizing functionality, see [Software Equalizing on page 197](#).

Program stop and restart

Stop during the motion and restart

The robot stops on the path. If the gun closure already is started the gun will open to the programmed position.

On restart, the robot continues towards the programmed position, closes the gun again and the sequence in `SpotL/J` carries on as normal.

Stop during welding and restart

The welding is finished, validation is done after the stop and the gun opens.

Continues on next page

On restart, the robot continues with next instruction.

Quick stop and restart

Quick stop during the motion and restart

The robot stops immediately probably deviated from the path. If the gun closure already is started the gun will open to the programmed or gun open position.

On restart, the robot first moves back to the path, then continues towards the programmed position, closes the gun again and the sequence in SpotL/J and SpotML/MJ carries on as normal.

Quick stop during welding and restart

The weld process is interrupted. The gun is still closed but the gun force will be reduced. (Servo guns only).

A pneumatic gun will open in this situation.

On restart, the weld error handling is executed with possibilities to reweld the last spot.

Power failure handling

At system restart after power failure:

- All spot welding output signals are set to the old status, except the weld start signal.

At program restart after power failure:

- The robot returns to the path and the program execution which was interrupted is continued.
- If a power failure occurred when a weld process was active, the current spot is automatically rewelded.

Instruction by instruction execution

Forward

The instruction is executed in two steps (Recommended setting, Step Mode = Step Over):

- 1 The robot will move to the weld position, an operator dialog will be shown with instructions on how to continue. After this step it is possible to modify the position if needed. It is possible to weld or skip the current position and move to next instruction.
- 2 If the step forward button is pressed again, current instruction will be skipped. If start button is pressed the current instruction will be welded.



Note

To perform a weld in this position, the start button must be pressed. Program execution will stop after the current instruction is ready. To restart the program normally, the start button must be pressed again.

Continues on next page

4 Programming

4.6 Process sequence and error handling

Continued

Backward

The motion is performed backwards to the programmed position with gun control, but the gun is not closed in the weld position and no weld process is activated. (Servo guns only).

For pneumatic guns the gun is set to work or highlift stroke depending on position of the `\OpenHLift` switch. The motion is performed backwards.

The gun is set to work or highlift stroke depending on the position of the `\CloseHLift` switch.

Simulation modes

The simulation modes can be set from the Spot FlexPendant interface, they can also be set from RAPID and are located in `curr_simdata` in SWUSER.

For more information, see [simdata - Simulation data on page 164](#).

Weld simulation in the robot controller

Activated by setting `sim_type = 1` in `curr_simdata` in SWUSER, simulated welding.

This will inhibit the weld start signal to the timer. The simulated weld time used is the time `sim_time` in `curr_simdata`. In this simulation mode the start signal is never sent to the welding timer.

No pre-weld supervision is performed, water air etc. Reading of timer input groups will still be done in this mode, tip force, plate thickness etc.

Weld simulation in the timer

Activated by setting `sim_type = 2` in `curr_simdata` in SWUSER, welding without current.

This will set the enable current signal low to the timer at the next weld, the weld program in the timer will be executed normally, but **without current**. The timer will perform a "dry weld".

No pre-weld supervision is performed, water air etc. Program valid check and reading of timer input groups will still be done in this mode, tip force, plate thickness etc

Testing without closing the guns

When simulation is active it is also possible to run **without closing** the gun.

Activated by setting `inhib_close` to `TRUE` in `curr_simdata`. This mode can only be used when `sim_type` is set to 1 or 2.

This inhibits the gun closing and opening.

Testing without plates

When simulation is active it is also possible to run without testing plate thickness (servo guns only).

Activated by setting `no_plates` to `TRUE` in `curr_simdata`. This mode can only be used when `sim_type` is set to 1 or 2. (Servo guns only).

This inhibits the plate thickness supervision.

Continues on next page

Weld position Touch Up mode

If *Spot Servo Equalizing* is installed it is possible to set `sim_type = 3` to activate the weld position TouchUp function. See [Software Equalizing on page 197](#)

Activated by setting `sim_type = 3` in `curr_simdata` or via the simulation view in Spot FlexPendant interface.



Note

It is possible to weld the new position after it has been modified.

Disable all simulations

All simulations are disabled if `sim_type = 0` in `curr_simdata`.

Error handling

The following error situations can occur:

- Instruction parameter supervision
- Equipment status supervision in the beginning of the movement
- Supervision of valid program selection
- Gun closure supervision (Pneumatic guns)
- Detection of missing or improper plates (Servo guns only)
- Weld equipment supervision before weld start
- Weld error
- Supervision after welding
- Gun opening supervision (Pneumatic guns)

Instruction parameter supervision

The error occurs when `SpotL/J` or a `SpotML/MJ` is called with faulty parameters.

- The signal `process_fault` for the current equipment is set. The program stops.
- An error message is displayed in a dialog box.
- The error message is logged

The parameter must be changed. When the program is restarted the current instruction is restarted from the beginning.

Supervision of valid program selection

Supervision of valid program selection is done if it is configured.



Note

For more information, see [Spot Weld timer configuration options on page 64](#).

If an error occurs then:

- The signal `process_fault` for the current equipment is set. The program stops.
- An error message is displayed in a dialog box with retry possibilities.
- The error message is logged.

Continues on next page

4 Programming

4.6 Process sequence and error handling

Continued



Note

If automatic rewelding is configured and used the program valid will only be checked at the first try, not on the consequent retries.

If the number of retries has been executed, a new check will be done when the operator selects "Reweld", see [Weld error on page 94](#)

Supervision in the beginning of the movement

The internal default supervision checks are executed if configured, and the `SwPrepare` routine is run. See [Process hooks on page 189](#).

If an error occurs then:

- The signal `process_fault` for the current equipment is set. The program stops.
- An error message is displayed in a dialog box with retry possibilities.
- The error message is logged.

See [The Spot Media Equipment instance on page 46](#)

Gun closure supervision

For a pneumatic gun the internal default gun closing sequence are executed if configured, and the `SwCloseGun` routine is run. See [Process hooks on page 189](#).

An error occurs if the `gun_open` signal is not set within a certain time.

- The signal `process_fault` the current equipment is set. The program stops.
- An error message is displayed in a dialog box with retry possibilities.
- The error message is logged

See [The Spot Gun Equipment instance on page 39](#).

Detection of missing or improper plates (Servo guns only)

An error will be detected by the process kernel if the plate thickness differ more than the allowed limit, defined by the tolerance, from the programmed thickness.

There are three types of errors:

- Negative gun position, one of the tips are missing on the gun, or a `tip_wear` calibration is needed.
- Missing plates, the plate thickness is smaller than the thickness defined in `spotdata`.
- Improper geometry, the plate thickness exceeds the tolerance defined in `spotdata`.

The gun opens.

- The signal `process_fault` for the current equipment is set. The program stops.
- An error message is displayed in a dialog box with retry possibilities.
- The error message is logged.

Continues on next page

Manual SPOTS_DISP_6_0.. (192.168...) Motors On Running (Speed 100%)

All Tasks T_ROB1 UIMessageBox

The plate geometry is not correct!

Code: 635 2014-08-07 13:54:44

Tolerance: 0.5 mm
 Expected thickness: 1 mm
 Achieved thickness: 4.2 mm

Current gun: 1 (M7C1B1_S)

Current robtarget: P20
 Press 'Ignore' to skip the thickness test

Ignore Retry

T_ROB1 MainModule RobotWare Spot ROB_1

xx1200000217

| | |
|--------|---|
| Ignore | Close the gun again but without thickness detection and continue the execution. |
| Retry | Start the interrupted process from the beginning. |

If the error is of the type improper geometry there is a possibility to do a retry with a higher force on the gun and complete the current weld, that is. when the plates are not properly fixed together.

Manual SPOTS_DISP_6_0.. (192.168...) Motors On Running (Speed 100%)

All Tasks T_ROB1 UINumEntry

The plate geometry is not correct!

Plates not clamped together properly.
 1. Check the clamping.
 2. Check the tips.

Increase the gun pressure, to force the plates together.

Press 'OK' to continue

2500

Min: 0
 Max: 5000

7 8 9 ←
 4 5 6 →
 1 2 3 ✕
 0 +/-

OK

T_ROB1 MainModule RobotWare Spot ROB_1

xx1200000216



Note

The accuracy of the thickness supervision is highly dependent of good gun tuning and correct mechanical data, e.g. *Transmission Gear Ratio*. It is also recommended to use a small value in *Close Position Adjust*.

Continues on next page

4 Programming

4.6 Process sequence and error handling

Continued



Note

If the system has been reset (**Reset system**) the calibrated zero position is not known anymore and a new gun initialization calibration needs to be performed in order to find a new zero position. If this step is ignored the value -1000 will be returned instead of the measured thickness and an error will be raised.

Supervision before the weld is started

The internal default preweld supervisions are executed if configured, and the `SwPreWeld` routine is run. See [Process hooks on page 189](#).

If an error occurs then:

- The signal `process fault` for the current equipment is set. The program stops.
- An error message is displayed in a dialog box with retry possibilities.
- The error message is logged

See [The Spot Weld Equipment instance on page 33](#).


Weld error

A weld error occurs either if the `weld fault` signal is set during the weld process or if the weld complete signal from the weld timer has not been set in a certain time, `Weld timeout` in the process configuration. See [The Spot Weld Equipment instance on page 33](#).


`SpotL/J` and `SpotML/MJ` can be configured to automatically reweld a certain number of times before the error is displayed and the execution stops, waiting for a manual action.

- The gun opens.
- The signal `process fault` for the current equipment is set. The program stops.
- An error message is displayed in a dialog box with retry possibilities.
- The error message and the current robot target name is logged.


Continues on next page




xx120000215

| | |
|--|---|
| <p>Skip (only available in manual mode)</p> | <ul style="list-style-type: none"> • The corresponding reset fault signal is pulsed. • The corresponding process fault signal is reset. • The current robtarget name will be stored in the log. The program execution is resumed but omitting the faulty weld. |
| <p>Reweld</p> | <ul style="list-style-type: none"> • The corresponding reset fault signal is pulsed. • The corresponding process fault signal is reset. • The gun closes. • The start signal is set after a short time delay and the program execution is resumed. <p> Note</p> <p>If the optional signal <code>Reset fault with reweld [DO]</code> is configured, the start weld signal will be set to 1 during the reweld sequence. This will enable the KSR mode in a Bosch weld timer when performing a re-weld in adaptive weld mode. See The Spot Weld Equipment instance on page 33.</p> |

Skip and Reweld error recovery can also be activated by using the digital inputs `skip_proc` and `reweld_proc`, see [Spot template I/O configuration for single gun system on page 52](#).

 **Note**

If the spot system is built with an additional **Bosch weld timer configuration** there will be more information in the operator dialog about the reason for the error, for example, hardware fault in the weld timer etc.

 **Tip**

The setup parameter `Number of automatic rewelds in Spot Error Handling` can be set to the number of welds required. See [The Spot Error Handling instance on page 30](#).

Continues on next page

4 Programming

4.6 Process sequence and error handling

Continued

Supervision after welding

For a pneumatic gun the internal default gun opening sequence are executed if configured, and the `SwOpenGun` routine is run. See [Process hooks on page 189](#).

An error occurs if the `gun open` signal is not set within a certain time.

- The signal `process fault` for the current equipment is set. The program stops.
- An error message is displayed in a dialog box with retry possibilities.
- The error message is logged

See [The Spot Gun Equipment instance on page 39](#).

Gun opening supervision (Servo guns only)

Any errors during gun opening will be detected by internal motion software. An error results in an error message on the FlexPendant and a program stop.

User defined error handling

All error situations described above can also be handled in a predefined user routine `SwErrorRecover` as an option to the built in error handling if needed. See [The Spot Error Handling instance on page 30](#).

If the "user defined" error handling is activated, a dedicated routine `SwErrorRecover` in `SWUSER` will be executed if any of the error cases described in section [Error handling on page 91](#) occur, except for parameter errors.

`SwErrorRecover` is always executed from the robot task.


The input parameters to the `SwErrorRecover` routine carry information about the error reason and the chosen error text.

Continues on next page

This routine allows customizing of the error handling response, that is. the FlexPendant layout and how to resume. For more information. See `SwErrorRecover` in *SWUSER on page 187*.

Example

Default example if weld error occurs.



xx1200000214

Software Equalizing

When the software equalizing functions are activated the execution of the `SpotL/J` instructions is influenced in different ways:

- The movement to the programmed position will be different.
- The gun pre close function is handled automatically.
- The `\Inpos` switch will not affect the program execution.



Note

The software equalizing functions are not implemented for the `SpotML/MJ` instructions.

For more information, see *Software Equalizing on page 197*.

Multiple gun forces during welding

During the welding phase when a `SpotL/J` or a `SpotML/MJ` instruction is executed there is a possibility to use multiple gun forces if needed.

The servo gun force can be controlled from the welding controller via group inputs. Internally in the Spot software an input group will be monitored during the weld, and if the value on the input group changes, the gun force will change immediately to a lower or higher force.

Continues on next page

4 Programming

4.6 Process sequence and error handling

Continued

For more information, see [How to use spot data programmed in the weld timer on page 290](#) and [Servo gun force calibration on page 231](#).



Note

Note that the force calibration procedure is very important if multiple forces has to be used. The gun position at each force will be stored in the motion parameters when running this routine. For more information see [Servo gun force calibration on page 231](#).



Note

A fast I/O response time is critical for this functionality.

Customizing

The Spot package gives the user plenty of scope for customizing the Spot functionality, see [Customizing RobotWare-Spot on page 279](#).


However the main subject of the `SpotL/J` and `SpotML/MJ` instructions description is the default setup.

4.7 Weld process timing

Weld process timing for pneumatic guns

The following graphic shows the weld process timing for a pneumatic gun and where in the sequence the user hooks will be executed and affect the internal behavior.

If welding is done with several guns at the same time then each process is handled in separate tasks independent of each other.



en120000238

Weld process timing for servo guns

The following figure shows the weld process timing for a servo gun and where in the sequence the user hooks will be executed and affect the internal behavior.

If welding is done with several guns at the same time then each process is handled in separate tasks independent of each other.

The system parameter *Post_sync_time* (*Post-synchronization Time*) in the topic *Motion*, type *SG Process*, defines the predicted release time of the next robot movement after a weld. Can be used to shorten the cycle time, the robot will start to move before the gun is completely opened. Default value is 0. See System Parameters, Topic Motion and Type SG Process *Technical reference manual - System parameters*.



Note


The value of this parameter (*Post-synchronization Time*) can affect the cycle time of the program negatively if for example two welding points are programmed at the same position. To minimize this risk the value can be increased. See *Application manual - Additional axes and standalone controller*.

Continues on next page

4 Programming

4.7 Weld process timing

Continued



en1200000239

Weld process timing for software equalizing with servo guns

The following graphic shows the weld process timing for a servo gun when software equalizing is activated, and where in the sequence the user hooks will be executed and affect the internal behavior.

If welding is done with several guns at the same times then each process is handled in separate tasks independent of each other.

The system parameter `Post_sync_time` (*Post-synchronization Time*) in the topic *Motion*, type *SG Process*, defines the predicted release time of the next robot movement after a weld. Can be used to shorten the cycle time, the robot will start to move before the gun is completely opened. Default value is 0. See System Parameters, Topic Motion and Type SG Process *Technical reference manual - System parameters*



Note


If *Soft Equalizing* is activated the Spot Gun Equipment process data parameters Gun pre closing time and Gun pre equalizing time are not used. The preclosing of the gun is in this case handled automatically, see [Software Equalizing on page 197](#).



Note

The value of this parameter (*Post-synchronization Time*) can affect the cycle time of the program negatively if for example two welding points are programmed at the same position. To minimize this risk the value can be increased. See *Application manual - Additional axes and standalone controller*.

Continues on next page



en120000237

4 Programming

4.8 Process data access

4.8 Process data access

General

If the additional Spot option Process data access is included when creating a spot system, some data from the weld process sequence and the status of the current ongoing weld will be stored in an internal data record and a log file when running spot welding instructions. The log file contains various information related to the process, e.g. target id, spot id, gun force, process ok/not ok etc.

The log file and data record will always be updated regardless of situation, weld completed, an error situation or if the spot instruction is aborted and skipped for some reason.

Prerequisites

Process data access is only available if the RobotWare option *Spot Welding (635-6)* is installed.

Function overview

After executing a spot instruction it is also possible to retrieve the last weld information by using the instruction *SwGetLastProclInfo*, see [SwGetCurrProclInfo - Get the latest process data for a spot instruction on page 180](#).

The size of the log file can be configured if needed, see [The Spot System instance on page 27](#).



Note

The content of the log file and data record may be changed and/or expanded in later software releases.

4.9 Miscellaneous information

4.9.1 Jogging the robot after unintentional servo gun disconnection

Servo gun disconnection

If the motor cables are unintentional disconnected when the servo gun is activated, the servo gun must be deactivated in order to jog the robot to a service position. Deactivation is done in the **Jogging** window by selecting axis and tapping **Deactivate**. After service or repair the revolution counter must be updated since the position has been lost.

For more information, see [Recover from accidental servo gun disconnection on page 237](#).

4 Programming

4.9.2 Tip dressing for servo guns

4.9.2 Tip dressing for servo guns

Tip dressing for servo guns

The `gundata` contains counters and tip wear information for each used gun. The counters will be automatically incremented for each spot and the tip wear information is updated after each gun calibration. This information can be used to decide when to do next tip dressing or tip exchange.

For more information see [gundata - Equipment specific weld data on page 152](#) and [Tip management on page 242](#).

4.9.3 Pneumatic spot welding gun and gripper

Pneumatic spot welding gun and gripper

When the robot has a pneumatic spot welding gun and a gripper, with or without a tool changer, it takes some special arrangements to control the clamps on the gripper. The reason is that the air pressure valve on the Media Panel is controlled by the weld timer, which uses the valve to obtain different gun forces. The weld timer is in control of the air pressure valve, even when the robot is holding the gripper.

Preparing control of the clamps

Use this procedure to prepare control of the clamps on the gripper:

- 1 In the weld timer, create weld programs for the desired pressures for gripper control.



Note

The weld current **MUST** be deactivated in the programs.

- 2 In the RAPID code, create the necessary control routines, and include `SetGO` instructions that sets the group output to the program number to the corresponding program in the weld timer.



Note

The `gX_new_prog` signal must be on at all times for the air pressure valve to follow immediately a new program number.

4 Programming

4.10 Supervision task SW_SUP

4.10 Supervision task SW_SUP

Description

In spot options, there is a separate semistatic monitoring task that runs in the background, `SW_SUP`. This task is selected by default when building a spot system in *Installation Manager* and can be deselected if a supervision task is not needed, e.g. if the supervision is handled by external equipment.

The `SW_SUP` task is handling the built in water supervision. There are some different configuration possibilities regarding the behaviour of the water supervision, see [The Spot Media Equipment instance on page 46](#).

In the `SWUSER` module there is a routine that is called from `SW_SUP` task, `SupervisionInit`, here it is possible to add custom functionality / monitoring to be run independently of program execution in motion task. No default functionality, [Supervision task hook on page 192](#).

5 RAPID references

5.1 Instructions

5.1.1 SpotL/SpotJ - The basic spot welding instructions

Descriptions

`SpotL` and `SpotJ` are used in spot welding when welding with one gun or several guns in sequence. The instructions are used to control the complete welding sequences, that is, the motion, gun closure/opening, and the welding process. `SpotL` moves the TCP linearly to the weld position and then activates the weld process. `SpotJ` moves the TCP non-linearly to the weld position before the weld process is activated.

- `SpotL` moves the TCP linearly to the weld position.
- `SpotJ` moves the TCP non-linearly to the weld position.

These instructions can only be used in the Main task or, if in a MultiMove system, in Motion tasks.

Example

```
SpotL p100, vmax, gun1, spot10, tool1;
```

This instruction can be used to implement a complete welding operation with one gun equipment.

- The TCP for `tool1` is moved on a linear path to the position `p100` with the speed given in `vmax`.
- The weld position is always a stop position since the welding is always performed while the robot is standing still.
- The gun is closed in advance when the robot is moved¹.
- The weld process is started and supervised until finished and the gun is reopened.
- The parameter `spot10` is a data of type *spotdata* containing spot weld specific parameters for the spot in `p100`, for example desired weld timer program number and gun force.
- The parameter `gun1` is an index number corresponding to the used gun equipment. This index number points at the corresponding `gundata` array index in `curr_gundata` in SWUSER and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

¹ May differ depending on configuration.

Arguments

```
SpotL ToPoint Speed GunNo [\GunD] Spot [\InPos] [\OpenHLift] [\CloseHLift]
[\QuickRelease] [\SMEQ | Search] Tool [\WObj] [\TLoad]
```

Continues on next page

5 RAPID references

5.1.1 SpotL/SpotJ - The basic spot welding instructions

Continued

SpotJ ToPoint Speed GunNo [\GunD] Spot [\InPos] [\OpenHLift] [\CloseHLift]
[\QuickRelease] [\SMEQ | Search] Tool [\WObj] [\TLoad]

ToPoint

Data type: robtarget

The destination point of the robot and additional axes. It is defined as a named position or stored directly in the instruction (marked with an * in the instruction).

Speed

Data type: speeddata

The speed data that applies to movements. Speed data defines the velocity for the tool center point, the tool reorientation and additional axes.

GunNo

Data type: num

Used gun equipment index number. This index number points at the corresponding `gundata` array index in `curr_gundata` in SWUSER and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

[\GunD]

Data type: gundata

Used gun equipment data for the process, see [gundata - Equipment specific weld data on page 152](#).

Can be used if external `gundata` is required. If used the external `gundata` will be temporary stored in the `curr_gundata` array during the process.

Spot

Data type: spotdata

Spot specific data for the weld process, weld program number, gun force etc, see [spotdata - Spot weld data on page 157](#)

[\InPos]

Data type: switch

The optional argument `\InPos` inhibits the preclosing of the gun. The gun is closed first when the robot has reached the end position. This argument will increase the execution time but is useful in narrow situations. This switch will not affect the execution when software equalizing is active.

[\OpenHLift]

Data type: switch

The optional argument `\OpenHLift` will set the gun to its large gap after the weld. If the argument is omitted the gun opens to its small gap (work stroke). If the instruction is executed backwards the gun opens to the large position before the motion. (Only valid for pneumatic guns).

[\CloseHLift]

Data type: switch

Continues on next page

The optional argument `\CloseHLift` will set the gun to its small gap (work stroke) before closing the gun. If the instruction is executed backwards the gun opens to the large position after the motion. (Only valid for pneumatic guns).

[`\QuickRelease`]

Data type: switch

The optional argument `\QuickRelease` will skip the release movement after the weld if software equalizing is activated. Can be used to save cycle time.

[`\SMEQ`]

Data type: smeqdata (SoftMove Equalizing data)

If the optional data `\SMEQ` is used the robot will be set into a soft state in the tool z direction during the approach movement to the position.

This method can be used as a complement to the standard software equalizing method if the tolerances of the parts to be welded are less exact.

For more information, see [SoftMove Equalizing on page 219](#).



Note

The SoftMove functionality is only available if the options *Spot Servo Equalizing (635-6)* and *SoftMove (885-1)* are installed together.

[`|Search`]

Data type: searchdata (Search data)

If the optional data `|Search` is used the external axis for the gun will be used to search for the plates, and the robot TCP will be **adjusted** in the tool z-direction based on the search hit distance.

This method can be used as a complement to the standard software equalizing method if the tolerances of the parts to be welded are less exact.

For more information see [Movable gun arm search mode on page 215](#) and [searchdata - Search data on page 169](#).



Note

The search functionality is only available if the additional spot option *Movable gun arm search (1583-1)* is present.



Note

The search functionality has to be tuned for the used gun, see *Application manual - Servo Gun Setup*.

Tool

Data type: tooldata

The tool in use when the robot moves. The tool center point is the point moved to the specified destination position, and should be the position for the electrode tips when the gun is closed.

Continues on next page

5 RAPID references

5.1.1 SpotL/SpotJ - The basic spot welding instructions

Continued

`[\WObj]`

Data type: wobjdata

The work object (coordinate system) to which the robot position in the instruction is related.

This argument can be omitted, and if it is, the position is related to the world coordinate system. If, on the other hand, a stationary TCP or coordinated additional axes are used, this argument must be specified in order to perform a linear movement relative to the work object.

`[\TLoad]`

Data type: loaddata

The `\TLoad` argument describes the total load used in the movement. The total load is the tool load together with the payload that the tool is carrying. If the `\TLoad` argument is used, then the loaddata in the current tooldata is not considered.

If the `\TLoad` argument is set to `load0`, then the `\TLoad` argument is not considered and the loaddata in the current tooldata is used instead. For a complete description of the `\TLoad` argument, see `MoveL`.

Communication

SpotL/J instructions communicates with the surrounding weld equipment using a standard I/O interface with digital signals.

For a complete description of the I/O configuration, see [Spot I/O configuration on page 51](#).

Program execution

For a complete description of the program execution sequence and error handling in the SpotL/J instruction, see [Process sequence and error handling on page 86](#).

Limitations



Note

It is not possible use independent gun mode when Software Equalizing is active. This will cause an error message. For more information, see [IndGunMove - Activates independent mode for a servo gun on page 145](#).



Note

It is only possible to run this instruction in semi coordinated mode.



Note

The `\QuickRelease` function is suitable to use if weld positions are located close to each other, not when there is a large distance between weld positions.

Continues on next page

**Note**

SpotL/SpotJ cannot be executed in an UNDO handler or RAPID routine connected to any of the following special system events: PowerOn, Stop, QStop, Restart, Reset or Step.

Syntax

```
SpotL or SpotJ
[ ToPoint ':=' ] < expression (IN) of robtarget > ', '
[ Speed ':=' ] < expression (IN) of speeddata > ', '
[ GunNo ':=' ] < expression (IN) of num >
[ '\ ' GunD ':=' ] < persistent(PERS) of gundata > ] ', '
[ Spot ':=' ] < persistent (PERS) of spotdata >
[ '\ ' InPos ]
[ '\ ' OpenHLift ]
[ '\ ' CloseHLift ]
[ '\ ' QuickRelease ]
[ '| ' Search ':=' ] < persistent(PERS) of searchdata > ] ', '
[ Tool ':=' ] < persistent (PERS) of tooldata > ]
[ '\ ' WObj ':=' ] < persistent (PERS) of wobjdata > ]
[ '\ ' TLoad ':=' ] < persistent (PERS) of loaddata > ] ';'

```

Related information

| | Described in: |
|--------------------------------------|--|
| Definition of velocity, speeddata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of zone data, zonedata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of tool, tooldata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of work objects, wobjdata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| MoveL | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of load data, loaddata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of spot data, spotdata | spotdata - Spot weld data on page 157 |
| Definition of gun data, gundata | gundata - Equipment specific weld data on page 152 |
| SpotML/MJ | SpotML/SpotMJ - Spot welding with multiple guns on page 113 |
| Overview Spot options | Spot option and features on page 17 |
| Customizing possibilities | Customizing RobotWare-Spot on page 279 |
| I/O configuration | Spot I/O configuration on page 51 |
| Servo gun introduction | Servo gun motion control on page 229 |
| Servo gun motion parameters | <i>Application manual - Additional axes and standalone controller</i> |

Continues on next page

5 RAPID references

5.1.1 SpotL/SpotJ - The basic spot welding instructions

Continued

| | Described in: |
|------------------------|---|
| Motion in general | <i>Technical reference manual - RAPID Overview</i> |
| Software Equalizing | Software Equalizing on page 197 |
| Movable gun arm search | Movable gun arm search mode on page 215 |

5.1.2 SpotML/SpotMJ - Spot welding with multiple guns

Description

`SpotML` and `SpotMJ` can be used in spot welding if welding with several guns at the same time is desired. The instructions are used to control the complete welding sequences, that is, the motion, gun closure/opening, and the welding process.

For servo guns it is possible to use two guns simultaneously and for pneumatic guns it is possible to use four guns at the same time. The instructions are used to control the complete welding sequences that is. the motion, gun closure/opening and the welding processes.

- `SpotML` moves the TCP linearly to the weld position.
- `SpotMJ` moves the TCP non-linearly to the weld position.

These instructions can only be used in the Main task or, if in a MultiMove system, in Motion tasks.

Example

```
SpotML p100, vmax \G1:=spot10 \G2:=spot20, tool1;
```

This instruction can be used to implement a complete welding operation with two gun equipment's.

- The TCP for `tool1` is moved on a linear path to the position `p100` with the speed given in `vmax`. The weld position is always a stop position since the welding is always performed while the robot is standing still. The guns are closed in advance when the robot is moved. The weld processes are started and supervised until finished and the guns are reopened.
- The optional arguments `\G1` and `\G2` will use gun equipment 1 and gun equipment 2. The parameter `spot10` is a data of type `spotdata` containing weld parameters for the welding with gun equipment 1, for example desired weld timer program number and gun pressure. The parameter `spot20` contains weld parameters for the welding with gun equipment 2.

The parameters `G1` and `G2` serves also as index numbers corresponding to the used gun equipment's. The index numbers points at the corresponding `gundata` array indexes in `curr_gundata` in SWUSER and the equipment instances in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

Arguments

`SpotML ToPoint Speed [\G1] [\G2] [\G3] [\G4] [\Gun1] [\Gun2] [\Gun3] [\Gun4] [\InPos] [\OpenHLift] [\CloseHLift] Tool [\WObj] [\TLoad]`

`SpotMJ ToPoint Speed [\G1] [\G2] [\G3] [\G4] [\Gun1] [\Gun2] [\Gun3] [\Gun4] [\InPos] [\OpenHLift] [\CloseHLift] Tool [\WObj] [\TLoad]`

ToPoint

Data type: `robtargt`

Continues on next page

5 RAPID references

5.1.2 SpotML/SpotMJ - Spot welding with multiple guns

Continued

The destination point of the robot and additional axes. It is defined as a named position or stored directly in the instruction (marked with an * in the instruction). This name will be stored in the log if a error occurs during the welding.

Speed

Data type: speeddata

The speed data that applies to movements. Speed data defines the velocity for the tool center point, the tool reorientation and additional axes.

[G1] - [G4]

Data type: spotdata for gun equipment 1 - 4

Spot data with the spot specific data associated with the weld with gun equipment 1 - 4, see [spotdata - Spot weld data on page 157](#) and [gundata - Equipment specific weld data on page 152](#). The parameter serves also as index numbers corresponding to the used gun equipment's. The index numbers points at the corresponding gundata array indexes in `curr_gundata` in SWUSER and the equipment instances in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

[\Gun1] - [\Gun4]

Data type: gundata

Used gun equipment data for the process, see [gundata - Equipment specific weld data on page 152](#).

Can be used if external gundata is required. If used the external gundata will be temporary stored in the `curr_gundata` array during the process.

[\InPos]

Data type: switch

The optional argument \InPos inhibits the preclosing of the guns. The guns are closed first when the robot has reached the end position. This argument will increase the execution time but is useful in narrow situations.

[\OpenHLift]

Data type: switch

The optional argument \OpenHLift will set the guns to its large gap after the weld. If the argument is omitted the guns opens to its small gap (work stroke). If the instruction is executed backwards the guns opens to the large position before the motion. (Only valid for pneumatic guns).

[\CloseHLift]

Data type: switch

The optional argument \CloseHLift will set the guns to its small gap (work stroke) before closing the guns. If the instruction is executed backwards the guns opens to the large position after the motion. (Only valid for pneumatic guns).

Tool

Data type: tooldata

Continues on next page

The tool in use when the robot moves. The tool center point is the point moved to the specified destination position, and should be the position for the electrode tips when the gun is closed.

[\Wobj]

Data type: wobjdata

The work object (coordinate system) to which the robot position in the instruction is related.

This argument can be omitted, and if it is, the position is related to the world coordinate system. If, on the other hand, a stationary TCP or coordinated additional axes are used, this argument must be specified in order to perform a linear movement relative to the work object.

[\TLoad]

Data type: loaddata

The \TLoad argument describes the total load used in the movement. The total load is the tool load together with the payload that the tool is carrying. If the \TLoad argument is used, then the loaddata in the current tooldata is not considered.

If the \TLoad argument is set to load0, then the \TLoad argument is not considered and the loaddata in the current tooldata is used instead. For a complete description of the \TLoad argument, see [MoveL](#).

Communication

SpotML/MJ instructions communicates with the surrounding weld equipment using a standard I/O interface with digital signals.

For a complete description of the I/O configuration, see [Spot I/O configuration on page 51](#).

Program execution

For a complete description of the program execution sequence and error handling in the SpotML/MJ instruction, see [Process sequence and error handling on page 86](#).

Limitations

SpotML/SpotMJ cannot be executed in an UNDO handler or RAPID routine connected to any of the following special system events: PowerOn, Stop, QStop, Restart, Reset or Step.

This instruction will not be installed if a *Weld Timer Configuration* option is selected when building a spot system in RobotStudio. In this case only a minimal installation of spot will be done with predefined signals for one weld equipment only.



Note

It is not possible to use Software Equalizing mode for this instruction, SpotML/SpotMJ.

For more information, see [Software Equalizing on page 197](#).

Continues on next page

5 RAPID references

5.1.2 SpotML/SpotMJ - Spot welding with multiple guns

Continued



Note

It is only possible to run this instruction in semi coordinated mode.

Syntax

```
SpotML or SpotMJ
[ ToPoint ':=' ] < expression (IN) of robtarget > ','
[ Speed ':=' ] < expression (IN) of speeddata > ','
[ '\ G1 ':=' < persistent (PERS) of spotdata > ]
[ '\ G2 ':=' < persistent (PERS) of spotdata > ]
[ '\ G3 ':=' < persistent (PERS) of spotdata > ]
[ '\ G4 ':=' < persistent (PERS) of spotdata > ]
[ '\ Gun1 ':=' < persistent (PERS) of gundata > ]
[ '\ Gun2 ':=' < persistent (PERS) of gundata > ]
[ '\ Gun3 ':=' < persistent (PERS) of gundata > ]
[ '\ Gun4 ':=' < persistent (PERS) of gundata > ]
[ '\ InPos ]
[ '\ OpenHLift ]
[ '\ CloseHLift ]','
[ Tool ':=' ] < persistent (PERS) of tooldata > ]
[ '\ WObj ':=' < persistent (PERS) of wobjdata > ]
[ '\ TLoad':=' ] < persistent (PERS) of loaddata > ] ';'

```

Related information

| | Described in: |
|--------------------------------------|--|
| Definition of velocity, speeddata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of zone data, zonedata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of tool, tooldata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of work objects, wobjdata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| MoveL | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of load data, loaddata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of spot data, spotdata | spotdata - Spot weld data on page 157 |
| Definition of gun data, gundata | gundata - Equipment specific weld data on page 152 |
| SpotL/J | SpotL/SpotJ - The basic spot welding instructions on page 107 |
| Overview Spot options | Spot option and features on page 17 |
| Customizing possibilities | Customizing RobotWare-Spot on page 279 |
| I/O configuration | Spot I/O configuration on page 51 |
| Servo gun introduction | Servo gun motion control on page 229 |

Continues on next page

| | Described in: |
|-----------------------------|---|
| Servo gun motion parameters | <i>Application manual - Additional axes and standalone controller</i> |
| Motion in general | <i>Technical reference manual - RAPID Overview</i> |

5 RAPID references

5.1.3 SetForce - Close and Open a gun with desired force and time

5.1.3 SetForce - Close and Open a gun with desired force and time

Description

`SetForce` is used in spot welding to close the gun and apply a predefined force during a desired time without activating a weld process. The gun will open again after the elapsed time or when a digital input signal is set. This instruction can for example be used for tip dressing.

Example

```
SetForce gun1, force10;
```

`Forcedata force10` contains the parameters for the `SetForce` action, for example desired tip force and force time.

The parameter `gun1` is an index number corresponding to the used gun equipment. This index number points at the corresponding `gundata` array index in `curr_gundata` in `SWUSER` and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

Arguments

`SetForce GunNo [\GunD] Force [\RetThickness] [\PrePos] [\CloseSpeed] [\OpenHLift] [\CloseHLift]`

`GunNo`

Data type: num

Used gun number. This index number points at the corresponding `gundata` array index in `curr_gundata` in `SWUSER` and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

`[\GunD]`

Data type: gundata

Optional parameter. Used gun equipment data for the process, see [gundata - Equipment specific weld data on page 152](#).

Can be used if external `gundata` is required. If used the external `gundata` will be temporary stored in the `curr_gundata` array during the process.

`Force`

Data type: forcedata

The forcedata with the force parameters. See [forcedata - Spot gun force data on page 161](#).

`[\RetThickness]`

(returned thickness)

Data type: num

Continues on next page

Optional parameter. The achieved thickness [mm] (servo guns only).

**Note**

If the system has been reset (**Reset system**) the calibration position is not known anymore and a new gun init calibration needs to be performed in order to find a new zero position.

[\IndPos]

(independent pre-position)

Data type: num

Optional parameter. The desired independent pre-position when the specified gun speed should be used [mm]. (servo guns only).

[\GunSpeed]

(gun speed)

Data type: num

Optional parameter. The desired gun speed that shall be used from the specified independent pre-position [%]. (servo guns only). This parameter can be used to get a better performance when e.g. tip dressing by reducing the gun speed.

If an independent pre-position is not used the gun speed will be reduced from the actual start position.

[\OpenHLift]

Data type: switch

The optional argument \OpenHLift will set the gun to its large gap after the instruction. If the argument is omitted the gun opens to its small gap (work stroke). If the instruction is executed backwards the gun opens to the large position before the motion. (Only valid for pneumatic guns).

[\CloseHLift]

Data type: switch

The optional argument \CloseHLift will set the gun to its small gap (work stroke) before closing the gun. If the instruction is executed backwards the gun opens to the large position. (Only valid for pneumatic guns).

Program execution

Internal sequence when a SetForce instruction is executed:

- 1 The gun is closed to the specified thickness in the used *forcedata*. If **pre-position** is used \IndPos, gun will be set to independent mode internally, and the closing speed will be reduced from the independent position according to the specified value in \GunSpeed.
- 2 The plate thickness is checked (servo guns only).
- 3 The requested gun force is established.
- 4 Wait until the desired force time elapsed or the force complete signal is activated.

Continues on next page

5 RAPID references

5.1.3 SetForce - Close and Open a gun with desired force and time

Continued

- 5 If configured, the second gun force in the used `forcedata` is established, see [forcedata - Spot gun force data on page 161](#).
- 6 If configured, wait until the second force time has elapsed or the force complete signal is activated.
- 7 The gun is opened to the previous position. If an independent **pre-position** is used, the opening speed will be reduced to the independent position according to the specified value in `\GunSpeed` and the independent mode will be reset.

The force complete signal for each used gun is predefined in the I/O configuration. For a complete description of the I/O configuration, see [Spot I/O configuration on page 51](#).

Error handling

Instruction parameter supervision

The error occurs when `SetForce` is called with faulty parameters. The program stops.

The parameter must be changed. When the program is restarted the current instruction is restarted from the beginning.

Detection of missing or improper plates (Only for servo guns)

An error will be detected by the process kernel if the plate thickness differ more than the allowed limit defined by the tolerance from the programmed thickness.

There are three different types of errors:

- Negative gun position, one of the tips are missing on the gun, or a `tip_wear` calibration is needed.
- Missing plates, the plate thickness is smaller than the thickness defined in `forcedata`.
- Improper geometry, the plate thickness exceeds the tolerance defined in `forcedata`.

- 1 The gun opens.
- 2 The `process fault` signal for the current equipment is set. The program stops.
- 3 An error message is displayed in a dialog box with retry possibilities.
- 4 The error message is logged.

Continues on next page

5.1.3 SetForce - Close and Open a gun with desired force and time

Continued

xx120000217

| | |
|--------|---|
| Ignore | Close the gun again but without thickness detection and continue the execution. |
| Retry | Start the interrupted process from the beginning. |

If the error is of the type improper geometry there is a possibility to do a retry with a higher force on the gun and complete the instruction, that is. when the plates are not properly fixed together.

xx120000216



Note

The accuracy of the thickness supervision is highly dependent of good gun tuning and correct mechanical data, e.g. *Transmission Gear Ratio*. It is also recommended to use a small value in *Close Position Adjust*.

Continues on next page

5 RAPID references

5.1.3 SetForce - Close and Open a gun with desired force and time

Continued



Note

If the system has been reset (**Reset system**) the calibrated zero position of the gun is not known anymore and a new gun initialization calibration has to be performed in order to find a new zero position. The value -1000 will be returned instead of the measured thickness and an error will be raised.

Limitations

If the `\IndPos` argument is used the gun will be set to an independent position. If the instruction is aborted and the program pointer is moved, or an error occur while the independent mode is active, the independent mode will be cleared depending on if the system is in motors on state or not. If motors off state independent mode will be cleared at the next start or restart.

Independent mode will cleared in the following situations:

Stop / QStop / Start / ReStart or program pointer moved:

- If motors on state: Independent mode will be cleared.
- If motors off state: Independent mode will **not** be cleared.

For more information about independent gun mode, see [IndGunMove - Activates independent mode for a servo gun on page 145](#) and [IndGunMoveReset - Resets servo gun from independent mode on page 147](#).

Syntax

```
SetForce
[ GunNo ':=' ] < expression (IN) of num >
[ '\ GunD ':=' ] < persistent(PERS) of gundata > ] ','
[ Force ':=' ] < persistent (PERS) of forcedata >
[ '\ RetThickness ':=' < variable or persistent(INOUT) of num
> ]
[ '\ IndPos ':=' < expression (IN) of num > ]
[ '\ GunSpeed ':=' < expression (IN) of num > ]
[ '\ OpenHLift ]
[ '\ CloseHLift ]
[ '\ NoEqualize ]';'

SetForce
[ GunNo ':=' ] < expression (IN) of num >
[ '\ GunD ':=' ] < persistent(PERS) of gundata > ] ','
[ Force ':=' ] < persistent (PERS) of forcedata >
[ '\ RetThickness ':=' < variable or persistent(INOUT) of num
> ]
[ '\ IndPos ':=' < expression (IN) of num > ]
[ '\ GunSpeed ':=' < expression (IN) of num > ]
[ '\ OpenHLift ]
[ '\ CloseHLift ]';'
```

5.1.4 CalibL/CalibJ - Calibrate a servo gun during robot movement

Description

CalibL/J is used in spot welding to calibrate the distance between the gun tips for servo guns. This is necessary after tip change or tool change and it is recommended after welding of a number of spots or performing a tip dress. Calibrate will also update the tip wear data in the used `gundata`. The calibration is done during a robot movement to a programmed position.

NB: The gun performs two non-synchronized close/open movements during the calibration.

If the option `Spot Servo Equalizing` is installed there are additional error handling included for lost tips when a **tip change** calibration is done and supervision of the tip wear when a **tip wear** calibration is done.

This instruction can only be used in the main task `T_ROB1` or, if in a MultiMove system, in Motion tasks.

Example

```
CalibL p400, v500, gun1\ TipWear, fine, tool1;
```

- The gun `gun1` is calibrated for tip wear during the linear movement to `p400`.
- The parameter `gun1` is an index number corresponding to the used gun equipment. This index number points at the corresponding `gundata` array index in `curr_gundata` in SWUSER and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).
- The data `curr_tip_wear` in `curr_gundata` will be automatically updated.

For more information about tip management, see [Tip management on page 242](#).

Arguments

CalibL ToPoint Speed GunNo [\GunD] [\TipChg] | [\ToolChg] | [\TipWear] [\RetTipWear] [\RetPosAdj] [\PrePos] [\TWeld], Zone Tool [\WObj] [\TLoad]
 CalibJ ToPoint Speed GunNo [\GunD] [\TipChg] | [\ToolChg] | [\TipWear] [\RetTipWear] [\RetPosAdj] [\PrePos] [\TWeld], Zone Tool [\WObj] [\TLoad]

ToPoint

Data type: `robtarget`

The destination point of the robot and additional axes. It is defined as a named position or stored directly in the instruction (marked with an * in the instruction). A movement of the gun tip position can not be programmed. This will cause an error message.

Speed

Data type: `speeddata`

The speed data that applies to movements. Speed data defines the velocity for the tool center point, the tool reorientation and additional axes.

Continues on next page

5 RAPID references

5.1.4 CalibL/CalibJ - Calibrate a servo gun during robot movement

Continued

GunNo

Data type: num

Used gun equipment number. This index number points at the corresponding `gundata` array index in `curr_gundata` in SWUSER and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

[\GunD]

Data type: gundata

Used gun equipment data for the process, see [gundata - Equipment specific weld data on page 152](#).

Can be used if external `gundata` is required. If used the external `gundata` will be temporary stored in the `curr_gundata` array during the process.

[\TipChg]

(tip change calibration)

Data type: switch

Calibration type. This calibration type is used after tip change.

The gun will close and open two times. The first close movement will be slow to find the unknown contact position. The total tip wear is reset to zero.

If Software equalizing is used the difference since last calibration will be supervised. If the difference since the last calibration exceeds the supervision value in the `Tip change supervision value` an error will be raised. See [The Spot Gun Equipment instance on page 39](#).

For more information about tip management, see [Tip management on page 242](#), [Tip wear compensation on page 209](#), [MeasureWearL - Measure current electrode wear and recalculate the TCP on page 133](#) or the [ReCalcTCP - Calculate current electrode wear and recalculate the TCP on page 141](#).

[\ToolChg]

(tool change calibration)

Data type: switch

Calibration type. This calibration type is used after tool change, see [Servo tool change on page 245](#).

The gun will close and open two times. The first close movement will be slow to find the unknown contact position. The total tip wear will remain unchanged.

[\TipWear]

(tip wear calibration)

Data type: switch

Calibration type. This calibration type is used to update the tip wear and adjust the contact position after tip dress or after welding a number of spots.

The gun will close and open fast two times. The total tip wear is updated.

If Software equalizing is used the difference since last calibration will be supervised. If the difference since the last calibration exceeds the supervision value in the `Tip`

Continues on next page

wear supervision value an error will be raised. See [The Spot Gun Equipment instance on page 39](#).

For more information about tip management, see [Tip management on page 242](#), [Tip wear compensation on page 209](#), [MeasureWearL - Measure current electrode wear and recalculate the TCP on page 133](#) or the [ReCalcTCP - Calculate current electrode wear and recalculate the TCP on page 141](#).

`[\RetTipWear]`

Data type: num

The achieved tip wear [mm].

`[\RetPosAdj]`

Data type: num

The positional adjustment since the last calibration [mm].

`[\PrePos]`

(pre position)

Data type: num

The position to move with high speed to before search for contact position with slower speed is started [mm].

`[\TWeld]`

(test weld)

Data type: spotdata

If selected, a weld with the specified parameters will be performed after the calibration and during the robot movement.

A weld can be done after tip dressing to check the tips, and to save cycle time the test weld argument can be used instead of adding an extra `SpotL` instruction after the calibration.

Zone

Data type: zonedata

Zone data for the movement. Zone data describes the size of the generated corner path.

Tool

Data type: tooldata

The tool in use when the robot moves. The tool center point is the point moved to the specified destination position, and should be the position for the electrode tips when the gun is closed.

`[\WObj]`

Data type: wobjdata

The work object (coordinate system) to which the robot position in the instruction is related.

This argument can be omitted, and if it is, the position is related to the world coordinate system. If, on the other hand, a stationary TCP or coordinated additional

Continues on next page

5 RAPID references

5.1.4 CalibL/CalibJ - Calibrate a servo gun during robot movement

Continued

axes are used, this argument must be specified in order to perform a linear movement relative to the work object.

[\TLoad]

Data type: loaddata

The \TLoad argument describes the total load used in the movement. The total load is the tool load together with the payload that the tool is carrying. If the \TLoad argument is used, then the loaddata in the current tooldata is not considered.

If the \TLoad argument is set to load0, then the \TLoad argument is not considered and the loaddata in the current tooldata is used instead. For a complete description of the \TLoad argument, see MoveL.

Program execution

Internal sequence when a CalibL/J instruction is executed:

- The robot starts the movement to the destination position.
- The gun will close and open two times during the robot movement. Different tip speeds depending on selected calibration type.
- If the \TWeld is selected a test weld with the specified data will be done.
- The gun is opened to the previous position.
- For certain calibration types: curr_tip_wear in the array curr_gundata in SWUSER is updated and saved.

Positional adjustment

The optional argument RetPosAdj can be used to detect if for example the tips are lost after a tip change. The parameter will hold the value of the positional adjustment since the last calibration. The value can be negative or positive.

If Software equalizing is used this value will be used to calculate the difference since last calibration and supervise the tips when calibrating.

Using a pre position

In order to speed up the calibration, it is possible to define a pre position. When the calibration starts, the gun arm will be run fast to the pre position, stop and then continue slowly forward in order to detect the tip contact position. A pre position will be ignored if it is larger than the current gun position (in order not to slow down the calibration).

Instruction by instruction execution

| | |
|-----------------------|--|
| Forward | As during continuous execution. |
| Backward | The motion is performed backwards to the programmed position, but no calibration is activated. NB, the tip distance in this case is the programmed value in the instruction. |
| Positional adjustment | The optional argument RetPosAdj can be used to detect if for example the tips are lost after a tip change. The parameter will hold the value of the positional adjustment since the last calibration. The value can be negative or positive. If Software equalizing is used this value will be used to calculate the difference since last calibration and supervise the tips when calibrating. |

Continues on next page

| | |
|----------------------|--|
| Using a pre position | In order to speed up the calibration, it is possible to define a pre position. When the calibration starts, the gun arm will be run fast to the pre position, stop and then continue slowly forward in order to detect the tip contact position. A pre position will be ignored if it is larger than the current gun position (in order not to slow down the calibration). |
|----------------------|--|

Error handling

Instruction parameter supervision

The error occurs when `CalibL/J` is called with faulty parameters or if no calibration type switch is programmed. The program stops with error text.

The parameter must be changed. When the program is restarted the current instruction is restarted from the beginning.

Tip change supervision

If the calculated difference to the last calibration of the gun exceeds the supervision value defined in the configuration data `Tip change supervision` value an error will be raised and the program execution will be stopped. This error can occur for example after tip change and when `CalibL/J ... \TipChg` is called with wrong (too large or too small tips) tips. The program stops with error message. See [The Spot Gun Equipment instance on page 39](#).

This error handling only exists for the `Spot Servo Equalizing` option. See [Additional components for Spot Servo Equalizing on page 153](#).

For more information about tip management, see [Tip management on page 242](#).

Tip wear supervision

If the calculated difference to the last calibration of the gun exceeds the supervision value defined in the configuration data `Tip wear supervision` value an error will be raised and the program execution will be stopped. This error can occur for example after tip dressing when `CalibL/J .. \TipWear` is called with badly dressed tips. The program stops with error message. See [The Spot Gun Equipment instance on page 39](#).

This error handling only exists for the `Spot Servo Equalizing` option. See [Additional components for Spot Servo Equalizing on page 153](#).

For more information about tip management, see [Tip management on page 242](#).

Test weld error

If a weld error occur during the robot movement it will be handled in the same way as a normal weld error, see [Weld error on page 94](#).

It is also possible to handle a weld error in the user defined error handling if needed, see [User defined error handling on page 96](#).

Limitations



Note

It is only possible to run this instruction from a motion task.

Continues on next page

5 RAPID references

5.1.4 CalibL/CalibJ - Calibrate a servo gun during robot movement

Continued



Note

It is only possible to run this instruction in semi coordinated mode.

Syntax

```
CalibL or CalibJ
[ ToPoint ':=' ] < expression (IN) of robtarget > ', '
[ Speed ':=' ] < expression (IN) of speeddata > ', '
[ GunNo ':=' ] < expression (IN) of num >
[ '\ ' GunD ':=' ] < persistent(PERS) of gundata > ]
[ \TipChg ] | [ \ToolChg ] | [ \TipWear ]
[ '\ ' RetTipWear ':=' < variable or persistent(INOUT) of num >
  ]
[ '\ ' RetPosAdj ':=' < variable or persistent(INOUT) of num > ]
[ '\ ' PrePos ':=' < variable or persistent(IN) of num > ]
[ '\ ' TWeld ':=' < persistent(IN) of spotdata > ] ', '
[ Zone ':=' ] < expression (IN) of zoneddata > ] ', '
[ Tool ':=' ] < persistent (PERS) of tooldata > ]
[ '\ ' WObj ':=' < persistent (PERS) of wobjdata > ]
[ '\ ' TLoad':=' ] < persistent (PERS) of loaddata > ] ';'

```

Related information

| | Described in: |
|--------------------------------------|--|
| Definition of velocity, speeddata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of zone data, zonedata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of tool, tooldata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of work objects, wobjdata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| MoveL | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of load data, loaddata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Overview Spot options | Spot option and features on page 17 |
| Servo gun introduction | Servo gun motion control on page 229 |
| Calibration without movement | Servo gun motion control on page 229 |
| Software Equalizing | Software Equalizing on page 197 |
| Setup data for Software Equalizing | The Spot SoftWare Equalizing instance on page 48 |

5.1.5 Calibrate - Calibrate a servo gun

Description

`Calibrate` is used in spot welding to calibrate the distance between the gun tips for servo guns. This is necessary after tip change or tool change and it is recommended after welding of a number of spots or performing a tip dress. `Calibrate` will also update the tip wear data in the used `gundata`. NB The gun performs two non-synchronized close/open movements during the calibration. The open distance after the calibration is finish will be the same as before the calibration started.

If the option `Spot Servo Equalizing` is installed there are additional error handling included for lost tips when a tip change calibration is done and supervision of the tip wear when a tip wear calibration is done.

Example

```
Calibrate gun1\ TipChange;
```

- The gun `gun1` is calibrated after tip change.
- The parameter `gun1` is an index number corresponding to the used gun equipment. This index number points at the corresponding `gundata` array index in `curr_gundata` in SWUSER and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).
- The data `curr_tip_wear` in `curr_gundata` will be automatically set to zero.

For more information about tip management, see [Tip management on page 242](#).

Arguments

Calibrate GunNo [`\GunD`] [`\TipChg`] | [`\ToolChg`] | [`\TipWear`] [`\RetTipWear`] | [`\RetPosAdj`] | [`\PrePos`]

GunNo

Data type: num

Used gun equipment number. This index number points at the corresponding `gundata` array index in `curr_gundata` in SWUSER and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

[`\GunD`]

Data type: `gundata`

Used gun equipment data for the process, see [gundata - Equipment specific weld data on page 152](#).

Can be used if external `gundata` is required. If used the external `gundata` will be temporary stored in the `curr_gundata` array during the process.

[`\TipChg`]

Data type: switch

Continues on next page

5 RAPID references

5.1.5 Calibrate - Calibrate a servo gun

Continued

Calibration type. This calibration type is used after tip change.

The gun will close and open two times. The first close movement will be slow to find the unknown contact position. The total tip wear is reset to zero.

If Software equalizing is used the difference since last calibration will be supervised. If the difference since the last calibration exceeds the supervision value in the `Tip change supervision value` an error will be raised. See [The Spot Gun Equipment instance on page 39](#).

For more information about tip management, see [Tip management on page 242](#), [Tip wear compensation on page 209](#), [MeasureWearL - Measure current electrode wear and recalculate the TCP on page 133](#) or the [ReCalcTCP - Calculate current electrode wear and recalculate the TCP on page 141](#).

`[\ToolChg]`

Data type: switch

Calibration type. This calibration type is used after tool change, see [Servo tool change on page 245](#).

The gun will close and open two times. The first close movement will be slow to find the unknown contact position. The total tip wear will remain unchanged.

`[\TipWear]`

Data type: switch

Calibration type. This calibration type is used to update the tip wear and adjust the contact position after tip dress or after welding a number of spots.

The gun will close and open fast two times. The total tip wear is updated.

If Software equalizing is used the difference since last calibration will be supervised. If the difference since the last calibration exceeds the supervision value in the `Tip wear supervision value` an error will be raised. See [The Spot Gun Equipment instance on page 39](#).

For more information about tip management, see [Tip management on page 242](#), [Tip wear compensation on page 209](#), [MeasureWearL - Measure current electrode wear and recalculate the TCP on page 133](#) or the [ReCalcTCP - Calculate current electrode wear and recalculate the TCP on page 141](#).

`[\RetTipWear]`

Data type: num

The achieved tip wear [mm].

`[\RetPosAdj]`

Data type: num

The positional adjustment since the last calibration [mm].

`[\PrePos]`

Data type: num

The position to move with high speed to before search for contact position with slower speed is started [mm].

Continues on next page

Program execution

Internal sequence when a Calibrate instruction is executed:

- The gun will close and open two times. Different tip speeds depending on selected calibration type.
- The gun is opened to the previous position.
- For certain calibration types: `curr_tip_wear` in the array `curr_gundata` in SWUSER is updated and saved.

Positional adjustment

The optional argument `RetPosAdj` can be used to detect if for example the tips are lost after a tip change. The parameter will hold the value of the positional adjustment since the last calibration. The value can be negative or positive.

If Software equalizing is used this value will be used to calculate the difference since last calibration and supervise the tips when calibrating.

Using a pre position

In order to speed up the calibration, it is possible to define a pre position. When the calibration starts, the gun arm will be run fast to the pre position, stop and then continue slowly forward in order to detect the tip contact position. A pre position will be ignored if it is larger than the current gun position (in order not to slow down the calibration).

Error handling

Instruction parameter supervision

The error occurs when `Calibrate` is called with faulty parameters or if no calibration type switch is programmed. The program stops with error text.

The parameter must be changed. When the program is restarted the current instruction is restarted from the beginning.

Tip change supervision

If the calculated difference to the last calibration of the gun exceeds the supervision value defined in the configuration data `Tip change supervision value` an error will be raised and the program execution will be stopped. This error can occur for example after tip change and when `Calibrate ... \TipChg` is called with wrong (too large or too small) tips. The program stops with error message. See [The Spot Gun Equipment instance on page 39](#).

This error handling only exists for the `Spot Servo Equalizing` option.

For more information about tip management, see [Tip management on page 242](#).

Tip wear supervision

If the calculated difference to the last calibration of the gun exceeds the supervision value defined in the configuration data `Tip wear supervision value` an error will be raised and the program execution will be stopped. This error can occur for example after tip dressing when `Calibrate ... \Tip-Wear` is called with badly dressed tips. The program stops with error message. See [The Spot Gun Equipment instance on page 39](#).

This error handling only exists for the `Spot Servo Equalizing` option.

Continues on next page

5 RAPID references

5.1.5 Calibrate - Calibrate a servo gun

Continued

For more information about tip management, see [Tip management on page 242](#).

Syntax

```
Calibrate
  [ GunNo ':=' ] < expression (IN) of num >
  [ '\ ' GunD ':=' ] < persistent(PERS) of gundata > ]
  [ \TipChg]
  | [ \ToolChg]
  | [ \TipWear]
  [ '\ ' RetTipWear ':=' < variable or persistent(INOUT) of num >
    ]
  [ '\ ' RetPosAdj ':=' < variable or persistent(INOUT) of num > ]
  [ '\ ' PrePos ':=' < variable or persistent(IN) of num > ] ';'

```

Related information

| | Described in: |
|------------------------------------|--|
| Overview <i>Spot Servo</i> | Spot option and features on page 17 |
| Servo gun introduction | Servo gun motion control on page 229 |
| Calibration with movement | Servo gun motion control on page 229 |
| Software Equalizing | Software Equalizing on page 197 |
| Setup data for Software Equalizing | The Spot SoftWare Equalizing instance on page 48 |

5.1.6 MeasureWearL - Measure current electrode wear and recalculate the TCP

Description

MeasureWearL is used in spot welding to measure current electrode wear for the tip on the fixed electrode. This can be done with or without external measurement equipment, and without manual interaction. The TCP is automatically recalculated after the measurement. The instruction also updates tip wear data in the used `gundata`.


When the gun is held by the robot the gun performs a search movement during the measurement. The gun is moving in the z-direction, in the tool coordinate system, until the fixed electrode touches a fixed reference plate or a sensor of some sort, e.g. *BullsEye*.

This instruction can be used also for stationary guns. In this case the robot moves the gripper and the work object until a reference position on the gripper is touching the tip on the fixed electrode. This instruction is only available if the `Spot Servo Equalizing` configuration is installed.

This instruction can only be used in the main task T_ROB1 or, if in a MultiMove system, in Motion tasks.

Example

In this example the gun is held by the robot. The principles are the same also when stationary guns are used.



xx120000206

| | |
|---|------------------|
| A | Fix plate |
| B | Search direction |

Continues on next page

5 RAPID references

5.1.6 MeasureWearL - Measure current electrode wear and recalculate the TCP

Continued

Measurement preparation

The measurement instruction is executed with a reference tip with an accurate TCP (tooldata in this example: `ref_tool1`). This reference measurement has to be done before the tip wear measuring is performed the first time. Also each time when the TCP for this gun is changed for some reason or if the reference plate or sensor is dislocated for some reason.

Running the instruction `Calibrate\TipChg` after the `MeasureWearL` will also reset the total wear of the tips `curr_tip_wear` in `curr_gundata` and check the difference since the last calibration.

Program example for reference measurement:

```
MoveJ p1,v1000,z50,ref_tool1;
MeasureWearL p2,v1000,gun1\Reference,ref_tool1;
tool1 := ref_tool1;
! tool1 is then used during the production
MoveL p1,v1000,z50,tool1;
Calibrate gun1\TipChg;
```

When the `MeasureWearL` instruction with the optional argument `\Reference` is executed, first a linear movement to a position about 10 mm outside `p2` is done. Then the gun is moved in the z direction in the tool coordinate system until the fixed tip touches the reference plate. During this reference measurement the reference plate is touched twice. When the measurement is ready some reference data is stored, `tw_ref_tool` and `tw_ref_dist` in `SWUSER`.

The parameter `gun1` is a `num` corresponding to the used gun equipment. All gun equipment used are defined in the `gundata` array `curr_gundata` in `SWUSER`.



Tip

To verify if the selected measuring position or gun orientation is good enough a service routine is available; `ManualCheckMeasPos`. Run this routine in the selected position and status information will be presented on the FlexPendant whether the position is suitable or not. See [Manual actions on page 84](#).

Measurement after tip wear

When it is time to compensate for current tip wear, probably after each tip dressing, the following instruction sequence should be executed:

Program example for tipwear measurement:

```
MoveJ p1,v1000,z50,tool1;
MeasureWearL p2,v1000,gun1\TipWear,tool1;
MoveL p1,v1000,z50,tool1;
Calibrate gun1\TipWear;
```

When the instruction with the optional argument `TipWear` is executed, a search movement to the reference plate or sensor is performed and the tip wear of the fixed electrode is measured. The TCP in the used tooldata `tool1` is then recalculated and the data `curr_wear_fix` in `curr_gundata` is automatically updated.

Continues on next page

5.1.6 MeasureWearL - Measure current electrode wear and recalculate the TCP

Continued

Running the instruction `Calibrate\TipWear` after the `MeasureWearL` will also update the total wear of the tips `curr_tip_wear` in `curr_gundata` and check the difference since the last calibration.

Measurement after tip change (with or without tip dressing)

In the first measurement after tip change a similar sequence can be used as after tip wear. In this case the optional argument `\TipChange` has to be used.

Program example for tip change measurement:

```
MoveJ p1,v1000,z50,tool1;
MeasureWearL p2,v1000,gun1\TipChange,tool1;
MoveL p1,v1000,z5,tool1;
Calibrate gun1\TipChg;
```

When the instruction with the optional argument `TipChange` is executed, similar movements as above are performed and the tip wear of the fixed electrode is measured. The TCP in the used tooldata `tool1` is then recalculated and the data `curr_wear_fix` in `curr_gundata` is automatically updated. This is the same functionality as after tip wear above. Only some extra error handling is done internally.

Running the instruction `Calibrate\TipChg` after the `MeasureWearL` will also reset the total wear of the tips `curr_tip_wear` in `curr_gundata` and check the difference since the last calibration. See [SWUSER on page 187](#)



Note

It is important that `p2` is the same position in all cases above. If this position is modified a new reference or reference changed measurement has to be done.

Measurement after reference plate/sensor changed

This mode can be used when the TCP for this gun is changed for some reason or if the reference plate or sensor is dislocated for some reason.

Program example for reference changed measurement:

```
MoveJ p1,v1000,z50,ref_tool1;
MeasureWearL p2,v1000,gun1\RefChange,ref_tool1;
MoveL p1,v1000,z50,tool1;
```

When the `MeasureWearL` instruction with the optional argument `\RefChange` is executed, first a linear movement to a position about 10 mm outside `p2` is done. Then the gun is moved in the z direction in the tool coordinate system until the fixed tip touches the reference plate. During this reference measurement the reference plate is touched twice. When the measurement is ready some reference data is stored, `tw_ref_dist` in the `SWUSER.SYS` module.

Continues on next page

5 RAPID references

5.1.6 MeasureWearL - Measure current electrode wear and recalculate the TCP

Continued

The parameter `gun1` is a `num` corresponding to the used gun equipment. All gun equipment used are defined in the `gundata` array `curr_gundata` in the `SWUSER.SYS` module. See [SWUSER on page 187](#).



Tip

To verify if the selected measuring position or gun orientation is good enough a service routine is available; `ManualCheckMeasPos`. Run this routine in the selected position and status information will be presented on the FlexPendant whether the position is suitable or not. See [Manual actions on page 84](#).

Arguments

`MeasureWearL ToPoint Speed GunNo [\GunD] [\Reference] | [\TipWear] | [\TipChange] | [\RefChange] [\SSearch], Tool [WObj] [TLoad]`

`ToPoint`

Data type: `robtarget`

The destination point for the robot and additional axes. This position should be a point close to the reference position, see figure in the example above. If this position is modified a new reference measurement has to be done.

`Speed`

Data type: `speeddata`

The speed data that applies to movements. Speed data defines the velocity for the tool center point, the tool reorientation and additional axes.

`GunNo`

Data type: `num`

Used gun equipment number. This index number points at the corresponding `gundata` array index in `curr_gundata` in `SWUSER` and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

`[\GunD]`

Data type: `gundata`

Used gun equipment data for the process, see [gundata - Equipment specific weld data on page 152](#).

Can be used if external `gundata` is required. If used the external `gundata` will be temporary stored in the `curr_gundata` array during the process.

`[\Reference]`

(reference measurement)

Data type: `switch`

Measurement type. This calibration type is used for the reference measurement with a reference tip with a well known TCP.

This measurement has to be done before the tip wear measuring is done the first time and each time when the TCP for this gun (with the reference tip mounted) is

Continues on next page

5.1.6 MeasureWearL - Measure current electrode wear and recalculate the TCP

Continued

changed. It has also to be done if the reference plate (or reference position when a stationary gun is used) is dislocated of any reason.

If the reference plate is moved the switch `\RefChange` can be used instead.

For more information about tip management, see [Tip wear compensation on page 209](#).

[`\TipWear`]

(tip wear measurement)

Data type: switch

Measurement type. This measurement type is used when it is time to compensate for current tip wear, probably after each tip dressing. The data `curr_wear_fix` in `curr_gundata` will be automatically updated and the TCP in the used `tooldata` is recalculated.

For more information about tip management, see [Tip management on page 242](#) and [Tip wear compensation on page 209](#).

[`\TipChange`]

(tip change measurement)

Data type: switch

Measurement type. This measurement type is used in the first measurement after tip change. The data `curr_wear_fix` in `curr_gundata` will be automatically updated and the TCP in the used `tooldata` is recalculated.

For more information about tip management, see [Tip management on page 242](#) and [Tip wear compensation on page 209](#).

[`\RefChange`]

(reference changed measurement)

Data type: switch

Measurement type. This calibration type is used if the reference plate (or reference position when a stationary gun is used) is dislocated of any reason.

The reference tool `tw_ref_tool` in `SWUSER` module will not be updated if this calibration type is used.

[`\SSearch`]

(signal/sensor search)

Data type: switch

Measurement method. If this switch is used, the search will be done against a sensor signal instead of a fixed reference surface.

The required I/O signal that should be used is defined in the process configuration, see [The Spot Gun Equipment instance on page 39](#).

Tool

Data type: `tooldata`

Continues on next page

5 RAPID references

5.1.6 MeasureWearL - Measure current electrode wear and recalculate the TCP

Continued

The tool in use when the robot moves. The tool center point (TCP) is the point moved to the specified destination position, and should for a spot weld gun be the position on the tip of the fixed electrode.



Note

The TCP is automatically recalculated and changed when the optional argument `\TipWear` or `\TipChange` is used.

[`\WObj`]

Data type: wobjdata

The work object (coordinate system) to which the robot position in the instruction is related.

This argument can be omitted, and if it is, the position is related to the world coordinate system. If, on the other hand, a stationary gun is used, this argument must be specified in order to perform a linear movement relative to the work object.

[`\TLoad`]

Data type: loaddata

The `\TLoad` argument describes the total load used in the movement. The total load is the tool load together with the payload that the tool is carrying. If the `\TLoad` argument is used, then the loaddata in the current tooldata is not considered.

If the `\TLoad` argument is set to `load0`, then the `\TLoad` argument is not considered and the loaddata in the current tooldata is used instead. For a complete description of the `TLoad` argument, see `MoveL`.

Program execution

Internal sequence when a `MeasureWearL` instruction is executed:

- 1 The robot starts the movement to the destination position.
- 2 When the destination position is reached the search movements to the reference position or sensor is started.
- 3 If using the reference position search method the fixed tip will touch the reference position with a predefined pressure, this force can be modified by changing the setup data `MeasureWearL TouchUp force` in the process configuration. See [The Spot SoftWare Equalizing instance on page 48](#).
- 4 If the optional argument `\Reference` is used: Some reference data is stored in the user module `swuser.sys`, `tw_ref_tool` and `tw_ref_dist`.
- 5 If the optional argument `\TipWear` or `\TipChange` is used: The TCP in the used tooldata is recalculated and the data `curr_wear_fix` in `curr_gundata` is updated.



Note

If `MeasureWearL` is executed in touchup mode and with the `\Reference` or `\RefChange` switch active the current position will be automatically checked if it's suitable for tip wear measurement or not.

Continues on next page

5.1.6 MeasureWearL - Measure current electrode wear and recalculate the TCP

Continued

Instruction by instruction execution

| | |
|----------|---|
| Forward | As during continuous execution. |
| Backward | The motion is performed backwards to the destination position, but no measurement is activated. |

Error handling

Following error situations are handled:

- If the search distance after tip wear measurement or measurement after tip change differs a lot from expected (for example missed tip). It is possible to change the tip change and tip wear supervision limit values, see [The Spot Gun Equipment instance on page 39](#).
- If the search sequence is interrupted by for example a Stop or Emergency Stop then the search sequence is automatically restarted from the beginning at program restart.

Limitations

About how to place a fixed reference plate:

The reference plate can be mounted in an optional position in the work range, but it is necessary to orient the tool in the measuring position in that way that an **additional torque** is generated on at least one of the robot motors when the robot is touching the reference position, preferably axis 4 to 6.



Note

When using the reference plate search method there are occasions when the MeasureWearL is less suitable, for example very large guns and/or when an acceptable touch up position is not possible to reach for some reason (poor position, axis configuration). Then the ReCalcTCP method should be used instead.



Note

When using the sensor search method (\SSearch) a fast I/O response is critical for a good performance. A slow or inconsistent I/O response can give poor accuracy.



Note

It is only possible to run this instruction in semi coordinated mode.

Syntax

```
MeasureWearL
  [ ToPoint ':=' ] < expression (IN) of robtargt > ', '
  [ Speed ':=' ] < expression (IN) of speeddata > ', '
  [ GunNo ':=' ] < expression (IN) of num >
  [ '\ ' GunD ':=' ] < persistent(PERS) of gundata > ]
  [ \Reference ] | [ \TipWear ] | [ \TipChange ] | [ \RefChange ]
```

Continues on next page

5 RAPID references

5.1.6 MeasureWearL - Measure current electrode wear and recalculate the TCP

Continued

```
[ '\ SSearch ] ','  
[ Tool ':=' ] < persistent (PERS) of tooldata > ]  
[ '\ WObj ':=' < persistent (PERS) of wobjdata > ]  
[ '\ TLoad':=' ] < persistent (PERS) of loaddata > ] ';' 
```

Related information

| | Described in: |
|--------------------------------------|--|
| Definition of velocity, speeddata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of tool, tooldata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of work objects, wobjdata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| MoveL | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Definition of load data, loaddata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| Overview Spot options | Spot option and features on page 17 |
| System module SWUSER | SWUSER on page 187 |
| Definition of gundata | gundata - Equipment specific weld data on page 152 |
| Software Equalizing | The Spot SoftWare Equalizing instance on page 48 |

5.1.7 ReCalcTCP - Calculate current electrode wear and recalculate the TCP

Description

ReCalcTCP is used in spot welding to calculate current electrode wear for the tip on the fixed electrode and then recalculate the used TCP to compensate for current tip wear. The calculation is based on stored information about the **total tip wear** and about the **expected tip wear ratio**, the wear of the fixed tip related to the total tip wear. The instruction also updates tip wear data in the used gundata.

This instruction can be used also for stationary guns.

This instruction is only available if the `Spot Servo Equalizing` option is installed.

Example

In this example the gun can be hold by the robot or stationary. The principles are the same also when stationary guns are used.

Preparation

First the expected relation between the tip wear of the fixed tip and the total tip wear must be established, the data `Tip wear ratio, fixed vs total wear` in the process configuration must be set to a relevant value. For example 50, the wear of the fixed tip is 50% of the total wear. See [The Spot Gun Equipment instance on page 39](#).

This instruction has to be executed with the `\Reference` switch activated before it is used for tip wear compensation the first time. This also has to be done when the TCP for this gun, with new tips mounted, is changed for some reason. The TCP in the `tooldata` parameter, `ref_tool1` in this example, has to be valid for `gun1` with new tips with the same size mounted.

```
ReCalcTCP gun1\Reference,ref_tool1;
tool1 := ref_tool1;
! tool1 is then used during the production.
```

When the ReCalcTCP instruction with the optional argument `\Reference` is executed some reference data (the `tooldata ref_tool1`) is stored internally in the user module `swuser.sys`. See [Data on page 188](#).

The parameter `gun1` is a `num` corresponding to the used gun equipment. All gun equipment used are defined in the `gundata` array `curr_gundata` located in the `SWUSER` module.

Compensation after tip wear

When it is time to compensate for tip wear, after each tip dressing, the ReCalcTCP instruction should be executed with the `\TipWear` switch activated. This has to be done after the gun calibration, since the total tip wear is updated during the calibration and used when executing ReCalcTCP.

```
Calibrate gun1\TipWear;(CalibL/J can also be used)
ReCalcTCP gun1\TipWear,tool1;
```

When the ReCalcTCP instruction with the optional argument `\TipWear` is executed, the TCP in the used `tooldata` (`tool1` in this example) is recalculated and the data `curr_wear_fix` in `curr_gundata` is automatically updated. The data

Continues on next page

5 RAPID references

5.1.7 ReCalcTCP - Calculate current electrode wear and recalculate the TCP

Continued

`curr_tip_wear` and in `gundata` and the Tip wear ratio, fixed vs total wear in the process configuration is used for the calculations. See [The Spot Gun Equipment instance on page 39](#).

Reset the TCP after tip change

After the tips has been replaced with new ones, the instruction has to be executed, with the `\TipChange` switch activated.

```
Calibrate gun1\TipChange;  
ReCalcTCP gun1\TipChange,tool1;
```

When the `ReCalcTCP` instruction with the optional argument `\TipChange` is executed, the TCP in the used tooldata, `tool1`, is set to the value used for new tips and the data `curr_wear_fix` in `curr_gundata` is cleared.

Arguments

ReCalcTCP GunNo [\GunD] [\Reference] | [\TipWear] | [\TipChange] Tool

GunNo

Data type: num

Used gun equipment number. This index number points at the corresponding `gundata` array index in `curr_gundata` in SWUSER and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

[\GunD]

Data type: gundata

Used gun equipment data for the process, see [gundata - Equipment specific weld data on page 152](#).

Can be used if external `gundata` is required. If used the external `gundata` will be temporary stored in the `curr_gundata` array during the process.

[\Reference]

Data type: switch

This switch is used for preparation of the calculations. This preparation has to be done before the tip wear compensation is done the first time and also each time the TCP for this gun (with new tips mounted) is changed, e.g different tip sizes.

The TCP in tooldata has to be valid for a gun with new tips mounted.

Fore more information about tip management, see [Tip wear compensation on page 209](#).

[\TipWear]

Data type: switch

This switch is used when it is time to compensate for current tip wear, probably after the gun calibration after each tip dressing. The data `curr_wear_fix` in `curr_gundata` will be automatically updated and the TCP in the used tooldata is recalculated. See [Additional components for Spot Servo Equalizing on page 153](#).

For more information about tip management, see [Tip management on page 242](#) and [Tip wear compensation on page 209](#).

Continues on next page

5.1.7 ReCalcTCP - Calculate current electrode wear and recalculate the TCP

Continued

`[\TipChange]`

Data type: switch

This switch is used when the instruction is executed after tip change. The data `curr_wear_fix` in `curr_gundata` is cleared and the TCP in the used tooldata is set to the value valid for new tips. See [Additional components for Spot Servo Equalizing on page 153](#).

For more information about tip management, see [Tip management on page 242](#) and [Tip wear compensation on page 209](#).

Tool

Data type: tooldata

Tooldata for the used gun. The tool center point (TCP) should for a spot weld gun be the tip position for the fixed electrode tip.



Note

The TCP in current tooldata is automatically recalculated and changed when the optional argument `\TipWear` or `\TipChange` is used.

Program execution

Internal sequence when a `ReCalcTCP` instruction is executed:

- If the optional argument `\Reference` is used: Some reference data is stored internally.
- If the optional argument `\TipWear` is used: The TCP in the used tooldata is recalculated and the data `curr_wear_fix` in `curr_gundata` is updated.
- If the optional argument `\TipChange` is used: The TCP in the used tooldata is set to a value valid for new tips and the data `curr_wear_fix` in `curr_gundata` is cleared.

Error handling

Following error situations are handled:

- If the calculated tip wear differ a lot from expected (for example missed tip or wrong sized tip). It is possible to change the tip wear supervision limit value if needed, see [The Spot Gun Equipment instance on page 39](#).

Syntax

```
ReCalcTCP
  [ GunNo ':='] < expression (IN) of num >
  [ '\' GunD ':='] < persistent(PERS) of gundata > ]
  [ \Reference ] | [ \TipWear ] | [ \TipChange ]
  [ Tool ':= ' (PERS) of tooldata > ';' ]
```

Related information

| | Described in: |
|---------------------------------|--|
| Definition of gun data, gundata | gundata - Equipment specific weld data on page 152 |

Continues on next page

5 RAPID references

5.1.7 ReCalcTCP - Calculate current electrode wear and recalculate the TCP

Continued

| | Described in: |
|-----------------------|--|
| Overview Spot options | Spot option and features on page 17 |
| System module SWUSER | SWUSER on page 187 |
| Software Equalizing | The Spot SoftWare Equalizing instance on page 48 |

5.1.8 IndGunMove - Activates independent mode for a servo gun

Description


IndGunMove (Independent Gun Movement) is used to set the gun in independent mode and thereafter move the gun to a specified independent position. The gun will stay in independent mode until the instruction IndGunMoveReset is executed. During independent mode, the control of the servo gun is separated from the robot. The gun can be closed, opened, calibrated or moved to a new independent position, but it will not follow coordinated robot movements.

It is also possible to set the gun in independent mode from a background task while the robot in the main task can continue with for example move instructions. For more information of how to set the gun in independent mode, see *Technical reference manual - RAPID Instructions, Functions and Data types*.

Example

```
PROC tipdress()
  ! Note that the gun will move to current robtaraget position, if
  ! already in independent mode.
  IndGunMoveReset gun1;
  .....
  .....
  .....
  IndGunMove gun1, 30;
  .....
  SetForce gun1, force10;
  .....
  IndGunMoveReset gun1;
ENDPROC
```

Independent mode is activated and the gun is moved to an independent position (30 mm). During independent mode the instruction SetForce is executed, without interfering with robot motion. The instruction IndGunMoveReset will take the gun out of independent mode and move the gun to current robtaraget position.



xx120000207

The position p1 depends on the position of the gun given in the robtaraget just performed by the robot.

Continues on next page

5 RAPID references

5.1.8 IndGunMove - Activates independent mode for a servo gun

Continued

Arguments

IndGunMove GunNo [\GunD] GunPos

GunNo

Data type: num

Used gun equipment number. Corresponding to the element number in the gundata array `curr_gundata` located in the `SWUSER.SYS` module. See [SWUSER on page 187](#)

[\GunD]

Data type: gundata

Used gun equipment data for the process, see [gundata - Equipment specific weld data on page 152](#).

Can be used if external gundata is required. If used the external gundata will be temporary stored in the `curr_gundata` array during the process.

GunPos

Data type: num

The position (stroke) of the servo gun in mm.

Program execution

The instruction activates independent mode and moves the gun from the coordinated position to a specified independent position. During the independent mode the gun may be closed, opened, calibrated or moved to a new independent position without interfering with robot motion.

Program restart during independent mode will always start with a regain movement to the current independent position.

The gun will recover independent mode after a system restart. Moving the program pointer will NOT reset independent mode. When the program is started, no regain movement will occur but the gun will return to independent mode after the first gun closing or calibration.

Limitations

It is not possible to use this instruction is used in combination with spot instructions when Software equalizing is activated.

Syntax

```
IndGunMove
  [ GunNo ':=<expression (IN) of num> ]
  [ '\GunD ':=<persistent(PERS) of gundata > ] ','
  [ GunPos ':=<expression (IN) of num> ] ';'

```

Related information

| | Described in: |
|----------|---|
| SetForce | SetForce - Close and Open a gun with desired force and time on page 118 |
| STIndGun | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |

5.1.9 IndGunMoveReset - Resets servo gun from independent mode

Description

IndGunMoveReset (Independent Gun Movement Reset) is used to reset the gun from independent mode and thereafter move the gun to current rotarget position.

Example

```
IndGunMoveReset gun1;
```

Arguments

IndGunMoveReset GunNo [GunD]

GunNo

Data type: num

Used gun equipment number. Corresponding to the element number in the gundata array `curr_gundata` located in the `SWUSER.SYS` module. The gun was previously set independent with the instruction `IndGunMove`.

[\GunD]

Data type: gundata

Used gun equipment data for the process, see [gundata - Equipment specific weld data on page 152](#).

Can be used if external gundata is required. If used the external gundata will be temporary stored in the `curr_gundata` array during the process.

Program execution

The instruction will reset the gun from independent mode and move the gun to current rotarget position. During this movement the coordinated speed of the gun must be zero, otherwise the reset will be delayed. The coordinated speed will be zero if the robot is standing still or if the current robot movement includes a "zero movement" of the gun.

Limitations

Note that the reset movement of the gun only will be finished if the coordinated speed of the tool between two points are zero or if the consecutive point is a stop point.

Syntax

```
IndGunMove
  [ GunNo ':=<' <expression (IN) of num> ]
  [ '\ GunD ':=<' < persistent(PERS) of gundata > ] ';' ;
```

Related information

| | Described in: |
|-----------------------|--|
| Definition of gundata | gundata - Equipment specific weld data on page 152 |

5 RAPID references

5.1.10 OpenHighLift/CloseHighLift - Control the position of a pneumatic gun

5.1.10 OpenHighLift/CloseHighLift - Control the position of a pneumatic gun

Description

`OpenHighLift` is used in spot welding to open a pneumatic gun to the highlift position (large gap).

`CloseHighLift` is used in spot welding to close a pneumatic gun to the work stroke position (small gap).

Example

```
OpenHighLift, gun1;
```

- The gun `gun1` is opened to the highlift position.

```
CloseHighLift, gun1;
```

- The gun `gun1` is closed to the work stroke position.

The parameter `gun1` is a `num` corresponding to the used gun equipment. All gun equipment used are defined in the `gundata` array `curr_gundata` in `SWUSER`.

Arguments

`OpenHighLift GunNo [\GunD]`

`CloseHighLift GunNo [\GunD]`

`GunNo`

Data type: `num`

Used gun equipment number. Corresponding to the element number in the `gundata` array `curr_gundata` in `SWUSER`.

`[\GunD]`

Data type: `gundata`

Used gun equipment data for the process, see [gundata - Equipment specific weld data on page 152](#).

Can be used if external `gundata` is required. If used the external `gundata` will be temporary stored in the `curr_gundata` array during the process.

Program execution

Internal sequence when a `OpenHighLift` instruction is executed:

- The `inhibit_close` is simulated.
- The user routine `SwInitUserIO` is executed.
- The user routine `SwOpenGun` is executed and the gun is opened to the highlift position.

Internal sequence when a `CloseHighLift` instruction is executed:

- The `inhibit_close` is simulated.
- The user routine `SwInitUserIO` is executed.
- The user routine `SwCloseGun` is executed and the gun is closed to the work stroke position.

Continues on next page

5.1.10 OpenHighLift/CloseHighLift - Control the position of a pneumatic gun

*Continued***Instruction by instruction execution**

| | |
|----------|---------------------------------|
| Forward | As during continuous execution. |
| Backward | As during continuous execution. |

Error handling

No error handling.

Syntax

```

OpenHighLift or CloseHighLift
  [ GunNo ':=' ] < expression (IN) of num >
  [ '\ ' GunD ':=' ] < persistent(PERS) of gundata > ] ';'

```

Related information

| | Described in: |
|----------------------|---|
| Overview <i>Spot</i> | Spot option and features on page 17 |

5 RAPID references

5.1.11 GunArmSearch - Used to search for a surface

5.1.11 GunArmSearch - Used to search for a surface

Description

GunArmSearch (Gun arm search) is used to search with the movable gun arm for a surface or an object.

Example

```
PROC my_search_routine()  
VAR num ret_pos;  
.....  
! The gun will start to move from 50mm to zero position and return  
  the hit position in the variable ret_pos.  
! After the search hit it will open to 50mm.  
GunArmSearch gun1, ret_pos \GunOpenPos:=50;  
.....  
TPWrite "Object is "+ValToStr(ret_pos)+"mm";  
.....  
ENDPROC
```

Arguments

GunArmSearch GunNo, RetPosition [*\GunOpenPos*]

GunNo

Data type: num

Used gun equipment number. This index number points at the corresponding *gundata* array index in *curr_gundata* in SWUSER and the equipment instance in the process configuration, see [gundata - Equipment specific weld data on page 152](#) and [The Spot Equipment instance on page 32](#).

RetPosition

Data type: num

The achieved position after search [mm].

[*\GunOpenPos*]

Data type: num

If the optional argument *\GunOpenPos* is used the gun arm will move to the specified position before and after the instruction. If the argument is omitted only the search movement will performed.

Program execution

The movable gun arm will move to the position specified in the argument *\GunOpenPos* if used, and then start the search movement to zero position. If an object is present between the tips the movement is stopped and the achieved position is returned in the argument *RetPosition*. After the search hit the movable gun arm is moved back to the position specified in the argument *\GunOpenPos* if used, if not, the movable gun arm is moved back a small distance specified in the system parameter 'Search reverse distance' in 'FORCE_MASTER' for the corresponding external axis.

Continues on next page

5.1.11 GunArmSearch - Used to search for a surface
Continued

The movable gun arm of the gun is moved with the speed defined in the system parameter 'Search speed' in 'FORCE_MASTER_CONTROL' for the corresponding external axis.

For more details, see System Parameters, Topic Motion, *Technical reference manual - System parameters*.

Limitations

It is only possible to run this instruction from a motion task.

Error handling**Instruction parameter supervision**

The error occurs when `GunArmSearch` is called with faulty parameters. The program stops with error text.

The parameter must be changed. When the program is restarted the current instruction is restarted from the beginning.

Syntax

```
GunArmSearch
  [ GunNo ':=' ] < expression (IN) of num > ', '
  [ RetPosition ':=' < variable or persistent(INOUT) of num >
  [ '\ ' GunOpenPos ':=' < expression (IN) of num > ] ';'

```

Related information

| | Described in: |
|---------------------------------|---|
| Movable gun arm search | Movable gun arm search mode on page 215 |
| Servo Gun Setup | <i>Application manual - Servo Gun Setup</i> |
| System Parameters, Topic Motion | <i>Technical reference manual - System parameters.</i> |

5 RAPID references

5.2.1 gundata - Equipment specific weld data

5.2 Data types

5.2.1 gundata - Equipment specific weld data

Description

`gundata` is used to define spot weld equipment specific data, to control the gun in an optimal way in the weld process when the spot instructions are used. Each `gundata` defines one gun equipment.



Note

The `gundata` structure and order of parameters differs between different spot options.

`gundata` has the following default structure when servo guns are used:

- Gun name
- Weld counter and a max value.
- Current tip wear and a max value.
- Specific parameters for the Software Equalizing functions. (Only if Spot Servo Equalizing is installed.)

`gundata` has the following default structure when pneumatic guns are used:

- Gun name
- Weld counter and a max value.

Components

`gun_name`

(gun name)

Data type: string

The name of the mechanical unit used for the servo gun. This name must be identical with the name of the mechanical unit defined in the motion servo gun parameters.

Normally the gun name will be updated automatically at startup. A service routine is available to search the system for servo guns and update the gun name, `ManualGunSearch`, see [Manual actions on page 84](#).

`weld_counter`

(weld counter)

Data type: num

Counter for the number of welds done with this gun. The counter is automatically incremented after process is ready. Use of this data is optional. Zero set shall be handled by the user program.

`max_nof_welds`

(max number of welds)

Data type: num

Continues on next page

Max number of performed welds. Use of this data is optional.

`curr_tip_wear`

(current tip wear)

Data type: num

Current tip wear [mm]. This data is automatically updated after each gun calibration. Use of this data is optional. (Servo guns only).

`max_tip_wear`

(max tip wear)

Data type: num

Max allowed tip wear before tip exchange [mm]. Use of this data is optional. (Servo guns only).

Additional components for Spot Servo Equalizing

`curr_wear_fix`

(current tip wear for the fixed tip)

Data type: num

Current tip wear for the fixed gun electrode tip [mm]. This data is automatically updated when `MeasureWearL` or `ReCalcTCP` is used.

`wear_moveable`

(current tip wear for the moveable tip)

Data type: num

Current tip wear for the moveable gun electrode tip [mm]. This data is automatically updated when `CalibL/J` and `Calibrate` is used.

`release_dist`

(release distance)

Data type: num

The release distance [mm] when the robot is moving between weld positions during normal program execution and during Weld position Touch Up.

`deflection_dist_z`

(deflection distance in z-direction)

Data type: num

TCP deviation [mm] in z-direction caused of gun arm deflection when the gun is closed with the force specified in `deflection_force`. This data is used for the deflection compensation movement of the robot. Default value 0 mm.

Continues on next page

5 RAPID references

5.2.1 gundata - Equipment specific weld data

Continued

Only positive values are allowed, the `Opposite z-direction` parameter determines the direction for the deflection compensation. See [The Spot Gun Equipment instance on page 39](#).



Note

This parameter can also be configured via system parameters, see System Parameters, Topic Motion and Type SG Process, *Technical reference manual - System parameters*.

In this case this parameter has to be removed, see [How to change the Spot data types on page 287](#).

`deflection_dist_x`

(deflection distance in x-direction)

Data type: num

TCP deviation [mm] in x-direction caused of gun arm deflection when the gun is closed with the force specified in `deflection_force`. This data is used for the deflection compensation of the robot. Default value 0mm.

This value can be both positive and negative depending on which direction the deflection compensation shall be performed.

Example: If the gun bends outwards 2mm (positive x), this value should be set to 2mm.



Note

This parameter can also be configured via system parameters, see System Parameters, Topic Motion and Type SG Process, *Technical reference manual - System parameters*.

In this case this parameter has to be removed, see [How to change the Spot data types on page 287](#).

`deflection_force`

(deflection force)

Data type: num

Applied force [N] corresponding to the TCP deviation `deflection_dist_` parameters caused of gun arm deflection. This data is used for the deflection compensation.



Note

This parameter can also be configured via system parameters, see System Parameters, Topic Motion and Type SG Process, *Technical reference manual - System parameters*.

In this case this parameter has to be removed, see [How to change the Spot data types on page 287](#).

Continues on next page

deflection_time

(deflection time)

Data type: num

The time for the gun to build up the gun force [s]. This data is used for the deflection compensation. If no data information exists, use the default value (0.1 s).

**Note**

This parameter can also be configured via system parameters, see System Parameters, Topic Motion and Type SG Process, *Technical reference manual - System parameters*.

In this case this parameter has to be removed, see [How to change the Spot data types on page 287](#).

Default structure

For servo guns if Spot Servo is installed:

```
<dataobject of gundata>
  <gun_name of num>
  <weld_counter of num>
  <max_nof_welds of num>
  <curr_tip_wear of num>
  <max_tip_wear of num>
```

For servo guns if Spot Servo Equalizing:

```
<dataobject of gundata>
  <gun_name of num>
  <weld_counter of num>
  <max_nof_welds of num>
  <curr_tip_wear of num>
  <max_tip_wear of num>
  <curr_wear_fix of num>
  <wear_moveable of num>
  <release_dist of num>
  <deflection_dist_z of num>
  <deflection_dist_x of num>
  <deflection_force of num>
  <deflection_time of num>
```

For pneumatic guns:

```
<dataobject of gundata>
  <gun_name of num>
  <weld_counter of num>
  <max_nof_welds of num>
```

Predefined data

For servo guns if Spot Servo is installed:

```
PERS gundata curr_gundata{4} :=
  [{"SGUN_1", 0, 1000, 0, 10},
  ["NOT USED", 0, 1000, 0, 10],
  ["NOT USED", 0, 1000, 0, 10],
  ["NOT USED", 0, 1000, 0, 10],
```

Continues on next page

5 RAPID references

5.2.1 gundata - Equipment specific weld data

Continued

```
["NOT USED", 0, 1000, 0, 10]]];
```

For servo guns if Spot Servo Equalizing is installed:

```
PERS gundata curr_gundata{4} :=  
  [{"SGUN_1", 0, 1000, 0, 10, 0, 0, 5, 0, 0, 5000, 0.1},  
  ["NOT USED", 0, 1000, 0, 10, 0, 0, 5, 0, 0, 5000, 0.1},  
  ["NOT USED", 0, 1000, 0, 10, 0, 0, 5, 0, 0, 5000, 0.1},  
  ["NOT USED", 0, 1000, 0, 10, 0, 0, 5, 0, 0, 5000, 0.1]]];
```

For pneumatic guns:

```
PERS gundata curr_gundata{4} :=  
  [{"PGUN_1", 0, 1000},  
  [{"PGUN_2", 0, 1000},  
  [{"PGUN_3", 0, 1000},  
  [{"PGUN_4", 0, 1000}]]];
```

`curr_gundata` is an array with active gundata parameters for each used gun. These parameters have to be changed by the user during the installation and programming phase to be in agreement with the weld equipment in use. In the default package, `curr_gundata` is defined in module SWUSER.

It is also possible to use external gundata in the spot instructions, [Arguments on page 107](#).



Note

The size of the gundata array may depend on the selected spot configuration, for a single gun configuration the size of the array will be only one instance as well as the process and I/O configuration.

Customizing

The Spot package provides opportunities for the user to customize the functionality to adapt to different types of spot weld equipment and user defined standards. For this data type it is possible to delete components if they are not used. It is also possible to give the components own user defined names.

However, the main subject of this description is the default setup.

See [Customizing RobotWare-Spot on page 279](#).

Related information

| | Described in: |
|-----------------------------------|--|
| SpotL/SpotJ | SpotL/SpotJ - The basic spot welding instructions on page 107 |
| Overview Spot options | Spot option and features on page 17 |
| Customizing possibilities | Customizing RobotWare-Spot on page 279 |
| Definition of spot data, spotdata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| System module SWUSER | SWUSER on page 187 |

5.2.2 spotdata - Spot weld data

Description

Spotdata is used to define the parameters that control the weld equipment when welding a certain spot.

Spotdata is used by the `SpotL/J` and `SpotML/J` instructions and contains data which controls the welding of one spot.

Spotdata has the following default structure when servo guns are used:

- Program number for the program in the weld timer to be used.
- Desired gun tip force.
Only valid for servo guns.
- Expected total plate thickness.
Only valid for servo guns.
- Allowed variation when checking the plate thickness.
Only valid for servo guns.



Tip

It is possible to use spot data parameters programmed in the weld timer if needed instead of the spotdata parameters, see

[Customizing RobotWare-Spot on page 279](#)

Components

`prog_no`

(program number)

Data type: dnum

Defines the internal program in the weld timer to be used for the welding. This data will set an output group signal when a spot instruction is run.

Permitted values: 0 - to the size of the I/O group for the equipment.

Absolute max is the size of dnum, 4294967295 - 32bit.

`part_id`

(part id)

Data type: string

Defines the part identity that can be used for tracing the actual part that is welded, e.g a specific door etc.

It is not used internally, but the information will be part of the process log file if the data is used.

This data is optional and not part of the default structure, so it needs to be added in the template modules by customizing the spot data type.

Max length is limited to 32 characters. Longer string will be truncated.

See [SwSetIntSpotData - Set the internal spotdata on page 173](#)

Continues on next page

5 RAPID references

5.2.2 spotdata - Spot weld data

Continued

tip_force

(gun tip force)

Data type: num

Defines the desired gun tip force. [Default - Newton], unit type can be changed via configuration, see [The Spot System instance on page 27](#).

Permitted values: -1, to the defined max gun force, see

[The Spot Gun Equipment instance on page 39](#)

-1 will disable this parameter, and external timer data will be used instead, see [How to use spot data programmed in the weld timer on page 290](#).

If pneumatic gun is used, this value controls a group output, see [The Spot Gun Equipment instance on page 39](#).

plate_thickness

(plate thickness)

Data type: num

Defines the expected total plate thickness. [mm].

Permitted values: -1, to the defined max plate thickness, see [The Spot System instance on page 27](#).

-1 will disable this parameter, and external timer data will be used instead, see [How to use spot data programmed in the weld timer on page 290](#).



Note

This parameter is only valid for servo guns.

plate_tolerance

(plate tolerance)

Data type: num

Defines the allowed variation when checking the plate thickness [mm]

If the value is 0 the thickness check is deactivated.

Permitted values: -1, to the defined max plate tolerance, see [The Spot System instance on page 27](#).

-1 will disable this parameter, and external timer data will be used instead, see [How to use spot data programmed in the weld timer on page 290](#).



Note

This parameter is only valid for servo guns.

Predefined data

Servo guns:

```
PERS spotdata spot1 := [1, 1000, 0, 0];
```

Pneumatic guns:

```
PERS spotdata spot1 := [1, 1];
```

Continues on next page

Defined in module SWUSR.M.

Spot1 is used as default in the first programmed Spot instruction and has following default data:

- The program number 1 in the weld controller shall be used.
- Desired gun tip force = 1000 N. (Gun pressure level 1 for pneumatic guns).
- Expected total plate thickness = 0 mm. (Servo guns).
- Allowed variation in the thickness = 0 (thickness check is deactivated) (Servo guns).

Servo guns:

```
PERS spotdata
curr_spotdata{4} := [[0,0,0,0],[0,0,0,0],[0,0,0,0],[0,0,0,0 ]];
```

Pneumatic guns:

```
PERS spotdata curr_spotdata{4} := [[0,0],[0,0],[0,0],[0,0]];
```

Defined in module SWUSER.

curr_spotdata is an array with active or latest used spotdata parameters for each defined gun. This parameters are automatically updated by the kernel when spot instructions are executed. This spotdata are used for reweld situations and if welding is manually activated (see [Manual actions on page 84](#)).

Customizing

The Spot package provides opportunities for the user to customize the functionality to adapt to different types of spot weld equipment and user defined standards. For this data type it is possible to delete components if they are not used. It is also possible to give the components own user defined names.

However, the main subject of this description is the default setup.

See [Customizing RobotWare-Spot on page 279](#).

Default structure

For servo guns:

```
<dataobject of spotdata>
  <prog_no of dnum>
  <tip_force of num>
  <plate_thickness of num>
  <plate_tolerance of num>
```

For pneumatic guns:

```
<dataobject of spotdata>
  <prog_no of dnum>
  <tip_force of num>
```

Related information

| | Described in: |
|---------------------------|---|
| SpotL/J | SpotL/SpotJ - The basic spot welding instructions on page 107 |
| Overview Spot options | Spot option and features on page 17 |
| Customizing possibilities | Customizing RobotWare-Spot on page 279 |

Continues on next page

5 RAPID references

5.2.2 spotdata - Spot weld data

Continued

| | Described in: |
|---------------------------------|--|
| Definition of gun data, gundata | gundata - Equipment specific weld data on page 152 |
| System module SWUSER | SWUSER on page 187 |

5.2.3 forcedata - Spot gun force data

Description

Forcedata is used to define the parameters for control of the spot weld gun when it is closed without welding, e.g. when tip dressing.

Forcedata is used when a **SetForce** instruction is run, or from certain manual actions.

It has the following default structure when servo guns are used:

- Desired gun tip force.
- Desired force time.
- Expected total plate thickness. (Only valid for servo guns.)

Allowed variation when checking the plate thickness. (Only valid for servo guns.)

Components

`tip_force`

(gun tip force)

Data type: num

Defines the desired gun tip force [Default - Newton], unit type can be changed via configuration, see [The Spot System instance on page 27](#).

If pneumatic gun is used, this value controls a group output, see [The Spot Gun Equipment instance on page 39](#).

`force_time`

(gun force time)

Data type: num

Defines the desired gun force time [s].

`plate_thickness`

Data type: num

Defines the expected total plate thickness [mm].



Note

This parameter is only valid for servo guns.

`plate_tolerance`

(plate tolerance)

Data type: num

Defines the allowed variation when checking the plate thickness [mm].

If the value is 0 the thickness check is deactivated.



Note

This parameter is only valid for servo guns.

Continues on next page

5 RAPID references

5.2.3 forcedata - Spot gun force data

Continued

`\tip_force2`

(optional second gun tip force)

Data type: num

Defines the second gun tip force [Default - N]. This data can be used when a second gun force is required. See [SwSetIntForceData - Set the internal forcedata on page 174](#).

`\force_time2`

(optional second gun force time)

Data type: num

Defines the second gun force time [s]. This data can be used when a second force time is required. See [SwSetIntForceData - Set the internal forcedata on page 174](#)

Predefined data

Servo guns:

```
PERS forcedata force1 := [1000, 1, 0, 0];
```

Pneumatic guns:

```
PERS forcedata force1 := [1, 1];
```

Defined in module SWUSR.M.

force1 is used as default in the first programmed `SetForce` instruction and has following default data:

- Desired gun tip force = 1000 N.
(Gun pressure 1 for pneumatic gun)
- Desired force time = 1 s.
- Expected total plate thickness = 0 mm.
(Servo gun)
- Allowed variation in the thickness = 0 (thickness check is deactivated)
(Servo gun)

Servo guns:

```
PERS forcedata curr_forcedata{2} := [[0,0,0,0],[0,0,0,0]];
```

Pneumatic guns:

```
PERS forcedata curr_forcedata{2} := [[0,0],[0,0]];
```

Defined in module SWUSER.

`curr_forcedata` is an array with active or latest used forcedata parameters for each defined gun. This parameters are automatically updated by the kernel when a `SetForce` instruction is executed. The parameters are used when gun closure is manually activated, see [Manual actions on page 84](#).

Customizing

The Spot package provides opportunities for the user to customize the functionality to adapt to different types of spot weld equipment and user defined standards. For this data type it is possible to delete components if they are not used. It is also possible to give the components own user defined names.

Continues on next page

However, the main subject of this description is the default setup. See [Customizing RobotWare-Spot on page 279](#).

Default structure

For servo guns:

```
<dataobject of forcedata>
  <tip_force of num>
  <force_time of num>
  <plate_thickness of num>
  <plate_tolerance of num>
```

For pneumatic guns:

```
<dataobject of forcedata>
  <tip_force of num>
  <force_time of num>
```

Related information

| | Described in: |
|-----------------------------------|---|
| SetForce | SetForce - Close and Open a gun with desired force and time on page 118 |
| Overview Spot options | Spot option and features on page 17 |
| Customizing possibilities | Customizing RobotWare-Spot on page 279 |
| Definition of spot data, spotdata | spotdata - Spot weld data on page 157 |
| System module SWUSER | SWUSER on page 187 |

5 RAPID references

5.2.4 simdata - Simulation data

5.2.4 simdata - Simulation data

Description

`Simdata` is used to define the parameters that control the different simulation modes used when testing spot weld programs.

`Simdata` has the following default structure when servo guns are used:

- Desired simulation type.
- Desired simulation time.
- If testing is performed with/without gun closure.
- If testing is performed with/without plates. (Only valid for servo guns).

Components

`sim_type`

(simulation type)

Data type: num

Desired simulation type. Permitted values:

| | |
|---|--|
| 0 | All simulations are deactivated. (Weld mode) |
| 1 | Simulation of the weld is performed in the robot controller. (No start signal to weld controller). Program valid check is done and timer input groups are checked if configured. |
| 2 | Simulation of the weld is performed in the weld controller with no current. The signal <code>enable_current</code> is reset. |
| 3 | Weld position Touch Up mode. Only available if Spot Servo Equalizing is installed. |

`sim_time`

(simulation time)

Data type: num

Defines the desired simulation time [s] when simulation of the weld is performed in the robot controller (`sim_type = 1`).

`inhib_close`

(inhib close)

Data type: bool

Testing without closing the guns. Only relevant if `sim_type = 1` or `2`.

`no_plates`

(no plates)

Data type: bool

Testing without plates. Only relevant if `sim_type = 1` or `2`. If this mode is set, the robot and gun will move to the nominal positions. The plate thickness supervision, SoftMove Equalizing will be disabled to be able to run a cycle without parts. (Only valid for servo guns).

Continues on next page

Predefined data**Servo guns:**

```
PERS simdata data curr_simdata := [0, 0.5, FALSE, FALSE];
```

Pneumatic guns:

```
PERS simdata data curr_simdata := [0, 0.5, FALSE];
```

Defined in module SWUSER.

`curr_simdata` is holding all active simulation data. This data influences all used weld equipment when `SpotL/J` or `SpotML/J` instructions are executed. The user has to change this data to activate a simulation mode. All simulations are deactivated if `sim_type = 0` (default).

Customizing

The Spot package provides opportunities for the user to customize the functionality to adapt to different types of spot weld equipment and user defined standards. For this data type it is possible to delete components if they are not used. It is also possible to give the components own user defined names. However, the main subject of this description is the default setup.

See [Customizing RobotWare-Spot on page 279](#).

**Note**

It is possible to control all simulation modes via the Spot FlexPendant interface, see [Simulation on page 256](#).

Default structure**For servo guns:**

```
<dataobject of simdata>
  <sim_type of num>
  <sim_time of num>
  <inhib_close of bool>
  <no_plates of bool>
```

For pneumatic guns:

```
<dataobject of simdata>
  <sim_type of num>
  <sim_time of num>
  <inhib_close of bool>
```

Related information

| | Described in: |
|---------------------------|---|
| SpotL | SpotL/SpotJ - The basic spot welding instructions on page 107 |
| SpotML | SpotML/SpotMJ - Spot welding with multiple guns on page 113 |
| Overview <i>Spot</i> | Spot option and features on page 17 |
| Customizing possibilities | Customizing RobotWare-Spot on page 279 |
| System module SWUSER | SWUSER on page 187 |

Continues on next page

5 RAPID references

5.2.4 simdata - Simulation data

Continued

| | Described in: |
|----------------------|------------------------------------|
| System module SWUSRМ | SWUSRМ on page 193 |

5.2.5 smeqdata - SoftMove Equalizing data

Description

`Smeqdata` is used to define the parameters used to control the SoftMove function that can be used when welding a certain spot.

This optional data can be used by the `SpotL/J` instructions if SoftMove equalizing is required.

`smeqdata` has the following structure:

- Desired `smeq_type` of the robot for the specific position.
- Desired `force_offset` friction compensation for the specific position.

Components

`smeq_type`

(SoftMove type of the robot)

Data type: `smeqtype` (alias num)

Defines what SoftMove type that shall be used in the specific position, there are 2 types possible, no gun deflection mode(0), standard mode(1).

0 - No gun deflection mode: During the final robot movement to the position and closing of the gun the robot will be set into soft state using the specified `force_offset` value during the complete weld cycle.

1 - Standard mode: During the final robot movement to the position and closing of the gun the robot will be set into soft state using the specified `force_offset` value, during the weld cycle the robot will be stiff and gun arm deflection will be used.

`force_offset`

(friction compensation)

Data type: num

Defines the desired force in Newton, corresponding to the static friction of the robot in the soft z direction and the force needed to achieve a small movement to the plate. This value must be set for each position the first time the program is executed.

If the force value is too low it will be difficult for the robot to reach the position, and if the force value is too high the robot may damage the plate. Possible values for this parameter are in between 0.1 and 2000 N. The friction compensation needed

Continues on next page

5 RAPID references

5.2.5 smeqdata - SoftMove Equalizing data

Continued

will be measured for each SpotL/J instruction if the initial value is zero, see [Friction compensation procedure on page 224](#).



Note

The `force_offset` should be seen as friction force and force applied to the plates.

Example: 100N is identified in the friction compensation procedure.

To be sure that robot will move to the plate the `force_offset` can be set to 130N. If the friction is constant during the movement it will be 30N applied on the plate.

Example

Program example with and without SoftMove Equalizing functionality:

```
PERS smeqdata smeq10:=[1,150];
PERS smeqdata smeq11:=[1,170];

PROC main()
  MoveJ P10, v1000, z50, tool1;
  SpotL P20, vmax, gun1, spot11, tool1;
  SpotL P30, vmax, gun1, spot12 \SMEQ:=smeq10, tool1;
  SpotL P40, vmax, gun1, spot13 \SMEQ:=smeq11, tool1;
  SpotL P50, vmax, gun1, spot14, tool1;
ENDPROC
```

Default structure

```
<dataobject of smeqdata>
<smeq_type of smeqtype>
<force_offset of num>
```

Related information

| | Described in: |
|---------------------|---|
| SpotL/J | SpotL/SpotJ - The basic spot welding instructions on page 107 |
| SoftMove Equalizing | SoftMove Equalizing on page 219 |
| SoftMove | Application manual - SoftMove |

5.2.6 searchdata - Search data

Description

`Searchdata` is used to activate the movable gun arm search functionality that can be used when welding a certain spot.

This optional data can be used by the `SpotL/J` instructions if movable gun arm search is required.

`searchdata` has the following structure:

- **Desired `search_pos_adjust` plate sheet stiffness compensation for the specific position.**

Components

`search_pos_adjust`

(search position adjust)

Data type: num

Defines the distance in mm, that can be used to adjust the searched position depending on the stiffness of the sheet metal for example if it is weaker in a specific position. The value can be positive or negative.

A positive value will move the gun and TCP position back from the search hit position.

Default value is 0 mm.

Example

Program example with and without movable gun arm search functionality: P20 and P50 is executed in standard software equalizing mode.

P30 is executed with in gun arm search mode because of tolerance variations in that specific position. Since the sheet is relatively stiff in this position there is no need to compensate for softer sheet metal.

P40 is also executed with gun arm search mode for the same reason. But because of the softer sheet metal in this specific target, and to not deform the sheet the gun will move back 2 mm to reduce the impact.

Since the search functionality only is needed in these two specific positions, it is only used there because of the additional cycle time impact.

```
PERS searchdata search1:=[0];
PERS searchdata search2:=[2];
PROC main()
  MoveJ P10, v1000, z50, tool1;
  SpotL P20, vmax, gun1, spot11, tool1;
  SpotL P30, vmax, gun1, spot12 \Search:=search1, tool1;
  SpotL P40, vmax, gun1, spot13 \Search:=search2, tool1;
  SpotL P50, vmax, gun1, spot14, tool1;
ENDPROC
```

Continues on next page

5 RAPID references

5.2.6 searchdata - Search data

Continued

Default structure

<dataobject of searchdata>
<search_pos_adjust of num>

Related information

| | Described in: |
|------------------------|---|
| SpotL/J | SpotL/SpotJ - The basic spot welding instructions on page 107 |
| Movable gun arm search | Movable gun arm search mode on page 215 |
| Servo Gun Setup | Application manual - Servo Gun Setup |

5.3 Global instructions and functions

5.3.1 SwGetCurrTargetName - Get the current robtarget name

Description

`SwGetCurrTargetName` can be used in the user routines to retrieve the current robtarget name for each spot instruction.

Example

A basic example of the function `SwGetCurrTargetName` used in the `SwPrepare` hook is illustrated below.

```
PROC main()
  SpotL p100, vmax, gun1, spot10, tool1;
ENDPROC
PROC SwPrepare(num GunNum, string ErrText)
  VAR string tmp_str;
  tmp_str := SwGetCurrTargetName();
  TPWrite "Current robtarget name - "+tmp_str;
ENDPROC
```

- 1 The robot executes a `SpotL` instruction to the position `p100`.
- 2 In the `SwPrepare` user hook the function `SwGetCurrTargetName` is called.
- 3 The `TPWrite` instruction will write "p100" on the FlexPendant.

Return value

Data type: string

If a spot instruction has been executed prior to this, the robtarget name will be returned, otherwise an empty string will be returned.

Syntax

```
SwGetCurrTargetName '(' ' ')
```

A function with a return value of the data type string.

5 RAPID references

5.3.2 SwGetCurrSpotName - Get the current spotdata name

5.3.2 SwGetCurrSpotName - Get the current spotdata name

Description

`SwGetCurrSpotName` can be used in the user routines to retrieve the current spotdata name for each spot instruction.

Example

A basic example of the function `SwGetCurrSpotName` used in the `SwPrepare` hook is illustrated below.

```
PROC main()
  SpotL p100, vmax, gun1, spot10, tool1;
ENDPROC
PROC SwPrepare(num GunNum, string ErrText)
  VAR string tmp_str;
  tmp_str := SwGetCurrSpotName();
  TPWrite "Current spotdata name - "+tmp_str;
ENDPROC
```

- 1 The robot executes a `SpotL` instruction to the position `p100`.
 - 2 In the `SwPrepare` user hook the function `SwGetCurrSpotName` are called.
 - 3 The `TPWrite` instruction will write "spot10" on the FlexPendant.
-

Return value

Data type: string

If a spot instruction has been executed prior to this, the spotdata name will be returned, otherwise an empty string will be returned.

Syntax

```
SwGetCurrSpotName '(' ' ')
```

A function with a return value of the data type string.

5.3.3 SwSetIntSpotData - Set the internal spotdata

Description

The `SwSetIntSpotData` routine is used to transfer user spotdata components to internally used spotdata components.

Example

An example of the function `SwSetIntSpotData` used in the `DefineSpotData` routine is illustrated below.

```
PROC DefineSpotData(spotdata Spot, num GunNum)
  SwSetIntSpotData GunNum \ProgNo:=Spot.prog_no
  \TipForce:=Spot.tip_force;
ENDPROC
```

- 1 The robot executes a `SpotL` instruction and calls the `SwSetIntSpotData` routine.
- 2 The internally used spotdata parameters are updated and used during the process.

Syntax

```
[ GunNum ':=' ] < expression (IN) of num >
[ '\ ProgNo ':=' ] < expression (IN) of dnum >
[ '\ TipForce ':=' ] < expression (IN) of num > ]
[ '\ PlateThickness ':=' ] < expression (IN) of num > ]
[ '\ PlateTolerance ':=' ] < expression (IN) of num > ]
[ '\ ReleaseDist ':=' ] < expression (IN) of num > ]
'[ '\ PartID ':=' ] < expression (IN) of string > ]';'
```

5 RAPID references

5.3.4 SwSetIntForceData - Set the internal forcedata

5.3.4 SwSetIntForceData - Set the internal forcedata

Description

The `SwSetIntForceData` routine is used to transfer user forcedata components to internally used forcedata components.

Example

An example of the function `SwSetIntForceData` used in the `DefineForceData` routine is illustrated below.

```
PROC DefineForceData(forcedata Force, num GunNum)
  SwSetIntForceData GunNum \TipForce:=Force.tip_force
  \ForceTime:=Force.force_time
  \PlateThickness:=Force.plate_thickness
  \PlateTolerance:=Force.plate_tolerance;
ENDPROC
```

Example of the function `SwSetIntForceData` routine with optional force data parameters is illustrated below.

```
PROC DefineForceData(forcedata Force, num GunNum)
  SwSetIntForceData GunNum \TipForce:=Force.tip_force
  \ForceTime:=Force.force_time
  \PlateThickness:=Force.plate_thickness
  \PlateTolerance:=Force.plate_tolerance
  \TipForce2:=Force.tip_force2
  \ForceTime2:=Force.force_time2;
ENDPROC
```

- 1 The robot executes a `SetForce` instruction and calls the `SwSetIntForceData` routine.
 - 2 The internally used forcedata parameters are updated and used during the process.
-

Syntax

```
[ GunNum ':' ] < expression (IN) of num >
[ '\ TipForce ':' ] < expression (IN) of num > ]
[ '\ ForceTime ':' ] < expression (IN) of num > ]
[ '\ PlateThickness ':' ] < expression (IN) of num > ]
[ '\ PlateTolerance ':' ] < expression (IN) of num > ]
[ '\ TipForce2 ':' ] < expression (IN) of num > ]
[ '\ ForceTime2 ':' ] < expression (IN) of num > ]';
```

5.3.5 SwSetIntGunData - Set the internal gundata

Description

The `SwSetIntGunData` routine is used to transfer user gundata components to internally used gundata components.

Example

An example of the function `SwSetIntGunData` used in the `DefineGunData` routine is illustrated below.

```
PROC DefineGunData()
  SwSetIntGunData GunNum \GunName:=curr_gundata{GunNum}.gun_name
                  \TotalTipWear:=curr_gundata{GunNum}.curr_tip_wear;
ENDPROC
```

- 1 The robot executes a `SpotL` instruction and calls the `SwSetIntGunData` routine.
- 2 The internally used gundata parameters are updated and used during the process.

Syntax

```
[ GunNum ':=' ] < expression (IN) of num >
[ '\' GunName ':=' ] < expression (IN) of string >
[ '\' CurrWearFix ':=' ] < expression (IN) of num > ]
[ '\' CurrWearMov ':=' ] < expression (IN) of num > ]
[ '\' TotalTipWear ':=' ] < expression (IN) of num > ]
[ '\' MaxTipWear ':=' ] < expression (IN) of num > ]
[ '\' ReleaseDist ':=' ] < expression (IN) of num > ] ';'

```

5 RAPID references

5.3.6 SwSetIntSimData - Set the internal simdata

5.3.6 SwSetIntSimData - Set the internal simdata

Description

The `SwSetIntSimData` routine is used to transfer user `simdata` components to internally used `simdata` components.

Example

An example of the function `SwSetIntSimData` used in the `DefineSimData` routine is illustrated below.

```
PROC DefineSimData()  
  SwSetIntSimData \SimType:=curr_simdata.sim_type  
                \SimTime:=curr_simdata.sim_time  
                \InhibGunClose:=curr_simdata.inhib_close;  
ENDPROC
```

- 1 The robot executes a `SpotL` instruction and calls the `SwSetIntSimData` routine.
 - 2 The internally used `simdata` parameters are updated and used during the process.
-

Syntax

```
[ '\ SimType :=' ] < expression (IN) of num > ]  
[ '\ SimTime :=' ] < expression (IN) of num >  
[ '\ InhibGunClose :=' ] < expression (IN) of bool > ]  
[ '\ PlatesCheck :=' ] < expression (IN) of bool > ]';'
```


5.3.7 SwGetCalibData - Get the latest total tip wear and position adjustment

Description

SwGetCalibData can be used to retrieve the current total tip wear and positional adjustment for the specified gun after a CalibL/J or Calibrate instruction has been run.

Example

A basic example of the routine SwGetCalibData is illustrated below.

```
PROC MyProc()
  VAR num curr_tip_wear;
  VAR num curr_pos_adj;
  CalibL p10, vmax, gun1\TipChg, z50, tool1;
  SwGetCalibData \CurrTipWear:=curr_tip_wear
  \CurrPosAdj:=curr_pos_adj;
ENDPROC
```

- The robot executes a CalibL instruction to the position p10.
- The instruction SwGetCalibData are called.
- The curr_tip_wear and curr_pos_adj variables are assigned with the return values from the CalibL instruction.

Syntax

```
[ GunNum ':=' ] < expression (IN) of num > ]
[ '\ CurrTipWear ':=' ] < expression (INOUT) of num > ]
[ '\ CurrPosAdj ':=' ] < expression (INOUT) of num > ]';'
```

5 RAPID references

5.3.8 SwGetFixTipData - Get the latest fixed tip wear and position adjustment

5.3.8 SwGetFixTipData - Get the latest fixed tip wear and position adjustment

Description

SwGetFixTipData can be used to retrieve the current fixed tip wear and positional adjustment for the specified gun after a MeasureWearL or ReCalcTCP instruction has been run..

Example

A basic example of the routine SwGetFixTipData is illustrated below.

```
PROC MyProc()  
  VAR num curr_tip_wear;  
  VAR num curr_pos_adj;  
  ReCalcTCP gun1\TipWear, tool1;  
  SwGetFixTipData \CurrTipWear:=curr_tip_wear  
    \CurrPosAdj:=curr_pos_adj;  
ENDPROC
```

- The robot executes a ReCalcTCP instruction.
 - The instruction SwGetFixTipData is called.
 - The curr_tip_wear and curr_pos_adj variables are assigned with the return values from the ReCalcTCP instruction.
-

Syntax

```
[ GunNum ':=' ] < expression (IN) of num > ]  
[ '\ CurrTipWear ':=' ] < expression (INOUT) of num > ]  
[ '\ CurrPosAdj ':=' ] < expression (INOUT) of num > ]';'
```

5.3.9 SwGetCurrThickness - Get the latest measured thickness for a spot instruction

5.3.9 SwGetCurrThickness - Get the latest measured thickness for a spot instruction

Description

SwGetCurrThickness can be used to retrieve the current plate thickness for the specified gun after a SpotX instruction has been run..

Example

A basic example of the routine SwGetCurrThickness is illustrated below.

```
PROC MyProc()  
  VAR num curr_thickness;  
  SpotL p10, vmax, gun1, spot1, tool1;  
  curr_thickness := SwGetCurrThickness(gun1);  
ENDPROC
```

- The robot executes a SpotL instruction.
- The instruction SwGetCurrThickness is called.
- The curr_thickness variable are assigned with the measured thickness from the SpotL instruction.

Syntax

```
SwGetCurrThickness ('[ GunNum :='] < expression (VAR) of num >  
  ')'
```

A function with a return value of data type num.

5 RAPID references

5.3.10 SwGetCurrProcInfo - Get the latest process data for a spot instruction

5.3.10 SwGetCurrProcInfo - Get the latest process data for a spot instruction

Description

`SwGetCurrProcInfo` can be used to retrieve latest process information for the specified gun after a `SpotX` instruction has been run.

Example

A basic example of the routine `SwGetCurrProcInfo` is illustrated below.

```
PROC MyProc()  
  VAR swprocinfo curr_proc_info;  
  SpotL p10, vmax, gun1, spot1, tool1;  
  SwGetCurrProcInfo gun1, curr_proc_info;  
ENDPROC
```

- The robot executes a `SpotL` instruction.
- The instruction `SwGetCurrProcInfo` is called.
- The `curr_proc_info` string array variable is assigned with the latest process information from the `SpotL` instruction.



Note

The content of this data may be changed and/or expanded in later software releases.

Syntax

```
[ GunNum ':=' ] < expression (IN) of num > ]  
[ ProcessInfo ':=' ] < expression (INOUT) of swprocinfo > ]';'
```

5.3.11 SwDebugState - Activate and deactivate debug state

Description

The `SwDebugState` routine can be used to activate or deactivate debug mode for the spot instructions. Log results will be stored in a log file located in the `Home/Spot/Logs` directory, `SwDebug.log`.



Note

Do not use the debug mode unless there is a specific need for it. If activated cycle time will be increased.

Example

An example of the instruction `SwDebugState` is illustrated below.

```
PROC main()  
  SwDebugState \On;  
  SpotL p100, vmax, gun1, spot10, tool1;  
  SwDebugState \Off;  
ENDPROC
```

- 1 The robot executes the `SwDebugState` instruction with switch `\On` to activate the logging.
- 2 The robot executes a `SpotL` instruction.
- 3 The robot executes the `SwDebugState` instruction with switch `\Off` to deactivate the logging.

Syntax

```
[ '\ ' On ]  
[ '\ ' Off ] ';' ]
```

5 RAPID references

5.3.12 SGClose - Used to close a servo gun

5.3.12 SGClose - Used to close a servo gun

Description

SGClose (Servo gun close) can be used to close the servo gun with a specific force. The gun will stay in force control mode until the instruction **SGOpen** is executed.

Example

```
PROC tipdress()
VAR string gun1:="SGUN_1";
.....
! Note that the gun will move to current robtarger position, if
  already in independent mode.
STIndGunReset gun1;
.....
! The gun will move to a position just above the cutters.
STIndgun gun1, 30;
.....
SetDO doStartDresser, 1;
! The gun will close with reduced speed, 10% not to slam into the
  cutters.
SGClose gun1, 1500, 20 \GunSpeed:=10;
WaitTime 1;
! The gun will open with reduced speed, 10% to remove eventual
  chips on the electrodes.
SGOpen gun1 \GunSpeed:=10;
SetDO doStartDresser, 0;
.....
STIndGunReset gun1;
ENDPROC
```

Independent mode is activated and the gun is moved to a position just above the cutters (30 mm). During independent mode the dresser is started and the instruction **SGClose** is executed with reduced gun speed, without interfering with robot motion. After the dress time of 1 second the instruction **SGOpen** is executed with reduced speed and the dresser is stopped. The instruction **STIndGunReset** will take the gun out of independent mode and move the gun to current robtarger position.

Arguments

SGClose GunName, GunForce, Thickness [**RetThickness**] [**GunPos**]

GunName

Data type: string
The name of the servo gun.

GunForce

Data type: num
The desired gun force [N].

Continues on next page

Thickness

Data type: num

The expected contact position for the servo gun [mm].

\RetThickness

Data type: num

The achieved thickness [mm].

\GunSpeed

Data type: num

The closing speed of the servo gun in percent, 0 - 100%.

Program execution


If the servo gun exists then it is ordered to close to the expected thickness and force. The closing will start to move the gun arm to the expected contact position (thickness). The movement is stopped in this position, and a switch from position control mode to force control mode is done.

The movable gun arm of the gun is moved with max speed and acceleration as it is defined in the system parameters for corresponding external axis. If the optional argument \GunSpeed is used the speed of the gun arm can be reduced. As for other axes movements, the speed is also reduced in manual mode. When the desired tip force is achieved the instruction is ready and the achieved thickness is returned if the optional argument \RetThickness is specified.

It is possible to close the servo gun during a programmed robot movement as long as the robot movement **does not** include a movement of the movable gun arm. For more details see Servo tool motion control.

Error handling

The following recoverable errors are generated and can be handled in an error handler. The system variable ERRNO will be set to:

| Name | Cause of error |
|-----------------|---|
| ERR_NO_SGUN | The specified servo tool name is not a configured servo gun (mecunit). |
| ERR_SGUN_ESTOP | Emergency stop during servo gun movement.  Note Note that if the instruction is invoked from the main task then the program pointer will be stopped at the instruction, and the instruction will be restarted from the beginning at program restart. |
| ERR_SGUN_MOTOFF | The instruction is invoked from a background task and the system is in motors off state. |
| ERR_SGUN_NOTACT | The servo gun mechanical unit is not activated. Use instruction ActUnit to activate the servo gun. |

Continues on next page

5 RAPID references

5.3.12 SGClose - Used to close a servo gun

Continued

| Name | Cause of error |
|------------------|---|
| ERR_SGUN_NOTOPEN | The servo gun is not open when SGClose is invoked. |
| ERR_SGUN_NOTINIT | The servo gun position is not initialized. The servo gun position must be initialized the first time the gun is installed or after a fine calibration is made. Use the service routine ManualServiceCalib. The current tip wear data will be reset in this case. |
| ERR_SGUN_NOTSYNC | The servo gun position are not synchronized. The servo gun tool position must be synchronized if the revolution counter has been lost and/or updated. Use the service routine ManualServiceCalib. Tip wear data will not be reset in this case. |

Syntax

```
SGClose
  ['GunName ':='] < expression (IN) of string > ','
  ['Gunforce ':='] < expression (IN) of num > ','
  ['Thickness ':='] < expression (IN) of num >
  ['\ ' RetThickness ':='] < variable or persistent (INOUT) of num
    ] >
  ['\ ' GunSpeed] < expression (IN) of num > ] ';'

```

Related information

| | Described in: |
|---------------|--|
| SGOpen | SGOpen - Used to open a servo gun on page 185 |
| STIndGun | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| STIndGunReset | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |

5.3.13 SGOpen - Used to open a servo gun

Description

SGOpen (Servo gun open) can be used to open a servo gun.

Example

Example 1:

```
SGOpen "SGUN_1";
Open the servo gun SGUN_1.
```

Example 2:

```
SGOpen "SGUN_1" \WaitZeroSpeed;
Stop the servo gun SGUN_1, wait until any coordinated movement has
finished, and then open the servo gun SGUN_1.
```

Arguments

STOpen GunName [WaitZeroSpeed] [GunSpeed]

GunName

Data type: string
The name of the servo gun.

[\WaitZeroSpeed]

Data type: switch
Stop the servo gun, wait until any coordinated movement has finished, and then open the servo gun.

GunSpeed

Data type: num
The opening speed of the servo gun in percent, 0 - 100%.

Program execution

If the servo gun exists then the servo gun is ordered to open. The tip force is reduced to zero and the movable gun arm is moved back to the pre_close position. The movable gun arm is moved with max speed and acceleration as it is defined in the system parameters for the corresponding external axis. If the optional argument \GunSpeed is used the speed of the gun arm can be reduced. As for other axes movements, the speed is also reduced in manual mode.

It is possible to open the gun during a programmed robot movement as long as the robot movement **does not** include a movement of the movable gun arm. If the gun is opened during such movement then an error *50251 Tool opening failed* will be displayed. The switch \WaitZeroSpeed can be used to reduce the risk for this error.

For more details, see Servo tool motion control.

Continues on next page

5 RAPID references

5.3.13 SGOpen - Used to open a servo gun

Continued

Error handling

The following recoverable errors are generated and can be handled in an error handler. The system variable ERRNO will be set to:

| Name | Cause of error |
|------------------|---|
| ERR_NO_SGUN | The specified servo gun name is not a configured servo gun (mecunit). |
| ERR_SGUN_NOTACT | The servo gun mechanical unit is not activated. Use instruction ActUnit to activate the servo gun. |
| ERR_SGUN_NOTINIT | The servo gun position is not initialized. The servo gun position must be initialized the first time the gun is installed or after a fine calibration is made. Use the service routine ManualServiceCalib. The current tip wear data will be reset in this case. |
| ERR_SGUN_NOTSYNC | The servo gun position are not synchronized. The servo gun tool position must be synchronized if the revolution counter has been lost and/or updated. Use the service routine ManualServiceCalib. Tip wear data will not be reset in this case. |

Syntax

```
SGOpen  
  ['GunName ':= ' ] < expression (IN) of string >  
  ['\ ' WaitZeroSpeed ]  
  ['\ ' GunSpeed ':= ' < expression (IN) of num > ] ';' ;
```

Related information

| | Described in: |
|---------------|--|
| SGClose | SGClose - Used to close a servo gun on page 182 |
| STIndGun | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| STIndGunReset | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |

5.4 System modules

5.4.1 SWUSER

Description

The `SWUSER` user module is configured to run in all tasks in the system, and contains the default spot data definitions, and routines that can be used to shape the behavior of the process, e.g add additional supervisions in the process sequence if needed.

In normal cases there is no need to change the content of this module. The default functionality should be good enough in most cases. But if the default data types needs to be modified for any reason, and/or additional logic has to be added in the process sequence this module needs to be changed. See [How to change the Spot data types on page 287](#).

It contains process routines (hooks) (for example `SwPreWeld` and `SwPostWeld`), and it also contains a supervision task routine where custom functionality/supervision can be added if needed.

The process routines has no default functionality, but can easily be changed to fit different environment/equipment in case the default process behavior is not suitable, for example, add supervision in the process sequence.



Note

Default content depends on the spot configuration.



Note

After changing any routines in `SWUSER`, the following steps must be taken before there is an effect on the application:

- Save `SWUSER`. The old one is overwritten.
- Generate a Reset Rapid restart to affect all tasks.

Data definitions

The following global data records are predefined.

| Record data | Description | Default value |
|-------------|-------------------------------|---|
| forcedata | Definition of force data | num tip_force; num force_time; num plate_thickness; num plate_tolerance; |
| simdata | Definition of simulation data | num sim_type; num sim_time; bool inhib_close; bool no_plates; |

Continues on next page

5 RAPID references

5.4.1 SWUSER

Continued

| Record data | Description | Default value |
|-------------|---------------------------------|--|
| spotdata | Definition of process spot data | dnum prog_no; num tip_force; num plate_thickness; num plate_tolerance; |
| gundata | Definition of process gun data | string gun_name; num weld_counter; num max_nof_welds; num curr_tip_wear; num max_tip_wear; num curr_wear_fix; num curr_wear_mov; |



Note

Some of the parameters in gundata only concerns servo guns and Software Equalizing and depends on the selected configuration.

Data

The names are predefined and used internally when Spot instructions are used. They must therefore not be deleted or renamed.

Global data

The following global data are predefined:

| Name | Declaration | Description |
|-------------------|----------------|---|
| curr_gundata{4} | PERS gundata | Current gun specific data for gun equipment 1 to 4. |
| curr_spotdata{4} | PERS spotdata | Current or latest used spot data for gun equipment 1 to 4. Is automatically updated from the instruction before the first process hook is called. This data is used when the manual action <code>ManualSpot</code> is activated. |
| curr_forcedata{4} | PERS forcedata | Current or latest used forcedata for gun equipment 1 to 4. Is automatically updated when the <code>SetForce</code> instruction are run. Is also used when manual actions are activated (<code>ManualGunControl</code> and <code>ManualSetForce</code>). |
| curr_simdata | PERS simdata | Current parameters for simulation. These parameters have influence on all used equipment. |
| tw_ref_dist{4, 2} | PERS num | Distance to the reference surface for the reference fixed tip. See Tip measurement sequence on page 210 . (This only concerns Spot servo equalizing) |
| tw_ref_tool{4} | PERS tooldata | Reference tooldata for each gun, used in software equalizing. See Tip measurement sequence on page 210 . (This only concerns Spot servo equalizing) |

Continues on next page

| Name | Declaration | Description |
|-------------------|-------------|---|
| reference_done{4} | PERS bool | Boolean used in routine ReCalcTCP to check if a reference measurement has been done. (This only concerns Spot servo equalizing) |

Process hooks

The following predefined routines are installed with the application. They are called from the kernel during the process. These routines has no default functionality but can easily be modified to fit specific equipment's.

Parameters description for the process hooks:

- num GunNum: Gun equipment number.
- INOUT ErrText: Error message. If an error text is returned in this parameter it will generate an error dialog with possibilities for the operator to decide what to do. If ErrText = "Retry" is returned from some of the hooks then no interaction with the operator will be performed. The process is restarted from the beginning.



Note

The process hooks below is run from the internal process task(s) in the application when running spot instructions. However the SwErrorRecover hook is **only** run from the robot task, so any errors raised from the process hooks will be handled in the robot task.



Note

Any errors discovered in the process hooks should be raised and then handled in the SwErrorRecover hook.

PROC SwInitUserIO(num GunNum)

This routine is the first called process hook, called in the beginning of the motion towards the position.

There is no default functionality.

PROC SwPrepare(num GunNum, INOUT string ErrText)

This routine is called in the beginning of the motion part but after SwInitUserIO. See [The Spot Media Equipment instance on page 46](#).

No default functionality.

PROC SwCloseGun(num GunNum, INOUT string ErrText)

This routine is called a predefined time, pre closing time before the robot TCP reaches the weld position. See [The Spot Gun Equipment instance on page 39](#)

No default functionality.



Note

The presence of this routine depends on the selected spot configuration.

Continues on next page

5 RAPID references

5.4.1 SWUSER

Continued

PROC SwPreWeld(num GunNum, INOUT string ErrText)

This routine is called in the weld position and is the last routine to be called before the start signal to the timer is activated. See [The Spot Weld Equipment instance on page 33](#).

No default functionality.

PROC SwOpenGun(num GunNum, INOUT string ErrText)

This routine is called just after receiving the weld complete signal from the timer, before the open gun order is activated. See [The Spot Gun Equipment instance on page 39](#).

No default functionality.



Note

The presence of this routine depends on the selected spot configuration.

PROC SwPostWeld(num GunNum, INOUT string ErrText)

This routine is called when the process is ready, after the SwOpenGun is executed.

- If no simulations are active then the weld counter in `curr_gundata` is updated.

PROC SwWeldFault(num GunNum, INOUT string ErrText)

This routine is called when the configured weld timeout time has elapsed without receiving the weld complete signal from the timer, or when receiving the 'fault signal' from the weld timer during the weld sequence. The gun has been ordered to open just before this hook is called. See [The Spot Weld Equipment instance on page 33](#).

Here the weld equipment status can be checked before weld.

PROC SwErrorRecover(num GunNum, string ErrType, string ErrText, \num CurrThickness INOUT num Status)

This routine will be called instead of the built-in error handling from the motion task if the process configuration data `User defined error handling` is set to Yes. When using this routine it is possible to customize the error dialogs on the FlexPendant when an error has occurred. No means that default built-in error recovery is used. See [The Spot Error Handling instance on page 30](#).

| Parameter | Description |
|-----------|--------------------|
| GunNum | Current gun number |

Continues on next page


| Parameter | Description |
|-----------|--|
| ErrType | <p>Type of error that occurred. Possible cases are:</p> <ul style="list-style-type: none"> • SW_PREPARE_ERR: prepare error. Error reported in the prepare sequence or by the <code>SwPrepare</code> routine. • SW_CLOSE_GUN_ERR: close gun error. Error reported in the close gun sequence or by the <code>SwCloseGun</code> routine. • SW_PRE_WELD_ERR: preweld supervision error. Error reported in the preweld sequence or by the <code>SwPreWeld</code> routine. • SW_WELD_ERR: weld error timeout. • SW_WELD_TEST_ERR: weld test error timeout. Error if test weld error in the <code>CalibL</code> or <code>CalibJ</code> instructions. • SW_OPEN_GUN_ERR: open gun error. Error reported in the open gun sequence or by the <code>SwOpenGun</code> routine. • SW_POST_WELD_ERR: postweld supervision error. Error reported in the post weld sequence or by the <code>SwPostWeld</code> routine. • SW_TIP_POS_ERR: tip position error. Only for servo guns. • SW_PROG_VALID_ERR: program valid timeout. • SW_WATER_SUP_ERR: water flow timeout. Water flow error reported by the <code>SW_SUP</code> task if the continuous water supervision is activated. See The Spot Media Equipment instance on page 46. • SW_MEAS_TIP_CHANGE_ERR: Tip change supervision error in the <code>MeasureWearL</code> instruction. • SW_MEAS_TIP_WEAR_ERR: Tip wear supervision error in the <code>MeasureWearL</code> instruction. • SW_RECAL_TIP_WEAR_ERR: Tip wear supervision error in the <code>ReCalcTCP</code> instruction. • SW_CALIB_TIP_CHANGE_ERR: Tip change supervision error in the <code>CalibX</code> instructions. • SW_CALIB_TIP_WEAR_ERR: Tip wear supervision error in the <code>CalibX</code> instruction. |

Continues on next page

5 RAPID references

5.4.1 SWUSER

Continued

| Parameter | Description |
|-----------|--|
| |  Note To retrieve the latest measured data when a tip management error has occurred, the instructions SwGetFixTipData - Get the latest fixed tip wear and position adjustment on page 178 and SwGetCalibData - Get the latest total tip wear and position adjustment on page 177 can be used. |
| ErrText | Text string that was returned by the function that reported the error. |

The return values of this function defines how the Spot options shall resume after this error. There are three possible return values:

| Return value | Description |
|--------------|--|
| SW_RETRY | The weld process is started from the beginning after weld error and after errors reported by: <ul style="list-style-type: none">• SwPrepare• SwCloseGun• SwPreWeld |
| SW_SKIP | The current spot weld process is abandoned and cleaned up. |
| SW_IGNORE | The current tip position error is ignored and the weld is executed again without plate thickness supervision. (Only for servo guns.) |



Note

The number of available user hooks depends on the selected configuration.

Supervision task hook

The SupervisionInit routine is called from the main routine in the SW_SUP task at power on.

- SupervisionInit()

PROC SupervisionInit()

There is no default functionality.

Related information

| | Described in: |
|---------------------------|--|
| Customizing possibilities | Customizing RobotWare-Spot on page 279 |

5.4.2 SWUSRM

Description

The SWUSRM user module is configured to run in all motion tasks in the system, and contains some default Spot related data. It also contains routines for data transfer (for example `DefineSpotData`, used to copy user defined spotdata to internally used spotdata).

In normal cases there is no need to change this module. The default functionality should be good enough in most cases. But if the default data types are changed there may be a need to modify this module also.



Note

Default functionality depends on the spot configuration.



Note

After changing any routines in SWUSRM, the following steps must be taken before there is an affect on the application:

- Save SWUSRM. The old one is overwritten.
- Generate a Reset Rapid restart to affect all tasks




Note

If data is moved from this module the Spot MMI application might not work properly!

Default data

The following default data are predefined.

| Name | Description | Default value |
|---------|--|--|
| gun1, 4 | Gun number used in the spot instruction, gun index number in <code>curr_gundata</code> . | 1 to 4 |
| spot1 | <p>Default spotdata when programming the spot instructions on the FlexPendant.</p> <p> Tip</p> <p>It is possible to use spot data parameters programmed in the weld timer if needed instead of the spotdata parameters, see How to use spot data programmed in the weld timer on page 290.</p> | <p>prog_no - 1</p> <p>tip_force - 1000 N</p> <p>plate_thickness 0 mm</p> <p>plate_tolerance - 0 mm</p> |

Continues on next page

5 RAPID references

5.4.2 SWUSR

Continued

| Name | Description | Default value |
|--------|--|--|
| force1 | Default forcedata when programming the SetForce instruction on the FlexPendant | tip_force - 1000 N force_time 1 s plate_thickness 0 mm plate_tolerance - 0 mm |

Process data routines

These routines can be used to perform actions inside the Spot routines. The following process routines are installed with the application.

PROC DefineUsrData(num GunNum \INOUT gundata UserGunData)

This routine is called in the beginning of all Spot shell routines. Here user gundata can be transferred into the Spot instruction, using this data instead of the default curr_gundata.



Note

The optional \UserGunData parameter will be used if the optional \GunD argument is used in the spot instructions. See [SpotL/SpotJ - The basic spot welding instructions on page 107](#).

```
IF Present (UserGunData) THEN
  curr_gundata{GunNum} := UserGunData;
ENDIF
```

PROC UpdateUsrData(num GunNum \INOUT gundata UserGunData)

This routine is called at the end of all Spot shell routines. Here gundata can be transferred back to the user gundata.



Note

The optional \UserGunData parameter will be used if the optional \GunD argument is used in the spot instructions. See [SpotL/SpotJ - The basic spot welding instructions on page 107](#).

```
IF Present (UserGunData) THEN
  UserGunData := curr_gundata{GunNum};
ENDIF
```

Data definition routines

The following predefined routines are used to transfer user defined data to internally used data. They are used by the spot welding instructions and are called from the kernel during the process. Some of them are also called during system events such like poweron, program start, program stop etc.

Continues on next page

These routines have a default functionality but can easily be changed. The routines cannot be deleted since they are called from internal modules.

PROC DefineSpotData(spotdata Spot, num GunNum)

This routine is executed in the beginning of each `Spot` instruction. Transfer user `spotdata` to internal spot data, that is `spotdata` in the `SpotL` instruction.

The weld program group output signal will be set just after leaving this routine.

See [SwSetIntSpotData - Set the internal spotdata on page 173](#).

PROC DefineGunData()

This routine is executed in the beginning of all `Spot` shell routines, `SwStart` or `SwReStart`. Transfer user gun data to internal gun data, that is `curr_gundata`.

See [SwSetIntGunData - Set the internal gundata on page 175](#).

PROC DefineForceData(forcedata Force, num GunNum)

This routine is executed in the beginning of each `SetForce` instruction. Transfer user `forcedata` to internal force data, that is `forcedata` in the `SetForce` instruction. See [SwSetIntForceData - Set the internal forcedata on page 174](#).

PROC DefineSimData(\num IOCtrlSimType \bool IOCtrlInhibClose \bool IOCtrlNoPlates)

This routine is executed in the beginning of all `Spot` shell routines. Transfer user `simdata` to internal `simdata`, that is `curr_simdata`. See [SwSetIntSimData - Set the internal simdata on page 176](#).

The optional parameters `\IOCtrlSimType`, `\IOCtrlInhibClose` and `\IOCtrlNoPlates` are used when the simulation modes are controlled via optional I/O signals defined in the configuration, see [The Spot System instance on page 27](#). This way the simulation modes can be controlled from a PLC etc.

PROC UpdateCalibData(num TotalTipWear, num WearMoveable, num GunNum \switch ToolChg | switch TipChg | switch TipWear | switch FineCalib)

This routine updates the current tipwear parameters in `curr_gundata`. It is executed at the end of each `CalibL/J` and `Calibrate` instruction.

PROC UpdateFixTipData(num CurrWearFixed, num DiffDistance, num GunNum \switch Reference | switch TipChange | switch TipWear | switch RefChange)

This routine updates the current fixed tipwear parameters in `curr_gundata`. It is executed at the end of each `MeasureWearL` and `ReCalcTcp` instruction.



Note

This routine is only present if the `SoftWare Equalizing` option is selected.

PROC UpdateSpotData(z_int_spotdata Spot, num GunNum)

This routine updates the `curr_spotdata` with the latest used `spotdata`. It is executed at the start of motion, that is when the robot starts to move.



Note

Default functionality depends on the spot configuration.

Continues on next page

5 RAPID references

5.4.2 SWUSRM

Continued

Event routines

The following predefined event routines are installed with the application. These routines have no default functionality but can easily be changed. If not needed they can be removed.

PROC SwPowerOn()

This routine is called when the robot is restarted (warm started) or by power on. There is no default functionality.

PROC SwStart()

This routine is called when execution is started from the beginning of the program. There is no default functionality.

PROC SwReStart()

This routine is called when execution is started from the position where it was stopped.

There is no default functionality.

PROC SwStop()

This routine is called when the program is stopped.

There is no default functionality.

PROC SwQStop()

This routine is called when the robot is quick stopped (E-stop).

There is no default functionality.

6 Software Equalizing

6.1 Introduction to Software Equalizing

Introduction

This chapter describes the Software Equalizing functions. These functions makes it possible to use spot welding guns without mechanical equalizing systems. The functions are available if the *Spot Servo Equalizing* configuration is installed.

Available functions

The Software Equalizing functions are a number of functions intended to handle these issues for the user. However, it is not always necessary to use all functions. It depends on desired accuracy, sheet stiffness, gun properties as type, size and stiffness and so on.

The following Equalizing functions are available:

- Weld position Touch Up.
- Release of the fixed gun arm.
- Gun arm Deflection Compensation.
- Tip Wear Measurement and Compensation.
- Movable gun arm search.

It is possible to use guns with mechanical equalizing and guns using Software Equalizing in the same user program. The equalizing type is determined in the process data `Use SoftWare equalizing` located in `Spot Gun Equipment`. For more information, see [gundata - Equipment specific weld data on page 152](#).

Recommendations

When guns without mechanical equalizing systems are used it is very important to have good accuracy when the TCP is defined and when the weld positions are taught.

It is also important to handle the tip wear and recalculate the TCP regularly and also to release the fixed gun arm from the sheet when the gun is moved between weld positions. For most guns it is also necessary to handle the gun arm deflection during the weld.



Note

When using Software equalizing it is important to have good control of the part tolerances and the tip wear of the electrodes. This functionality can only tolerate variations up to approximately 1-2 mm.

Limitations

- The functions Gun Arm Release and Deflection Compensation are available for the `SpotL/SpotJ` instructions are used.

Continues on next page

6 Software Equalizing

6.1 Introduction to Software Equalizing

Continued

- The gun pre closing time is **not** used when software equalizing is active. In this case the pre closing is handled automatically during the movement from the release distance to the weld position.
- For some special configurations an acceptable touch up position can be hard to reach with the `MeasureWearL` instruction. If that is the case, `ReCalcTcp` instruction can be used as an alternative method.
- It is not possible to run `SpotL/SpotJ` instructions with software equalizing active if independent mode is activated.
- It is only possible to run spot instructions in semi coordinated mode.
- When using only gun arm deflection compensation it is important to have good control of the tolerances of the parts, and the wear of the electrodes. This functionality can only tolerate variations up to approximately 1-2 mm.



Note

Software Equalizing functions does not work for the `SpotML` and `SpotMJ` instructions.

6.2 Some basic definitions


How to define the TCP

The TCP has to be defined, as normally, on the tip of the fixed gun arm.

It is important to define also the z-direction in the tool coordinate system since all automatically search movements and compensations will be done in the z-direction. See the graphics below.

Normally the z-direction should point out from the fixed tip, and the tip of the gun should move towards the work piece when jogging the robot in the positive z-direction.

To achieve the same behavior on a stationary tool the z-direction needs to be reversed into the fixed tip, and in order to get the correct search and compensation movements, the setup data `Opposite z-direction` has to be set to `Yes` in `Spot Gun Equipment` process data, see [The Spot Gun Equipment instance on page 39](#).



en120000236

| | |
|---|--|
| A | Directions in the tool coordinate system |
| B | TCP |
| C | Fixed electrode |


Continues on next page

6 Software Equalizing

6.2 Some basic definitions

Continued

The z-direction when different gun types are used:



en120000235



Note


It is very important to define the z-direction correctly in the tool coordinate system since all automatically search movements and compensations will be done in the z-direction.

How to set up the tool TCP

- 1 Define the TCP for the used gun with a new tip mounted. Use the 5 point method.
See Operating manual - IRC5 with FlexPendant.
- 2 Store the result in a `tooldata` for example `ref_tool1`.
- 3 Save the tip (tool) as a reference tip (the physical tip).

Continues on next page

How to program the weld positions



en120000234

| | |
|---|--------------------------|
| A | Fixed tip |
| B | Programmed weld position |

The weld position should be taught in the position where the fixed electrode is touching the sheet during the weld process. See the graphic above.

**Note**

Before touching up the weld positions a `MeasureWearL` with the `Reference` switch has to be done. See [Tip measurement sequence on page 210](#).

6 Software Equalizing


6.3 Weld position Touch Up

6.3 Weld position Touch Up

Introduction

This is a support function used in manual mode to get a faster and easier way to adjust the programmed weld positions. During the touch up it is possible to change the fixed gun tip in the z-direction and it is also possible to change the position for the movable gun arm.

Normally a touch up has to be done at least once in the beginning after manual or offline programming of the weld positions.



en1200000232

| | |
|---|------------------|
| A | Movable tip |
| B | Fixed tip |
| C | Release distance |

How to use the weld position touch up function

- 1 Make sure that current TCP is relevant for the used tip, define the tool data correctly.
- 2 Set the system in weld position 'touch up mode' in the simulation view in Spot UI, or via the I/O signal interface. See [simdata - Simulation data on page 164](#).
- 3 Start the program. The robot is running the program as normal, but all `SpotL` and `SpotJ` instructions are executed as move instructions.
- 4 The robot stops in each programmed weld position and a user interaction is started which gives possibilities to confirm and directly go to next spot, or adjust or weld current position.
- 5 During adjustment the fixed gun tip is moved in small steps to the sheet or to desired distance from the sheet.

It is also possible to adjust the position of the movable gun arm in a similar way.

Continues on next page

- 6 When both tips are in desired position it is possible to do a **Modpos**, with confirmation, to definitely reprogram the position.
- 7 When the gun is moved between programmed weld positions the fixed gun tip is automatically released from the sheet.

Desired distance to the sheet is a user defined data predefined for each used `gun`, `release_dist`.

This release movement can be skipped to save cycle time if the optional switch `\QuickRelease` is selected in the `SpotL` or `SpotJ` instruction.

See [gundata - Equipment specific weld data on page 152](#) and [SpotL/SpotJ - The basic spot welding instructions on page 107](#).

- 8 When all weld positions are checked, reset the simulation mode to disable the 'touch up mode' mode.

See [gundata - Equipment specific weld data on page 152](#).


6 Software Equalizing

6.4 Releasing of the fixed gun arm and gun opening

6.4 Releasing of the fixed gun arm and gun opening

Description

This function is used to get an automatic release of the fixed gun arm from the sheet, when the gun is moved between the weld positions during normal program execution.



en1200000231

| | |
|---|-------------------|
| A | Movable electrode |
| B | Fixed electrode |
| C | The weld position |

Releasing the fixed gun arm

During execution of `SpotL/SpotJ` instructions, the robot moves the gun to the weld position, via a position a release distance from the sheet.

After the weld when the gun is opened, an extra movement is performed to release the fixed gun arm from the sheet except if the `QuickRelease` functionality is activated in the `SpotL/SpotJ` instruction.

If the `\QuickRelease` switch is selected in the `SpotL/SpotJ` instruction the release distance movement after the weld will be skipped, this may save some cycle time and can be used when the spots are located close together



Note

The `\QuickRelease` function is suitable when programming close weld positions, not when there are large distances between the weld positions.

The release distance, `release_dist`, is a user defined data predefined for each used gun. see [gundata - Equipment specific weld data on page 152](#).

Continues on next page

This function will be disabled if `release_dist` is set to zero or if `softw_equ` is set to `FALSE` in current `gundata`.



Note

To get a good synchronization between the release movement and the gun opening when software equalizing is used, the gun is always held in the closed state 40 ms extra after weld complete. To save cycle time, the programmed cool time after weld in the weld controller can be reduced this amount of time (2 periods).

Gun opening

The gun opening gap must be large enough that the tips are free from the plates when welding.

So therefore, the software will compensate for the release distance that is used, and the plate thickness, as the opening position is the same as the tips closed with plates + `release_dist`.

Example:

If `release_dist` is 10mm, the moving tip will open to 10mm even if you modify the position with the gun closed on the plate surface.

A simple recommendation is to have approximately the same distance from the plate to the movable electrode as the `release_dist` that has been configured.

For more information about the `release_dist` parameter, see [Additional components for Spot Servo Equalizing on page 153](#).

6 Software Equalizing


6.5 Gun arm deflection compensation

6.5 Gun arm deflection compensation

Introduction

Most weld guns deflects more or less depending on the stiffness of the gun arms when the gun is closed with force. In these cases there is a need to compensate for the fixed gun arm bending with an extra **robot movement** to minimize the risk of deformation on the sheets. The deflection compensation can be done in the tool z and x-direction.

With this function the gun arm deflection is automatically compensated with an extra **robot movement** when the gun is closed and the gun force is applied. See graphic below.




xx1200000230

| | |
|---|-----------------------------|
| A | Sheets |
| B | Robot flange |
| C | Gun arm deflection |
| D | Robot compensation movement |

The graphic shows gun arm deflection in both z and x-directions, and robot compensation movement in the opposite directions. If the gun bends outwards (positive x), the robot will move in the opposite direction.

Continues on next page



en1200000229

Data

Data for the correlation between the gun force and the arm deflection is user defined data, predefined for each used gun: deflection_dist_z, deflection_dist_x, deflection_force and deflection_time, see [gundata - Equipment specific weld data on page 152](#). This data is normally found in the data sheet for the used gun.

Then, during program execution of SpotL/J instructions, there is an added robot movement, activated at the same time as the gun force is established, to compensate for the gun arm deflection, see graphics above.

The actual gun arm deflection is calculated from the force value (tip_force) in current spotdata. Deflection calculation in SpotL/SpotJ instruction.

```
deflection := spotdata.tip_force * gundata.deflection_dist /
gundata.deflection_force;
deflection := spotdata.tip_force * gundata.deflection_dist /
gundata.deflection_force;
```

A movement in the opposite direction is performed after the weld, when the gun is opened. This movement is combined with the release movement.

Continues on next page

6 Software Equalizing

6.5 Gun arm deflection compensation

Continued

This function is disabled if the deflection distance parameters are set to zero, or if the `Spot Gun Equipment, Use Software equalizing setup data` is not activated.

How to setup the data for gun arm deflection

- 1 Find out how much gun arm deflection there is at a specific force when the gun arms are closed, this data is normally found in the data sheet for the used gun.



Tip

If this information is missing the gun arm deflection can be measured manually by closing the gun at a specific force, for example 4000 N and measure how much the gun arm deflects related to a fixed reference position on the tip dresser stand or using a dial indicator.

- 2 Enter the measured values in `gundata`, `deflection_dist_z` and `deflection_force`, for example 5 mm at 4000 N.
See [gundata - Equipment specific weld data on page 152](#).
- 3 Save the user module `swuser.sys` since the current `gundata` is located there.

6.6 Tip wear compensation

Introduction

When guns without mechanical equalizing systems are used, it is important to handle the tip wear, especially the tip wear on the fixed tip, since this tip is controlling the weld position. Therefore the tip wear has to be regularly compensated during production. There are two methods available for the compensation.

Method 1


`MeasureWearL`, the tip wear for the fixed tip is measured and the tip wear is then compensated in current used `tooldata`.

Method 2

`ReCalcTcp`, the tip wear of the fixed tip is calculated based on stored information about the total tip wear and the expected relation between the tip wear of the fixed tip and the total tip wear. The tip wear is then compensated in current used `tooldata`. This method can be used as an alternative if method 1 is not suitable.

Method 1: Tip wear measurement and compensation with `MeasureWearL`

A RAPID instruction is available for tip wear measuring and TCP adjustment: `MeasureWearL`. This instruction is used one time for a reference measurement with new tips and then one time after each tip dressing and after the tips have been exchanged.



en1200000228

A code sequence with the measuring instruction included has to be prepared in the user program. The position in the `MeasureWearL` instruction has to be programmed close to a fix reference plate, see figure above. Also see [Measurement preparation on page 134](#).

When the instruction is executed the robot first moves the gun to a start position for the search movement about 10 mm from the reference plate. Then the gun is moved until the fixed gun tip touches the reference plate. The tip wear of the fixed

Continues on next page

6 Software Equalizing

6.6 Tip wear compensation

Continued

gun tip is calculated. Currently used TCP value is automatically recalculated and tip wear data for the fixed tip in `gundata` is automatically updated.



Note

This movement of 10mm has to take care of the wear of the tips that could be for example 20mm, it means that the total gun opening should take care of the 10mm position, the plate thickness and the total wear of the tips.

When using this method the gun calibration instructions (`Calibrate` or `CalibL/J`) has to be executed **after** `MeasureWearL` since the moveable tip wear will be calculated based on the result of the measurement.

The reference plate can be mounted in an optional position in the work range, preferably on the tip dresser stand. But it is necessary to orient the tool in the measuring position in that way that an additional torque is generated on at least one of the robot motors when the robot is touching the fixed plate, preferably axis 4 to 6.

It is possible to verify if the selected measuring position or gun orientation is good enough by using a service routine; `ManualCheckMeasPos`. Just run the service routine when the robot is in the selected position and you will get status information on the display.

How to find a good measuring position

- 1 Jog the robot to the position where the fixed plate is mounted, for example on the tip dresser stand.
- 2 Run the service routine `ManCheckMeasPos` to find out if the position is good or not, if not jog/reorient the robot to a new position.

See [Manual actions on page 84](#).

- 3 Create a program with a code sequence with the measuring instruction included.

See [MeasureWearL - Measure current electrode wear and recalculate the TCP on page 133](#).

Tip measurement sequence

The reference measurement with `MeasureWearL \Reference` will calibrate the position of the reference plate for the tip wear measurement with the robot. The parameters of the tool used for the reference measurement (`RefTool`) and the calibration values are stored in the persistent variables `tw_ref_tool` and `tw_ref_dist` located in the user module `swuser.sys`. All following calls of `MeasureWearL (\TipWear, \TipChg)` measures only the difference to the reference position.

The tips (or the real TCP) and the tool (`RefTool`) used for the reference measurement must be the same as used for teaching of the weld positions (`robtargets`).

The reference measurement needs to be done again when the reference plate has been moved or the TCP has been changed (for example after a crash) or the

Continues on next page

`\RefChange` switch can be used instead, see [Measurement after reference plate/sensor changed on page 135](#).

For the measurements the robot contacts the reference surface always with the same force, `MeasureWearL TouchUp` force in the `Spot Equalizing` process configuration. See [The Spot SoftWare Equalizing instance on page 48](#).

Since the calibration values are stored in `swuser.sys` the file should be saved after the reference measurement.

Input values of `CurrTipWear` and `RetPosAdj` in `UpdateCalibData` and `UpdateFixTipData`.

| | <code>CurrTipWear</code> | <code>RetPosAdj</code> |
|---|--------------------------|--|
| <code>Calib* ... \TipWear</code> | 0 | Difference to the last calibration of the gun. Normally last call with <code>\TipWear</code> . Total difference between the new and the old (worn) tips. |
| <code>Calib* ... \TipChg</code> | Total wear of both tips | Difference to the last calibration of the gun. |
| <code>Calib* ... \ToolChg</code> | Total wear of both tips | Difference to the last calibration of the gun. |
| <code>MeasureWearL .. \TipChg</code> | 0 | Difference between the actual and the tip used for the reference measurement. |
| <code>MeasureWearL .. \Reference</code> | 0 | Measured reference distance. |

See [MeasureWearL - Measure current electrode wear and recalculate the TCP on page 133](#).



Note

For some special configurations the `MeasureWearL` is less suitable, for example very large guns and/or when an acceptable touch up position is not possible to reach for some reason. Then the `ReCalcTcp` method should be used instead.

Tip wear measurement and compensation for stationary guns

Generally when stationary tools are used, the work object is held by the robot and related to the wrist coordinate system and the TCP, still defined on the tool, is related to the world coordinate system. This is the case also when stationary guns are used. As before, the TCP has to be defined on the fixed tip and the z-direction has to be defined, see figure below and [How to define the TCP on page 199](#)

The parameter `robhold` in current `tooldata` and `wobjdata` defines whether the robot is holding the gun or not.


Continues on next page

6 Software Equalizing

6.6 Tip wear compensation

Continued

For more information about how to define the stationary tool coordinate system, see *Operating manual - IRC5 with FlexPendant*.




| | |
|---|-----------------|
| A | Fixed electrode |
| B | Gripper |

All Software Equalizing functions are working in a similar way as when the robot is holding the gun. But the tip wear measurement has to be arranged a little different, since it is not possible to use a fix reference plate in this case. To be able to use

Continues on next page

the same principles for the measurement and the `MeasureWearL` instruction, it has to be done as described in following items:



en1200000226

| | |
|---|-----------------|
| A | Fixed electrode |
| B | Gripper |

- Select or create a relatively stable position on the robot held gripper. It shall be possible for the robot to move this point to the fixed gun tip. see an example in the figure above.
- As in the normal case, code sequences with the measuring instructions included have to be prepared in the user program to be used for the reference measurement and for the tip wear measurement.
- We recommend programming the gun calibration instructions in the same code sequences, directly after the tip wear measurement. See [Calibrate - Calibrate a servo gun on page 129](#) and [CalibL/CalibJ - Calibrate a servo gun during robot movement on page 123](#).
- The position in the `MeasureWearL` instruction has to be programmed close to the selected position on the gripper, see graphic above.
- When the instruction is executed the fixed gun tip is touched by the gripper. The tip wear of the fixed gun tip is calculated. Currently used TCP value is automatically recalculated and tip wear data in `gundata` is automatically updated. For more information, see [MeasureWearL - Measure current electrode wear and recalculate the TCP on page 133](#).

Continues on next page

6 Software Equalizing

6.6 Tip wear compensation

Continued

Method 2: Tip wear calculation and compensation with ReCalcTcp

A RAPID instruction to be used for tip wear calculation and TCP adjustment with this method is available: `ReCalcTCP`.

As the measurement instruction used in method 1, `MeasureWearL` this instruction is used one time for a preparation and then one time after each tip dressing and after the tips have been exchanged. But in this case the instruction is a logical instruction without movements.

When the instruction is executed the tip wear of the fixed tip is calculated. The calculations are based on stored information about the total tip wear and the expected relation between the tip wear of the fixed tip and the total tip wear. The tip wear is then compensated in current `tooldata`. Current used TCP value is then automatically recalculated and tip wear data for the fixed tip in `gundata` is automatically updated.

In this case the gun calibration instructions (`Calibrate` or `CalibL/J`) has to be executed **before** `ReCalcTCP` is used since the total tip wear is used for the calculations.

For more information, see [ReCalcTCP - Calculate current electrode wear and recalculate the TCP on page 141](#).

The advantages with the calculation method is that it is faster since no extra measurement has to be done, and it is also easier to set up since no reference position has to be arranged for. The disadvantage is that the compensation will not be as accurate as with the measuring method in the cases when the tip wear ratio value not is set to a value in agreement with the reality, or after tip change if the new tips not have the same size every time.

6.7 Movable gun arm search mode

General

The movable gun arm search method can be used as a complement to the standard software equalizing method if there is a need to compensate for programming errors, or tolerance variations, that is, the plates are not located exactly in the nominal position.

When a spot instruction with search mode activated is run, the robot will move to the programmed and nominal position, and then use the external axis for the gun to search for the plates and adjust the TCP in the tool z-direction based on search hit distance.

Prerequisites

Movable gun arm search mode is available for the `SpotL` and `SpotJ` instructions, and it is only available if the RobotWare options *Spot Welding (635-6)* and *Spot Servo Equalizing* configuration and *Movable gun arm search (1583-1)* are installed together.

Recommendations

When using movable gun arm search mode it is important that the gun search performance is properly tuned.

Some general tips when using movable gun arm search mode:

- Verify that the search performance is tuned properly, bad tuning may have a negative or harder impact on the plates or the search movement may stop before the plates are actually reached.
- The clamping distances cannot be too far apart, as there must be some resistance for the gun arm to react on.

For information about how to tune the search performance, see *Application manual - Servo Gun Setup*.

Limitations

The following limitations apply when using movable gun arm search mode:

- The search performance is gun dependent, and it may be difficult to tune some guns because of various reasons, motor type, construction etc.
- This function should in general have a low force impact on the plates during the welding sequence, however the search performance is dependent on the gun tuning.
- Cannot be used to compensate for too large variations, only up to a few mm.
- Cycle times will be longer when using search mode because of the the slower gun arm speed during the search sequence.



Note

Movable gun arm search mode is only implemented for the `SpotL` and `SpotJ` instructions and does not work for the `SpotML` and `SpotMJ` instructions.

Continues on next page

6 Software Equalizing

6.7 Movable gun arm search mode

Continued



Note

This function allows the tolerances of the parts to vary a bit more compared to using only standard software equalizing. Note that the total weld process cycle time will be longer than without, up to 500 ms per spot depending on the current settings and the actual plate position.

Function overview

Movable gun arm search mode is activated by selecting an optional switch in the `SpotL` and `SpotJ` instructions, see [SpotL/SpotJ - The basic spot welding instructions on page 107](#).

With the `\Search` data activated in the spot instruction the external axis for the gun will be used to search for the plates, and the robot TCP will be adjusted in the tool z-direction based on the search hit distance.



Note

If the normal software equalizing functionality is deactivated then the movable gun arm search mode will also be deactivated, and it is considered that mechanical equalizing system is being used.

Programming

An optional parameter must be activated in the spot instructions to be able to use the movable gun arm search functionality (`\Search`). The parameter is an on/off switch for the search functionality, that is, if the parameter is not used, then the normal software equalizing functionality will be used for that position, see programming example below.

The optional parameter `\Search` of type `searchdata` has one data component for adjusting the position after search, specific for each position.

The `searchdata` has the following structure:

- `search_pos_adjust` (search position adjust) for the specific position.

The parameter `search_pos_adjust` can be used to compensate for soft sheet metal stiffness of the plates for example if the plates are weaker in a specific position. The value can be positive or negative, see [smeqdata - SoftMove Equalizing data on page 167](#).

Example

Program example with and without movable gun arm search functionality: P20 and P50 is executed in standard software equalizing mode.

P30 is executed with in gun arm search mode because of tolerance variations in that specific position. Since the sheet is relatively stiff in this position there is no need to compensate for softer sheet metal.

P40 is also executed with gun arm search mode for the same reason. But because of the softer sheet metal in this specific target, and to not deform the sheet the gun will move back 2 mm to reduce the impact.


Continues on next page

Since the search functionality only is needed in these two specific positions, it is only used there because of the additional cycle time impact.

```
PERS searchdata search1:=[0];
PERS searchdata search2:=[2];
PROC main()
  MoveJ P10, v1000, z50, tool1;
  SpotL P20, vmax, gun1, spot11, tool1;
  SpotL P30, vmax, gun1, spot12 \Search:=search1, tool1;
  SpotL P40, vmax, gun1, spot13 \Search:=search2, tool1;
  SpotL P50, vmax, gun1, spot14, tool1;
ENDPROC
```

Execution

When a spot instruction with \Search data active is run, the robot will move to the programmed and nominal position, and then use the movable gun arm to search for the plates. When the plates are found the position will be recalculated and adjusted in the tool z-direction based on the search hit distance, and the weld will be performed in the new position, see figure below.



SearchSequen

- 1 Movement to the nominal position, via release distance.
- 2 The gun will start the search movement from the open position.
- 3 When the gun hits the plate the position will be recalculated and adjusted in the z-direction based on the search hit distance and the weld will be done from that new position.
- 4 After weld the robot will move out to the release distance at the same time as the gun opens.

Related information

| | Described in |
|----------------|---|
| Manual actions | Manual actions on page 84 |

Continues on next page

6 Software Equalizing

6.7 Movable gun arm search mode

Continued

| | Described in |
|-----------------------|---|
| Process configuration | Spot process configuration on page 25 |
| MeasureWearL | MeasureWearL - Measure current electrode wear and recalculate the TCP on page 133 |
| ReCalcTcp | ReCalcTCP - Calculate current electrode wear and recalculate the TCP on page 141 |
| Customizing | Customizing RobotWare-Spot on page 279 |
| SpotL/SpotJ | SpotL/SpotJ - The basic spot welding instructions on page 107 |
| Search data | searchdata - Search data on page 169 |
| Servo Gun Setup | Application manual - Servo Gun Setup |

6.8 SoftMove Equalizing

Introduction

This section describes the SoftMove Equalizing method which can be used as a complement to the standard software equalizing method if there is a need to compensate for programming errors, for example if the plates are not located in the nominal position.

When a spot instruction with SoftMove activated is run, the robot will move to the programmed and nominal position, and set the robot into soft state using SoftMove in the tool z-direction during the last part of the movement into the position.

Prerequisites

SoftMove Equalizing is available for the `SpotL` and `SpotJ` instructions, and it is only available if the RobotWare options *Spot Servo Equalizing (635-6)* and *SoftMove (885-1)* are installed together.

Recommendations

When using SoftMove Equalizing it is important that the tool data (`tooldata`) is defined correctly, especially the mass. Errors in the load definition will be interpreted as external forces, which in turn can cause the robot to move. Hence, an incorrect definition can cause unwanted robot movements.

Some general tips when using SoftMove Equalizing:

- Verify that the load definition of the tool is correct.
- Avoid singular robot orientations.
- The robot axis configuration will affect the softmove performance, there are configurations where performance can be poor.
- A gun configuration that allows axis 5 movement gives better performance in general (Avoid gun configurations when z-axis of the gun is in linearity with axis 6 of the robot).
- The clamping distances cannot be too far apart, as there must be some resistance for the robot to react on.

For more information about SoftMove, see *Application manual - SoftMove*.

Limitations

The following limitations apply when using SoftMove Equalizing:

- The same limitations as for Software Equalizing also applies for SoftMove equalizing.
- Cannot be used to compensate for too large variations in the objects to be welded, only up to a few mm.
- **Not all** positions or arm configurations are suitable for SoftMove Equalizing, if poor performance (for example not reaching the position or pressing too hard) is experienced, then try to reorient the robot axes or gun arm configuration if possible. Friction force may vary too much so that the force offset needed will be too high, this can deform the plate.

Continues on next page

6 Software Equalizing

6.8 SoftMove Equalizing

Continued

- SoftMove performance will in general depend on robot type, robot arm configuration, gun configuration, and load data definition. Larger robot types will have higher internal gear friction and inertia and that will affect the sensitivity, and it will be harder to find a friction value good enough.
- This function should in general have relatively low impact on the plates, but note that there are positions in the work area where it will be very hard to get good results, and the force applied on plates can be much higher.
- When tuning the friction compensation needed in a position, the robot can move in a unexpected direction because of high friction in axis 2 and/or 3, this may indicate a difficult or unsuitable position.
- Cycle times will be longer when using SoftMove Equalizing because of the the lower TCP speed and gun speed into position, compared to using standard SoftWare Equalizing.
- When tuning the friction compensation in a certain position the value is usually good enough, but the acheived value may need to be manually tuned to get better performance. If the measured value is higher than ~300 N there may also be a need to manually modify the measured value.
- When SafeMove is used together with SoftMove there is a risk for servo lag problems. The recommended action is to add a Contact Application Tolerance (CAP) in the area where SoftMove is active.

When the function is active, that is, during the welding phase in the `SpotL/J` instructions, the following functionality is not accessible:

- *Collision Detection* (option 613-1)



Note

For more information about SoftMove limitations, see *Application manual - SoftMove*.



Note

For safety reasons the position supervision limits in x, y, and z directions has been limited. These values can be changed in the motion parameter configuration if needed, for example type *Motion type CSS* and *Max pos error in z*. Default configuration is x = 10 mm, y = 10 mm, and z = 10 mm.



Note

SoftMove Equalizing is only implemented for the `SpotL` and `SpotJ` instructions and does not work for the `SpotML` and `SpotMJ` instructions.



Note

This function allows the tolerances of the parts to vary a bit more compared to using only standard software equalizing, but it should be noted that the cycle time will be significantly longer than without, up to 700 ms per spot depending on the current settings and the actual plate position.

Continues on next page



WARNING

When using SoftMove Equalizing it is very important that the load definition of the tool is defined correctly.

Function overview

SoftMove equalizing is activated by selecting an optional switch in the `SpotL` and `SpotJ` instructions, see [SpotL/SpotJ - The basic spot welding instructions on page 107](#).

When a spot instruction with SoftMove activated is run, the robot will move to the programmed and nominal position, but during the last part of the movement into the position the robot will be set into soft state in the tool z-direction. When the gun has closed, the soft mode will be deactivated if SoftMove type is set to 1, and the deflection compensation will be activated as normal during the welding process if configured. If SoftMove type is set to 0, SoftMove will be activated during the complete weld cycle and no gun deflection compensation will be performed, see [smeqdata - SoftMove Equalizing data on page 167](#).

The SoftMove equalizing method can be more forgiving regarding programming errors than only using the standard software equalizing method. For example, if the plates are not located exactly in the nominal position but some millimeters away, up to 4-5 mm.



Note

If the normal software equalizing is deactivated then the SoftMove equalizing will also be deactivated, and it is considered that mechanical equalizing system is being used.

Programming

An optional parameter must be activated in the spot instructions to be able to use the SoftMove Equalizing functionality (`\SMEQ`). The parameter is an on/off switch for the SoftMove functionality, that is, if the parameter is not used, then the normal software equalizing functionality will be used for that position, see programming example below.

The optional parameter `\SMEQ` of type `smeqdata` has data components for SoftMove, specific for each position. `smeqdata` has the following structure:

- Desired `smeq_type` (SoftMove type) used in the specific position.
- Measured `force_offset` (friction compensation and force applied on the plates) for the specific position.

The parameter `smeq_type` defines what SoftMove type that shall be used in the specific position. There are 2 types; no gun deflection mode (0) and standard mode (1).

The parameter `force_offset` is needed to compensate for the robot's static friction in a specific position and to achieve a small movement to the plates. The

Continues on next page

6 Software Equalizing

6.8 SoftMove Equalizing

Continued

value must be set for each position for the first time the program is executed, see [Friction compensation procedure on page 224](#).



Note

The `force_offset` should be seen as friction force and force applied to the plates.

Example: 100N is identified in the friction compensation procedure.

To be sure that robot will move to the plate the `force_offset` can be set to 130N. If the friction is constant during the movement it will be 30N applied on the plate.



Note

It may be possible to use the same `force_offset` value for several positions.

For more information about this data type, see [smeqdata - SoftMove Equalizing data on page 167](#).

Example

This program example uses `SpotL` instructions with and without SoftMove Equalizing functionality. Instructions at targets P20 and P40 will be executed with only software equalizing activated while instruction at P30 is executed with SoftMove Equalizing because of tolerance issues in that position.

```
PERS smeqdata smeq1:=[1,150]
PROC main()
  MoveJ P10, v1000, z50, tool1;
  SpotL P20, vmax, gun1, spot11, tool1;
  SpotL P30, vmax, gun1, spot12\SMEQ:=smeq1, tool1;
  SpotL P40, vmax, gun1, spot14, tool1;
ENDPROC
```

Execution

No gun deflection mode (SoftMove type 0)

When a spot instruction is executed with the `\SMEQ` data set, the robot will move to the programmed and nominal position, at the same time as the gun starts to close. During the movement and closing of the gun the robot will be set into soft state with the specified force offset activated, according to the used data to overcome the friction of the robot.


When the gun has closed the position is considered to be "found" and the weld will be performed from that new position. After the weld process is completed the gun will start to open and SoftMove will be deactivated, see figure below.



Note

This method is a bit quicker compared to the standard mode because no synchronization with the gun closing is done before the process is started, but it is only suitable for guns with no or very small arm deflection values.

Continues on next page



en1200000225

- 1 Movement to the nominal position, via release distance.
- 2 From the SoftMove offset distance SoftMove is activated with the specified `force_offset` (friction compensation+force applied on the plate) while the gun closes.
- 3 When the gun is closed the plate is considered to be "found" and the weld will be done from that new position.
- 4 After weld the gun and robot will move to the release distance at the same time as the gun opens and SoftMove is deactivated.

Standard mode (SoftMove type 1)

When a spot instruction is executed with the `\SMEQ` data set, the robot will move to the programmed and nominal position, at the same time as the gun starts to close. During the movement and closing of the gun the robot will be set into soft state with the specified force offset activated, according to the used data to overcome the friction of the robot.

When the gun has closed the position is considered to be "found" and the soft state will be deactivated and the normal gun arm deflection compensation will be performed if configured. After the weld process is completed the gun will start to open and the gun arm deflection will be deactivated, see figure below.



Note


This method is a bit slower compared to the no gun deflection mode because the process waits for the gun closing before the process is started and performs arm deflection compensation during the weld. This method is suitable for guns with relatively big arm deflection values.

Continues on next page

6 Software Equalizing

6.8 SoftMove Equalizing

Continued



en1200000225

- 1 Movement to the nominal position, via release distance.
- 2 From the SoftMove offset distance SoftMove is activated with the specified `force_offset` (friction compensation+force applied on the plate) while the gun closes.
- 3 When the gun is closed the plate is considered to be "found" and SoftMove will be deactivated and the weld will be done from that new position.
- 4 After weld the gun and robot will move to the release distance at the same time as the gun opens.

Friction compensation procedure

When a spot instruction is executed with SoftMove Equalizing activated for the first time there is a need to compensate for the robot's static friction in a specific position and to achieve a small movement towards the plate. For this there is a parameter that needs to be tuned to a certain value for each position that uses SoftMove in the program, `force_offset`


By default the tuning will be done automatically for each position, it is possible to configure manual tuning if needed, see [The Spot SoftWare Equalizing instance on page 48](#).

When a spot instruction is run the `force_offset` parameter in the current `smeqdata` will be checked, if the value is equal to zero the robot will move to the release distance outside the `robtarg` specified in the instruction and stop, or if configured, perform an auto tuning in that position. The operator can then tune the `force_offset` value needed for the current position, see figures below.

If the `force_offset` parameter is greater than zero the spot instruction will be executed normally with the current value to compensate for the friction. The `force_offset` should be seen as friction force and force applied to the plates.


Continues on next page

A typical force offset value for an IRB 6640 can be approximately 100-400 N depending on arm configuration.



en120000223

| | |
|------|---|
| Stop | Stops the program execution. |
| Tune | The force offset will be tuned for the current position. The tuning will take a few seconds and after that a dialog appears with the possibility to accept the measured value or redo the tuning. |



en120000222

| | |
|------|--|
| Redo | Returns to the previous screen with the possibility to tune the force offset needed again. |
| OK | Updates the current smeqdata with the measured value. |

Continues on next page

6 Software Equalizing

6.8 SoftMove Equalizing

Continued



Note

The `force_offset` should be seen as friction force and force applied to the plates.

Example: 100N is identified in the friction compensation procedure.

To be sure that robot will move to the plate the `force_offset` can be set to 130N. If the friction is constant during the movement it will be 30N applied on the plate.



Note

The measured value of `force_offset` is an **approximate** value and it may be necessary to have a higher or lower value than measured for the current position since the friction value is measured while the robot is not moving.

The actual force needed to overcome the friction or overcome frictional force and accomplish a movement of the robot may vary slightly depending on cold/warm robot etc. And it may turn out that the value may seem a little too low when running the robot in manual mode, but when running in automatic mode, the value is right. If the robot does not reach the position in manual mode, increase the value manually by 5-10N and run again.

For more information about SoftMove limitations, see *Application manual - SoftMove*



Note

When tuning the friction compensation in a certain position the value is usually good enough, but the achieved value may need to be manually tuned to get better performance. If the measured value is higher than ~300 N there may also be a need to manually modify the measured value.



Note

It is recommended that the friction compensation procedure is done without welding activated.

Related information

| | Described in |
|-----------------------|---|
| Manual actions | Manual actions on page 84 |
| Process configuration | Spot process configuration on page 25 |
| MeasureWearL | MeasureWearL - Measure current electrode wear and recalculate the TCP on page 133 |
| ReCalcTcp | ReCalcTCP - Calculate current electrode wear and recalculate the TCP on page 141 |
| Customizing | Customizing RobotWare-Spot on page 279 |

Continues on next page

6 Software Equalizing

6.8 SoftMove Equalizing *Continued*

| | Described in |
|--------------------------|---|
| SpotL/SpotJ | SpotL/SpotJ - The basic spot welding instructions on page 107 |
| SoftMove Equalizing data | smeqdata - SoftMove Equalizing data on page 167 |
| SoftMove | <i>Application manual - SoftMove</i> |

This page is intentionally left blank

7 Servo gun motion control

7.1 Servo gun introduction

Additional axes

The robot controller has functionality to control additional axes configured as servo guns (other types of supported additional axes are track motion, positioners, conveyors etc.). All servo guns are handled as separate mechanical units. This means that before a servo gun may be moved, the mechanical unit to which it belongs must be activated. Several servo guns may be active at the same time.

Hardware overview

Servo gun axes are controlled by the drive module. Internal drive units (ADU's) are mounted inside a standard drive module (for example for an IRB 6700 with one servo gun or for an IRB 6700 with two stationary servo guns).

Motion servo gun parameters

A set of motion servo gun parameter file should be installed in the controller for each servo gun. The parameter files are optimized designed concerning system behavior and motion/process performance.

It is possible to read and change most of the parameters from the RobotStudio application after installation. With the Spot options some gun specific system parameters may be updated temporarily directly in the robot program using the instruction `STTune`. This function will make tuning of gun parameters easier.



Note

Normally the gun specific parameters are supplied by the gun manufacturer.

References

| Type of information | See |
|---|--|
| CalibL, CalibJ, Calibrate, SpotL, SpotJ, SetForce, STTune, gundata, spotdata, forcedata | RAPID references on page 107 |
| General motion control and programming | <i>Operating manual - IRC5 with FlexPendant</i> |
| ActUnit, DeactUnit, MoveL, MoveJ, robtarg, tooldata | <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> |
| How to tune a servo gun | <i>Application manual - Servo Gun Setup</i> |
| Hardware: motors, resolvers, drives, servo gun parameters, tuning a servo gun | <i>Application manual - Additional axes and standalone controller</i> |

7 Servo gun motion control


7.2 Installation and service

7.2 Installation and service

Install servo gun parameters

If the system is cold started, the servo gun parameters are most likely not loaded. If no backup of the system is available then follow these steps, otherwise restore the backup, then the complete system will be ready for production after restart

- 1 Load the servo gun parameters from RobotStudio via the configuration editor, tap **Configuration, Load Parameters**. If a complete `moc.cfg` file is loaded, then select **Delete existing parameters before loading** instead.
- 2 Restart the system.
- 3 Activate the gun in order to control and monitor the axis if it is not already activated via the configuration, see [Servo tool change on page 245](#).



Set the servo gun name

After the gun parameters has been installed and the system has been restarted, the `gundata` needs to be updated with the servo gun name (mechanical unit name). For this a service routine is available to search for installed guns in the system, instead of manually enter the gun name in `gundata`.

| Action | Note |
|--------|--|
| 1 | <ul style="list-style-type: none">• From the Spot FlexPendant interface, select SpotWare and Manual Actions and tap Search for servo gun.• From the Code Editor, tap Debug, and then tap Call Service Routine and tap ManualGunSearch. <p>See gundata - Equipment specific weld data on page 152.</p> |
| 2 | Ready. |


Continues on next page

Servo gun force calibration

There is a RAPID service routine to calibrate the motor torque versus tip force characteristics, `ManualForceCalib`. A separate sensor is needed to measure the tip force. An optional number of force recordings (2-10) can be made where measured tip force is inserted with corresponding motor torque.

A force calibration must be done in order to get a good force accuracy and also to protect the servo gun from too high forces.

From the Spot FlexPendant interface, tap **Manual actions** then tap **Gun force calibration**. Or from the Code Editor, Tap **Debug** and then tap **Call Service Routine**.



xx230000086

| | Action | Note |
|---|--|---|
| 1 | Run the service routine <code>ManualForceCalib</code> , tap Setup . | Enter the max allowed force for the gun, the lower force limit, the number of force measurements and the sensor thickness to be used during the calibration sequence. |
| 2 | Then tap Run . This will perform the calibrations. | Follow the instructions in the routine. |
| 3 | Ready. | |

Number of measurements

Enter number of measurements, for example 2.

Most times 2 measurements are good enough, but sometimes more samples may be needed, e.g. for non linear guns.

Max gun force

Enter the max force for the gun, for example 4000 N.

The lower force limit will then be recalculated based on the specified max force and number of measurements.

Continues on next page

7 Servo gun motion control

7.2 Installation and service

Continued

Lower force limit

The lower force limit is always set to the calculated step value at start of the routine, for example $4000 / 2 = 2000$ N or if the number of measurements and/or max gun force is changed.

Lower limit can be tuned to a different value, and that value will be valid as long as the force calibration routine is run. It will be reset to the calculated step value if the routine is restarted.

Sensor thickness

Enter the force sensor thickness used to measure the forces, for example 15 mm.

Squeeze time

Enter the duration of the force measurements, for example 2 s.



Note

The lower force limit will be recalculated if the maximum gun force and/or number of measurements are changed.



Note

The lower force value will be limited to 1100 [N], or 110 [daN] or 250 [lbf] depending on configuration setting, but it can be changed to a lower value if needed. It is mandatory to validate the selected force if a value lower than the calculated step value is entered.



Note

It is important to specify the correct sensor thickness to achieve the correct gun force accuracy.



Note

The first time this routine is run and if working from a servo gun template file, a default force table with 2 forces based on the entered max force will be created. Follow the instructions in the routine.



Note

For the force change functionality to work correctly, the gun positions are stored in the `SG_PROCESS` table when performing a force calibration, `squeeze_pos1 - 10`. It is really important for the gun force accuracy and performance that this procedure is done properly.

It is also very important that the gun forces used during production later on is in the range of the force calibration table in order to get a acceptable accuracy of the force. See [Multiple gun forces during welding on page 97](#).

Continues on next page



Note

If a gun service / repair has been made, the force calibration should be done again to ensure the forces are the same as before.

Servo gun force gravity compensation

In the `ManualForceCalib` routine it is also possible to setup configuration data that can be used for gun force gravity compensation. See [The Spot Gun Equipment instance on page 39](#).


This function can be used if a servo gun loses force when the movable gun arm moves against gravity when closing. Normally there should be no need to compensate for loss of gun force, but for certain types of guns there may be a risk that gravity can influence the gun force negatively depending on on the moveable gun arm weight etc.

In those cases this functionality can be used to minimize the loss of gun force and maintain a stable force during welding.

There are two methods that can be used to setup the needed compensation data.

- A manual method that requires a hand held force sensor.
- An automatic method that will move the gun (axis 5) between 0 to 90° and 0 to -90° and calculate/estimate the gun force in the "worst" angle and update the compensation data.

From the Spot FlexPendant interface, tap **Manual actions** then tap **Gun force calibration**. Or from the Code Editor, Tap **Debug** and then tap **Call Service Routine**.



xx230000086

| | Action | Note |
|---|--|---|
| 1 | Run the service routine Gun force calibration , select 'Setup'. | Change the force calibration setup data, i.e. the sensor thickness and the max force to be used during the setup. |
| 2 | Then select 'Gravity'. | Follow the instructions in the routine. |

Continues on next page

7 Servo gun motion control

7.2 Installation and service

Continued

| | Action | Note |
|---|--------|------|
| 3 | Ready. | |



WARNING

If using the automatic method the robot will first move to sync position, and then start move axis 5 in-between 0 and 90° and/or 0 to -90°. Make sure that the robot can move freely without crashing into objects around it.



Note


The actual force will not be compensated with 100% accuracy, but the deviation from ordered gun force will be less than without compensation.

Servo gun initialization calibration

After installing the gun parameters and restarting the system, the gun like any other additional axis must be calibrated by performing a fine calibration or a revolution counter update. Apart from other kinds of additional axes, it is also required to run a RAPID service routine to find the contact position or zero position of the gun.

There are two options in this routine that can be run depending on if the gun has been fine calibrated or if the revolution counters has been updated. See [Manual actions on page 84](#).

From the Spot FlexPendant interface, tap **Manual actions** then tap **Gun initialization**. Or from the Code Editor, Tap **Debug**, **Call Service Routine** and then tap `ManualServiceCalib`.





xx230000086

Continues on next page

Servo gun initialization after fine calibration

Fine calibration must be performed when installing a new servo gun or if the servo gun axis is in state **Not Calibrated**.

Use this procedure to fine calibrate.

| | Action | Note |
|---|---|--|
| 1 | On the FlexPendant go to the Calibrate view, select the desired gun and then tap Calibration Methods, Calibration Parameters and Fine calibration . There is no need to jog the axis to any particular position. |  Note Make sure that new electrode tips are used since all tip wear data will be cleared. |
| 2 | Run the service routine Gun initialization with Initialize . Follow the instructions in the routine. | If the gun is considered to be force calibrated, the gun will move fast to the selected pre-position and then close slowly until tip contact is detected, since the zero position is unknown. Otherwise a warning dialog will be displayed with a question whether the gun has been force calibrated or not. Answering Yes will perform the service calibration anyway, No will end the routine.  Note If the gun is not force calibrated and properly tuned, follow the tuning procedure described in <i>Application manual - Servo Gun Setup</i> . |
| 3 | As a result, the gun position is updated to be zero in the position of contact and the tip wear value is reset. | Ready. |

Servo gun initialization after revolution counter update

An update of the revolution counter must be performed if the position of the axis is lost. If this happens, this is indicated by the calibration state **Rev. Counter not updated**. These steps are required to update the counter.


| | Action | Note |
|---|---|------|
| 1 | On the FlexPendant go to the Calibration view, select the desired gun and tap Calibration Methods and Revolution Counters . There is no need to jog the axis to any particular position. | |

Continues on next page

7 Servo gun motion control

7.2 Installation and service

Continued

| | Action | Note |
|---|---|--|
| 2 | Run the service routine Gun initialization with <i>Synchronize</i> . Follow the instructions in the routine. | If the gun is considered to be force calibrated, the gun will move slowly until tip contact is detected, since the zero position is unknown. Otherwise a warning dialog will be displayed with a question whether the gun has been force calibrated or not. Answering Yes will perform the service calibration anyway, No will end the routine.  Note If the gun is not force calibrated and properly tuned, follow the tuning procedure described in <i>Application manual - Servo Gun Setup</i> . |
| 3 | As a result, the gun position is updated an integer number of revolutions to be zero in the position of contact. Tip wear of the gun remains unchanged. | |
| 4 | Ready. | |



Note

The first time this routine is run and if working from a servo gun template file, a default force table with 2 forces based on the entered max force will be created. Follow the instructions in the routine.



Note

It will not be possible to run any Spot instructions until a 'gun initialization' has been done.



WARNING

If the force calibration procedure has not been done properly, the servo gun can be damaged, please make sure that the servo gun is force calibrated and tuned and that the force calibration values are correct, see *Application manual - Servo Gun Setup*.

Disconnect and reconnect a servo gun, tool changing

If the servo gun is deactivated, using the `DeactUnit` instruction, it may be disconnected and removed. The gun position at deactivation will be restored when the gun is connected and reactivated. Make a **tool change calibration** to make sure the tip position is OK in case the gun arm has moved while it was disconnected.

Simplified tool change procedure.

- 1 Run the routine `DeactUnit`.
- 2 Disconnect the gun.
- 3 Connect the second gun.

Continues on next page

- 4 Run the routine `ActUnit`.
- 5 Perform a tool change calibration for the second gun.
- 6 Start using the second gun.

For more information about tool changing see [Servo tool change on page 245](#).

Recover from accidental servo gun disconnection

If the motor/resolver cables are disconnected by accident when the servo gun is activated, the servo gun must be deactivated in order to move the robot to a service position.

- 1 To deactivate the gun, select the mechanical unit and tap the **Activate** button in the Jogging window and deactivate the mechanical unit.
- 2 Move the robot to a service position and repair the gun.
- 3 Perform a revolution counter update since the position has been lost.
- 4 Perform a gun position synchronization, see [Servo gun initialization calibration on page 234](#).

Replace a servo gun

Normally there is no need to replace the gun parameters if the the new gun is identical to the old one.

- 1 Connect the new gun.
- 2 Start up the system.
- 3 Perform a fine calibration of the gun.
- 4 Perform a gun position initialization, see [Servo gun initialization calibration on page 234](#).
- 5 To make sure the gun force is correct a force calibration should be performed if it is not already done for that gun, see [Servo gun force calibration on page 231](#).



Note

The spare gun must have same parameter names as the original gun, otherwise the installation will just add the new gun, keeping the old gun in parallel. Eg SGUN_1.

7 Servo gun motion control

7.3 General motion control for servo guns

7.3 General motion control for servo guns

Introduction

The motion functionality described in this section is common for servo guns and most other types of additional axes. The description is however adapted for servo guns.

Activation and deactivation

A servo gun may be activated when the robot and all additional axes have come to a standstill by using the `ActUnit` instruction. This means that the servo gun is controlled and monitored by the robot controller.

A servo gun is normally automatically activated directly after loading its parameters and starting up the system (activate at startup). It may be deactivated during program execution later.

If several guns are sharing one tool changer there will be no automatic activation at startup. When the connected gun is activated, it will not be possible to activate another gun until the first one is deactivated (mutual exclusion).

Deactivation of the gun is only needed if the gun has to be disconnected, for service or for a tool change. The deactivation will store the guns current position. This position will be restored when the gun is activated next time. Deactivation is performed with a `DeactUnit` instruction and this will also stop the control and monitoring of the axis.

Jogging

The position of the gun arm can be jogged with the joystick (see *Operating manual - IRC5 with FlexPendant*). The distance between the two tips is displayed in the jogging window, expressed in mm. An out of range supervision will stop the movement if the gun is reaching max stroke or min stroke. Min stroke is normally zero or a small negative value (gun tips closed to contact with each other).

Synchronous movements of robot and servo gun

Normally, as for other additional axes a servo gun axis is moved synchronous with the robot movements in such a way that both movements will be completed exactly at the same time. However, it can also be moved independent of the robot movements, for example when closing the gun tips with a force. But during normal movements (for example `MoveL`, `MoveJ`, `MoveC`) in program execution, the tool axis movement will be synchronized. The combined path of robot and servo gun(s) will be repeatable and independent of programmed speed. The robot TCP path, will be the same irrespective of the programmed movements of the servo gun's movable arm.

A `robtarget` includes position data for additional axes which also will be set when a `ModPos` is performed. Example:

- `p10` is a `robtarget` RAPID data.
- `p10.extax.eax_a` is the position of the additional axis with logical axis 7.
- `p10.extax.eax_b` is the position of the additional axis with logical axis 8.

Continues on next page

- `p10.extax.eax_f` is the position of the additional axis with logical axis 12.

Logical axis is a system parameter defined for each axis (RobotStudio: Configuration Editor, Motion, Joint). The robot itself uses logical axes 1-6 and additional axes use 7-12. The user can change the logical axis number to fit the application. Only axes with unique logical axis numbers may be activated at the same time.

For a servo gun, the position is defined as the opening distance of the tips in mm. The value `9E+09` is defined for axes that are not used.

Independent gun movement

The gun is in independent mode and can be moved to a specified independent position. During independent mode, the control of the servo gun is separated from the robot. The gun can be closed, opened, calibrated or moved to a new independent position, but it will not follow coordinated robot movements.

The instruction `IndGunMove` is used to set the gun in independent mode and thereafter move the gun to a specific independent position, see [IndGunMove - Activates independent mode for a servo gun on page 145](#). This mode can be reset by executing the instruction `IndGunMoveReset`. See [IndGunMoveReset - Resets servo gun from independent mode on page 147](#).

Supervision during general motion control

An out of range supervision will stop the movement if the gun is reaching max stroke or if it is closed to contact with the tips (reaching min stroke). Motion collision detection may be activated for the robot. There is also a separate motion supervision for each controlled axis, including the gun axis. This axis supervision will detect if the gun arm collides or get stuck. A motion error will occur and the motion will be stopped.

7 Servo gun motion control

7.4 Asynchronous movements with force control

7.4 Asynchronous movements with force control

Introduction

The motion functionality described in this section is only valid for servo gun axes.

Opening and closing in general

The gun may be closed asynchronously (independent of current robot movement) to a predefined plate thickness and tip force. The closing will immediately start to run the gun arm to the expected contact position (thickness). The closing movement will interrupt an on-going synchronous movement of the gun. When the tips reaches the programmed plate thickness, the movement is stopped and there is an immediate switch from position control mode to force control mode. In the force control mode a motor torque will be applied to achieve the desired tip force.

The force remains constant until an opening is ordered unless support for multiple forces are configured. See [Multiple gun forces during welding on page 97](#).

Opening of the gun will reduce the tip force to zero and move the gun arm back to the pre-close position, that is, the position of the axis specified in the robtarget.

The gun opening may also take place while the robot is moving. But it is not possible if the robot movement includes a synchronized movement of the servo gun axis. In that case a motion error, tool opening could not be synchronized with robot movement, will occur.

Welding

A gun closing is done when performing a weld. The applied force may be taken from the weld timer or from a RAPID data (spotdata). See [spotdata - Spot weld data on page 157](#).

During force build up, the thickness of the plates will be measured. The welding is started when the force is reached but only if the measured plate thickness is approved. When the weld is ready, the gun is immediately opened to the pre-close to position.

In the Spot options, the closing, opening, thickness measurement, weld start and opening is integrated in the `SpotL/J` and `SpotML/MJ` instructions. See [SpotL/SpotJ - The basic spot welding instructions on page 107](#) and [SpotML/SpotMJ - Spot welding with multiple guns on page 113](#).

Squeezing without welding, tip dressing

A gun closing is also typically done after tip dressing and after changing tips. The force will be held constant for a certain time, and then the gun is opened up again.

If using the `SetForce` instruction it will squeeze the gun with a specified force, thickness and during a specified time. `SetForce` takes a `forcedata` as argument where these values are defined. A thickness test is integrated in the instruction. See [SetForce - Close and Open a gun with desired force and time on page 118](#).

Continues on next page

Supervision during asynchronous movements with force control

During the position control phase of the closing/opening, motion supervision is active for the servo gun to detect if the arm collides or gets stuck. There is a maximum motor torque defined in the motion parameters for the gun that never will be exceeded in order to protect the gun from damage.

If the force is programmed out of range according to the guns force-torque table, the output force will be limited to this maximum allowed motor torque and a motion warning will be logged.

During the force control phase, the motion supervision will supervise the gun position not to exceed a certain distance from the expected contact position. This distance, `Forced on Position Limit`, is defined in the motion gun parameters (topic `Motion`, type `Supervision`) and will typically depend on the flexibility of the gun arm. This supervision will protect the gun if for instance one tip is lost.

During the force control phase there is an active speed limitation which will limit the speed of the gun. The speed limit value is defined in the gun parameters (see the tuning chapter in *Application manual - Additional axes and standalone controller*) or the Servo Gun Setup wizard (see *Application manual - Servo Gun Setup*).

The speed will be actively limited to increase further when the speed limit is reached. The speed limitation will give a controlled behavior of the gun when it is ordered to close to a position where the tips not are in contact, avoiding a hard impact when tip contact is established.

7 Servo gun motion control

7.5 Tip management

7.5 Tip management

Introduction

The tip management functionality will find and calibrate the contact position of the gun tips automatically. It will also update and monitor the total tip wear of the gun tips. The total tip wear for each gun is stored in a RAPID data (see [gundata - Equipment specific weld data on page 152](#)). The tips are calibrated with special RAPID instructions. Typically, two gun closings will be performed during a calibration. The calibration may be done when the robot is standing still, see [Calibrate - Calibrate a servo gun on page 129](#), or during a robot movement, see [CalibL/CalibJ - Calibrate a servo gun during robot movement on page 123](#).

Three different types of calibrations are supported: tip wear, tip change and tool change. All three will calibrate the contact position of the tips. The total tip wear will however be updated differently by these methods.



Note

If software equalizing is used there are other methods available for the tip wear compensation. See [Software Equalizing on page 197](#).

Tip wear calibration

To be used after a tip dressing. The gun contact position is calibrated and the total tip wear of the gun is updated. The calibration movements are fast and the switch to force control mode will take place at the zero position.



Note

This method must only be used to make small positional adjustments (< 3 mm) caused by tip wear / tip dressing

Tip change calibration

To be used after mounting a new pair of tips. The gun contact position is calibrated and the total tip wear of the gun is reset. The first calibration movement is slow in order to find the unknown tip collision position and switch to force control. The second calibration movement is fast. This calibration method will handle big positional adjustments of the gun.

This calibration may be followed by a gun closing in order to squeeze the tips in place (using the `SetForce` instruction). A new tip change calibration is then done to update possible positional differences after the tip squeeze.

Tool change calibration

To be used after reconnecting and activating a servo gun. The gun contact position is calibrated and the total tip wear of the gun remains unchanged. The first calibration movement is slow in order to find the unknown tip collision position and switch to force control. The second calibration movement is fast. This calibration method will handle big positional adjustments of the gun.

Continues on next page

The method should always be used after reconnecting a gun since the activation will restore the latest known position of the gun, and that position may be different from the actual gun arm position; the gun arm may have been moved when disconnected. This calibration method will handle big positional adjustments of the gun.

Tip change requirement

The total tip wear of the gun (stored in RAPID `gundata`) may be supervised in order to detect when a tip change is needed. See [gundata - Equipment specific weld data on page 152](#).

Tool center point adjustment

Part of the total tip wear may be used to adjust / optimize the tool center point of the robot tool (RAPID `tooldata`). The instructions `MeasureWearL` or `RecalcTcp` should be used in combination with the `CalibL/J` or `Calibrate` instructions to update the fixed tip of the gun (tool center point). For more information see [Tip wear compensation on page 209](#) and [MeasureWearL - Measure current electrode wear and recalculate the TCP on page 133](#) or the [ReCalcTCP - Calculate current electrode wear and recalculate the TCP on page 141](#).

Supervision during tip calibration

The same supervision will be active during calibration as during asynchronous movements with force control.

7 Servo gun motion control

7.6 Stationary gun

7.6 Stationary gun

Description

A stationary servo gun is mounted on the floor and the robot is holding the work piece. The only difference when using a stationary servo gun is that the robot tool (RAPID `tooldata`) should be defined as stationary (`robhold = false`), and the used work objects as robot held.



Note

In case software equalizing functions are used for the stationary gun, there may be a need to configure the deflection and release movement direction.

See [The Spot Gun Equipment instance on page 39](#) on how to configure movement direction.

7.7 Servo tool change

Description

It is possible to change servo gun during production. The functionality is realized as the option *Servo Tool Change*. There is no software limitation in how to combine different kinds of servo guns (for example brands, sizes or motors) with a tool changer.

The used servo guns share the same drive unit, and the same node on the measurement board. They are activated as different mechanical units, but of course never at the same time. They may use the same or different logical axis.

Prerequisites

Changing gun requires a deactivation of the operating gun and then unplugging its motor cables. The motor cables are plugged in to the next gun, and this gun is activated and ready to run. The plug-in mechanism requires a mechanical tool changer interface to the guns. One individual set of gun parameters are installed for each gun.

Limitations

Servo tool change can be used up to 8 different tools but is limited by 14 axes in total for the drive module. E.g if robot is on a track motion or if another additional axis is connected to a drive module it reduces that number of allowed tools that can be used with servo disconnect.



Note

Tool changing with servo guns requires the option *Servo Tool Change*.

Changing *Motion* parameters

The system parameters in type *Mechanical Unit* and *Relay* and *Measurement Channel* (topic *Motion*) should be set like this when tool changing.

- 1 Set *Activate at StartUp* to No.
- 2 Set *Deactivate Ptc at Disconnect* to Yes.
- 3 Define *Use Connection Relay* with the same name as defined in *Name*, for example SGUN_1.
- 4 Define an *Input Signal* in type *Relay* with a signal that is also defined in the I/O configuration.
For example *diToolConnected*, and this input signal should be connected to a sensor on the tool changer that indicates a physically connected gun.
- 5 Set the parameter *Disconnect at Deactivate* in type *Measurement Channel* to Yes.

Continues on next page

7 Servo gun motion control

7.7 Servo tool change

Continued

If this setup is used a safe tool change functionality will be achieved.



Note

To be sure that the a servo gun is activated and have a safe way to tool change, it is strongly recommended that the connection relay functionality is used when tool changing.

Basic example, tool change procedure

The procedure to switch between gun SGUN_1 and gun SGUN_2 must includes these minimal actions (excluded here is the needed communication with the tool changer, the tool stand and necessary robot movements):

Specify a connection relay signal for the gun to prevent accidental activation of not not connected gun as described above.

- 1 Deactivate gun SGUN_1 with the instruction DeactUnit.
The position of gun SGUN_1 is stored.
- 2 Disconnect gun SGUN_1.
Disconnect the servo gun motor cables.
- 3 Connect gun SGUN_2.
Connect the motor cables to motor SGUN_2.
- 4 Activate gun SGUN_2 with the instruction ActUnit.
The latest position of gun SGUN_2 is restored.
- 5 Run a tool change calibration of gun SGUN_2 with the instruction STCalib \ToolChg or the corresponding spot instruction Calibrate \ToolChg.
Verify that the position is correct.



WARNING

If the servo gun axis has been moved during deactivation, the position of the axis might be wrong after activation, and this will not be detected by the controller. The position after activation will be correct if the axis not has been moved, or if the movement is less than 0.5 motor revolutions. Always use the tool change tip calibration after activation. The tool change calibration will adjust any positional error caused by gun movements during deactivation.

Continues on next page



WARNING

It is important that no other mechanical units that are used with a tool changer, are activated but only the one corresponding to the currently connected servo gun!

An activation of wrong mechanical unit may cause unexpected movements or errors. Some tool changers support I/O signals that specifies which gun is currently connected (Tool ID). That information may be used to make sure correct mechanical unit is activated.

It is recommended to block activation of not connected mechanical units by specifying a digital input (DI) in the connection relay motion system parameter (type *Relay* in topic *Motion*) for each servo gun. This digital input, which also is setup in the I/O configuration, is read when the mechanical unit is activated from the tool change program sequence. If set to 1 the activation will take place normally, otherwise a recoverable motion error will occur and the activation will be denied.

This page is intentionally left blank

8 FlexPendant Interface


8.1 Application Overview

Introduction

This chapter describes the Spot FlexPendant interface intended to simplify the use of the spot welding functionality. The operator have the most common information together in one place, easy to use and understand.

This is not a replacement for the standard FlexPendant functionality, but it can be seen as a complement. Spot related information are presented in an instructive way, enabling operators to easily and quickly get their every day tasks done.

To start the Spot UI application, go to the Home menu and then tap **SpotWare**. The main view will be started. From here all spot related functions can be accessed. For further information on using the FlexPendant, see *Operating manual - IRC5 with FlexPendant*.



xx230000088

Content

The Spot UI has the following content:

- **Main View**
- **Manual Actions**
- **Process Equipment**
- **Simulation**
- **Information**
- **Configuration**

The Spot main view provides basic status information about the current executing spot program with possibilities to reach other views and sub views. The welding process can be followed for each spot instruction.


8 FlexPendant Interface

8.2 Main View

8.2 Main View

Basic functionality in the main view

- 1 Tap the **Home** menu and then select **SpotWare**. A window will appear containing status information to follow the welding progress, latest/current spot instruction, name of the executing weld program, access manual actions, set simulation modes and so on.




xx2300000088

- 2 Tap **Simulation** control to access and edit simulation data.
- 3 Tap **Process equipment** to view the connected equipment status.
- 4 Tap **Manual Actions** to access an run the spot service routines.
- 5 Tap **Configuration** to view and edit some of the spot related configuration data.
- 6 Tap the **Info** to view version info etc.
- 7 Tap **Select task** button to view another spot welding robot.

Continues on next page

Manual actions


Contains all available application related service routines in the system.



xx230000086

Simulation

If the simulation mode is changed the **Simulation** button will flash with yellow tone as long as the simulation is active. For more information about simulation see [Simulation modes on page 82](#).



xx230000087

Continues on next page


8 FlexPendant Interface

8.2 Main View

Continued

Process equipment

Information in this area shows the current equipment counters, for example tip wear, number of welds etc. The information in this will be updated when Spot instructions are executed.




xx230000105

Information

Information in this view shows application version and misc. system info.

Configuration

1 Tap tap Configuration in the SpotWare main window



xx230000090

- 2 Select the configuration instance to be changed.
- 3 View or edit the value.
- 4 New value will be written to the controller as soon as a value has changed. Tap **Back** to return to the previous window without any changes.

Continues on next page



Note

Access to the configuration may be limited by the user grants for the specific user. **Modify system parameters** grant is required.



Note

Not all application and system configuration are accessible from here, only a subset of SpotWare related configuration data can be viewed and/or edited.

8 FlexPendant Interface

8.3 Manual Actions


8.3 Manual Actions

Manual Actions

Manual actions contains all available application related service routines in the system. The user can easily start any routine by tapping the button for the action he would like to run.

Basic functionality in the Manual actions window

- 1 Tap **Manual actions** button in the main view. A window appears containing all available spot related service routines in the system.



xx230000086

Starting a service routine

- 1 Make sure that a program is loaded without errors and set the system in **MotorsOn** state.
- 2 Tap the service routine you would like to run.

For a complete description of the available service routines, see [Manual actions on page 84](#).


Manual versus Automatic mode

If the system is in manual mode you can run service routines, view or edit data, set simulation mode. When you switch to automatic mode all views are locked, but it's possible to see the current status.

8.4 Process Equipment

Basic functionality in the Process equipment view

- 1 Tap the **Process equipment** button in the main view. A window appears containing status information connected to different parts of the equipment, tip wear etc.




xx230000105

- 2 Tap **Select equipment** to switch between all available gun equipment's in the system.

8.5 Simulation

Basic functionality in the Simulation view

- 1 Tap the **Simulation** button in the main view. A window appears containing quick settings for the different simulation modes.



xx230000087

- 2 Tap **Simulation Off/On** to activate or deactivate simulation mode.
- 3 Select desired **Simulation mode**.
- 4 **Gun simulation**, tap **Inhibit gun control** to prevent gun closing/opening or tap **Inhibit plate thickness check** during program execution.



Note

In order to be able to change simulation modes, the proper access is needed, *Modify current value*. This gives access to modify RAPID data. For more information about grants see *Operating manual - IRC5 with FlexPendant*.


8.6 Configuration

Process Configuration

Process Configuration presents application specific configuration data, thus offering a quick and easy way to edit or view some parts of the application related configuration.

Basic functionality in the Configuration window

- 1 Tap Configuration in the SpotWare main window.



xx230000090

- 2 Select the configuration instance to be changed.
- 3 View or edit the value.
- 4 New value will be written to the controller as soon as a value has changed.
Tap **Back** to return to the previous window without any changes.



Note

Not all application and system configuration are accessible from here, only a subset of SpotWare related configuration data can be viewed and/or edited. To access all system configuration RobotStudio is required.



Note

In order to edit configuration data, the right access is needed, *Modify system parameters*. This gives access to modify configuration parameters. For more information about grants see *Operating manual - IRC5 with FlexPendant*.



Note

Some configuration changes may need a system restart.


Continues on next page

8 FlexPendant Interface

8.6 Configuration Continued


Change configuration

- 1 Tap **Configuration** in the SpotWare main window.
- 2 Select the configuration instance to be changed, for example **Error handling**.



xx230000090

- 3 Select the parameter you want to change. New value will be written to the controller as soon as a value has changed.
Tap **Back** to return to the previous window without any changes.
- 4 Depending on the selected parameter, numeric pad, drop down list, alpha pad or radio buttons with **Yes/No** selection.



xx230000094

More information about the application process configuration can be found in [Introduction on page 25](#)

8.7 Customizing the UI

Configuration of the Manual Actions view

The Manual Actions view can be modified to fit the current configuration. It is possible to add/remove service routines and also add custom service routines if needed.

| Service Routine | Yes | No | Notes |
|--|----------------------------------|-----------------------|---|
| Show simulation settings view | <input checked="" type="radio"/> | <input type="radio"/> | Yes = Simulation view is present in Spot UI application |
| Show 'Spot' service routine | <input checked="" type="radio"/> | <input type="radio"/> | |
| Show 'SetForce' service routine | <input checked="" type="radio"/> | <input type="radio"/> | |
| Show 'Gun init' service routine | <input checked="" type="radio"/> | <input type="radio"/> | |
| Show 'Gun calibration' service routine | <input checked="" type="radio"/> | <input type="radio"/> | |
| Show 'Gun force calibration' service routine | <input checked="" type="radio"/> | <input type="radio"/> | |
| Show 'Gun search' service routine | <input checked="" type="radio"/> | <input type="radio"/> | |
| Show 'Gun position' service routine | <input checked="" type="radio"/> | <input type="radio"/> | |
| User defined service routine 1 | <input type="text"/> | | |
| User defined service routine 2 | <input type="text"/> | | |
| User defined service routine 3 | <input type="text"/> | | |
| User defined service routine 4 | <input type="text"/> | | |

xx230000123

This page is intentionally left blank

9 Bosch FlexPendant Interface

9.1 Application Overview

Introduction

This chapter describes the user interface intend to simplify the use of the Bosch weld timer functionality. To access the Bosch FlexPendant interface you need the software option *Bosch Weld Timer Interface*. You also need recommended hardware (Bosch weld timer, cable for communication).

The operator has the most common data and weld timer errors and fault collected together in one place, easy to use and understand. To start Bosch Timer tap the **ABB** menu and then tap **Bosch Weld Timer**. The Bosch Timer desktop shows all common weld timer functions. For further information on using the FlexPendant, see *Operating manual - IRC5 with FlexPendant*. For information about weld parameters, see *Bosch operating and programming manual volume 2*.



en120000605

Bosch Timer desktop has four function buttons:

- Pre Warning
- Weld Fault
- Last Weld
- Weld Parameters

Pre Warning

Pre Warning present information about all electrodes configured for a certain weld timer.

Weld Fault

Weld Fault lists all weld faults and warnings connected to the welding process and the weld timer.

Continues on next page

9 Bosch FlexPendant Interface

9.1 Application Overview

Continued

Last Weld

Last Weld present information about the last weld performed by the weld timer.

Weld Parameters

Weld Parameters offering a quick and easy way to view or edit ordinary weld parameters.

General information before start using the Bosch interface

The Bosch application cannot access all timer functions, so before using the Bosch application some necessary offline setup is needed, use the PC software BOS5000/BOS6000. Connect the PC to the X1 serial connection port on the timer.

- Transformer parameter setup.
- Gun force and weld current calibration of the electrodes.



Note

If or when an extra ordinary weld fault (hardware fault) occurs the user have to connect the BOS5000/BOS6000 pc-software to get the real cause of the problem.



Note

To do a backup or restore the weld timer the user have to connect the BOS5000/BOS6000 pc-software to take this action.



Note

Make sure you understand what happens to the welding sequence if you turn off the Ignition parameter under the Settings or General node on the FlexPendant, or if you change the simulation type in *RobotWare Spot*, see [Simulation modes on page 82](#).



Note

Avoid to close the application during loading or saving weld parameters in the Weld Parameters window, this can lead to loss of data.

Limitations

- It is only possible to connect one weld timer to a robot controller.
- Avoid disconnecting the RS232 cable during loading or saving weld parameters in the **Weld Parameters** window, the Bosch MMI application should be closed before disconnecting the cable.
- It is not possible to access all timer functions and settings from the Bosch MMI application.
- It is not possible to backup or restore weld parameters from the Bosch MMI application.
- Not all possible timer faults will be visible in the **Weld Fault** view.
- Can not be combined with the option 634-1 MultiProcess.

Continues on next page

Manual versus Automatic mode

If the system is in manual mode you can view or edit weld parameters and see information about the warning and error that can occur in the system. When you switch to automatic mode or when executing a program you cannot open the Weld Parameters window but you can still open the other windows.

General information


The information at the upper right side shows if the communication with the timer is ok or not (if problem see the system Event Log for further information). In the upper left side you have the information about the used device net protocol for the connected timer.

9.2 Pre Warning

Basic functionality in the Pre Warning window

- 1 Tap **Pre Warning**.

A window will appear containing information of all configured electrodes in the weld timer.



en1200000588

- 2 Tap **Reset** to reset the value of the selected electrode (only possible if a row is selected in the list view).
- 3 Tap **Update** to search for new information about the electrodes.
- 4 Tap **Close** to return to the Bosch Timer desktop.

Resetting the value of an electrode


- 1 Select the electrode in the list view to be changed.
- 2 Tap **Reset**.

9.3 Weld Fault

Basic functionality in the Weld Fault window


1 Tap Weld Fault.

A window will appear containing information about all errors and warnings connected to the welding process and the weld timer.



en1200000589

2 Tap twice on a row in the list view to open up a new window for more information about the weld error or warning.




en1200000590

3 Tap Close to return to the Bosch Timer desktop or OK to return to the previous window.

9.4 Last Weld

Basic functionality in the Last Weld window

- 1 Tap **Last Weld**. A window will appear containing information about the last weld performed by the weld timer.



en1200000591


- 2 Tap **Close** to return to the Bosch Timer desktop.

9.5 Weld Parameters

Basic functionality in the Weld Parameters window

1 Tap Weld Parameters.

A window will appear containing information about the weld parameters that is possible to view and edit in the weld timer (this view is not available in automatic mode).



en1200000592

- 2 Tap **Change Program No.** to view weld parameters for different programs in the weld timer.
- 3 Tap **Browse Electrodes** to change electrode number.
- 4 Tap **Close** to return to the Bosch Timer desktop.



WARNING

Changing parameters in this view requires very good knowledge about the welding equipment and the welding parameters, otherwise it is easy to damage or destroy the welding equipment and/or compromise the welding quality.



Note

In order to edit RAPID data, the right access is needed, *Modify current value*. This gives access to modify the value of any RAPID variable. For more information about grants see *Operating manual - IRC5 with FlexPendant*.

Continues on next page

9 Bosch FlexPendant Interface


9.5 Weld Parameters

Continued

Sheets node

The sheets node contains parameters related to the sheet thickness and sheet tolerance for each welding program.

See *Bosch weld timer manual volume 2* for more information about the parameters.



xx160000035

- 1 Tap **Change Program No.** to view weld parameters for different programs in the weld timer.
- 2 Tap **Save** to save the changes done to the parameters and stay in current window.
- 3 Tap **Close** to close the window and return to the previous window.




Note

The values can be specified as a I/O group value. The values can be recalculated into millimeters if configured, see [How to use spot data programmed in the weld timer on page 290](#).

Continues on next page

Settings node

The settings node contains parameters related to the selected welding program. See *Bosch weld timer manual volume 2* for more information about the parameters.



en120000595

- 1 Tap **Change Program No.** to view weld parameters for different programs in the weld timer.
- 2 Tap **Save** to save the changes done to the parameters and stay in current window.
- 3 Tap **Close** to close the window and return to the previous window.

Continues on next page

9 Bosch FlexPendant Interface


9.5 Weld Parameters

Continued

Slope node

The slope node contains parameters related to the welding sequence, if up and down slope of the current is required changes are done here.

See *Bosch weld timer manual volume 2* for more information about the parameters.



en120000594


- 1 Tap **Change Program No.** to view weld parameters for different programs in the weld timer.
- 2 Tap **Save** to save the changes done to the parameters and stay in current window.
- 3 Tap **Close** to close the window and return to the previous window.

Continues on next page

Supervision node

The supervision node contains parameters related to the supervision of the current. Each weld time (1, 2, 3) can be supervised separately.

See *Bosch weld timer manual volume 2* for more information about the parameters.



en120000601

- 1 Tap **Change Program No.** to view weld parameters for different programs in the weld timer.
- 2 Tap **Save** to save the changes done to the parameters and stay in current window.
- 3 Tap **Close** to close the window and return to the previous window.

Continues on next page

9 Bosch FlexPendant Interface


9.5 Weld Parameters

Continued

Cycle node

The cycle node contains parameters related to the welding sequence.

See *Bosch weld timer manual volume 2* for more information about the parameters.



en120000593


- 1 Tap **Change Program No.** to view weld parameters for different programs in the weld timer.
- 2 Tap **Save** to save the changes done to the parameters and stay in current window.
- 3 Tap **Close** to close the window and return to the previous window.

Continues on next page

HeatStepper node

The heatstepper node contains parameters related to the wear of the electrodes, if the customer use this parameters changes are done continuously.

See *Bosch weld timer manual volume 2* for more information about the parameters.



en120000596

- 1 Tap **Change Program No.** to view weld parameters for different programs in the weld timer.
- 2 Tap **Browse Electrodes** to change electrode number.
- 3 Tap **Save** to save the changes done to the parameters and stay in current window.
- 4 Tap **Close** to close the window and return to the previous window.

Continues on next page

9 Bosch FlexPendant Interface


9.5 Weld Parameters

Continued

Stepper node

The stepper node contains parameters related to the wear of the electrodes, if the customer use this parameters changes are done continuously.

See *Bosch weld timer manual volume 2* for more information about the parameters.



en1200000597


- 1 Tap **Change Program No.** to view weld parameters for different programs in the weld timer.
- 2 Tap **Browse Electrodes** to change electrode number.
- 3 Tap **Save** to save the changes done to the parameters and stay in current window.
- 4 Tap **Close** to close the window and return to the previous window.

Continues on next page

Dress node

The dress node contains parameters related to the wear of the electrodes, if the customer use this parameters changes are done continuously.

See *Bosch weld timer manual volume 2* for more information about the parameters.



en120000598

- 1 Tap **Change Program No.** to view weld parameters for different programs in the weld timer.
- 2 Tap **Browse Electrodes** to change electrode number.
- 3 Tap **Save** to save the changes done to the parameters and stay in current window.
- 4 Tap **Close** to close the window and return to the previous window.

Continues on next page

9 Bosch FlexPendant Interface


9.5 Weld Parameters

Continued

Electrode node

The electrode node contains parameters related to the electrode (electrode number), changes to this parameters are done in the start phase or when a new gun is initiated.

See *Bosch weld timer manual volume 2* for more information about the parameters.



en1200000599


- 1 Tap **Change Program No.** to view weld parameters for different programs in the weld timer.
- 2 Tap **Browse Electrodes** to change electrode number.
- 3 Tap **Save** to save the changes done to the parameters and stay in current window.
- 4 Tap **Close** to close the window and return to the previous window.

Continues on next page

General node

The general node contains parameters related to the complete weld timer. They are normally set up in the start up phase.

See *Bosch weld timer manual volume 2* for more information about the parameters.



en120000600

- 1 Tap **Save** to save the changes done to the parameters and stay in current window.
- 2 Tap **Close** to close the window and return to the previous window.

9.6 Communication and configuration

Configuration

The communication is done via an RS232 cable connected from the controller to the weld timer.

The necessary configuration is loaded when installing the system, and it is located in the SIO configuration, ABB/Configuration/Topics/Communication.

Example:

```
SIO:CFG_1.0:5:0::  
#  
COM_PHY_CHANNEL:  
-Name "COM1" -Connector "COM1" -Baudrate 19200 -Parity "even"  
#  
COM_TRP:  
-Name "trpbosv24_1:" -Type "BOSV24" -PhyChannel "COM1"
```

Currently it is not possible to connect more than one weld timer to the robot controller.

10 Customizing RobotWare-Spot

10.1 Introduction

Customizing possibilities

The Spot Options are general and can be extensively customized to fit to different spotweld equipments. They have a default "ready to use" functionality after installation, but can easily be customized by changing configuration data, RAPID data, and RAPID routines from RobotStudio for example.

One purpose of the customizing process can be to reduce the amount of data and number of variables presented to the operator.

The following customizing is described in this manual:

- [How to remove not used signals from the process sequence on page 282](#)
- [How to remove not used process hooks on page 283](#)
- [How to change the number of guns equipment to be used on page 284](#)
- [How to define max/min values for data components on page 286](#)
- [How to change the Spot data types on page 287](#)
- [How to add functionality in the process sequence on page 288](#)
- [How to use spot data programmed in the weld timer on page 290](#)
- [How to set the number of automatic rewelds after weld error on page 292](#)
- [How to change the user modules names and file path on page 293](#)
- [How to package and install the result from the customizing on page 294](#)


10 Customizing RobotWare-Spot

10.2 Files to be changed during customizing

10.2 Files to be changed during customizing

Description

Customizing can be done by changing a number of predefined data and routines, preferably using an ordinary PC with RobotStudio. The following RAPID modules and configuration files can be changed during the customizing process:



xx1200000602

SWUSRM

This module can be modified if the the default data types are changed. Normally there is no need to edit this module, but the possibility exists.

SWUSRM is running in **all motion tasks** and contains routines for data transfer between the user code and the kernel code, for example `DefineSpotData` and `DefineGunData`. This module can be changed from RobotStudio if needed.

See [SWUSRM on page 193](#).

SWUSER

This module can be modified if there is a need to customize the process sequence, ie add additional logic or conditions during the process, or change the content of the default types. The data and routines in this module are possible to modify from RobotStudio.

SWUSER is running in **all task** in the system and contains all the data definitions for the Spot data types and current values for the different defined Spot related data types. It also contains a number of process hook that can be modified if needed. See [SWUSER on page 187](#).

Process configuration

The process configuration is used to to setup the spot system. See [Spot process configuration on page 25](#).



Note

Depending on the spot configuration, different default process configuration will be installed.

Continues on next page

I/O configuration

Depending on the spot configuration, a different default setup of spot weld signals will be installed, and all signals are connected to virtual I/O units. See [Spot I/O configuration on page 51](#).



Tip

If a predefined Weld Timer Configuration option is installed, only signals for one gun equipment will be defined.

MMC configuration

This configuration file contains for example information about which instructions are included in the different instruction pick lists, and which routines are added to the **Debug/Call** routine menu in the program editor, to be used as manual actions. See [Manual actions on page 84](#).

SYS configuration

This configuration file contains for example information about which tasks that the user modules are loaded in. See [System modules on page 187](#).

MOC configuration

This configuration file contains for example parameters for servo guns. See [Servo gun motion control on page 229](#)

10 Customizing RobotWare-Spot

10.3.1 How to remove not used signals from the process sequence

10.3 Customizing guides

10.3.1 How to remove not used signals from the process sequence

Description

Use RobotStudio or the FlexPendant to edit the process configuration.

Example on FlexPendant:

Remove the `diWaterFlow20k` signal from the `Water flow sensor2` instance, this will disable the function of the signal. See [The Spot Media Equipment instance on page 46](#).

- 1 Press ABB/Control Panel/Configuration/Process/Spot Media Equipment.
- 2 Replace the signal name with the predefined `NO_SIGNAL` string in the `Water flow sensor2` instance. See [The Spot Media Equipment instance on page 46](#).
- 3 Save the configuration and restart the system.

The same procedure can be used on other not used signals if needed.

10.3.2 How to remove not used process hooks

Description

Use RobotStudio or the FlexPendant to edit the SWUSER module.

By default the SWUSER module are setup with a number of process hooks (routines), where custom code can be added if there is a need to add additional logic that is not part of the default process.

These routines can be removed if not needed to get a cleaner code.

Remove the SwInitUserIO user routine from the SWUSER module. See [Process hooks on page 189](#).

- 1 Save the module and/or apply the changes.
- 2 Restart the system, with **Reset RAPID**.

The same procedure can be used on other not used process hooks if needed.



Note

The user hook SwPostWeld is used to update the weld counter in the used gundata. If this hook is removed the counter will not update after weld.



Note

Code changes in this module requires a restart using the mode **Reset RAPID**.

10 Customizing RobotWare-Spot

10.3.3 How to change the number of guns equipment to be used

10.3.3 How to change the number of guns equipment to be used

Description

Use RobotStudio to edit the SWUSRM and SWUSER modules.

By default the user modules are setup for one gun equipment, or four gun equipment depending on the selected configuration (Multiple Guns etc). But it is possible to use and configure up to ten (10) gun equipment in the system if the default configuration is not sufficient.

- 1 Add or remove the number of instances in following spot data related arrays in SWUSER.

- curr_gundata
- curr_spotdata
- curr_forcedata

Example:

```
PERS spotdata curr_spotdata{2} := [[0,0,0,0],[0,0,0,0]];
```


- 2 Add or remove the predefined gunnum gun index data in SWUSRM accordingly, ie. gun1, gun2.

Example:

```
PERS gunnum gun1 := 1;  
PERS gunnum gun2 := 2;
```

- 3 Add or remove spot equipments and the signals needed for that equipments in the process configuration. See [Spot process configuration on page 25](#).

Example:



xx2300000135

- 4 Add or remove signals and I/O units in the I/O configuration for the equipments to be used if required. See [Spot I/O configuration on page 51](#).

Continues on next page



Tip

If an additional spot weld timer option is selected when creating a new system, that is, a Bosch weld timer option (options 782-X), only one process task and configurations for one gun equipment will be installed. The installed I/O configuration can then be easily modified in RobotStudio to fit the required equipment.



Note

Code changes in this module requires a restart using the mode **Reset RAPID**.

10 Customizing RobotWare-Spot

10.3.4 How to define max/min values for data components

10.3.4 How to define max/min values for data components

Description

Use RobotStudio to access the process configuration.

It is possible to change the max and min values for a number of data components. The limits will be tested at runtime. See [The Spot System instance on page 27](#), [The Spot SoftWare Equalizing instance on page 48](#) and [The Spot Gun Equipment instance on page 39](#).

10.3.5 How to change the Spot data types

Description

Use RobotStudio to edit the `SWUSER` and the `SWUSR` modules.

| To... | Note |
|--|---|
| <p>Change the definition of the Spot data types in <code>SWUSER</code> to desired. For more information see SWUSER on page 187.</p> <p>Example: add new components for second gun force in <code>forcedata</code>.</p> <pre> RECORD forcedata num tip_force; num force_time; num plate_thickness; num plate_tolerance; num tip_force2; num force_time2; ENDPROC </pre> | <p>It is possible to:</p> <ul style="list-style-type: none"> • Add or delete data components • Move data components from for example <code>gundata</code> to <code>spotdata</code> • Change the names of the data components |
| <p>Change the structure and the default values of following arrays in <code>SWUSER</code> (if corresponding data type is changed).</p> <p>Example new components in <code>forcedata</code>:</p> <pre> PERS forcedata force1 := [1000,2,0,0,500,2]; </pre> | <ul style="list-style-type: none"> • <code>curr_gundata</code> • <code>curr_spotdata</code> • <code>curr_simdata</code> • <code>curr_forcedata</code> |
| <p>Change corresponding instructions in the data definition routines in <code>SWUSR</code> if needed. These routines are used to connect the user defined data components to internal data. For more information see SWUSR on page 193.</p> | <ul style="list-style-type: none"> • <code>DefineSpotData</code> • <code>DefineGunData</code> • <code>DefineForceData</code> • <code>DefineSimData</code> |



Note

Code changes in this module requires a restart using the mode **Reset RAPID**.

10.3.6 How to add functionality in the process sequence

Description

Use RobotStudio to edit the SWUSER module.

If the supervision during the weld process needs to be changed, add code to the process hooks.

For example:

Add an `ErrWrite` instruction in the error handling sequence and set a custom signal `doMyAlarmSignal`.

```
PROC SwPreWeld(num GunNum, INOUT string ErrText)
  VAR bool timeout;
  ! Wait for my equipment ok signal, max 2 seconds.
  WaitDI diMyEquipmentOK, 1 \MaxTime := 2 \TimeFlag := timeout;
  IF timeout THEN
    ErrText := "My equipment is not ok";
    SetDO doMyAlarmSignal, 1;
    RETURN;
  ENDIF
ENDPROC
```

- 1 Add or change the code in the process hooks in SWUSER. See description of the process hooks in [Process hooks on page 189](#).
- 2 Apply changes and perform a Restart Rapid restart.

If the default autonomous supervision has to be changed, the supervision task routine in SWUSER has to be changed.

The normal way to add supervisions is to connect the supervised signal to a trap routine, e.g. (`MySupTrap`) and create a new supervision routine which is called from the trap routine.

For example:

```
PROC SupervisionInit()
  IDelete my_sup_init;
  CONNECT my_sup_init WITH MySupTrap;
  ISignalDO doMySupSignal, 1, my_sup_init;
ENDPROC

TRAP MySupTrap()
  TEST INTNO
  CASE my_sup_init:
    MySupervisionProc;
  ENDTEST
ENDTRAP

PROC MySupervisionProc()
  TPWrite "Executing MySupervisionProc";
  SetDO doMyAlarmSignal, 1;
ENDPROC
```

Continues on next page

See [Supervision task hook on page 192](#).



Note

Code changes in this module requires a restart using the mode **Reset RAPID**.

10.3.7 How to use spot data programmed in the weld timer

Description

Some weld timers are prepared for storing data like `tip_force` and `plate_thickness` for each weld program in the timer. When the robot controller sends a new program number the timer responds with this data (for example on separate input groups). Then it is possible to use this data instead of corresponding data from the current `spotdata`.

- 1 Make sure that the process configuration is setup to use weld timer data instead of the default `spotdata` parameters, see [The Spot Weld Equipment instance on page 33](#).

If the optional group signals `Gun force from timer [GI]`, `Plate thickness from timer [GI]` and `Plate tolerance from timer [GI]` are used, the default data in `spotdata` will be disabled if the corresponding data are set to -1.

Using the optional `Gun force from timer [GI]` signal group will also enable the possibility to use multiple forces during the weld cycle, that is after the weld start signal has been set and before the weld complete signal is set. The kernel will supervise this signal during the weld and change to a higher or lower value when the group value changes. See [Multiple gun forces during welding on page 97](#).



Note

This functionality may already be prepared depending on the spot configuration.



Note

To activate the use of the timer input signals the corresponding parameter in `spotdata` must be set to -1, e.g. `my_spot.tip_force := -1;`

See [spotdata - Spot weld data on page 157](#).

- 2 If needed, not used data components can be removed from `spotdata` in SWUSER. Do not forget to modify the default data declarations in the modules. See [How to change the Spot data types on page 287](#).

For example, remove all parameters except the weld program parameter.

Definition of default process spot data:

```
RECORD spotdata
  num prog_no;
  num tip_force;
  num plate_thickness;
  num plate_tolerance;
ENDRECORD
```

Continues on next page

3 Definition of customized process spot data:

```
RECORD spotdata  
    num prog_no;  
ENDRECORD
```

10 Customizing RobotWare-Spot

10.3.8 How to set the number of automatic rewelds after weld error

10.3.8 How to set the number of automatic rewelds after weld error

Description

By default the automatic reweld function is deactivated.

Use RobotStudio to change the number of automatic rewelds, set the data `Number of automatic rewelds` in the system configuration to the desired value. See [The Spot Error Handling instance on page 30](#).

10.3.9 How to change the user modules names and file path

Description

Since the user routines are called and executed with the user module name in the path this needs to be changed if "custom" user modules are to be used instead.

Perform the following steps to modify or change the user modules names and path location.

- 1 Rename the 'swuser.sys' and 'swusm.sys' and 'swusm.sysx' modules to something more suitable for the specific application, or create new modules with the same content.
- 2 Change spot system process configuration and specify the new module names in "Process task user module name" and "Motion task user module name".
- 3 Change the system process configuration and specify the new file path in 'Spot user modules file path', e.g. HOME:/MyMods.
- 4 Change the controller configuration, 'Automatic Loading of Modules' to reflect the new names and path, e.g. HOME:/MyMods/MyUsrMod.sys.
- 5 Reboot the system with **Reset RAPID** to reload all the modules.

For more information, see [The Spot System instance on page 27](#).

10 Customizing RobotWare-Spot

10.3.10 How to package and install the result from the customizing

10.3.10 How to package and install the result from the customizing

Description

After customizing the default template user modules and configuration files, it is appropriate to create a new additional RobotWare Add-In product, that is, a function package. This add-in product can then be included via Installation Manager in RobotStudio.

When the Add-In product is loaded into the system, the default spot user modules located in the home directory and configuration files will be replaced with the customized modules and configuration files included in the Add-In product.


For more information about RobotWare Add-Ins and how to create one, see *Application manual - RobotWare Add-Ins*.

11 SpotWare add-in

11.1 Distribution

Product distribution

The Spot option software is also distributed separately from RobotWare as a RobotWare Add-In. It can be accessed from the RobotStudio RobotApps Gallery. The SpotWare Add-in has its own release cycle and is not connected to a specific RobotWare release. This allows for faster update of the software when needed.



xx190000878

- In the Gallery, click **Add** in the SpotWare Add-in.

Compatibility

The SpotWare Add-in is compatible with, and can be used together with RobotWare versions from 6.05 and later.

Release information

Information about new features and/or corrections made since last release can be found under the Release Notes link in the SpotWare Add-in description.


11 SpotWare add-in

11.2 Installation

11.2 Installation

Product installation

The installation procedure is similar to how RobotWare Spot is installed, but requires that the SpotWare Add-in product is included in Installation Manager.




xx190000877

- Add the SpotWare Add-in product when building the system.

Selecting the Spot option

A valid license for RobotWare option 635-6 Spot Welding is required to be able to use the SpotWare Add-in, same as for the RobotWare Spot option.




xx190000880

- Select 635-6 Spot Welding in the Drive Modules tab.

Continues on next page

Selecting Spot configuration

The SpotWare Add-in configurations should be selected instead of the configurations in RobotWare Spot.




xx190000879

- Select desired spot configuration in the SpotWare Add-in tree in the Applications tab.

Updating system

Apply the changes in the Confirmation tab and restart the system.



xx190000903

- Click **Apply** to update the system with the SpotWare Add-in.

This page is intentionally left blank

Index

7

782-11 Bosch PROFINET MFDC, 68

782-7 Bosch DeviceNet MFDC, 64

782-1 Bosch DeviceNet AC, 64

A

Additional axes, 229

B

BOS5000/BOS6000, 262

Bosch FlexPendant Interface, 261

C

CalibJ, 123

CalibL, 123

Calibrate, 129

Changing Motion parameters, 245

CloseHighLift, 148

Configuration, 25

Customizing Spot, 279

D

Deflection Compensation, 197

E

Editing instructions, 81

Error handling, 91

Error handling, user defined, 96

Example tool change procedure, 246

F

Fine calibration, 74

FlexPendant Interface, 249

Forcedata, 161

G

Gripper and pneumatic gun, 105

Gun Arm Release, 197

Gun closure, 87

Gundata, 152

Gun equalizing, 83, 86

Gun force calibration, 74

Gun init after fine calibration, 235

Gun init after updated revolution counters, 235

Gun opening, 88

Gun preclosing, 83

I

I/O configuration, 51

Independent gun movement, 239

IndGunMove, 145, 150, 182, 185

IndGunMoveReset, 147

Install servo gun parameters, 230

integrator responsibility, 15

M

Manual actions, 84, 254

ManualCalib, 85

ManualCheckMeasPos, 85

ManualForceCalib, 85

ManualGunControl, 84

ManualGunPosition, 84

ManualGunSearch, 84

ManualServiceCalibceCalib, 85

ManualSetForce, 85

ManualSpot, 85

MeasureWearL, 133

Multiple gun forces during weld, 97

O

OpenHighLift, 148

options

782-11 Bosch PROFINET MFDC, 68

782-7 Bosch DeviceNet MFDC, 64

782-1 Bosch DeviceNet AC, 64

Servo Tool Change, 245

Simulated Weld Timer I/O, 52, 56, 60

Spot, 18

Spot Servo, 18

Spot Servo Equalizing, 18

P

Power failure behaviour, 89

Process configuration, 25, 257

Process sequence, 86

Programming example pneumatic gun, 76

Programming example servo gun, 75

Programming principles, 21

Programming spot welding instructions, 80

Program stop behaviour, 88

Q

Quick start for servo gun, 74

Quick stop behaviour, 89

R

ReCalcTCP, 141

Replace servo gun, 237

Reweld process, 95

S

safety, 15

Service routines, 84

Servo gun activation, 238

Servo gun deactivation, 238

Servo gun disconnection, 103

Servo gun force calibration, 231

Servo gun force gravity compensation, 233

Servo gun tuning, 73

Servo Tool Change, 245

SetForce, 118

Simdata, 164

Simulated welding, 90

Simulated Weld Timer I/O, 52, 56, 60

Simulation, 90

Simulation mode, 82

Skip process, 95

Smeqdata, 167, 169

Software Equalizing, 197

Spotdata, 157

SpotJ, 75, 107

SpotL, 75, 107

SpotMJ, 78, 113

SpotML, 78, 113

Spot options, 18

Spot welding data, 75

Stationary servo gun, 244

Step backward behaviour, 90

Step forward behaviour, 89

Supervision, 91–92, 96

SwGetCurrSpotName, 172–176, 181

SwGetCurrTargetName, 171

SwGetCurrThickness, 178–180
SWUSER, 187
SWUSRM, 193
Synchronous gun movement, 238
system integrator requirements, 15

T

TCP, 199
Tip change, 242
Tip dressing, 104

Tip management, 242
Tip wear, 242
Tool change, 242

V

Virtual I/O unit, 56

W

Weld error, 94
Welding, 88
Weld process timing, 99–100



ABB AB

Robotics & Discrete Automation

S-721 68 VÄSTERÅS, Sweden

Telephone +46 (0) 21 344 400

ABB AS

Robotics & Discrete Automation

Nordlysvegen 7, N-4340 BRYNE, Norway

Box 265, N-4349 BRYNE, Norway

Telephone: +47 22 87 2000

ABB Engineering (Shanghai) Ltd.

Robotics & Discrete Automation

No. 4528 Kangxin Highway

PuDong New District

SHANGHAI 201319, China

Telephone: +86 21 6105 6666

ABB Inc.

Robotics & Discrete Automation

1250 Brown Road

Auburn Hills, MI 48326

USA

Telephone: +1 248 391 9000

abb.com/robotics