

ROBOTICS

# **Safety manual for robot**

Manipulator and IRC5 or OmniCore  
controller



Trace back information:  
Workspace 23D version a8  
Checked in 2023-11-30  
Skribenta version 5.5.019

**Safety manual for robot  
Manipulator and IRC5 or OmniCore controller**

**IRC5 & OmniCore**

**Document ID: 3HAC031045-001**

**Revision: V**

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damage to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2008-2023 ABB. All rights reserved.  
Specifications subject to change without notice.

---

# Table of contents

Overview of this manual .....	7
<b>1 Safety information</b>	<b>9</b>
1.1 Limitation of liability .....	9
1.2 Requirements on personnel .....	10
<b>2 Safety signals and symbols</b>	<b>11</b>
2.1 Safety signals in the manual .....	11
<b>3 Robot stopping functions</b>	<b>13</b>
3.1 Protective stop and emergency stop .....	13
3.2 About emergency stop .....	15
3.3 Enabling device and hold-to-run functionality .....	16
<b>4 Robot operating modes</b>	<b>17</b>
4.1 About the manual mode .....	17
4.2 About the automatic mode .....	18
<b>5 Safety during installation and commissioning</b>	<b>19</b>
<b>6 Safety during operation</b>	<b>23</b>
<b>7 Safety during maintenance and repair</b>	<b>25</b>
7.1 Safety during maintenance and repair .....	25
7.2 Emergency release of the robot axes .....	28
<b>8 Safety during troubleshooting</b>	<b>29</b>
<b>9 Safety during decommissioning</b>	<b>31</b>
<b>Index</b>	<b>33</b>

**This page is intentionally left blank**

# Overview of this manual

## About this manual

This manual contains safety information for the robot controllers and the manipulators from ABB Robotics. The information applies to robot, that is, a combination of manipulator and controller, IRC5 or OmniCore. Each product is described in more detail in its respective product manual. Any deviations are listed in the *Declaration by Manufacturer* and further detailed in the respective product manuals.

## References

The documents that are listed below describe the robot in detail, including assembly, service, and safety instructions. All documents can be found via myABB Business Portal, [www.abb.com/myABB](http://www.abb.com/myABB).

Reference	Document ID
<i>Operating manual - Emergency safety information</i>	3HAC027098-001
<i>Declaration by Manufacturer</i> This document is delivered together with the robot.	
Product manual for the robot controller	
Product manual for the manipulator	
Operating manual for the robot	

## Revisions

Revision	Description
-	First revision.
A	Changes/corrections are made for the IRC5 controller.
B	Changes/corrections are made for the IRC5 controller.
C	Changes/corrections are made for the IRC5 controller.
D	Minor corrections.
E	Minor corrections.
F	Minor corrections.
G	Added information about batteries.
H	The manual is updated with the new main computer ( <i>DSQC1000</i> ).
J	Changes/corrections are made for the IRC5 controller.
K	Added information about robots for collaborative applications.
L	Release 17.1. Changes/corrections are made for the IRC5 controller.
M	Release 17.2. Minor corrections.
N	Release 18.1. The content in the manual is partly restructured.

*Continues on next page*

## Overview of this manual

---

Continued

Revision	Description
P	Release 20A. <ul style="list-style-type: none"><li>• The title is changed from <i>Operating manual - General safety information</i>.</li><li>• Added OmniCore robot controller.</li><li>• The content in the manual is restructured.</li></ul>
Q	Release 20B. <ul style="list-style-type: none"><li>• Added warning regarding unexpected movement of robot arm to concerned chapters.</li></ul>
R	Release 21A. Minor corrections.
S	Release 22A. <ul style="list-style-type: none"><li>• Added support for <i>General Stop</i> (GS) on OmniCore.</li><li>• Minor corrections.</li></ul>
T	Release 22B. <ul style="list-style-type: none"><li>• Added <a href="#">Verify the safety functions on page 21</a>.</li></ul>
U	Release 23A. <ul style="list-style-type: none"><li>• Minor corrections.</li></ul>
V	Release 23D. <ul style="list-style-type: none"><li>• Minor corrections.</li></ul>



# 1 Safety information

## 1.1 Limitation of liability

---

### Limitation of liability

Any information given in this manual regarding safety must not be construed as a warranty by ABB that the industrial robot will not cause injury or damage even if all safety instructions are complied with.

The information does not cover how to design, install and operate a robot system, nor does it cover all peripheral equipment that can influence the safety of the robot system.

In particular, liability cannot be accepted if injury or damage has been caused for any of the following reasons:

- Use of the robot in other ways than intended.
- Incorrect operation or maintenance.
- Operation of the robot when the safety devices are defective, not in their intended location or in any other way not working.
- When instructions for operation and maintenance are not followed as intended.
- Non-authorized design modifications of the robot.
- Repairs on the robot and its spare parts carried out by in-experienced or non-qualified personnel.
- Foreign objects.
- Force majeure.

---

### Spare parts and equipment

ABB supplies original spare parts and equipment which have been tested and approved for their intended use. The installation and/or use of non-original spare parts and equipment can negatively affect the safety, function, performance, and structural properties of the robot. ABB is not liable for damages caused by the use of non-original spare parts and equipment.

# 1 Safety information

---

## 1.2 Requirements on personnel

## 1.2 Requirements on personnel

---

### General

Only personnel with appropriate training are allowed to install, maintain, service, repair, and use the robot. This includes electrical, mechanical, hydraulics, pneumatics, and other hazards identified in the risk assessment.

Persons who are under the influence of alcohol, drugs or any other intoxicating substances are not allowed to install, maintain, service, repair, or use the robot.

The plant liable must make sure that the personnel is trained on the robot, and on responding to emergency or abnormal situations.

---

### Personal protective equipment

Use personal protective equipment, as stated in the instructions.

## 2 Safety signals and symbols

### 2.1 Safety signals in the manual






#### Introduction to safety signals

This section specifies all safety signals used in the user manuals. Each signal consists of:

- A caption specifying the hazard level (DANGER, WARNING, or CAUTION) and the type of hazard.
- Instruction about how to reduce the hazard to an acceptable level.
- A brief description of remaining hazards, if not adequately reduced.

#### Hazard levels

The table below defines the captions specifying the hazard levels used throughout this manual.

Symbol	Designation	Significance
	DANGER	Signal word used to indicate an imminently hazardous situation which, if not avoided, will result in serious injury.
	WARNING	Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in serious injury.
	ELECTRICAL SHOCK	Signal word used to indicate a potentially hazardous situation related to electrical hazards which, if not avoided, could result in serious injury.
	CAUTION	Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in slight injury.
	NOTE	Signal word used to indicate important facts and conditions.

**This page is intentionally left blank**

## 3 Robot stopping functions

### 3.1 Protective stop and emergency stop

#### Robot stopping functions

The robot has protective and emergency stop functions (stop category 0 or 1, in accordance with IEC 60204-1).

Stop category 0	As defined in IEC 60204-1, stopping by immediate removal of power to the machine actuators.
Stop category 1	As defined in IEC 60204-1, a controlled stop with power available to the machine actuators to achieve the stop and then removal of power when the stop is achieved.

A stop function, protective or emergency stop, has a default setting for the stop category, see [Inputs to initiate a protective stop or an emergency stop on page 13](#).

The default stop category for a protective or emergency stop can be re-configured. Activation of external safety rated devices, connected to the robot controller through dedicated discrete safety inputs or safety protocols, will initiate these stop functions.

#### Inputs to initiate a protective stop or an emergency stop

Inputs to initiate a stop function	Description	Default stop category	Stop category reconfigurable
Emergency Stop (ES)	Input to initiate the emergency stop function. The <i>Emergency Stop</i> function is initiated in both automatic and manual mode.	Stop category 0 For deviations, see the product manual for the manipulator.	Yes
Automatic Stop (AS) (IRC5)	Input to initiate the protective stop function <i>Automatic Stop</i> . The <i>Automatic Stop</i> function is only initiated in automatic mode.	Stop category 1	Yes
General Stop (GS) (IRC5)	Input to initiate the protective stop function <i>General Stop</i> . The <i>General Stop</i> function is initiated in both manual mode and automatic mode.	Stop category 1	Yes
Automatic Stop (AS) and General Stop (GS) (OmniCore)	Inputs to initiate the protective stop function. The protective stop function can be configured as <i>Automatic Stop</i> or <i>General Stop</i> . <i>Automatic Stop</i> is only initiated in automatic mode. <i>General Stop</i> is initiated in both manual mode and automatic mode. <sup>i</sup>	Stop category 1 For deviations, see the product manuals for the controller and the manipulator.	Yes

*Continues on next page*

### 3 Robot stopping functions

#### 3.1 Protective stop and emergency stop

*Continued*

Inputs to initiate a stop function	Description	Default stop category	Stop category reconfigurable
Superior Stop (SS) (IRC5)	Input to initiate the superior stop function. The <i>Superior Stop</i> function is initiated in both manual mode and automatic mode. (Superior stop is only available for IRC5.)	Stop category 1	Yes

<sup>i</sup> Depending on controller variant, there can be one or two inputs for the protective stop function. See the product manual for the robot controller.



#### Note

For OmniCore, the default configuration for the protective stop function triggered by the protective stop input is *Automatic Stop*.

For example, a safety rated output from a presence sensing device, connected to AS / GS, a dedicated discrete protective stop input on the robot controller, will when the protective stop function is configured as Automatic Stop (AS) initiate the protective stop function in automatic mode only.

The emergency stop function is a complementary protective measure and shall not be applied as a substitute for safeguarding measures or safety functions.



#### Note

For IRC5, a safety input on the panel board that is initiated, must remain active for at least 1.5 s.



#### Note

For OmniCore, a safety input used to initiate a protective stop must remain active for at least 100 ms.

The stop category configuration is detailed in the product manual for the controller.

## 3.2 About emergency stop

### The emergency stop

The purpose of the emergency stop function is to avert actual or impending emergency situations arising from the behavior of persons or from an unexpected hazardous event.

The emergency stop function is to be initiated by a single human action.

The emergency stop function is a complementary protective measure and shall not be applied as a substitute for safeguarding measures and other functions or safety functions.

The effect of an activated emergency stop device is sustained until the actuator of the emergency stop device has been disengaged. This disengagement is only possible by an intentional human action on the device where the command has been initiated. The disengagement of the emergency stop device shall not restart the machinery but only permit restarting.



#### Note

The emergency stop device on the FlexPendant is operational when the robot is powered. Indicators to be used to verify that the robot is powered are the main switch on the cabinet or the LED indicator on the cabinet when robot is in Motors On Mode.

## 3 Robot stopping functions

---

### 3.3 Enabling device and hold-to-run functionality

### 3.3 Enabling device and hold-to-run functionality

---

#### Three-position enabling device



#### CAUTION

The person using the three-position enabling device is responsible to observe the safeguarded space for hazards due to robot motion and any other hazards related to the robot.

The three-position enabling device is located on the FlexPendant. When continuously held in center-enabled position, the three-position enabling device will permit robot motion and any hazards controlled by the robot. Release of or compression past the center-enabled position will stop the robot motion.



#### CAUTION

For safe use of the three-position enabling device, the following must be implemented:

- The three-position enabling device must never be rendered inoperational in any way.
- If there is a need to enter safeguarded space, always bring the FlexPendant. This is to enforce single point of control.

---

#### Hold-to-run function in manual high speed mode

The hold-to-run function for manual high speed allows movement in conjunction with the three-position enabling device when the button connected to the function is actuated manually. This hold-to-run function can only be used in manual high speed mode. In case of hazard, release or compress the three-position enabling device.

How to use the hold-to-run function for manual high speed mode is described in the operating manual for the controller.

Deviations are listed in the product manual for the manipulator.



## 4 Robot operating modes

### 4.1 About the manual mode

---

#### The manual mode

Manual mode is a control state that allows for the direct control by an operator. The operator will through positioning the three-position enabling device to the center-position allow for movement of the manipulator.

There are two manual modes:

- Manual reduced speed
- Manual high speed (optional)

---

#### Safeguard mechanisms

Protective stop function initiated by

- Three-position enabling device (release of or compression past the center-enabled position)
- General Stop, GS (IRC5)
- General Stop, GS (the dedicated input, GS, or the dedicated input AS/GS configured to GS, see actual controller) (OmniCore)

Deviations are listed in the product manual for the controller.

## 4 Robot operating modes

---

### 4.2 About the automatic mode

### 4.2 About the automatic mode

---

#### Safeguard mechanisms

Protective stop function initiated by

- Automatic Stop, AS (IRC5)
- General Stop, GS (IRC5)
- Superior Stop, SS (IRC5)
- Automatic Stop, AS (the dedicated input, AS, or the dedicated input AS/GS configured to AS, see actual controller) (OmniCore)
- General Stop, GS (the dedicated input, GS, or the dedicated input AS/GS configured to GS, see actual controller) (OmniCore)



#### Note

Prior to allowing the robot to operate in automatic mode, ensure that any suspended safeguards, are returned to full functionality.

Deviations are listed in the product manual for the controller.

# 5 Safety during installation and commissioning

---

### National or regional regulations

The integrator of the robot system is responsible for the safety of the robot system.

The integrator is responsible that the robot system is designed and installed in accordance with the safety requirements set forth in the applicable national and regional standards and regulations.

The integrator of the robot system is required to perform a risk assessment.

---

### Layout

The robot integrated to a robot system shall be designed to allow safe access to all spaces during installation, operation, maintenance, and repair.

If robot movement can be initiated from an external control panel then an emergency stop must also be available.

If the manipulator is delivered with mechanical stops, these can be used for reducing the working space.

A perimeter safeguarding, for example a fence, shall be dimensioned to withstand the following:

- The force of the manipulator.
- The force of the load handled by the robot if dropped or released at maximum speed.
- The maximum possible impact caused by a breaking or malfunctioning rotating tool or other device fitted to the robot.

The maximum TCP speed and the maximum velocity of the robot axes are detailed in the section *Robot motion* in the product specification for the respective manipulator.

Consider exposure to hazards, such as slipping, tripping, and falling.

Hazards due to the working position and posture for a person working with or near the robot shall be considered.

Hazards due to noise emission from the robot needs to be considered.

Consider hazards from other equipment in the robot system, for example, that guards remain active until identified hazards are reduced to an acceptable level.

---

### Allergenic material

See the respective product manual for specification of allergenic materials in the product, if any.

---

### Securing the robot to the foundation

The robot must be properly fixed to its foundation/support, as described in the respective product manual.

When the robot is installed at a height, hanging, or other than mounted directly on the floor, there will be additional hazards.

---

*Continues on next page*

## 5 Safety during installation and commissioning

---

Continued

---

### Using lifting accessories and other external equipment

Ensure that all equipment used during installation, service and all handling of the robot are in correct condition for the intended use.

---

### Electrical safety

Incoming mains must be installed to fulfill national regulations.

The power supply wiring to the robot must be sufficiently fused and if necessary, it must be possible to disconnect it manually from the mains power.

The power to the robot must be turned off with the main switch and the mains power disconnected when performing work inside the controller cabinet. Lock and tag shall be considered.

Harnesses between controller and manipulator shall be fixed and protected to avoid tripping and wear.

Wherever possible, power on/off or rebooting the robot controller shall be performed with all persons outside the safeguarded space.



#### Note

Use a CARBON DIOXIDE (CO<sub>2</sub>) extinguisher in the event of a fire in the robot.

---

### Safety devices

The integrator is responsible for that the safety devices necessary to protect people working with the robot system are designed and installed correctly.

When integrating the robot with external devices to a robot system:

- The integrator of the robot system must ensure that emergency stop functions are interlocked in accordance with applicable standards.
- The integrator of the robot system must ensure that safety functions are interlocked in accordance with applicable standards.

---

### Other hazards

A robot may perform unexpected limited movement.



#### WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

The risk assessment should also consider other hazards arising from the application, such as, but not limited to:

- Water
- Compressed air
- Hydraulics

End-effector hazards require particular attention for applications which involve close human collaboration with the robot.

Continues on next page

---

### **Collaborative applications**

If a robot is intended for a collaborative application, where occasional contact between the robot and the operator is expected, the safety aspects must still be addressed. See the product manual for the manipulator.

---

### **Verify the safety functions**

Before the robot system is put into operation, verify that the safety functions are working as intended and that any remaining hazards identified in the risk assessment are mitigated to an acceptable level.

**This page is intentionally left blank**

## 6 Safety during operation

---

### Lock and change of operating mode

To prevent hazard, it is the responsibility of the integrator to make sure that keys used to lock or change the operating mode are handled only by authorized personnel.

An IRC5 controller with a physical key for the mode selector, is designed so that the key fits on all IRC5 controllers, unless unique keys are ordered.

---

### Automatic operation

Verify the application in the operating mode manual reduced speed, before changing mode to automatic and initiating automatic operation.

---

### Safety devices not in use

Safety devices that are not connected to the robot or robot system cannot initiate a protective or emergency stop. These must be stored out of sight so that they cannot be mistaken for being in use.

---

### Unexpected movement of robot arm



#### WARNING

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

A robot may perform unexpected limited movement.



#### WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

**This page is intentionally left blank**



## 7 Safety during maintenance and repair

### 7.1 Safety during maintenance and repair

#### General

Corrective maintenance must only be carried out by personnel trained on the robot. Maintenance or repair must be done with all electrical, pneumatic, and hydraulic power switched off, that is, no remaining hazards.

Hazards due to stored mechanical energy in the manipulator for the purpose of counterbalancing axes must be considered before maintenance or repair.

Never use the robot as a ladder, which means, do not climb on the controller, manipulator, including motors, or other parts. There are hazards of slipping and falling. The robot might be damaged.


Make sure that there are no tools, loose screws, turnings, or other unexpected parts remaining after maintenance or repair work.

When the work is completed, verify that the safety functions are working as intended.

#### Hot surfaces

Surfaces can be hot after running the robot, and touching these may result in burns. Allow the surfaces to cool down before maintenance or repair.

#### Allergic reaction

Warning	Description	Elimination/Action
 Allergic reaction	When working with lubricants there is a risk of an allergic reaction.	Make sure that protective gear like goggles and gloves are always worn.


#### Gearbox lubricants (oil or grease)

When handling oil, grease, or other chemical substances the safety information of the respective manufacturer must be observed.



#### Note

Take special care when handling hot lubricants.





Warning	Description	Elimination/Action
 Hot oil or grease	Changing and draining gearbox oil or grease may require handling hot lubricant heated up to 90 °C.	Make sure that protective gear like goggles and gloves are always worn during this activity.

*Continues on next page*

## 7 Safety during maintenance and repair

### 7.1 Safety during maintenance and repair

Continued

Warning	Description	Elimination/Action
 <b>Allergic reaction</b>	When working with lubricants there is a risk of an allergic reaction.	Make sure that protective gear like goggles and gloves are always worn.
 <b>Possible pressure build-up in gearbox</b>	When opening the oil or grease plug, there may be pressure present in the gearbox, causing lubricant to spray from the opening.	Open the plug carefully and keep away from the opening. Do not overfill the gearbox when filling.
 <b>Do not overfill</b>	Overfilling of gearbox lubricant can lead to internal over-pressure inside the gearbox which in turn may: <ul style="list-style-type: none"> <li>• damage seals and gaskets</li> <li>• completely press out seals and gaskets</li> <li>• prevent the robot from moving freely.</li> </ul>	Make sure not to overfill the gearbox when filling it with oil or grease. After filling, verify that the level is correct.
 <b>Specified amount depends on drained volume</b>	The specified amount of oil or grease is based on the total volume of the gearbox. When changing the lubricant, the amount refilled may differ from the specified amount, depending on how much has previously been drained from the gearbox.	After filling, verify that the level is correct.

#### Hazards related to batteries


Under rated conditions, the electrode materials and liquid electrolyte in the batteries are sealed and not exposed to the outside.

There is a hazard in case of abuse (mechanical, thermal, electrical) which leads to the activation of safety valves and/or the rupture of the battery container. As a result under certain circumstances, electrolyte leakage, electrode materials reaction with moisture/water or battery vent/explosion/fire may follow.

Do not short circuit, recharge, puncture, incinerate, crush, immerse, force discharge or expose to temperatures above the declared operating temperature range of the product. Risk of fire or explosion.

See safety instructions for the batteries in *Material/product safety data sheet - Battery pack (3HAC043118-001)*.

#### Unexpected movement of robot arm



**WARNING**

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

Continues on next page

A robot may perform unexpected limited movement.



**WARNING**

Manipulator movements can cause serious injuries on users and may damage equipment.

---

**Related information**

See also the safety information related to installation and operation.

## 7 Safety during maintenance and repair

---

### 7.2 Emergency release of the robot axes

### 7.2 Emergency release of the robot axes

---

#### Description

In an emergency situation, the brakes on a robot axis can be released manually by pushing a brake release button.

How to release the brakes is described in the section:

- *Manually releasing the brakes* in the product manual for the manipulator.

The robot may be moved manually on smaller robot models, but larger models may require using an overhead crane or similar equipment.

# 8 Safety during troubleshooting

---

### General

When troubleshooting requires work with power switched on, special considerations must be taken:

- Safety circuits might be muted or disconnected.
- Electrical parts must be considered as *live*.
- The manipulator can move unexpectedly at any time.



#### **DANGER**

Troubleshooting on the controller while powered on must be performed by personnel trained by ABB or by ABB field engineers.

A risk assessment must be done to address both robot and robot system specific hazards.



#### **WARNING**

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

A robot may perform unexpected limited movement.



#### **WARNING**

Manipulator movements can cause serious injuries on users and may damage equipment.

---

### Related information

See also the safety information related to installation, operation, maintenance, and repair.

**This page is intentionally left blank**

## 9 Safety during decommissioning

---

### General

See section *Decommissioning* in the respective product manual.

If the robot is decommissioned for storage, take extra precaution to reset safety devices to delivery status.



#### Note

The decommissioning process shall be preceded by a risk assessment.

### Unexpected movement of robot arm



#### WARNING

Hazards due to the use of brake release devices and/or gravity beneath the manipulator shall be considered.

A robot may perform unexpected limited movement.



#### WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

**This page is intentionally left blank**



# Index

## A

allergenic material, 19  
assessment of hazards and risks, 19

## C

cabinet lock, 20  
carbon dioxide extinguisher, 20  
category 0 stop, 13  
category 1 stop, 13  
climbing on robot, 25

## E

emergency stop, 13  
emergency stops, 15  
enabling device, 16

## F

fire extinguishing, 20

## G

grease, 25

## H

hanging  
  installed hanging, 19  
hazard levels, 11  
height  
  installed at a height, 19  
hold-to-run, 16  
hot surfaces, 25  
HRA, 19

## I

integrator responsibility, 19

## K

key of the mode switch, 23

## L

limitation of liability, 9  
lock and tag, 20  
lubricants, 25

## M

manual mode, 17  
mode switch key, 23

## N

national regulations, 19

## O

oil, 25  
operating mode  
  manual mode, 17

original spare parts, 9

## P

pedestal  
  installed on pedestal, 19  
personnel  
  requirements, 10  
PPE, 10  
protective equipment, 10  
protective stop  
  definition, 13  
protective wear, 10

## R

regional regulations, 19  
release brakes, 28  
responsibility and validity, 9  
risk of burns, 25

## S

safeguarding, 13  
safeguard mechanisms  
  automatic mode, 18  
  manual mode, 17  
safety  
  fire extinguishing, 20  
  release robot axes, 28  
  signals, 11  
  signals in manual, 11  
  stop functions, 13  
  symbols, 11  
safety devices, 20  
safety signals  
  in manual, 11  
signals  
  safety, 11  
stop category 0, 13  
stop category 1, 13  
stops  
  overview, 13  
symbols  
  safety, 11  
system integrator requirements, 19

## T

three-position enabling device, 16  
troubleshooting  
  safety, 29

## U

users  
  requirements, 10

## V

validity and responsibility, 9







**ABB AB**

**Robotics & Discrete Automation**

S-721 68 VÄSTERÅS, Sweden

Telephone +46 10-732 50 00

**ABB AS**

**Robotics & Discrete Automation**

Nordlysvegen 7, N-4340 BRYNE, Norway

Box 265, N-4349 BRYNE, Norway

Telephone: +47 22 87 2000

**ABB Engineering (Shanghai) Ltd.**

Robotics & Discrete Automation

No. 4528 Kangxin Highway

PuDong New District

SHANGHAI 201319, China

Telephone: +86 21 6105 6666

**ABB Inc.**

**Robotics & Discrete Automation**

1250 Brown Road

Auburn Hills, MI 48326

USA

Telephone: +1 248 391 9000

**[abb.com/robotics](http://abb.com/robotics)**